

This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

#### Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + Refrain from automated querying Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

#### **About Google Book Search**


Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at http://books.google.com/













				•		
			•			
			•	•		
			•			
					•	
•						•
		_				
		·				
					•	
_						
•						
	•					
			_			
			•			





# EXPERIMENTAL ENGINEERING.

FOR ENGINEERS AND FOR STUDENTS IN ENGINEERING LABORATORIES.

BY

ROLLA C. CARPENTER, M.S., C.E., M.M.E.,

ASSOCIATE PROFESSOR OF EXPERIMENTAL ENGINEERING, CORNELL UNIVERSITY.


SECOND REVISED EDITION.

FIRST THOUSAND.



NEW YORK:

JOHN WILEY & SONS, 58 EAST TENTH STREET. 1893.



CHYRIGHT, 1896,
BY
ROLLA C. CARPENTER.
518 () 1

HORERT DRUMMOND, Electrotyper, 444 & 446 Pearl Street, New York, TOI

37

Printers,
See Pearl Street,
New York.

# PREFACE.

THE present work is a third edition of "Notes to Mechanical Laboratory Practice," published in 1890; of which a second edition was published in 1891, and soon exhausted by an unexpected demand from engineering schools and the profession.

These earlier editions were prepared especially for the use of students in the Laboratory of Experimental Engineering, Sibley College, Cornell University, for the purpose of facilitating investigation of engineering subjects, and of providing a systematic course of instruction in experimental work.

The book has been rewritten and very much enlarged, so that the change in title to Text-book of Experimental Engineering seems to be justified. Its principal object is the same as that of the earlier editions, but it is also believed that the volume will not be without value as a reference-book to the consulting and practising engineer, since it is the only work on the subject which contains in a single volume the principal standard methods which have been from time to time adopted by various engineering societies for the testing of materials, engines, and machinery.

The book is, however, chiefly intended for use in engineering laboratories, and presents information which the experience of the author has shown to be necessary to carry out experiments intelligently and without great loss of time on the part of students.

The importance of engineering laboratories is now so fully recognized in colleges of engineering that it is hardly

necessary to refer to the advantages which they confer on such engineering students as avail themselves of the opportunities they present. The principal function of such a laboratory should doubtless be to afford the student an opportunity of obtaining practical knowledge of the application and limitation of theoretical principles by personal investigation, under such direction as will insure systematic methods of observation, accurate use of apparatus, and the proper methods of drawing conclusions and of making reports of any experimental investigation. One other function of an engineering laboratory is that of furnishing facilities by means of which skilled observers may undertake by systematic research to discover laws or coefficients of value to the engineering profession.

This work deals principally with the educational methods, the use of apparatus, and the preparation required for becoming a skilled observer.

In order that an engineering laboratory should best meet the educational needs of students, a systematic schedule of experiments should be adopted parallel to the course of instruction in theoretical principles. While such a laboratory course cannot be laid down here as applicable to any general course of instruction in engineering, the following scheme of laboratory experiments is presented for consideration as one which has been successfully followed for students in the Junior and Senior classes in Sibley College, Cornell University. The order of the experiments was largely determined by the attempt to make a limited amount of apparatus do maximum duty, and the course is presented more as an illustration of one that has been practically tested than as a model for other institutions to follow.

#### COURSE OF EXPERIMENTS, SIBLEY COLLEGE ENGINEER-ING LABORATORY.

JUNIOR YEAR. Fall Term.

Strength of Materials—Tensile and Transverse; Calibration—Indicator-springs and Steam-gauges; Weirs and Water-meters; Mercurial Thermometers; Pyrometers; Transmission-dynamometers.

#### Winter Term.

Strength of Materials—Compression and Torsion; Lubricants—Coefficient of Friction; Steam-engine—Indicator-practice; Flue-gas Analysis; Temperature—Pyrometers, Air-thermometers; Calibration—Indicator Drum-springs.

#### Spring Term.

Strength of Materials—Impact; Flexure; Lubricants—Viscosity; Chill-test; Flash-test; Steam-engine—Valve-setting; Efficiency-tests—Water-moter; Steam-boiler; Steam-pump; Steam-engine.

#### SENIOR YEAR.

#### Fall Term.

Strength of Materials—Brick; Stone; Cement; Calorimetry—Barrel and Continuous, Throttling and Separator; Efficiency-tests—Hot-air Engine; Gas-engine; Injector; Centrifugul Pump; Hydraulic Ram; Belting; Compound Engine.

#### Winter Term.

Steam-engine—Calorimetric Test by Hirn's Method; Efficiency-tests—Air-compressor; Triple-expansion Engine; University Electric-lighting Plant; Turbine Water-wheel; Windmill; Manufacturing Plant; Research and Thesis Work.

#### Spring Term.

Steam-engine—Compound and Triple-expansion Engine by Hirn's Method; Special Research; Thesis Work.

Note.—The course is arranged to give ten experiments in the fall term, nine in the winter, and eight in the spring; several important tests being repeated to make the requisite number. Students work in groups of three.

This work, being intended as a hand-book for laboratory use, in connection with a course similar to that mentioned, gives in a very brief manner, in connection with each experiment, a statement of the theoretic principles involved, a description of the apparatus or machines used in the experiment, and a full statement of the methods to be employed, followed by forms for data and report.

It also gives, for the convenience of the practising engineer as well as the student, a statement of the more important standard methods of testing adopted, and an extensive series of tables useful in computing results of experiments, or in comparing such results with those previously obtained.

A few demonstrations are given in full when references could not readily be given, but in general a simple statement of the methods of deriving the formulæ has been thought sufficient.

An attempt has been made, by dividing the book into several chapters of moderate length, by making the paragraphs short, and by placing the paragraph-numbers at the top of the page, to make references to the book easy to those who care to consult it. The references to the more complete treatises on the various subjects discussed will, it is believed, be found ample for all purposes of the student or engineer. The general design is presented in the following condensed Table of Contents.

That portion of each chapter which relates to the theory or principles is in general compiled from authorities named in the references, but some sections are for the first time printed in a form available for engineers. As illustrations, attention might be called to part or all of the following chapters: Testing-machines; Dynamometers; Measurement of Flow of Fluids; Moisture in Steam; Heating Value of Fuels; Steaminjector; Experimental Determination of Inertia.

The author desires to express thanks for co-operation and assistance in preparing the volume to Dr. R. H. Thurston, Director of Sibley College, Cornell University; Prof. C. W. Scribner, of the University of Illinois; Mr. E. F. Williams, of Buffalo, N. Y.; and to his colleagues and colaborers in the various departments of Sibley College.

ITHACA, N. Y., July 1, 1892.

# TABLE OF CONTENTS.

PAGE

A RTICLE

τ.	Objects of Engineering Experiment	xvii
2.	Relation of Theory to Experiment	iiiv
3.	The Method of Investigation	viii
4.	Classification of Experiments	xix
5.	Efficiency-tests	XX
	CHAPTER I.	
	CHAPTER I.	
	REDUCTION OF EXPERIMENTAL DATA.	
6.	Classification of Errors	1
7.	Probability of Errors	2
8.	Errors of Simple Observations	3
10.	Combination of Errors	5
12.	Deduction of Empirical Formulæ	6
15.	Rules and Formulæ for Approximate Calculation	11
16.	Rejection of Doubtful Observations	13
17.	Errors to be Neglected	14
18.	Accuracy of Numerical Calculation	15
19.	Graphical Representation of Experiments	16
21.	Autographic Diagrams	17
	CHAPTER II.	
	APPARATUS FOR REDUCTION OF EXPERIMENTAL DATA.	
23.	The Slide-rule	20
	The Vernier	23
-	The Polar Planimeter	2.1
30.	The Suspended Planimeter	33
_	The Coffin Planimeter	33
•	The Roller Planimeter	37
	Care and Adjustment of Planimeters	42
	Directions for Use of Planimeters	43
	ix	

ART	ICLE	PAGE
38.	Calibration of Planimeters	44
39.	Errors of Planimeters	47
40.	The Vernier Caliper	49
-	The Micrometer	50
	The Micrometer Caliper	51
43.	The Cathetometer	54
	CHAPTER III.	
	GENERAL FORMULÆ-STRENGTH OF MATERIALS.	
AE.	Definitions	58
	Strain-diagrams	59
	Viscosity	60
	Notation	62
49.	Tension	62
51.	Compression	63
52.	Flexure	66
	Shearing	71
	Modulus of Rigidity	73
	Combination of Two Stresses	74
60.	Thermodynamic Relations	76
•	CHAPTER IV.	
	TESTING-MACHINES-STRENGTH OF MATERIALS.	
61.	General Description of Machines	78
	Shackles or Holders	80
66.	Emery Testing-machine	82
68.	Riehlé Bros.' Testing-machine	89
	Olsen Testing-machine	92
	Thurston's Torsion Machine	96
	Riehlé Torsion Machine	99
	Impact Testing-machine	101
	Cement-testing Machines	101
	Testing-machine Accessories	
	Deflectometer	
٠,٠	- control of the cont	**5
٠	CHAPTER V.	
٠	METHODS OF TESTING MATERIALS OF CONSTRUCTION.	
88	Form of Test-pieces	T 1.4
	Ductility—Fracture	
93		3

	TABLE OF CONTENTS.	хi
ARTIC	LE PA	GE
94.	Strain-diagrams I	24
	Tension Tests	
99-	Compression Tests	34
	Transverse Tests	
	Elastic Curve 1	
	Torsion Test	
	Impact Test	
107.	Special Tests of Material 1.	45
		48
110.	Admiralty Tests 1	52
III.	Lloyd's Tests for Steel used in Ship-building 1	53
112.	Tests for Cast-iron Water-pipe 1	54
114.	Testing Stones I	55
115.	" Bricks I	
116.	" Paving Material I	
117.	" Hydraulic Cements	61
	CHAPTER VI.  FRICTION—TESTING OF LUBRICANTS.	
	Friction—Definitions—Useful Formulæ	-
•		73
	A A	73
129.		74
130.	Of Dublicated Surfaces	75
•	Testing of Lubricants—Density	-
136.	Viscosity	•
143.	Guinning	82
144.	rife-test	_
• • •		85
•	Oil-testing Machines—Rankine's	
152.	Thurston 5	-
		94
••	<u> </u>	96
-		98
-,	Ashcroft's Oil-testing Machine	
	Boult's " " 10	
	Experiment with Limited Feed	_
163.	Forms for Report of Lubricant Test	25
	CHAPTER VII.	
	MEASUREMENT OF POWER.	
165.	Absorption Dynamometer. The Prony Brake 20	<b>07</b>
173.	" The Alden Brake 2:	
		-

	٠	٠
v	•	1
^	1	1

# TABLE OF CONTENTS.

ARTIC	I.E								PAGE
	Practical Direc	tions for U	Jse of I	Brake					
	Pump-brakes.								
	Fan-brakes								•
	Traction Dyna								•
	Transmission								
186.	"	••							•
187.	**	"		•					
188.	66	44						• • • • • • • • • • • • • • • • • • •	•
180.	**	**						· · · · · · · · · · · · · · · · · · ·	
_ ,	**	44						• • • • • • • • • • • • • • • • • • •	-
192.	44	• •						•••••	
194.		44							
195.	Dala sanda a M							•••••	
197.	Belt-testing M	acnine, wi	in Dire	ctions	• • • • •	• • • • • •	• • • • • •	• • • • • • • • • • • • • • • • • • • •	230
			CHAP	TER V	III.				
		MEASUREM	ENTS O	F LIQUII	DS AN	ND GAS	es.		
		D. 4.11							
	Theory of the								
201.									
203.									
205.	** ** **								
206.	" "	in Circula	r Pipes			· • • • • •			249
207.	" " "								
209.	Method of Me	asuring the	Flow	of Water	by \	Weirs.			253
213.	61 61		"		" »	Meters			255
217.			••	16 16	" N	Vozzles			259
219.	** **	"	"	** **	" I	Diaphra	gms		260
220.	** **	"	• • •	**	" it	n Strea	ms		<b>261</b>
222.	46 46	**		"	" P	Pitot's	Tube		264
225.	Flow of Comp	ressible Fl	uids th	rough an	Orif	fice			267
229.									
230.	" "Steam								
232.	_								
233.	Anemometer.								
-55.								•••••	-,-
			CHA	PTER I	x				
			OIIA						
		ну	DRAUL	IC MACH	INER	Y.			
235.	Classification.		• • • • •					• • • • • • • • •	280
	Water-pressure								
241.	Overshot Wate	er-wheels				· · · · ·	• • • • • • •	• • • • • • • • •	283
	Breast-wheels.								
									-

	iii
	\G <b>E</b>
243. Undershot Wheels 2	
211. Impulse-wheels	
245. Turbine	
249. The Hydraulic Ram	
250. Methods of Testing Water-motors	
253. Pumps	
256. Test of Pumps 3	
258. Form for Data and Report of Pump-test 3	04
•	
CHAPTER X.	
DEFINITIONS OF THERMODYNAMIC TERMS.	
260. Text-books and Definitions 3	307
260. Units of Pressure 3	
261. Heat and Temperature 3	
265. Properties of Steam 3	
267. Steam-tables 3	316
CHAPTER XI.	
MEASUREMENT OF PRESSURE.	
268. Manometers 3	317
271. Mercury Columns 3	
273. Draught-gauges 3	
277. Steam-gauges 3	
281. Apparatus for Testing Gauges 3	35
CHAPTER XII.	
MEASUREMENT OF TEMPERATURE.	
285. Mercurial Thermometers 3	34 I
288. Air-thermometers 3	343
295. Calibration of Thermometers 3	
296. Metallic Pyrometers 3	352
298. Air and Calorimetric Pyrometers 3	353
299. Determination of Specific Heat 3	
302. Electric Pyrometers 3	357

,

### CHAPTER XIII.

	METHODS OF MEASURING MOISTURE IN STEAM.	
ARTIC		PAGI
	Definitions	
• •	General Methods	_
	Errors in Calorimeters	
	Sampling the Steam	
	Water Equivalent of Calorimeter	
	Barrel Calorimeter	
	Hoadley Calorimeter:	
323.	Barrus Continuous Calorimeter	380
326.	Barrus Superheating Calorimeter	386
	Throttling Calorimeter	
336.	Separator Calorimeter	398
341.	Chemical Calorimeter	404
	CHAPTER XIV.	
	HEATING VALUE OF COALS—FLUE-GAS ANALYSIS.	
242.	Combustion—Definition and Table	405
	Heat of Combustion	
	Determination of Heat by Welter's Law	
	Temperature produced by Combustion	
	Composition of Fuels	
	Fuel-calorimeters—Principle	
352.		410
353.		
354.		
355.		
356.	Continuous	
	Value of Fuel by Boiler-trial	
	Analysis of the Products of Combustion	
	Reagents for Flue-gas Analysis	
	Elliot's Flue-gas Apparatus	
	WIISON 5	
	rishers	
	11cmbie 2	
367.	Deductions from Flue gas Analysis	430
	CHAPTER XV.	
	METHOD OF TESTING STEAM-BOILERS.	
	·	
	Objects of Boiler-testing	
071	Efficiency of a Roiler	443

	TABLE OF CONTENTS.	χv
ARTIC		AGE
	Standard Method of Testing Steam-boilers	
377.	Concise Directions for Testing Boilers	458
	CHAPTER XVI.	
	THE STEAM-ENGINE INDICATOR.	
378.	Uses of the Indicator	450
380.	Early Forms	461
381.	Richards	462
	Thompson	
383.	Tabor	464
384.	Crosby	465
	Calkins	
	Bachelder, Straight-line, and Arc Indicators	
	Reducing-motions	
	Calibration	
	Method of Attaching to the Cylinder	
398.	Directions for Use	480
	CHAPTER XVII.	
	CHAPTER XVII.  THE INDICATOR-DIAGRAM.	
400.	THE INDICATOR-DIAGRAM.	48g
401. 403.	THE INDICATOR-DIAGRAM.  Definitions	493 495
401. 403. 406.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499
401. 403. 406. 407.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502
401. 403. 406. 407. 408.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503
401. 403. 406. 407. 408.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503
401. 403. 406. 407. 408. 409.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503 505
401. 403. 406. 407. 408. 409.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503 505
401. 403. 406. 407. 408. 409.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503 505
401. 403. 406. 407. 408. 409.	THE INDICATOR-DIAGRAM.  Definitions	493 495 499 502 503 505
401. 403. 406. 407. 408. 409. 410. 411.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.	493 495 499 502 503 505 507 509
401. 403. 406. 407. 408. 409. 410. 411.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.  Engine-efficiencies	493 495 499 502 503 505 507 509
401. 403. 406. 407. 408. 409. 410. 411.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.  Engine-efficiencies  Measurement of Speed.	493 495 499 502 503 505 507 509
401. 403. 406. 407. 408. 409. 410. 411.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.  Engine-efficiencies  Measurement of Speed.  Surface Condenser.	493 495 499 502 503 505 507 509
401. 403. 406. 407. 408. 409. 410. 411. 412. 413. 417. 418.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.  Engine-efficiencies  Measurement of Speed.  Surface Condenser.  Calibration of Apparatus.	493 495 499 502 503 505 507 509 511 513 518 520
401. 403. 406. 407. 408. 409. 410. 411. 412. 414. 417. 418. 419.	THE INDICATOR-DIAGRAM.  Definitions.  Measurement of Diagrams.  Form of Diagram.  Weight of Steam from the Diagram.  Clearance from the Diagram.  Cylinder-condensation and Re-evaporation.  Discussion of Diagrams.  Diagrams from Compound Engines.  Crank-shaft and Steam-chest Diagrams.  CHAPTER XVIII.  METHODS OF TESTING THE STEAM-ENGINE.  Engine-efficiencies  Measurement of Speed.  Surface Condenser.	493 495 499 502 503 505 507 509 511 513 518 520 523

4	

## TABLE OF CONTENTS.

	PAGE
422. Preliminary Indicator-practice	
423. Valve-setting	528
424. Friction-test	531
425. Efficiency-test	
426. Hirn's Analysis	
430. Hirn's Analysis of Compound Engines	545
CHAPTER XIX.	
ENGINES FOR SPECIAL USES.	
433. Standard Method of Testing Pumping-engines	552
434. Standard Method of Testing Locomotives	572
435. Experimental Engines	501
	J ) 4
CHAPTER XX.	
EXPERIMENTAL DETERMINATION OF INERTIA.	
436. General Effects of Inertia	508
437. The Williams Inertia-indicator	500
438. The Inertia-diagram	602
CHAPTER XXI.	
THE INJECTOR AND PULSOMETER.	
439. Description of the Injector	4.0
440-I. Theory	
442. Limits of	610
443-5. Directions for Testing	
446-7. The Pulsometer	
440-/. The fulsometer.	031
CHAPTER XXII.	
CHAPTER XXII.  HOT-AIR AND GAS ENGINES.	
HOT-AIR AND GAS ENGINES.	604
HOT-AIR AND GAS ENGINES.  448. General Principles	624
HOT-AIR AND GAS ENGINES.  448. General Principles	624
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625 627
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625 627 627
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625 627 627 630
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625 627 627 630 632
HOT-AIR AND GAS ENGINES.  448. General Principles	624 625 627 627 630 632 637

#### INTRODUCTION.

r. Objects of Engineering Experiments.—The object of experimental work in an engineering course of study may be stated under the following heads: firstly, to afford a practical illustration of the principles advanced in the class-room; secondly, to become familiar with the methods of testing; thirdly, to ascertain the constants and coefficients needed in engineering practice; fourthly, to obtain experience in the use of various types of engines and machines; fifthly, to ascertain the efficiency of these various engines or machines; sixthly, to deduce general laws of action of mechanical forces or resistances, from the effects or results as shown in the various tests made. The especial object for which the experiment is performed should be clearly perceived in the outset, and such a method of testing should be adopted as will give the required information.

This experimental work differs from that in the physical laboratory in its subject-matter and in its application, but the methods of investigation are to a great extent similar. In performing engineering experiments one will be occupied principally in finding coefficients relating to strength of materials or efficiency of machines; these, from the very nature of the material investigated, cannot have a constant value which will be exactly repeated in each experiment, even provided no error be made. The object will then be to find average values of these coefficients, to obtain the variation in each specific test

from these average values, and, if possible, to find the law and cause of such variation.

The results are usually a series of single observations on a variable quantity, and not a series of observations on a constant quantity; so that the method of finding the probable error, by the method of least squares, is not often applicable. This method of reducing and correcting observations is, however, of such value when it is applicable, that it should be familiar to engineers, and should be applied whenever practicable. The fact that single observations are all that often can be secured renders it necessary in this work to take more than ordinary precautions that such observations be made correctly and with accurate instruments.

2. Relation of Theory to Experiment.—It will be found in general better to understand the theoretical laws, as given in text-books, relating to the material or machine under investigation, before the test is commenced; but in many cases this is not possible, and the experiment must precede a study of the theory.

It requires much skill and experience in order to deduce general laws from special investigations, and there is always' reason to doubt the validity of conclusions obtained from such investigations if any circumstances are contradictory, or if any cases remain unexamined.

On the other hand, theoretical deductions or laws must be rejected as erroneous if they indicate results which are contradictory to those obtained by experiments under the conditions supposed to exist in both cases.

3. The Method of Investigation is to be considered as consisting of three steps: firstly, to standardize or calibrate the apparatus or instruments used in the test; secondly, to make the test in such a way as to obtain the desired information; thirdly, to write a report of the test, which is to include a full description of the methods of calibration and of the results, which in many cases should be expressed graphically.

The methods of standardizing or calibrating will in general consist of a comparison with standard apparatus, under the

conditions as nearly as possible the same as those in actual practice. These methods later will be given in detail. The manner of performing the test will depend entirely on the conditions.

The report should be written in books or on paper of a prescribed form, and should describe clearly: (1) Object of the experiment; (2) Deduction of formulæ and method of performing the experiment; (3) Description of apparatus used, with methods of calibrating; (4) Log of results, which must include all the figures taken in the various observations of the calibration as well as in the experiment. These results should be arranged, whenever possible, in tabular form; (5) Results of the experiment; these should be expressed numerically and graphically, as explained later; (6) Conclusions deduced from the experiment. Compare the results with those given by theory or other experiments.

- 4. Classification of Experiments.—The method of performing an experiment must depend largely on the special object of the test, which should in every case be clearly comprehended. The following subjects are considered in this treatise, under various heads: (1) The calibration of apparatus; (2) Tests of the strength of materials; (3) Measurements of liquids and gases; (4) Tests of friction and lubrication; (5) Efficiency-tests, which relate to (a) belting and machinery of transmission, (b) water-wheels, pumps, and hydraulic motors, (c) hot-air and gas engines, (d) air-compressors and compressedair machinery, (e) steam-engines, boilers, injectors, and direct-acting pumps.
- 5. Efficiency-tests.—Tests may be made for various ob jects, the most important being probably that of determining the efficiency.

The efficiency of a machine (Rankine's "Steam-engine," page 88) is a fraction expressing the ratio of the useful work to the whole work performed or to the whole energy expended. The limit to the efficiency of a machine is *unity*, which denotes the efficiency of a perfect machine.

The whole work performed in driving a machine is evi-

dently equal to the useful work, plus the lostwork. The lost work of a machine often consists of a constant part, and of a part bearing some definite proportion to the useful work; in some cases all the lost work is constant.

Efficiency-tests are made to determine the ratio of useful work to total work, and require the determination of, first, the work done or energy expended in driving the machine; second, the useful work delivered by the machine; third, the lost work, which for any given observation is the difference between the total work and the useful work. In case the efficiency of the various parts of the machine is computed separately, the efficiency of the whole machine is evidently equal to the product of the efficiencies of the various component parts, which transmit energy from the driving-point to the working-point.

The work done or energy transmitted is usually expressed in foot-pounds per minute of time, or in horse-power, which is equivalent to 33,000 foot-pounds per minute, or 550 foot-pounds per second of time.

The time of run of efficiency-tests should be as long as possible, in order to overcome errors of starting and stopping, and also to obtain a greater number of observations. In actual plant tests the length of test should never be less than ten hours, with forty observations, if conditions permit it; but in the laboratory practice-tests the time of run and time between observations is necessarily much shortened.



# MANUAL OF EXPERIMENTAL ENGINEERING.

# REDUCTION OF EXPERIMENTAL DATA.

METHOD OF LEAST SQUARES—NUMERICAL CALCULATIONS— GRAPHICAL REPRESENTATION OF EXPERIMENTS.

#### CHAPTER I.

# APPLICATION OF THE METHOD OF LEAST SQUARES.

In the following articles the application of this method to reducing observations and producing equations from experimental data is quite fully set forth. The theory of the Method of Least Squares is not given, but it can be fully studied in the work by Chauvenet published by Lippincott & Co., or in the work by Merriman published by John Wiley & Sons.

6. Classification of Errors.—The errors to which all observations are subject are divided into systematic and accidental.

Systematic errors are those which affect the same quantities in the same way, and may be further classified as *instrumental* and *personal*. The instrumental errors are due to imperfection of the instruments employed, and are detected by comparison with standard instruments or by special methods of adjustment. Personal errors are due to a peculiar habit of the observer tending to make his readings preponderate in a certain direction, and are to be ascertained by comparison of

observations: first, with those taken automatically; second, with those taken by a large number of observers equally skilled; third, with those taken by an observer whose personal error is known. Systematic errors should be investigated first of all, and their effects eliminated.

Accidental errors are those whose presence cannot be foreseen nor prevented; they may be due to a multiplicity of causes, but it is found, if the number of observations be sufficiently great, that their occurrence can be predicted by the law of probability, and the probable value of these errors can be computed by the METHOD OF LEAST SQUARES.

Before making application of the "Method of Least Squares," determine the value of the systematic errors, eliminate them, and apply the method of least squares to the determination of accidental errors.

7. Probability of Errors.—The following propositions are regarded as axioms, and are the fundamental theorems on which the Method of Least Squares is based:

1st. Small errors will be more frequent than large ones.

2d. Errors of excess and deficiency (that is, results greater or less than the true value) are equally probable and will be equally numerous.

3d. Large errors, beyond a certain magnitude, do not occur. That is, the probability of a very large error is zero.

From these it is seen that the probability of an error is a function of the error. Thus let x represent any error and y its probability, then

$$y = f(x)$$
.

By combination of the principles relating to the probability of any event Gauss determined that

$$y=ce^{-h^2x^2}, \quad \ldots \quad \ldots \quad (1)$$

in which c and h are constants, and e the base of the Napierian system of logarithms.

8. Errors of Simple Observations.—It can be shown by calculation: 1. That the most probable value of a series of observations made on the same quantity is the arithmetical mean. 2. If the observations were infinite in number the mean value would be the true value. 3. The residual is the difference between any observation and the mean of all the observations. The mean error of a single observation is the square root of the sum of the squares of the residuals, divided by one less than the number of observations. 4. The probable error is 0.6745 time the mean error. 5. The error of the result is that of a single observation divided by the square root of their number.

Thus let n represent the number of observations, S the sum of the squares of the residuals; let e, e, e, etc., represent the residual, which is the difference between any observation and the mean value; let  $\Sigma$  denote the sum of the quantities indicated by the symbol directly following.

Then we shall have

Mean error of a single observation 
$$\pm \sqrt{\frac{S}{n-1}}$$
. . . (2)

Probable error of a single observation 
$$\pm 0.6745\sqrt{\frac{S}{n-1}}$$
. (3)

Mean error of the result 
$$\pm \sqrt{\frac{S}{n(n-1)}}$$
. (4)

Probable error of the result 
$$\pm 0.6745 \sqrt{\frac{S}{n(n-1)}}$$
. (5)

In every case  $S = \Sigma e^2$ .

9. Example.—The following example illustrates the method of correcting observations made on a single quantity:

A great number of measurements have been made to determine the relation of the British standard yard to the

meter. The British standard of length is the distance, on a bar of Bailey's bronze, between two lines drawn on plugs at the bottom of wells sunk to half the depth of the bar. The marks are one inch from each end. The measure is standard at 72° Fah., and is known as the Imperial Standard Yard.

The meter is the distance between the ends of a bar of platinum, the bar being at 0° Centigrade, and is known as the Mètre des Archives.

The following are some of these determinations. That made by Clarke in 1866 is most generally recognized as of the greatest weight.

COMPARISON OF BRITISH AND FRENCH MEASURES.

Name of Observer.	Date.	Observed length of meter in inches.	Difference from the mean.  Residual = e.	Square of the Residuals.
KaterHasslerClarkeRogersComstock	1821 1832 1866 1884 1885	39.37079 39.38103 39.370432 39.37015 39.36985	- 0.001460 + 8780 - 1818 - 2100 - 0.002400	0.0000021316 0.0000770884 0.0000033124 0.0000044100 0.0000057600
Mean value		39.372250		0.0000907024

$$\Sigma e^{3} = S = 0.0000907024, \quad n = 5, \quad n(n-1) = 20.$$

Mean error of a single observation = 
$$\pm \sqrt{\frac{S}{n-1}}$$
 = 0.00476.

Probable error of single observation =  $\pm$  0.00317.

Mean error of mean value 
$$= \pm \sqrt{\frac{S}{n(n-1)}} = 0.00213.$$

Probable error of mean value  $= \pm 0.00142$ .

That is, considering the observations of equal weight, it would be an even chance whether the error of a single observation were greater or less than 0.00317 inch, and the error of the mean greater or less than 0.00142.

10. Combination of Errors.—When several quantities are involved it is often necessary to consider how the errors made upon the different quantities will affect the result.

Since the error is a small quantity with reference to the result, we can get sufficient accuracy with approximate formulæ.

Thus let X equal the calculated or observed result, F the error made in the result; let x equal one of the observed quantities, and f its error. Then will

in which  $\frac{dX}{dx}$  is the partial derivative of the result with respect to the quantity supposed to vary. In case of two quantities in which the errors are F, F', etc., the probable error of the result

$$= \pm \sqrt{F^3 + F'^3}. \quad . \quad . \quad . \quad . \quad (7)$$

11. As an example, discuss the effect of errors in counting the number of revolutions, and in measurement of the mean effective pressure, acting on the piston, with regard to the power furnished by a steam-engine. Denote the number of revolutions by n, the mean pressure by p, the length of stroke in feet by l, and the area of piston in square inches by a; the work in foot-pounds done on one side of the piston by W. Then

$$W = plan,$$
  $F = lanf,$   $\frac{F}{f} = \frac{dW}{dp} = lan,$   $F' = plaf'.$   $\frac{F'}{f'} = \frac{dW}{dn} = pla.$ 

The error f in the mean pressure is itself a complicated one, since p is measured from an indicator-diagram and depends on accuracy of the indicator-springs, accuracy of the indicatormotion, and the correct measurement of the indicator-diagram. These errors vary with different conditions. Suppose, however, the whole error to be that of measurement of the indicatordiagram. This is usually measured with a polar planimeter, of which the minimum error of measurement may be taken as 0.02 square inch; with an indicator-diagram three inches in length this corresponds to an error of 0.0067 of an inch in ordinate. In a similar manner the error in the number of revolutions depends on the method of counting: with a hand-counter the best results by an expert probably would involve an error of one tenth of a second; with an attached chronograph the error would be less, and would probably depend on the accuracy with which the results could be read from the chronographdiagram. The ordinary errors are fully three times those given here.

Take as a numerical example, a = 100 square inches, l = 2 feet, n = 300, p = 50 pounds, f = 0.335, f' = 0.5.

$$F = 20,100,$$
  $F' = 5,000,$   $W = 3,000,000.$ 

Probable error  $= \pm \sqrt{F^* + F'^*} = 20,712$  ft.-lbs., which in this case is 0.0069 of the work done.

12. Deduction of Empirical Formulæ.—Observations are frequently made to determine general laws which govern phenomena, and in such cases it is important to determine what formula will express with least error the relation between the observed quantities.

These results are *empirical* so long as they express the relation between the observed quantities only; but in many cases they are applicable to all phenomena of the same class, in which case they express *engineering* or *physical laws*.

In all these cases it is important that the form of the equation be known, as will appear from the examples to be given later. The form of the equation is often known from the general physical laws applying to similar cases, or it may be determined by an inspection of the curve obtained by a graphical representation of the experiment. A very large class of phenomena may be represented by the equation

$$y = A + Bx + Cx^2 + Dx^2 + \text{etc.}$$
 (8)

In case the graphical representation of the curve indicates a parabolic form, or one in which the curve approaches parallelism with the axis of X, the empirical formula will probably be of the form

$$y = A + Bx^{1} + Cx^{1} + Dx^{1} + \text{etc.}$$
 (9)

In case the observations show that, with increasing values of x, y passes through repeating cycles, as in the case of a pendulum, or the backward and forward motion of an engine, the characteristic curve would be a sinuous line with repeated changes in the direction of curvature from convex to concave. The equation would be of the form

$$y = A + B_1 \sin \frac{360^{\circ}}{m} x + B_1 \cos \frac{360^{\circ}}{m} x + C_1 \sin \frac{360^{\circ}}{m} 2x$$
  
+  $C_1 \cos \frac{360^{\circ}}{m} 2x + \text{etc.}$  (10)

Still another form which is occasionally used is

$$y = A + B \sin mx + C \sin^2 mx + \text{etc.}$$
 (11)

13. General Methods.—The method of deducing the empirical formula is illustrated by the following general case:

In a series of observations or experiments let us suppose that the errors (residuals) committed are denoted by e, e', e'',

etc., and suppose that by means of the observations we have deduced the general equations of conditions as follows:

$$e = h + ax + by + cz,e' = h' + a'x + b'y + c'z,e'' = h'' + a''x + b''y + c''z,e''' = h''' + a'''x + b'''y + c'''z,etc. etc. etc.$$

Let it be required to find such values of x, y, z, etc., that the values of the residuals e, e', e'', e''', etc., shall be the least possible, with reference to all the observations.

If we square both members of each equation in the above group and add them together, member to member, we shall have

$$e^{2} + e'^{2} + e''^{2} + e'''^{2} + \text{etc.} = x^{2}(a^{2} + a'^{2} + a''^{2} + \text{etc.})$$
  
  $+ 2x\{(ah + a'h' + a''h'' + \text{etc.}) + a(by + cz + \text{etc.})$   
  $+ a'(b'y + c'z + \text{etc.}) + \text{etc.}\} + h^{2} + h'^{2} + \text{etc.}$ 

This equation may be arranged with reference to x as follows:

$$u = e^3 + e'^2 + e''^2 + \text{etc.} = Px^3 + 2Qx + R + \text{etc.};$$

in which the various coefficients of the different powers of x are denoted by the symbols P, Q, R, etc.

Now in order that these various errors may be a minimum,  $e^2 + e'^2 + e''^2 + \text{etc.} = u$  must be a minimum, in which case its partial derivative, taken with respect to each variable in succession, should be separately equal to zero. Hence

$$\frac{du}{dx} = Px + Q = 0;$$

or, substituting the values of P and Q,

$$x(a^{2} + a'^{2} + \text{etc.}) + ah + ah' + \text{etc.} + a(by + cs + \text{etc.}) + a'(b'y + c's + \text{etc.}) + \text{etc.} = 0.$$

Similar equations are to be formed for each variable.

From the form of these equations we deduce the principle that in order to find an equation of condition for the minimum error with respect to one of the unknown quantities, as x for example, we have simply to multiply the second member of each of the equations of condition by the coefficient of the unknown quantity in that equation, take the sum of the products, and place the result equal to zero. Proceed in this manner for each of the unknown quantities, and there will result as many equations as there are unknown quantities, from which the required values of the unknown quantities may be found by the ordinary methods of solving equations.

14. Example.—As an illustration, suppose that we require the equation of condition which shall express the relation between the number of revolutions and the pressure expressed in inches of water, of a pressure-blower delivering air into a closed pipe. Let *m* represent the reading of the water-column, and *n* the corresponding number of revolutions. Suppose that the observations give

for 
$$m = 24$$
 inches,  $n = 297$  revolutions;  
"  $m = 32$  "  $n = 340$  "  
"  $m = 33$  "  $n = 355$  "  
"  $m = 35$  "  $n = 376$  "

Average values for m = 31 inches, n = 342 revolutions.

Arranging the results in the following form, we have:

Water-column.		Revolutions.	
Residuals.	Observations.	Residuals	
<b>-7</b>	297	<b>—</b> 45	
+ 1	340	<b>– 2</b>	
+ 2 + 4	355	+ 13 + 34	

Assume that the equation of condition is of the form

$$A + Bx + Cx^{3} = y.$$

To find those values of A, B, and C which will most nearly satisfy the equation, as shown in the experiment: Taking the values of x, as the residual or difference between the mean and any observation in height of water-column, and the value of y as the corresponding residual in number of revolutions, we have the following equations of condition:

$$A - 7B + 49C = -45,$$

$$A + B + C = -2,$$

$$A + 2B + 4C = +13,$$

$$A + 4B + 16C = +34.$$

Multiplying each equation by the coefficient of A in that equation, we have

$$A-7B+49C=-45$$
,  
 $A+B+C=-2$ ,  
 $A+2B+4C=+13$ ,  
 $A+4B+16C=+34$ .

Equations of minimum condition of error with respect to  $A$ .

4A + 0B + 70C = o. III. Sum of equations in group II.

Multiplying each equation in group I by the coefficient of B in that equation, we have

oA + 70B - 270C = 475 Sum of equations in group IV.

Multiplying each equation in group I by the coefficient of C in that equation, we have

70A - 268B + 2674C = -1611 Sum of equations in group V.

The sums of these various equations of minimum condition are the same in number as the unknown quantities, and by combining them the various values of A, B, C, etc., can be determined. We have, in the following case:

$$AA + OB + 70C = O$$
  
 $OA + 70B - 270C = 475$   
 $AA - 268B + 2674C = -1611$ 

Solving the above,

$$A = 1.508$$
;  $B = 7.140$ ;  $C = -0.0019$ .

Substituting in the original equation of condition,

$$y = 1.608 + 7.140x - 0.0919x^3$$
.

To reduce this form to an equation expressing the probable relation of the number of revolutions to the height of the water-column, we must substitute for y its value, n-342; and for x its value, m-31. In this case we shall have

$$n - 342 = 1.608 + 7.14(m - 31) - 0.0919(m - 31)^{3}$$
;

which reduced gives the following equation as the most probable value in accordance with the observations:

$$n = 34.952 + 13.02m - 0.0919m^{2}$$
;

which is the empirical equation sought.

15. Rules and Formulæ for Approximate Calculation.— When in a mathematical expression some numbers occur which are very small with respect to certain other numbers, and which are therefore reckoned as corrections, they may often be expressed with sufficient accuracy by an approximate formula, which will largely reduce the labor of computation.

On the principle that the higher powers of very small quantities may be neglected with reference to the numbers themselves, we can form a series by expansion by the binomial formula, or by division, in which, if we neglect the higher powers of the smaller quantities, the resulting formulæ become much more simple, and are usually of sufficient accuracy.

Thus, for instance, let  $\delta$  equal a very small fraction; then the expression

$$(a + \delta)^m = a^m + ma^{m-1}\delta + m\frac{(m-1)}{2}a^{m-1}\delta^2 + \text{etc.},$$

will become  $a^m + ma^{m-1}\delta$ , if the higher powers of  $\delta$  be neglected. If  $\delta$  is equal to  $\frac{1}{1000}$  part of a, the error which results from omitting the remaining terms of the series becomes very small, as in this case the value of  $\delta^2 = \frac{1}{10000000}a$ .

The following table of approximate formulæ presents several cases which can often be applied with the effect of materially reducing the work of computation, without any sensible effect on the accuracy:

$$(1+\delta)^m = 1 + m\delta, \quad (1-\delta)^m = 1 - m\delta; \quad . \quad . \quad . \quad (12)$$

$$(1+\delta)^2 = 1+2\delta, \qquad (1-\delta)^2 = 1-2\delta; \dots$$
 (13)

$$\sqrt{1+\delta}=1+\frac{1}{2}\delta, \qquad \sqrt{1-\delta}=1-\frac{1}{2}\delta; \ldots \ldots (14)$$

$$(1+\delta)^{a}=1+3\delta, \qquad (1-\delta)^{a}=1-3\delta; \dots$$
 (15)

$$\frac{1}{1+\delta} = 1-\delta, \qquad \frac{1}{1-\delta} = 1+\delta; \quad . \quad . \quad . \quad (16)$$

$$\frac{1}{(1+\delta)^2} = 1 - 2\delta, \qquad \frac{1}{(1-\delta)^2} = 1 + 2\delta; \dots (17)$$

$$\frac{1}{\sqrt{1+\delta}} = 1 - \frac{1}{2}\delta, \qquad \frac{1}{\sqrt{1-\delta}} = 1 + \frac{1}{2}\delta; \quad . \quad . \quad . \quad (18)$$

$$(1+\delta)(1+\epsilon)(1+\zeta)\dots 1+\delta+\epsilon+\zeta;\dots (19)$$

$$(1-\delta)(1-\epsilon)(1-\zeta)\dots 1-\epsilon-\zeta;\dots$$
 (20)

16. The Rejection of Doubtful Observations.\*—It often happens that in a set of observations there are certain values which are so much at variance with the majority that the observer rejects them in adjusting the results. This might be done by application of Rule 3, Article 7, provided the magnitude of the errors which could not occur were definitely determined; but to reject such observations without proper rules is a dangerous practice, and not to be recommended.

This brings into sight a class of errors which we may term mistakes, and which are in no sense errors of observation, such as we have been considering. Mistakes may result from various causes, as a misunderstanding of the readings, or from recording the wrong numbers, inverting the numbers, etc.: and when it is certainly shown that a mistake has occurred, if it cannot be corrected with certainty, the observations should be rejected. After making allowance for all constant errors, no results except those which are unquestionably mistakes should be rejected.

The remaining discrepancies will then fall under the head

<sup>\*</sup>See Adjustment of Observations, by T. W. Wright. N. Y., D. Van Nostrand.

of *irregular* or *accidental errors*, and are to be corrected as explained in the preceding articles; the fact of a large error is largely or wholly compensated for by the greater frequency of the smaller errors.

17. When to Neglect Errors.—Nearly all the observations taken on any experimental work are combined with observations of some other quantity in order to obtain the desired result. Thus, for example, in the test of a steamengine, observations of the number of revolutions and of the mean effective pressure acting on the piston are combined with the constants giving the length of stroke and area of piston. The product of these various quantities gives the work done per unit of time.

All of these quantities are subject to correction, and it is often important to allow for such correction in the result. Just how important these corrections may be depends on the degree of accuracy which is sought.

As the degree of accuracy increases, the number of influencing circumstances increases as well as the difficulty of eliminating them; hence this part of the work is often the most difficult and sometimes the most important. To what limit these corrections may be carried depends on our knowledge of the laws which govern the experiments in question, as well as the accuracy with which the observations may be taken. It is evidently unnecessary to correct by abstruse and difficult calculation for influences which make less difference than the least possible unit to be determined by observation, and this consideration should no doubt determine whether or not corrections should be taken into account or neglected.

Thus, in the case of the test of a steam-engine, we have errors made in obtaining the engine constants, i.e., length of stroke and area of piston. These errors may be simply of measurement, or they may be due to changes in the temperature of the body measured. The errors of measurement depend on accuracy of the scale used, care with which the observations are made, and can be discussed as direct observations on a single quantity. The errors due to change of temperature can be cal-

culated if observations showing the temperature are taken, and if the coefficient of expansion is known. A calculation will, in case of the steam-engine constants referred to above, show that in general the probable error of observation is many times in excess of any change due to expansion, and hence the latter may be neglected. The effect of errors in the other quantities has already been discussed in Article 11.

It is to be remembered that the method of correction outlined in the "Method of Least Squares" applies only to those accidental and irregular errors which cannot be directly accounted for by any imperfection in instruments or peculiar habit of the observer; usually the correction for instrumental and personal errors is to be made to the observations themselves, before computing the probable error.

18. Accuracy of Numerical Calculations.—The results of all experiments are expressed in figures which show at best only an approximation to the truth, and this accuracy of expression is increased by extending the number of decimal figures. It is, however, evidently true that the mere statement of an experiment, with the results expressed in figures of many decimal places, does not of necessity indicate accurate or reliable experiments. The accuracy depends not on the number of decimal places in the result, but on the least errors made in the observations themselves.

It is generally well to keep to the rule that the result is to be brought out to one more place than the errors of observation would indicate as accurate: that is, the last decimal place should make no pretensions of accuracy; the one preceding should be pretty nearly accurate. In doubtful cases have one place too many rather than too few. No mistake, however, should be made in the numerical calculations; and these, to insure accuracy, should be carried for one place more than is to be given in the result, otherwise an error may be made that will affect the last figure in the result. The extra place is discarded if less than 5; but if 5 or more it is considered as 10, and the extra place but one increased by 1.

In performing numerical calculations, it will be entirely



unnecessary to attempt greater accuracy of computation than can be carried out by a four-place table of logarithms, except in cases where the units of measurements are very small and the numbers correspondingly great. In general, sufficient accuracy can be secured by the use of the pocket slide-rule, the readings of which are hardly as accurate as a three-place table of logarithms. The slide-rule will be found of great convenience in facilitating numerical computations, and its use is earnestly advised.

10. Methods of representing Experiments Graphically. -Nearly all experiments are undertaken for the purpose of ascertaining the relation that one variable condition bears to another, or to the result. All such experiments can be represented graphically by using paper divided into squares. The result of the experiment is represented by a curve, drawn as follows: Lay off in a horizontal direction, using one or more squares as convenient, distances corresponding with the values of one of the various observations, and in a similar manner, using any convenient scale, lay off in a vertical direction from the points already fixed, distances proportional to the results obtained. Connect these various points with a light line, which often will be more or less irregular, but will represent by its direction the relation of the results to any one class or set of observations. This connecting line may form a smooth curve, but if, as is usually the case, the line is irregular and broken, a smooth curve should be drawn by a heavier line, representing the average value of the observations. In case the line drawn does not pass through all the points of observation, these points should be distinctly marked by a cross, or a point surrounded with a circle, triangle, or square; and farther, all observations of the same kind should be denoted by the same mark; so that the relation of the curve to the observations can be perceived at any time.

The value of the graphical method over the numerical one depends largely on the well-known fact that the mind is more sensitive to form, as perceived by the eye, than to large numbers obtained by computation. Indeed, when numbers are used, the averages of a series of observations are all that can be considered, and the effect of a gradual change, and the relation of that change to the result, which is often more important than any numerical determination, is entirely disregarded, and often not perceived.

Every experiment should be expressed graphically, and students should become expert in interpreting the various curves produced. A sample of paper well suited for representing experiments is bound in the back portion of the present work.

All important tests should also be accompanied by a graphical log; in this case time is taken as the abscissa, and the various observations corresponding to the time are plotted at convenient heights. The variation of these quantities from a horizontal line shows in a striking way irregularities which occur during the test, a horizontal line indicating uniform conditions.

- 20. Area of the Diagram represents Work done.— In case the horizontal distances or abscissæ represent space passed through, and the vertical distances or ordinates represent the force acting, then will the area included between this curve and the initial lines, represent the product of the mean force into the space passed through,—or, in other words, the work done. The units in which the work will be expressed will depend on the scales adopted. If the unit of space represent feet, the unit of force pounds, the results will be in foot-pounds. The initial lines in each case must be drawn at distances corresponding to the scales adopted, and must represent, respectively, zero-force and zero-space.
- 21. Autographic Diagrams.—In various instruments used in testing, a diagram is drawn automatically, in which the abscissa corresponds to the space passed through, the ordinate to the force exerted, and the area to the work done. A familiar illustration is the steam-engine indicator-diagram, in which horizontal distance corresponds to the stroke of the piston of the engine, and vertical distance or ordinates to the pressure acting on the piston at any point. The absolute amount of the pressures may be determined by reference to the

atmospheric line. The distance vertically between the lines drawn on the forward and back strokes of the engine is the effective pressure acting on the piston at the given position of its stroke; the mean length of all such lines is the mean effective pressure utilized in work. The vertical distance from any point on the atmospheric line to the curve drawn while the piston is on its forward stroke is the forward pressure, the corresponding distance to the back-pressure line is the back pressure, and the areas between these respective curves give effective or total work per revolution.

An autographic device is put on many testing-machines: in this case the ordinates of the diagram drawn represent pressure applied to the test specimen, and abscissæ represent the stretch of the specimen. This latter corresponds to the space passed through by the force, so that the area of the diagram included between the curve and line of no pressure represents the work done,—at least so far as the resistance of the testpiece is equal to the pull exerted, which is the case within the elastic limit only.

Various dynamometers construct autographic diagrams, in which ordinates are proportional to the force exerted and abscissæ to the space passed through, so that the area is proportional to the work done. The diagram so drawn would represent the work done equally well were ordinates proportional to space passed through, and abscissæ to the force exerted, but such diagrams are not often used.

22. Reduction of Diagrams.—In the reduction of autographic diagrams the process is reversed as compared with the construction of the diagram. The important data required are, first, the position of initial lines of force and of space; second, the respective scales of force and of space. In computing the work, it is usually customary to find the mean pressure from the diagram, and multiply this result by the space through which the body actually moves, instead of multiplying by the length of the diagram.

To find the length of the mean ordinate, from which the mean pressure is easily obtained, vertical lines are drawn so

close together that the portion of the curve included between them is sensibly straight; the sum of these lines, which may be expeditiously taken by transferring them successively to a strip of paper and measuring the total length, is found; and this result divided by the number gives the length of the mean ordinate. This length multiplied by the scale gives the pressure. An integrating instrument, the planimeter, is more frequently used for this purpose, and gives more accurate results. The theory of the instrument and method of using is of great importance to engineers, and is given in full in the following chapter.

## CHAPTER II.

## APPARATUS FOR REDUCTION OF EXPERIMENTAL DATA AND FOR ACCURATE MEASUREMENT.

23. The Slide-rule.—The slide-rule is made in several forms, but it consists in every case of a sliding scale, in which the distance between the divisions, instead of corresponding to the numbers marked on the scale, corresponds to the logarithms of these numbers. This scale can be made to slide past another logarithmic scale, so that by placing them in proper positions there may be shown the sum or difference of these scales, and the number corresponding. As these scales are logarithmic, the number corresponding to the sum is the product, that corresponding to the difference is the quotient. Operations involving involution and evolution can also be performed. Scales showing the logarithmic functions of angles are also usually supplied.



Fig. 1.-THE SLIDE-RULE.

The usual form of the slide-rule is shown in Fig. 1. This form carries four logarithmic scales, one on either edge of the slide, and one above and one below. Either scale can be used; that above is generally to one half the scale of the lower, and while not quite as accurate, is more convenient than the one below. The trigonometrical scales are on the back of the slide.

The principal use to the computer is the solution of problems in multiplication and division.

The following directions, which were kindly written by Prof. H. D. Williams of Sibley College, give a simple practical method of multiplying or dividing by the slide-rule, experience having shown that when these processes are fully understood the others are mastered without instruction.

Suppose that a student has a slide-rule of the straight kind, and similar to the one in Fig. 1, which consists of a stationary scale, a sliding-scale, and a sliding pointer or runner. These parts we will term, respectively, the "scale," the slide, and the runner.

24. Directions for using the Slide-rule.—Holding the rule so that the figures are right side up, four graduated edges will be seen, of which only the upper two are used in the problem we are about to describe. (The method of using the two lower scales would be exactly the same, the difference being, that they are twice as long, and that the slide is above instead of below the scale.)

Move the slide to such a position that the graduations agree throughout the length of the scale, and place the runner at a division marked I, and the rule is ready for use. Arrange the factors to be dealt with in the form of a fraction, with one more factor in numerator than in denominator, units being introduced if necessary to make up deficiencies in the factors.

Thus, to multiply 6 by 7 by 3 and divide by 8 times 2, arrange the factors as follows:

$$\frac{6\times7\times3}{8\times2}$$

The factors in the numerator show the successive positions which the runner must take; those in the denominator the positions of the slide. Thus, to solve above example, start (1) with runner at 6 on the scale, always reading from same side of runner; (2) bring figure 8 on slide to runner; (3) move runner to 7 on slide: the result can now be read on the scale; (4)

bring 2 on slide to runner; (5) move runner to 3 on slide. The result is read directly on the scale at position of runner.

Another example: Multiply 11 by 6 by 7 by 8, and divide by 31.

In this case arrange the factors

$$\frac{11 \times 6 \times 7 \times 8}{1 \times 1 \times 31}$$

Start with runner at 11 on scale, move 1 on slide to runner, move runner to 6 on slide, move 1 on slide to runner, runner to 7 on slide, move 31 on slide to runner, runner to 8 on slide: read result on scale at runner.

The numbers on the slide-rule are to be considered significant figures, and to be used without regard to the decimal point. Thus the number on the rule for 8 is to be used as 8 or 80 or 800, as may be desired, even in the same problem. The significant figures in the result are readily determined by a rough computation. In case the slide projects so much beyond the scale, that the runner cannot be set at the required figure on the slide, bring the runner to 1 on the slide, then move the slide its full length, until the other 1 comes under the runner. Then proceed according to directions above; i.e., move runner to number on slide, and read results on the scale:

$$\frac{6 \times 25 \times 3.5 \times 7 \times 7 \times 31}{\pi \times 426 \times 914 \times 1 \times 1} = ?$$

Begin with the first factor in the numerator, and multiply and divide alternately,—

$$\times$$
 6,  $\div$   $\pi$ ,  $\times$  25,  $\div$  426,  $\times$  3.5,  $\div$  914, etc.,—

until all the factors have been used, checking them off as they are used, to guard against skipping any or using one twice. To multiply, move the runner; to divide, move the slide; in

either case see that the runner points to a graduation on the slide corresponding to the factor. The result at the end or at any stage of the process is given by the runner on the stationary scale. Or, to be more exact, the significant figures of the result are given, for in no case does the slide-rule show where to place the decimal point. If the decimal point cannot be located by inspection of the factors, make a rough cancellation.

(See "Slide-rule, and How to Use it." By C. Hoare. No. 158 of the Scientific Series, pub. by D. Van Nostrand Co.)

25. The Vernier.—The vernier is used to obtain finer subdivisions than is possible by directly dividing the main scale, which in this discussion we will term the *limb*.

The vernier is a scale which may be moved with reference to the main scale or limb, or, vice versa, the vernier is fixed and the limb made to move past it.

The vernier has usually one more subdivision for the same distance than the limb, but it may have one less. It is important to thoroughly understand verniers and to be able to read them quickly, as they are used on nearly all instruments of precision. The theory of the vernier is readily perceived by the following discussion. Let d equal the value of the least subdivision of the limb; let n equal the number of subdivisions of the vernier which are equal to n-1 on the limb. Then the value of one subdivision on the vernier is  $d\left(\frac{n-1}{n}\right)$ .

The difference in length of one subdivision on the limb and one on the vernier is

$$d-d\left(\frac{n-1}{n}\right)=\frac{d}{n},$$

which evidently will equal the least reading of the vernier, and indicates the distance to be moved to bring the first line of the vernier to coincide with one on the limb. In case there is one more subdivision on the limb than on the vernier for the same distance, the interval between the graduations on the vernier is greater than on the limb, and the vernier must be

behind its zero-point with reference to its motion, and hence is termed *retrograde*. The formula for this case, using the same notation as before, gives  $d\left(\frac{n+1}{n}\right) - d = \frac{d}{n}$  for the least reading.

The following method will enable one to readily read any vernier: 1. Find the value of the least subdivision of the limb.

2. Find the number of divisions of the vernier which corresponds to a number one less or one greater than that on the limb: the quotient obtained by dividing the least subdivision of the limb by this number is the value of the least reading of the vernier. The following rules for reading should be carefully observed:

Firstly. Read the last subdivision of the limb passed over by the zero of the vernier on the scale of the limb as the reading of the limb.

Secondly. Look along the vernier until a line is found which coincides with some line on the limb. Read the number of this line from the scale of the vernier. This number multiplied by the least reading of the vernier is the reading of the vernier.

Thirdly. The sum of these readings is the one sought.

Thus, in Fig. 3, page 25, (1) the reading of the limb is 4.70 at a; (2) that of the vernier is 0.04; (3) the sum is 4.74.

26. The Polar Planimeter.—The planimeter is an instrument for evaluating the areas of irregular figures, and in some one of its numerous forms is extensively used for finding the areas of indicator and dynamometer diagrams.

The principal instrument now in use for this purpose was invented by Amsler and exhibited at the Paris Exposition in 1867. This form is now generally known as Amsler's Polar Planimeter; as most of the other instruments are modifications of this one, it is important that it be thoroughly understood.

The general appearance of the instrument is shown in Fig. 2, from which it is seen that it consists of two simple arms PK and FK, pivoted together at the point K. The arm PK during use is free to rotate around the point P, and is held in place by a weight. The arm KF carries at one end a tracing-point, which is passed around the borders of the area to be integrated

It also carries a wheel, whose axis is in the same vertical plane with the arm KF, and which may be located indifferently between and KF, or in KF produced. It is usually located in KF, produced as at D. The rim of this wheel is in contact with the paper, and any motion of the arm, except in the direction of its axis, will cause it to revolve. A graduated scale with a vernier denotes the amount of lineal travel of its circumference. This wheel is termed the record-wheel.




FIG. 2.—AMSLER'S POLAR PLANIMETER.

The detailed construction of the record-wheel, and the arrangement of the counter G, showing the number of revolutions,




FIG. 3.-THE RECORD-WHEEL. AMSLER'S POLAR PLANIMETER.

is shown in Fig. 3. The wheel D is subdivided into a given number of parts, usually 100; the value of one of these parts is to be obtained by dividing the circumference of the rim of the wheel which is in contact with the paper by the number of

divisions. This result will give the value of the least division on the limb; this is subdivided by an attached vernier, in this particular case to tenths of the reading of the limb, so that the least reading of the vernier is one thousandth of that of one revolution.

27. Theory of the Instrument. (See Fig. 4.)—First, the Zero-circle.—If the two arms be clamped so that the plane of the record-wheel intersects the centre B, and be revolved around E, the graduated circle will be continually travelling in the direction of its axis, and will evidently not revolve. A circle generated under such a condition around & as a centre is termed the zero-circle. If the instrument be unclamped and the tracing-point be moved around an area in the direction of the hands of a watch outside the zero circle the registering wheel will give a positive record, while if it be moved in the same direction around an area inside the zerocircle it will give a negative record. This fact makes it necessary in evaluating areas that are very large, and have to be measured by swinging the instrument completely around & as a centre, to know the area of this zero-circle, which must be added to the determination given by the instrument, since for such cases that circumference is the initial point for measurement.

Second, Movement of the Record-wheel.—From the preceding discussion it is seen that the record-wheel does not register, so long as its plane is radial, or so long as angle  $ED'F''=90^\circ$ . The amount of rotation due to variation in the angle EJD between the arms is, if an area be completely circumscribed, equal in opposite directions, and hence does not affect the result, so that it is necessary to discuss merely the case of motion around the pole E, with the angle EJD fixed. Thus, for instance, suppose angle EJD to remain constant, and the tracing-point to swing through the infinitesimal angle F''EF, designated by  $d\theta$ , the record-wheel would move near the path DD' more or less irregularly, but subtending an equal angle DED'. The component of this motion which constitutes the record is OD', designated by dR, which is the projection of

this path on a perpendicular to JF. Since DED' is infinitesimal, we have

$$DD' = DEd\theta$$
; also  $dR = OD' = DD' \cos ED'D$ ;

but ED'D = EDO from similar triangles. Hence

$$dR = ED \cos EDOd\theta$$
.

Denote the length of arm EJ by m, the length of arm EF from pivot to tracing-point by l, the distance JD from pivot to recordwheel by n, the angle EJD by B. Let fall a perpendicular from E on FD, or FD produced at O. Then we have

$$ED\cos EDO = OD = JO - JD = m\cos B - n.$$

Hence

Third, the infinitesimal area FtF''t', lying adjacent to the zero-circle.—Let EF = r, let EF'' = r', the radius of the zero-circle. Let dA = the area sought. Let  $d\theta = FEt$ . Then

area 
$$FEt = \frac{1}{4}r^3d\theta$$
.

and

area 
$$F''Et' = \frac{1}{2}r'^2d\theta$$
.

Then

$$dA = FEt - F''Et' = \frac{1}{2}(r^2 - r'^2)d\theta$$
. (2)

From the oblique triangle EJF,

$$r^2 = m^2 + l^2 + 2ml \cos B \cdot \cdot \cdot \cdot \cdot \cdot \cdot (3)$$

From the right triangle ED'F'',

$$r'^2 = m^2 + i^2 + 2nl$$
. . . . . . . . (4)

Substituting the values of  $r^2$  and  $r'^2$  in equation (2), we have

By comparing equation (5), the differential equation for the area, with equation (1), the corresponding equation for the




FIG. 4.—POLAR PLANIMETER.

record, we see that

or by integration between limits o and R, since s is a constant,

$$A = lR. \dots \dots (7)$$

This shows that the area is equal to the length of arm from pivot to the tracing-point, multipliea by the space registered

on the circumference of the record-wheel, and is independent of the other dimensions of the instrument.

That this is true for areas not adjacent to the zero-circle, or for areas partly inside and out, can readily be proved by subtracting the areas between the zero-circle and the given area, or by a similar process. Hence the demonstration is general.

The Amsler instrument is usually constructed so that the arm I is adjustable in length, and consequently it may be made available for any scale or for various units. Graduations are engraved on the arm which show the length required to give a record in a given scale or for given units.

The area of the zero-circle is usually engraved on the top of the arm l. In case it is not given, it may be found by evaluating the areas of two circles of known area, each greater than the area of the zero-circle  $\pi r'^2$ . Let the areas of such circles be respectively C and C', and the corresponding readings of the record-wheel R and R', in proper units. Then we have

$$C = \pi r'^2 + R$$
 and  $C' = \pi r'^2 + R'$ ,

from which

$$2\pi r'^2 = C + C' - (R + R').$$
 (8)

Having found  $r'^2$ , we can compute n, since  $r'^2 = m^2 + l^2 + 2nl$ , and m and l can both be obtained from measurement

28. Design of Polar Planimeters.—Polar planimeters are made in two forms: 1. With the pivot J, Fig. 4, fixed. 2. With pivot J movable, so that the arm l between pivot and tracing-point may be varied in length. Since the area is in each case equal to the length of this arm, multiplied by the lineal space R moved through by the record-wheel, we have in the first case, since l is not adjustable, the result always in the same unit, as square inches or square centimeters. In this case it is

customary to fix the circumference of the record-wheel and compute the arm l so as to give the desired units.

For example, the circumference of the record-wheel is assumed as equal to 100 divisions, each one-fortieth of an inch, thus giving us a distance of 2.5 inches traversed in one revolution. The diameter corresponding to this circumference is 0.796 inch, which is equal to 2.025 centimeters. The distance from pivot to tracing-point can be taken any convenient distance: thus, if the diameter of the record-wheel is as above, and the length of the arm be taken as 4 inches, the area described by a single revolution of the register-wheel will be  $2.5 \times 4 = 10.0$  square inches.

Since there were 100 divisions in the wheel, the value of one of these would be in this case 0.1 square inch. This would be subdivided by the attached vernier into ten parts, giving as the least reading one one-hundredth of a square inch. By making the arm larger and the wheel smaller, readings giving the same units could be obtained.

The formula expressing this reduction is as follows: Let d equal the value of one division on the record-wheel; let l equal the length of the arm from pivot to tracing-point; let l equal the area, which must evidently be either 1, 10, or 100 in order that the value of the readings in lineal measures on the record-wheel shall correspond with the results in square measures. Then by equation (7) we shall have, supposing 100 divisions,

100 
$$dl = A$$
; . . . . . . . . . (8)

If A = 10 square inches and  $d = \frac{1}{40}$  inch,

$$l = \frac{10}{2.5} = 4.$$

If A = 10 square inches and  $d = \frac{1}{10}$  inch,

$$l = \frac{10}{2} = 5.$$

The length of the arm from centre to the pivot has no effect on the result unless the instrument makes a complete revolution around the fixed point E, in which case the area of the zero-circle must be considered. It is evident, however, that this arm must be taken sufficiently long to permit free motion of the tracing-point around the area to be evaluated.

The second class of instruments, shown in Fig. 2, are arranged so that the pivot can be moved to any desired position on the tracing-arm KF, or, in other words, the length can be changed to give readings in various units. The effect of such a change will be readily understood from the preceding discussion.

29. The Mean Ordinate by the Polar Planimeter.— If we let p equal the length of the mean ordinate, and let L equal the length of the diagram, then the area A = Lp, but the area A = lR [eq. (7)]. Therefore Lp = lR, from which

$$l \div L = p \div R$$
. . . . . . (10)

In an instrument in which l is adjustable, it may be made the length of the area to be evaluated. Now if l be made equal L, p = R. That is, if the adjustable arm be made equal to the length of the diagram, the mean ordinate is equal to the reading of the record-wheel, to a scale to be determined.

The method of making the adjustable arm the length of the diagram is facilitated by placing a point U on the back of the planimeter at a convenient distance back of the tracing-point F and mounting a similar point V at the same distance back of the pivot C; then in all cases the distance UV will be equal to the length of the adjustable arm I. The instrument is readily set by loosening the set-screw S and sliding the frame

carrying the pivot and record-wheel until the points UV are at the respective ends of the diagram to be traced, as shown in Fig. 5.

In the absence of the points U and V the length of the diagram can be obtained by a pair of dividers, and the distance of the pivot C from the tracing-point F made equal to the length of the diagram.

In this position, if the tracing-point be carried around the diagram, the reading will be the mean ordinate of the diagram




Fig. 5.-Method of Setting the Planimeter for Finding the Mean Ordinate.

expressed in the same units as the subdivisions of the recordwheel; thus if the subdivisions of this wheel are fortieths of one inch, the result will be the length of the mean ordinate in fortieths. This distance, which we term the scale of the recordwheel, is not the distance between the marks on the graduated scale, but is the corresponding distance on the edge of the wheel which comes in contact with the paper.

The scale of the record-wheel evidently corresponds to a linear distance, and it should be obtained by measurement or computation. It is evidently equal to the number of divisions in the circumference divided by  $\pi d$ , in which d is the diameter, or it can be obtained by measuring a rectangular diagram with a length equal to l, and a mean ordinate equal to one inch, in which case the reading of the record-wheel will give the number of divisions per inch. A diameter of 0.795 inch, which corresponds to a radius of one centimeter, with a hundred sub-

divisions of the circumference, corresponds almost exactly to a scale of forty subdivisions to the inch, and is the dimension usually adopted on foreign-made instruments.

30. The Suspended Planimeter.—In the Amsler suspended planimeter as shown in Fig. 6, pure rolling motion without slipping is assumed to take place. The motion of the record-wheel, not clearly shown in the figure, is produced by the rotation of the cylinder c in contact with the spherical



FIG. 6.—SUSPENDED PLANIMETER.

segment K. The rotation of the segment is due to angular motion around the pole O, that of the cylinder c to its position with reference to the axis of the segment. This position depends on the angle that the tracing arm, ks, makes with the radial arm, BB. The area in each case being, as with the polar planimeter, equal to the product of the length of tracing arm from pivot to tracing point multiplied by a constant factor.

- 31. The Coffin Planimeter and Averaging Instrument.—This instrument is shown in Fig. 7, from which it is seen that it consists of an arm supporting a record-wheel whose axis is parallel to the line joining the extremities of the arm. This instrument was invented by the late John Coffin, of Johnstown, in 1874. The record-wheel travels over a special surface; one end of the arm travels in a slide, the other end passes around the diagram.
- 32. Theory of the Coffin Instrument.—This planimeter may be considered a special form of the Amsler, in which the point P, see Fig. 8, page 35, moves in a right line instead of

swinging in an arc of a circle, and the angle CPT, corresponding to B in eq. (1), is a fixed right angle. The differential equation for area therefore is

$$dA = lnd\theta$$
, . . . . . (11)




FIG. 7.-THE COFFIN AVERAGING INSTRUMENT.

and the differential equation of the register becomes

$$dR = nd\theta$$
. . . . . . . . . . . . 12)

Hence, as in equation (7),

$$A = lR.$$
 . . . . . . (13)

That is, the area is equal to the space registered by the recordwheel multiplied by the length of the planimeter arm.

This instrument may be made to give a line equivalent to the M. E. P. by placing the diagram to be measured so that




FIG. 8.—COFFIN AVERAGING INSTRUMENT.

one edge is in line with the guide for the arm; starting at the farthest portion of the diagram, run the tracing-point around in the usual manner to the point of starting, after which run the tracing-point perpendicular to the base along a special guide provided for that purpose until the record-wheel reads as at the beginning. This latter distance will be equivalent to the M. E. P.

To prove, take as in Art. 29 the M. E. P. = p, the length of diagram = L, the perpendicular distance = S. Then

$$A = pL = lR. . . . . . . . (14)$$

Let C be the angle, EPT, that the arm makes with the guide, Fig. 8. In moving over a vertical line this angle will remain constant, and the record will be

$$R = S \sin C. . . . . . . (15)$$

For the position at the end of the diagram

$$\sin C = L \div l$$
;

therefore

$$R = SL \div l$$
.

Substituting this in equation (14),

$$pL = lR = lSL \div l = SL$$
.

Hence p = S(15a), which was to be proved.

From the above discussion it is evident that areas will be measured accurately in all positions, but that to get the M. E. P. the base of the diagram must be placed perpendicular to the guide, and with one end in line of the guide produced.

It is also to be noticed that the record-wheel may be placed in any position with reference to the arm, but that it must have its axis parallel to it, and that it registers only the perpendicular distance moved by the arm.

33. New Planimeter.—A planimeter, termed the New Planimeter, is manufactured by the Mechanical Specialties Co. of Boston, Mass. This instrument consists of a single arm, one end of which moves in a fixed groove; the other end carries a tracing-point which is moved around the diagram to be

evaluated, and in this respect is similar to the Coffin Planimeter. The perpendicular motion of the arm is measured by the slipping of a sharp-edged wheel on a graduated axis perpendicular to the arm.

The mathematical demonstration is exactly as for the Coffin Planimeter, but in this case it is evident that the perpendicular distance which is registered on the axis is independent of the circumference of the wheel. The only conditions of accuracy are, that the axis of the wheel shall be at right angles to the arm of the planimeter, and that its graduations shall be equal to the area to be measured divided by the length of the arm.

Although not especially designed for this purpose, the mean ordinate may be obtained by proceeding exactly as in the Coffin Planimeter; that is, place the diagram so that the dimension representing the length will be perpendicular to the guides, and one extremity will be in the line of the guides. Start at the farthest point, and after passing around the diagram, move in a parallel direction to the guides until the initial reading is obtained. This last distance is equal to the mean ordinate.

The Engineers' Instrument Company of New York are manufacturing a form of the Amsler Polar Planimeter for large areas, in which the total number of revolutions of the recordwheel is given by a scale carried by a revolving-screw in the axis of the record-wheel.

34. The Roller-planimeter.—This is the most accurate of the instruments for integrating plane areas, and is capable of measuring the area of a surface of indefinite length and of limited breadth. This instrument was designed by Herr Corradi of Zurich, and is manufactured in this country by Fauth & Company of Washington, D. C.

A view of the instrument is shown in Fig. 9. The features of this instrument are: firstly, the unit of the vernier is so small that surfaces of quite diminutive size may be determined with accuracy; secondly, the space that can be encompassed by one fixing of the instrument is very large; thirdly, the

results need not be affected by the surface of the paper on which the diagram is drawn; and, fourthly, the arrangement of its working parts admit of being kept in good order a long time.

The frame B is supported by the shaft of the two rollers  $R_1R_1$ , the surfaces of which are fluted. To the frame B are fitted the disk A, and the axis of the tracing-arm F. The whole apparatus is moved in a straight line to any desired length upon the two rollers resting on the paper, while the tracing-point travels around the diagram to be integrated. Upon the shaft that forms the axis of the two rollers  $R_1R_1$  a minutely




Fig. 9.—Roller-planimeter.

divided mitre-wheel R, is fixed, which gears into a pinion R. This pinion, being fixed upon the same spindle as the disk A, causes the disk to revolve, and thereby induces the rolling motion of the entire apparatus.

The measuring-roller E, resting upon the disk A, travels thereon to and fro, in sympathy with the motion of the tracingarm F, this measuring-roller being actuated by another arm fixed at right angles to the tracing-arm and moving freely between pivots. The axis of the measuring-roller is parallel to the tracing-arm F. The top end of the spindle upon which

the disk A is fixed pivots on a radial steel bar  $CC_1$ , fixed upon the frame B.

39

35. Theory.—The following theory of the roller-planimeter is partly translated from an article by F. H. Reitz, in the Zeitschrift für Vermessungs-Wesen, 1884.

According to the general theory of planimeters furnished with measuring-rollers, it is immaterial what line the free end of the tracing-arm travels over; nevertheless there is some practical advantage in the construction of the apparatus to be obtained from causing that end to travel as nearly as possible in a straight line. Still it is obvious that a slight deviation from the straight line would not involve any inaccuracy in the result.

Seeing that the fulcrum of the tracing-arm keeps travelling in a straight line, it appears advisable, in evolving the theory of the apparatus, to assume a rectangular system of co-ordinates, and fix upon the line along which that fulcrum travels as the axis of abscissæ.


The passage of the tracing-point around the perimeter of a diagram may be looked upon as being made up of two motions—one parallel to the axis of abscissæ and the other at right angles to that axis. Inasmuch as the latter of these two motions, in the direction of the axis of ordinates, is after all but an alternate motion of the tracing-point which takes place in an equal ratio until the tracing-point has returned to its starting-point, no one point of the circumference of the measuring-roller is continuously moved forward in consequence of this motion. Therefore it is only necessary to take the differential motion of the tracing-point in the direction of the axis of abscissæ into consideration.

In Fig. 10 the same letters of reference denote identical parts or organs as in Fig. 9, and the position of the parts in the two figures correspond exactly, the letter D denoting the distance between the fulcrum of the tracing-arm and the axis of the disk A. The amount of motion of a point on the recordwheel E, while the tracing-point travels to the extent of dx, must be determined. If the construction of the planimeter is

correct, this quantity must be the product of a constant derived from the instrument, multiplied by the differential expression for the surface. This latter quantity with reference to rectangular co-ordinates is ydx.

It is readily seen that as the tracing-point moves an amount equal to dx, a point in the circumference of the rollers  $R_1R_1$  must be shifted the same amount, since the axes of these rollers are parallel to the ordinate y.

Any point in the pitch-line of the mitre-wheel  $R_s$  must move an amount equal to  $\frac{R_s}{R_s}dx$ .



Suppose that while the tracing-point moves a distance dx, the disk A moves a distance ab, Fig. 10, since this disk is turned by the mitre-wheel whose pitch-circle is  $R_1$ , and ad is the distance from record-wheel to the axis of this wheel, we must have

$$\vec{ab} = \frac{R_1}{R_1} \cdot \frac{ad}{R_1} dx. \qquad (16)$$

Because of the position of the axis of the record-wheel E, the motion of the disk A to the extent of ab produces a shifting of a point in the circumference of E equal to cb, while the record-wheel slips a distance ac. The distance cb is the reading of the record-wheel and is the quantity required. We have  $dab = 90^{\circ}$ ,  $cag = 90^{\circ}$ ; hence  $caf = \alpha$ , and  $fab = \beta$ , and  $cab = \alpha + \beta$ . So that since  $acb = 90^{\circ}$ ,

$$cb = ab \sin (\alpha + \beta) = ab (\sin \alpha \cos \beta + \cos \alpha \sin \beta)$$
. (17)

But it is seen that

$$\sin \alpha = \frac{y}{F}.$$

Hence

$$\cos \alpha = \sqrt{1 - \frac{y^3}{F^3}};$$

$$\sin \beta = \frac{af}{ad} = ag \frac{\sin \alpha}{ad} = \frac{agy}{Fad};$$

$$\cos \beta = \frac{df}{ad} = \frac{D - ag\sqrt{1 - \frac{y^3}{F^3}}}{ad}.$$

Substitute these values in equation (17):

$$\epsilon b = ab \frac{\sqrt{1 - \frac{y^2}{F}}}{ad} + \sqrt{1 - \frac{y^2}{F^2}} \left( \frac{ag \frac{y}{F}}{ad} \right) = ab \frac{yD}{Fad}. \quad (18)$$

Substitute the value of ab in (16),

$$cb = \frac{R_1Dy}{R_1R_2F}dx = \text{(constant) } ydx, \dots$$
 (19)

which was to be proved.

The differential distance cb is the reading of the record-wheel; let this be represented by dr, denote by C the constant  $\frac{DR_*}{FR_*R_*}$ ; then

$$dr = Cydx$$
;  $ydx = \frac{dr}{C}$ ;  $\int ydx = \frac{1}{C} \int_{r_0}^{r_1} dr$ .

This expression integrated gives

Area = 
$$\frac{1}{C}(r_1 - r_2) = \frac{FR_1R_2}{DR_2}(r_1 - r_2);$$
 (20)

in which  $r_1$  and  $r_2$  are the initial and final readings of the record-wheel.

In the construction of the instrument  $R_1$ ,  $R_2$ ,  $D_3$ , and  $R_4$  are fixed quantities, but the length of the tracing-arm F can be varied, with a corresponding variation in the unit of measurement.

36. Care and Adjustment of Planimeters.—From the preceding discussion it is seen that the area in every case is the product of the distance actually moved by the circumference of the record-wheel into the length of the arm from the tracing-point to the pivot, into a constant which may be and is, in the polar planimeter, equal to one. It is also to be noticed that the record-wheel is so arranged as to register the distance moved by a point in a direction perpendicular to that of the tracing-arm, and that for other directions it slips. This indicates that any change whatever in the diameter of the record-wheel or gear-wheels, due to wear or dirt, will require a corresponding change in the length of tracing-arm; and further, any irregularities in the edge of this wheel will make the relative amounts of slipping and rolling motion uncertain, and consequently impair its accuracy.

Again, the plane of the record-wheel must be perpendicular to the tracing-arm, otherwise an error will result.

In the planimeter the moving parts usually have pivot-

bearings which can be loosened or tightened as required. The revolving parts should spin around easily but at the same time accurately, and the various arms should swing easily and show no lost motion. The pitch-line of the record-wheel should be as close as possible to the vernier, but yet must not touch it; the counting-wheel must work smoothly, but in no way interfere with the motion of the record-wheel.

- 37. Directions for Use.—1. Oil occasionally with a few drops of watch or nut oil.
- 2. Keep the rim of the record-wheel clean and free from rust. Wipe with a soft rag if it is touched with the fingers.
- 3. Prepare a smooth level surface, and cover it with heavy drawing-paper, for the record-wheel to move over. Stretch the diagram to be evaluated smooth.
- 4. Handle the instrument with the greatest care, as the least injury may ruin it. Select a pole-point so that the instrument will in its initial position have the tracing-arm perpendicular either to the pole-arm or to the axis of the fluted rollers, as the case may be; for in this position only is the error neutralized, which arises from the fact that the tracer is not returned to its exact starting-point. Then marking some starting-point, trace the outline of the area to be measured in the direction of the hands of a watch, slowly and carefully, noting the reading of the record-wheel at the instant of starting and stopping. It is generally more accurate to note the initial reading of the record-wheel than to try and set it at zero.
- 5. Special Directions.—To obtain the mean ordinate with the polar planimeter, make the length of the adjustable arm equal to the length of the diagram, as explained in Art. 28, page 30, and follow directions for use as before.
- 6. In using the Coffin planimeter, the grooved metal plate I is first attached to the board, upon which the apparatus is mounted as shown in the cut, page 34, being held in place by a thumb-screw applied to the back side.

The diagram will be held securely in place by the spring-clips adjacent, A and C, Fig. 7. The area may be found by running the tracing-point around the diagram, as described for the

polar planimeter, for any position within the limits of the arm. The mean ordinate may be found by locating the diagram as shown in the cut, with one extreme point in the line of the metal groove produced, and the dimension representing the length of the diagram perpendicular to this groove. Start to trace the area at the farthest distance of the diagram from the metal guide produced, as shown in Fig. 7; pass around in the direction of the motion of the hands of a watch to the point of beginning; then carry the tracing-point along the straightedge, AK, which is parallel to the metal groove, until the recordwheel shows the same reading as at the instant of starting: this latter distance is the length of the mean ordinate.


38. Calibration of the Planimeter.—In order to ascertain whether the instrument is accurate and graduated correctly, it is necessary to resort to actual tests to determine the character and amount of error.

It is necessary to ascertain: 1. If the same readings are given by different portions of the record-wheel. 2. Whether the position of the vernier is correct, and agrees with the constants tabulated or marked on the tracing-arm. 3. Whether the scale of the record-wheel is correct, and agrees with the constants marked on the tracing-arm.

These tests are all made by comparing the readings of the instrument with a definite and known area. To obtain a definite area, a small brass or German-silver rule, shown at L, Fig. II, is used; this rule has a small needle-point near one end, and a series of small holes at exact distances of one inch or one centimeter from the needle-point. To use the rule the needle-point is fixed on a smooth surface covered with paper, the planimeter is set with its tracing-point in one of the holes of the rule, and the pole-point fixed as required for actual use. With the tracing-point in the rule describe a circle, as shown by the dotted lines (Fig. II) around the needle-point as a centre. Since the radius of this circle is known, its area is known; and as the tracing-point of the planimeter is guided in the circumference, the reading of the record-wheel should give the correct area.

The method of testing is illustrated in Figs. 11, 12, 13, and 14. Figs. 11 and 13 show the method with reference to the polar-planimeter, Figs. 12 and 14 show the corresponding methods of testing the rolling-planimeter. In Figs. 11 and 13 P is the position of the pole, B the pole-arm, and A the tracing-arm. In Figs. 12 and 14 B is the axis of the rollers and A is the tracing-arm.

First Test. This operation, see Figs. 11 and 12, consists in locating the planimeters as shown, and then slowly and




carefully revolving so as to swing the check-rule as shown by the arrow. Take readings of the vernier at initial point, and again on returning to the starting-point: the difference of these readings should give the area. Repeat this operation several times.

The instrument is now placed in the position shown in Figs. 13 and 14 when the circle  $\mathcal{X}$  appears on the *right*-hand side of the tracing-arm A, and the passage of the tracer takes place in exactly the same way.

If the results obtained right and left of the tracing-arm be equal to one another, it is clear that the axis ab of the measuring-wheel is parallel to the tracing-arm, and, this being so, the second test may now be applied. But if the result be greater in the first case, that is to say, when the circle lies to the left

of the tracing-arm, the extremity a of the axis of the measuring-wheel must be further removed from the tracing-arm; if it be *less*, that extremity must be brought nearer to the tracingarm.

Second Test. The tracing-arm is adjusted by means of the vernier on the guide and by means of the micrometer-screw, in accordance with the formulæ for different areas; it then is fixed within the guide by means of the binding-screw. The circumference of circles of various sizes are then travelled over



with the check-rule, and the results thus obtained are multiplied into the unit of the vernier corresponding to the area given for that particular adjustment by the formula. The figures thus obtained ought to be equal to the calculated area of the circles included by the circumferences. If the results obtained with the planimeter fall short of the calculated areas to the extent of  $\frac{1}{n}$  of those areas, the length of the tracing-arm, that is to say, the distance between the tracer and the fulcrum of the tracing-arm, must be reduced to the extent of  $\frac{1}{n}$  of that length; in the opposite case it must be increased in the same proportion. The vernier on the guide-piece of the tracing-arm shows the length thus defined with sufficient accuracy, usually

in half-millimeters, or about fiftieths of an inch, on the gauged portion of the arm.

In order to test the accuracy of the readings according to the two methods just described, some prefer the use of a check-plate in lieu of the check-rule. The check-plate is a circular brass disk upon which are engraved circles with known radii.

It is advisable to apply the second test also to a large diagram drawn on paper and having a known area.

The instrument having been found correct or its errors determined, it may now be used with confidence.

The following form is used to record the results of the test:

Calibration of	Planimeter.	
by		Dia. register-wheel, in
Formula of Instrument	Length of	arms, pole to pivot, in
Pivot to register-wheel, in	Pi	vot to tracing-point, in
In Roller Pla, radius roller, in	Pitch radius G	ears, No. INo. II

#### COMPARISON WITH STANDARD.

	A	REA.		ME	AN ORDINATE.	
No.	Inst. Reading.	Difference from Mean.	ca .	Inst. Reading.	Difference from Mean.	4
Mean						

Mean error of one observation,  $\pm \sqrt{\sum e^2 + (n-1)}$  in area..., in ordinate...in. Mean error of result,  $\pm \sqrt{\sum e^2 + n(n-1)}$  in area..., in ordinate...in. Probable error of one obs.,  $\pm 0.67 \sqrt{\sum e^2 + (n-1)}$  in area..., in ordinate...in. Probable error of result,  $\pm 0.67 \sqrt{\sum e^2 + n(n-1)}$  in area..., in ordinate...in.

39. Errors of Different Planimeters.—Professor Lorber, of the Royal Mining Academy of Loeben, in Austria, made

extensive experiments on various planimeters, with the results shown in the following table:

		The error in one passage of the tracer amounts on an the following fraction of the area measured by					
ARBA IN-		The ordinary	e ordinary Stark's Linear Suspended		Rolling Pl	animeter—	
		imeter Unit	Unit of Ver-	Unit of Ver-	Unit of Ver-	Unit of Ver-	
Square cm.	Square inches.	or vernier: ro sq. mm. = .o15 sq. in.		105q. mm. = 1 sq. mm.	1 \$q. mm. = .0015 \$q. in,	nier: 1 sq. mm. = .0015 sq. in.	nier: .1 sq. mm. = .0001 sq. in.
10	1.55	78	5 Å B	8 1 8	र है ह	20,00	
20	3.10	148	Tooo	TYTE	1000	2000	
50	7.75	385	TEEF	ARGO	₹0 <mark>100</mark>	80,00	
100	15.50	683	1857	4167	#25E	30,00	
200	31.00	1974	4388	7748	8188	7898	
300	46.50		••••	9878	8000	10000	

The absolute amount of error increases much less than the size of the area to be measured, and with the ordinary polar planimeter is nearly a constant amount.

The following table is deduced from the foregoing, and shows the error per single revolution in square inches:


		Error in	one passage of the	tracer in square i	nch <del>es</del> —
Ari	EA IN—	Polar Planim-	eter Unit of   imeter Unit of		animeter —
Square cm.	Square inches.	Vernier: 10 sq. mm. = .015 sq. inches.	Vernier:  1 sq. mm. =  .0015 sq. inches.	Unit of Vernier: r sq. mm. = .0015 sq. inches.	Unit of Vernier .r sq. mm. = .coor sq. inches
10	1.55	0.0207	0.0025	0.0025	0.00155
20	3.10	0.0206	0.0028	0.0031	0.00158
50	7.75	0.0221	0.0031	0.0038	0.00258
100	15.50	0.0227	0.0035	0.0043	0.00310
200	31.00	0.0243	0.0043	0.0060	0.00403
300	46.50		0.0049	0.0058	0.00165

These errors were expressed in the form of equations, as follows, by Professor Lorber. Let f equal the area corre-

sponding to one complete revolution of the record-wheel; let dF be the error in area due to use of the planimeter. Then for the different planimeters we have the following equations:

Lineal planimeter,	$dF = 0.00081f + 0.00087 \sqrt{Ff};$
Polar planimeter,	$dF = 0.00126f + 0.00022 \sqrt{Ff};$
Precision polar planimeter,	$dF = 0.00069f + 0.00018 \sqrt{Ff};$
Suspended planimeter,	$dF = 0.0006f + 0.00026 \sqrt{Ff};$
Rolling planimeter,	$dF = 0.0009f + 0.0006 \sqrt{Ff}.$

40. Other Instruments much more complicated than those described have been made for special purposes, of which we will mention Amsler's planimeter for finding the moment of inertia, and an instrument described by Sylvanus Thompson for drawing the derivative of any curve, the principal curve being known.



40. Vernier Caliper.—This instrument consists of a sliding-jaw, which carries a vernier, and may be moved over a fixed scale. The form shown in Fig. 15 gives readings to  $\frac{1}{4}$ 0 inch on the limb, and  $\frac{1}{26}$  this amount or to one-thousandth of

an inch on the vernier. The reading of the vernier as it is shown in the figure is 1.650 from the scale, and 0.002 on the vernier, making the total reading 1.652 inches. This instrument is useful for accurate measurements of great variety; the especial form shown in the cut has a heavy base, so that it will stand in a vertical position and may be used as a height-gauge. To use it as a caliper, the specimen to be measured is placed between the sliding-jaw and the base; the reading of the vernier will give the required diameter.

41. The Micrometer.—This instrument is used to measure small subdivisions. It consists of a finely cut screw, one revolution of which will advance the point an amount equal to the pitch of the screw. The screw is provided with a graduated head, so that it can be turned a very small and definite portion of a revolution. Thus a screw with forty threads to the inch will advance for one complete revolution  $\frac{1}{40}$  of an inch, or 25 thousandths. If this be provided with a head subdivided to 250 parts, the point would be advanced one tenthousandth of an inch by the motion sufficient to carry the head past one subdivision.

The micrometer is often used in connection with a microscope having cross-hairs, and in such a case represents the most accurate instrument known for obtaining the value of minute subdivisions; it is also often used in connection with the vernier. The value of the least reading is determined by ascertaining the advance due to one complete revolution, and dividing by the number of subdivisions. The total advance of the screw is equal to the advance for one revolution multiplied by the number of revolutions plus the number of subdivisions multiplied by the corresponding advance for each.

The accuracy of the micrometer depends entirely on the screw which is used.

Accuracy of Micrometer-screws.—The accuracy attained in cutting screws is discussed at length by Prof. Rogers in Vol. V. of Transactions of American Society of Mechanical Engineers, from which it is seen that while no screw is perfectly accurate, still great accuracy is attained. The following errors are those

in one of the best screws in the United States, expressed in hundred thousandths of an inch, for each half-inch space, reckoned from one end.

CORNELL UNIVERSITY SCREW.

Total Errors in Hundred-thousandths of an Inch.

No. of Space.	Total Error.	No. of Space.	Total Error.	No. of Space.	Total Error.
0 1 2 3 4 5 6	0 +6 +8 +9 +7 +9 +7 +9	12 13 14 15 16 17 18	- 4 - 7 - 9 - 7 - 10 - 11 - 11	24 25 26 27 28 29 30	- 8 - 7 - 7 - 9 - 9 - 7 - 7
8 9 10	+5 0 -1 -2	20 21 22 23	— 10 — 11 — 10	32 33 34 35 36	- 7 - 7 - 3 - 2 0

A recent investigation made by the author of the errors in the ordinary Brown and Sharpe micrometer-screw, failed to detect any errors except those of observation, which were found to be about 4 hundred-thousandths of an inch for a distance equal to three-fourths its length. The errors in the remaining portion of the screw were greater; the total error in the whole screw being 12 hundred-thousandths of an inch. As the least reading was one ten-thousandth, the screw was in error but slightly in excess of the value of its least subdivision. In another screw of the same make the error was three times that of the one described.

42. Micrometer Caliper consists of a micrometer-screw shown in Fig. 16, which may be rotated through a fixed nut. To the screw is attached an external part or *thimble*, which has a graduated edge subdivided into 25 parts. The fixed nut is prolonged and carries a cylinder, termed the *barrel*, on which are cut concentric circles, corresponding to a scale of equal parts, and a series of parallel lines, which form a vernier with refer-

ence to the scale on the thimble, the least reading of which is one tenth that on the thimble. If the screw be cut 40 threads per inch, one revolution will advance the point 0.025 inch; and if the thimble carry 25 subdivisions, the least reading past any fixed mark on the barrel would be one thousandth of an inch.

By means of the vernier the advance of the point can be read to ten-thousandths of an inch. Thus in the sketches of




FIG. 16.-MICROMETER CALIPER.

the barrel and thimble scales in Fig. 16 the zero of the vernier coincides in the upper sketch with No. 7 on the thimble; but in the lower figure the zero of the vernier has passed beyond 7, and by looking on the vernier we see that the 3d mark coincides with one on the thimble, so that the total reading is 0.007 + 0.0003, which equals 0.0073 inch.

This number must be added to the scale-reading cut on the barrel to show the complete reading. The principal use of the instrument is for measuring external diameters less than the travel of the micrometer-screw.


The Sweet Measuring-machine.—The Sweet measuring-machine is a micrometer caliper, arranged for measuring larger diameters than the one previously described. The general

form of the instrument is shown in Fig. 17. The micrometerscrew has a limited range of motion, but the instrument is furnished with an adjustable tail spindle, which is set at each



FIG. 17.-SWEET'S MEASURING-MACHINE.


observation for distances in even inches, and the micrometerscrew is used only to measure the fractional or decimal parts of an inch. The instrument is furnished with an external



scale, graduated on the upper edge to read in binary fractions of an inch, and on the lower edge to read in decimals of an inch; this scale can be set at a slight angle with the axis to correct for any error in the pitch of the micrometer-screw.

The graduated disk is doubly graduated; the right-hand graduations corresponding to those on the lower side of the scale. The scale and graduated disk is shown in Fig. 18, and the readings corresponding to the positions shown in the figure are 0.6822, the last-number being estimated.

The back or upper side of the seale, and the left-hand disk, are for binary fractions, the figures indicating 32ds. Fig. 19



shows the arrangement of the figures. Beginning at 0 and following the line of chords to the right, the numbers are in regular order, every fifth one being counted, and coming back to 0 after five circuits. This is done to eliminate the factor five from the ten-thread screw. In Fig. 18 the portion to the left of 0 in Fig. 19 is seen.

The back side of the index-bar is divided only to 16ths, the odd 32ds being easily estimated, as this scale is simply used for a "finder;" thus: In the figure the reading line is very near the 11 mark, or six 32ds beyond the half-inch. This shows that 6 is the significant figure upon this thread of the screw. The other figures belong to other threads. The figure 6 is brought to view when the reading line comes near this division of the scale. Bring the 6 to the front edge of the index-bar, and the measurement is exactly 11 without any calculation. Thus every 32d may be read, and for 64ths and other binary fractions take the nearest 32d below and set by the intermediate divisions, always remembering that it requires five spaces to count one.

43. The Cathetometer.—This instrument is used extensively to measure differences of levels and changes from a horizontal line. Primarily it consists of one or more telescopes sliding over a vertical scale, with means for clamping the telescope in various positions and of reading minute distances. The one shown in the engraving (Fig. 20) consists of a solid brass tripod or base supporting a standard of the same metal, the cross-section of which is shown at different points by the small figures on the left. A sliding-carriage upon which is

secured the small levelling instrument, and which has also a vernier scale as shown, is balanced by heavy lead weights, sus-




FIG. 20.-THE CATHETOMETER.

pended within the brass tubes on either side by cords attached to the upper end of the carriage, and passing over the pulleys

shown at the top of the column. The column is made vertical by reference to the attached plumb-line.

The movable clamping-piece below the carriage is fixed at any point required, by the screw, shown at its side, after which the telescope can be raised or lowered by rotating the micrometer-screw attached to the clamp. The telescope is provided with cross-hairs, which can be adjusted by reversing in the wyes and turning 180 degrees in azimuth. The vertical scale is provided with vernier and reading-microscope.

## STRENGTH OF MATERIALS.

### CHAPTER III.

## GENERAL FORMULÆ.

In this chapter a statement is made of the principal formulæ required for the experimental work in "Strength of Materials." The full demonstration of these formulæ is to be found in "Mechanics of Engineering," by I. P. Church; "Strength of Materials," by D. V. Wood; "Materials of Construction," by R. H. Thurston: N. Y., J. Wiley & Sons.

44. Object of Experiments.—The object of experiments relating to the "Strength of Materials" is to ascertain, firstly, the resistance of various materials to strains of different character; secondly, the characteristics which distinguish the different qualities, i.e., the good from the bad; thirdly, experimental proof of the laws deduced theoretically; fourthly, general laws of variation, as dependent on form, material, or quality.

The following methods of testing are ordinarily employed:
(1) by tension or pulling; (2) by compression; (3) by transverse loading; (4) by torsion; (5) by impact; (6) by repeated loading and unloading, or fatigue.

45. **Definitions.**—Stress is the distributed force applied to the material; it may be internal or external.

Stress is of two kinds, normal or direct, and shearing or tangential, the latter force acting at right angles to the first. A direct stress on an element is always accompanied by a shearing stress, which tends to move the particles at right

angles to the line of action of the force. This is well shown in the simple break by tension, in which case the particles are not only pulled apart, but they are moved laterally, since the break is accompanied with an elongation of the original specimen, and a corresponding reduction in area of the cross-section.

Strain is the distortion of the material due to the action of the force, and within the limits of elasticity is proportional to the stress.

Each stress produces a corresponding strain.

Elasticity is the property that most materials have of regaining their original form when the forces acting on them are removed. This property is possessed only to a limited extent, and if the deformation or strain exceeds a certain amount, the material will not regain its original form.

The critical condition beyond which the body cannot be strained without a permanent distortion or set is termed the elastic limit; this point is gradually reached in most materials, and is indicated by an increase in the increment of strain due to a constant increment of stress.

Rigidity or stiffness is the property by means of which bodies resist change of form.

The coefficient of ultimate strength is the number of pounds per square inch required for rupture, and is obtained by calculation from the known area and actual breaking-load. The coefficient of strength at the elastic limit is the number of pounds per unit of area acting upon the material when a failing in strength is shown by an increased increment of distortion for an equal increment of load.

The resilience is the potential energy stored in the body, and is the amount of work the material would do on being relieved from a state of strain. Within the elastic limit, it is the work done by the force acting on the body, and is evidently equal at any point to the product of one half the load, into the distortion of the piece, this latter being the space passed through. The ductility is the total relative strain; it is usually expressed in percentage of the full length, and is calculated for the point of rupture. In connection with

this should be measured the *reduction* of area of cross-section. The *modulus of elasticity* is the ratio of the stress per unit of area to the corresponding increment of distortion. The *modulus of rigidity* is the amount of tangential stress per unit of area, divided by the deformation it produces, expressed in angular or  $\pi$  measure. The *maximum load* is usually greater than the load at rupture.

The safe load must always be less than the load at the elastic limit, and is usually taken as a certain portion of the ultimate or breaking load. The ratio of the breaking-load to the safe load is termed a factor of safety.

The different kinds of stress, consequently the different kinds of strain produced, are: Longitudinal, divided into tension and compression; Transverse, into shearing and bending; and Twisting or Torsional.

46. Strain-diagrams are diagrams which show the relations which the increments of strain bear to the stress. If the strain-diagrams of several specimens be drawn on the same sheet, the relative values of stress and of strain at elastic limit and at breaking can be determined by inspection. Within the elastic limit the diagram will be a straight line.

Strain-diagrams are constructed (see Article 19, p. 16) by laying off the strain on the horizontal axis to a scale that is readily apparent to the eye, and the corresponding loads as ordinates to a convenient scale, as 3000 or 5000 pounds per inch: a curve drawn through the extremities of these various ordinates will be the strain-diagram. When no part is perfectly elastic, as in cast-iron or rubber, no portion of the curve will be straight.

The general form of the strain-diagram, as drawn autographically, is shown in Fig. 21. In this diagram the strain is represented by distances parallel to OX, the stress as a certain number of pounds per inch parallel to OY. For a short distance from O to A the diagram is a straight line, showing that the increments of strain and stress are uniform; at A there is a sudden increase in the strain, without a marked increase in load, shown by the curved line A to B. The point A is often spoken of as the *yield-point*. In most of the ductile materials

this sudden increase of strain is accompanied with an apparent reduction of stress, as shown by the curve from B to C. This reverse curvature is often well marked on curves taken automatically, and is probably due to the fact that the increase in




FIG. 21.-THE STRAIN-DIAGRAM.

strain is so great that the scale-beam of the machine falls until the stress is increased. The curve then continues to rise, reaching its maximum position at D, and falling soon after when the specimen breaks, as shown at E.

47. Viscosity or Plasticity.—This is the term applied to denote the change of form or flow that results from the application of stress for a long time. It is the result of internal molecular friction, and the resistance exerted is proportioned to the rapidity of the change. The definition of viscosity is given by Maxwell (see Theory of Heat) as follows: "The viscosity of a substance is measured by the tangential or shearing

force on the unit of area of either of two horizontal planes at the unit of distance apart, one of which is fixed, while the other moves with the unit of velocity, the space between being filled with the viscous substance."

Let the substance be in contact with one fixed plane and with one plane moving with the velocity v; denote the distance between the planes by c. Let F be the coefficient of shearing-force, or the force per unit of area tending to move the substance parallel to either plane. Let  $\mu$  be the coefficient of viscosity.

Then we have

$$F = \mu \frac{v}{c}. \quad . \quad (I)$$

If we let b = the breadth and a the length of the plane and R the total force acting,

$$R = abF$$
.

Hence

$$\mu = \frac{cF}{v} = \frac{cR}{vab}.$$

When c, a, and b each equal unity,

$$\mu = R$$
.

If R is the moving force that would generate a certain velocity v in the mass M in time t, R will equal  $Mv \div t$ ; from which

$$\mu = \frac{Mvc}{tvab}; \quad . \quad . \quad . \quad . \quad . \quad (1a)$$

all of which quantities may be determined by experiment.



# 48. Notation.—The notation used is the same as that in Church's "Mechanics of Engineering," and is as follows:

		Sym	<b>b</b> ol.	
Quantity.	Maximum Load.	'Breaking- Load.	Elastic Limit.	Safe Limit
Load applied	$P_m$	P	P"	P'
Load per square inch		ø	<b>ø</b> "	
Moduli of tenacity	Tm	P	p'' T''	p' T'
" compression	. Cm	C	C''	ζ' λ'
" " shearing	. Sm	S	S"	5"
Total elongation	λ,,,	À	λ"	λ'
Increment of elongation		Δλ .	⊿λ"	⊿λ′
Relative elongation	€ 🖛	$\epsilon$	€″	€'
Resilience		$\mid U \mid$	U"	U'
Bending-moment	Mm	M 8	M''	M'
Relative shearing distortion	.	8	δ''	δ'
Transverse load-total	$W_{m}$	w	W'	W'
Transverse shear	/**		J"	<i>I'</i>

Modulus of Elasticity		Compression. $E_c$	Shearing. $E_s$
Area sq. inches	<b></b>	F	
Length, "			
Factor of safety	• • • • • • • • • • • • • • • • • • • •		
Ordinary moment of inertia	·······	. <b></b> <i>I</i>	
Polar moment of inertia		<i>I</i> p	
Maximum fibre-distance			

40. Formulæ for Tensile Strength. (Church's Mechanics, pp. 207-221.)—Since in tension the stress is uniformly distributed, we have

$$P = FT; \ldots \ldots (2)$$

$$\epsilon = \frac{\lambda}{l}$$
. . . . . . . . . (4)

The modulus of elasticity by definition equals the load per square inch divided by the strain per inch of length, within the elastic limit. Hence

Resilience  $U = \text{mean force} \times \text{total space} = \frac{1}{2}P''\lambda'' = \frac{1}{2}P''\epsilon''l = \frac{1}{2}T'\epsilon''Fl$ . But Fl equals the volume V.

$$\therefore U = \frac{1}{2}T''\epsilon''V = \frac{1}{2}P''\epsilon''l. \qquad (6)$$

50. Modulus of Elasticity from Sound emitted by a Wire.—Let l equal the length of the wire, d equal its specific gravity, n equal the number of vibrations per second, v equal the velocity in feet per second.

Determine the number of vibrations by comparing the sound emitted, caused by rubbing longitudinally, with that made by the vibration of a tuning-fork. In this manner determine the note emitted. The number of vibrations per second can be found by consulting any text-book devoted to acoustics.

We shall have finally

$$v = 2nl;$$

also

$$v = \sqrt{\frac{Eg}{d}}$$

from which

$$E = \frac{v^*d}{g} = \frac{4n^*l^*d}{g}. \quad . \quad . \quad . \quad . \quad (7)$$

This result usually gives a larger value by one or two per cent than that obtained by tension-tests, owing to the viscosity of the body.

51. Formulæ for Compression-tests.—The compression-tests are of value in determining the safe dimensions of material subject in use to a crushing or compressive stress. Nearly

all bearings in machinery, a portion of the framework, the connecting-rod of an engine, during some portion of a revolution, are illustrations of common occurrence, of members strained by compression. Columns and piers of buildings, masonry-walls, are familiar illustrations in structures.

The subject is naturally divided into two heads, the strength of short specimens and the strength of long specimens, since the strain is manifestly different in each case.

Short Pieces, or those in which the length is not more than four diameters, yield by crushing, and the force acts uniformly over each square inch of area, so that formulæ similar to those used in tension apply. (For notation see article 48, page 62.) We have

$$P_{\epsilon} = FC; \quad p = \frac{P}{F} \dots \dots$$
 (8)

$$E_{c} = \frac{p}{\epsilon} = \frac{pl}{\lambda} = \frac{Pl}{F\lambda}$$
 . . . (10)

Resilience 
$$U_{\epsilon} = \frac{1}{2}P''\lambda'' = \frac{1}{2}P''\epsilon''l = \frac{1}{2}C''\epsilon''Fl$$
. (11)

The compression-strain is accompanied with a shearingstrain acting at right angles to the specimen equal to  $P \sin \alpha$ cos  $\alpha$ , being a maximum when  $\alpha = 45^{\circ}$ . Hence, brittle materials tend to fly to pieces at that angle, leaving two pyramids with facing points.

Long Pieces, in which the length equals ten or twenty diameters, yield by bending on the side of least resistance.

Rankine's formula is most used for this case (Church's Mechanics, page 374).

Breaking-load for flat ends,

$$P_{1} = FC \div \left(1 + \beta \frac{l^{2}}{k^{2}}\right).......(12)$$

Breaking-load for round-ended or two-pin column, '

$$P_{\bullet} = FC \div \left(1 + 4\beta \frac{l^*}{k^*}\right). \quad . \quad . \quad . \quad (12a)$$

Breaking-load for one round end and one square end or pin and square end,

$$P_{\bullet} = FC \div \left( \mathbf{I} + \frac{16}{9} \beta \frac{l^2}{\overline{k}^3} \right). \quad . \quad . \quad . \quad (12b)$$

VALUE OF COEFFICIENTS AS GIVEN BY RANKINE.

Coefficients.	Cast-iron.	Wrought-iron.	Timber.
C in pounds per sq. inch		36000 1 + 36000	7200 I + 3000

Notation in above Formulas.

F = area in square inches.

l = length in inches.

K = radius of gyration.

 $K^2 = I \div F$ . See page 68 for values of I.

In case the modulus of elasticity is required, Euler's formula should be used; in this

$$P_{\bullet}^{\prime\prime} = EI\pi^{2} \div l^{\prime\prime2}$$

for round-ended columns, in which  $l'' = l - \lambda$ ,

$$E = \frac{P_0''(l-\lambda)^2}{I\pi^2}.$$
 (13)

For a column with flat ends,

For a column with one pin or round end and the other end square,

$$P_{*}^{"} = \frac{9}{4}EI\pi^{3} \div l^{"2}, \quad l^{"} = l - \lambda. \quad . \quad . \quad (13b)$$

Euler's formula has only been approximately verified by experiment.

52. Transverse Stress.—Theory.—In case of transverse stress the force, or a component of the force, is applied at right angles to the principal dimensions of the material. The material is generally in the form of a beam, and the strains produced make the beam assume a concave form with reference to the direction of the force applied. The result of this is a compression of the fibres nearest the force, and a corresponding elongation of those farthest away. The fibres of the beam not strained or deformed by any longitudinal force lie in what is called the neutral axis. The curve which the neutral axis assumes due to the forces acting is termed the elastic curve.

The weight carried tends to rupture the beam at right angles to the neutral axis; this stress is equal to the resultant force acting at any point, and is termed the *transverse shear*. In addition to this there is a shearing-force tending to move the fibres of the beam with reference to each other in a longitudinal direction, which is termed *parallel shear*; this force is a small one compared with the other forces, and for that reason is difficult to measure experimentally.

Formulæ.—In this case the external load is applied with an arm, and tends to produce rotation; the result is termed the Moment of Flexure or Bending-moment, which is denoted by M.

The internal moment of resistance is equal to  $pI \div e$ , in which p equals the intensity of strain on the outermost fibre of the piece, I equals the moment of inertia, e equals the distance of the outermost fibre to the neutral axis. Since these moments must be equal, we have

$$M = pI \div e$$
, . . . . (14)

which formula may be used for strength. We also have

$$EI \div \rho = M$$
, . . . . . (15)

which may be used for flexural stiffness (Church's Mechanics, page 250), in which  $\rho = \text{radius}$  of curvature =  $\mathbf{i} \div \frac{d^3y}{dx^2}$  (approximately).

Hence

$$\pm EI\frac{d^3y}{dx^3} = M, \quad . \quad . \quad . \quad . \quad (16)$$

which is the differential equation of the elastic curve.

To find the external moment M, consider the beam as a lever, subject to action of forces, only on one side of the free section. If we consider A as the amount carried by any abutment, or the resistance acting at one end, x the distance to the free section, W the weight of any load or loads between the abutment and the free section, and x' the distance of the point of centre of gravity of these loads to the free section, then by the principles of moments we have the general equation

$$M = Ax - Wx'. . . . . . . (17)$$

In problems relating to the elastic curve assume the general differential equation

$$\pm EI\frac{d^{n}y}{dx^{n}}=M.$$

Find the numerical value of M expressed in terms of one dimension of the beam as variable. Thus, as above, M = Ax - Wx. Select the origin of co-ordinates in such a position that the constants of integration can be determined. Then integrate. The first integration will give the value of  $\frac{dy}{dx}$  or the tangent of the elastic curve; the second integration will give y, the ordinate to the elastic curve.

The parallel shear is maximum in the neutral axis, and decreases either way proportionally to the ordinates of a parabola.

The value of the parallel shear per unit of section in the neutral axis is

$$Z_{\bullet} = \frac{f}{Ib_{\bullet}} \times \left\{ \begin{array}{c} \text{area above neu-} \\ \text{tral axis (or below)} \end{array} \right\} \times \left\{ \begin{array}{c} \text{the distance of its} \\ \text{centre of gravity} \\ \text{from that axis.} \end{array} \right\}; (18)$$

in which I is equal to the moment of inertia, J the total transverse shear, and  $b_{\bullet}$  the thickness of beam in the neutral axis.

In the ordinary cases of *shearing-forces*, such as act on rivets or pins, the intensity is uniform; this case is considered later.

The following tables of moments of inertia, of transverse loads, and of external moments will be useful in working up the results of the experiments.

TABLE NO. I.

Moments of Inertia.

	Ordinary Moment.	Polar Moment.	Max. Fibre Dist.
Rectangle, width b, depth h		$\frac{1}{13}\delta h(\delta^2 + h^2)$	1/4
Hollow rectangle, symmetrical	$\frac{1}{18}(b_1h_1^8-b_2h_2^8)$		1/2
Triangle, width = $b$ , height = $h$	1 6 h2		3 /2
Circle of radius r	$\frac{1}{4}\pi r^4$	<u>1</u> πr⁴	7
Ring of concentric circles	$\frac{1}{4}\pi(r_1^4-r_2^4)$	$\frac{\frac{1}{2}\pi r^4}{\frac{1}{2}\pi(r_1^4-r_2^4)}$	<i>r</i> 1
Rhombus $h = $ vertical diagonal	180k8	120h4	1/2
Square with side (b) vertical	1264	164	16
" (b) at 45°		164	10 1/2

TABLE NO. II.
FORMULAS FOR TRANSVERSE LOADS.

	CANTII	LEVERS.		TITH TWO
	With one End Load P Wt. of Beam neglected.	With Uniform Load.  W = wl.	Load P, in Middle. Wt. of Beam neglected.	Uniform Load. W = tel.
Deflection = d	$\frac{1}{2}PI^{0} + EI$	$W^3 + EI$	$\lambda Pl^3 + EI$	str W! + E!
Maximum fibre-strain ≱	Ple + I	Wle+2I	Ple+41	W'le + 8/
Safe load	R'I + le	2R' I + le	4R'I + le	8R'1+1e
Coefficient R'	Pla + I	Wle + 21	Ple+Al	Wle + 81
Relative strength, equal length	1	2	4	8
Relative stiffness, equal load	1	9	16	129
" " safe load	1 1	4	4	i,
Modulus elasticity	$Pl^3 + 3dI$	$Wl^3 + 8dl$	$PI^{0} + 48dI$	5W13+384d1
Max. shear	P at support	W at support	₽at supp't	Wat supp't

TABLE NO. 111.

TABLE OF EXTERNAL MOMENTS IN FLEXURE.

CASS.	Resistance at Origin.	Distance Load to Pt. of Stress.	Shear.	Position for Max. Shear.	Ratio of Shearing Force to	External Moment.	Position for Max. Moment.	Ratio of Max. Moment. to W.
	٩٢	34	`	দ	J+W	Я	4	M=+W!
BRAMS FIXED AT ONE BAD.								
W. W. Extreme end with	•	4	* 1	anywhere	¥ 1	- 16/3	~	:
THE PARTY OF INCESSION	•	4	****	`	ī	grm4 -	~	†
us, Uniorm load, or intensity  w = and additional load  W' at extreme end	•		- W' - wx.	7	-	$-W'z - \frac{wx^3}{s}$	~	14. + A
BRAMS SUPPORTED AT BOTH RNDS.  IV. Single load W in the middle: Half of beam next origin.	**	*- /	A.	anywhere		+Wx	*	
Farther half	<i>M</i> +	14-x	- + W	anywhere	1	$\frac{1}{4}W(l-x)$	*	**
V. Single load W applied at x'' from origin: Between x'' and origin.	$W^{(l-x'')}_{l}$	4	$M = \frac{I - x^n}{i}$	anywhere	<b>4</b> 1	$M\frac{l}{l} = x^{\prime\prime} W$	ħ	$\frac{x''(l-x'')}{l^2}$
Beyond x"	:	1,2 - 2	# 1 /2 / 1 / 1 / 1 / 1 / 1 / 1 / 1 / 1 /	anywhere	<sup>1</sup> x   1	$\frac{A(l-x)!V}{l}$	:	3
VI. Uniform load of intensity $w = W + L$	ì	4	$\left(x-\frac{1}{s}\right)m$	o and ?	<b>+</b> + +	$\frac{wx(l-x)}{s}$	*	
	wx''(1-x'')	14 1 EN	$w\left(x^{\prime\prime} - \frac{x^{\prime\prime 3}}{2^{\prime}} - \frac{x}{2}\right)$	•	$1 - \frac{x''}{2\ell}$	$\operatorname{wx}\left\{\left(x^{\prime\prime}-\frac{x^{\prime\prime\prime}}{2}\right)-\frac{x}{2}\right\}$	14 14.18 ·	$\frac{x^{\prime\prime}}{2l}\left(1-\frac{x^{\prime\prime}}{2l}\right)^{\frac{n}{2}}$
origin. Beyond x"	:	E - 12"	78 -		E	$\frac{4x - l}{s} = \frac{1}{s}$		

53. Moment of Inertia by Experiment.—If the body can be suspended on a knife-edge so that it can be oscillated backward and forward like a pendulum, its moment of inertia can be found as follows: First, balance the body on a knife-edge, and find experimentally the position of its centre of gravity; denote the distance of the centre of gravity from the centre of suspension by S. Weigh the body, and compute its mass M; denote its weight by W. Suspend the body on the knife-edge, and set it swinging through a very small arc; find the time of a single vibration, by allowing it to swing for a long time and dividing by the number of vibrations. Let t equal the time in seconds of a single vibration or beat; let K equal radius of gyration, so that  $MK^*$  equals moment of inertia.

Then, by mechanics,

$$M = W \div g;$$

$$*MK^3 = \frac{Mt^3gs}{\pi^3};$$

or, by reduction,

$$K^{\bullet} = \frac{f'gs}{\pi^{\bullet}}. \quad . \quad . \quad . \quad . \quad . \quad (19)$$

In this equation K is reckoned from the point of suspension, and the moment of inertia is the moment around the point of suspension.

The moment of inertia about a parallel axis through the centre of gravity, may be denoted by  $MK_c^a$ , and we shall have

$$MK' + MS' = MK'$$
;

<sup>\*</sup> See Weisbach, Vol. I., page 662.

from which

$$K_{\epsilon}^{\bullet} = K^{\bullet} - S^{\bullet}$$

and

$$MK_{\mathfrak{c}}^{\mathfrak{d}} = M(K^{\mathfrak{d}} - S^{\mathfrak{d}}).$$

54. Shearing-strain.—This strain acts in a transverse direction, without an arm, and thus tends to produce a square break; it acts uniformly over the whole section, so that

$$P = SF; S = P \div F. \dots (20)$$

The strain produces on the molecules of the material an angular distortion, which is usually expressed in  $\pi$  measure, or the linear length of the degree of distortion to a radius unity, and is denoted by  $\delta$ .

Let  $p_s$  be the stress per square inch.

$$E_s = p_s \div \delta$$
. . . . . . (21)

 $E_s$  is termed the modulus of rigidity.

The coefficient of shearing-strength S can be obtained by direct experiments, by using the specimen in the form of pins or rivets holding links together, the links being fitted to go in the machine like tensile specimens, and tensile force applied; if the specimen is a plate, its resistance to shearing-strain can be found by forcing a punch through, as in compression-strains. The angular distortion cannot be measured directly, but may be determined by tests in torsion, as described.

55. Torsion.—The strain produced by torsion is essentially a shearing-strain on the elements of the specimen. The effect of torsion is to arrange the outer fibres of the specimen into the form of helices, as can readily be seen by examining a test-piece broken by torsion stress; each one of these fibres makes an angle with its original position or axis of the piece, equal to its angular distortion, or  $\delta$ , which is expressed in  $\pi$  measure. This has the effect also of moving any particle in the surface of

the specimen, through an angle lying in a plane perpendicular to the axis and with its vertex in the axis. This last angle is called  $\alpha$ . Letting l equal the length of the specimen, e equal its radius, we have, neglecting functions of small angles,

$$e\alpha = l\delta$$
, . . . . . . . . (22)

from

$$\delta = e\alpha \div l$$
 . . . . . . . (22a)

But since  $E_s = p_s \div \delta$ ,

$$E_{\bullet} = p I \div e \alpha$$
; . . . . . (22b)

from which  $E_{\epsilon}$ , the modulus of rigidity, may be computed. Since the external moment of forces is equal to the internal moment of resistance, if we let P equal the external load, a its lever-arm, and  $I_{\epsilon}$  the polar moment of inertia, we will have

$$Pa = (p_i I_j) \div e$$
, . . . . (23)

from which

$$p_{\epsilon} = Pae \div I_{p}.$$
 . . . . (24)

For a circular rod of radius  $r_1$ ,

$$I_r = \frac{\pi r_1^4}{2}$$
, also  $\epsilon = r$ .

Let the external moment  $Pa = M_i$ . Then

$$M_i = Pa = \frac{p_i \pi r^i}{2};$$

$$p_s = \frac{2M_t}{\pi r^3}.$$

The torsional resilience, or work done, will equal the average load multiplied by the space, or

$$U_1 = \frac{1}{2}P_1 a\alpha$$
. . . . . . . (25)

56. Modulus of Rigidity of a Wire by swinging under Torsion.—The transverse modulus of elasticity, or the modulus of rigidity, can be determined by hanging a heavy weight on the wire, and swinging it around a vertical axis passing through its point of suspension. Let lequal its length in feet,  $\tau$  its radius in feet,  $I_{\bullet}$  the polar moment of inertia of the swinging weight, t the time in seconds of an oscillation. be the modulus of rigidity. Then

$$E_{i} = \frac{\pi I_{\rho}l}{g^{\alpha}l^{\alpha}r^{\alpha}}. \qquad (26)$$

57. Relation of E. and Et.—Let the distortion in direction of the stress equal  $\epsilon$ , the angular lateral distortion =  $\delta$ , the lineal lateral distortion = m; then

$$\tan\left(45^{\circ} - \frac{\delta}{2}\right) = \frac{1-m}{1+\epsilon} = 1-m-\epsilon$$
, nearly.

But since  $\delta$  is small,

$$\tan\left(45^{\circ}-\frac{\delta}{2}\right)=1-\delta$$
, nearly.

Hence, by substituting,

$$\delta = m + \epsilon$$
.

Now

$$E_i = \frac{p}{\epsilon}$$
 and  $E_i = \frac{\frac{1}{2}p}{\delta}$ ;

Hence

$$\frac{E_i}{E_i} = \frac{\epsilon}{2\delta} = \frac{\epsilon}{2(m+\epsilon)}.$$

In cast-iron, by experiment, Prof. Bauschinger found for cast-iron m = .23e; hence for this case  $E_t = 0.407E_t$ .

58. Combination of Two Stresses. Intensity of combined Shearing\* and normal Stress.—Let q be the intensity of the shearing-stress, which acts on the transverse section and on a parallel section, and let p be the intensity of the normal stress on the transverse section; it is required to find a third plane such that the stress on it is wholly normal, and to find r the intensity of that stress; let this plane make an angle  $\theta$  with the transverse section. Then, from equilibrium of forces,

$$(r-p)\cos\theta=q\sin\theta$$
, and  $r\sin\theta=q\cos\theta$ .

Hence.

$$q^{2}=r(r-p),$$

$$\tan 2\theta = 2q \div p$$
. . . . . (27)

$$r = \frac{1}{2}p \pm \sqrt{q^2 + \frac{1}{2}p^2} \dots$$
 (28)

58a. Twisting combined with Longitudinal Stress.—In a circular rod of radius  $r_1$ , a total longitudinal force P in the direction of the axis gives a longitudinal normal stress

$$p_1 = P \div \text{area} = p \div \pi r_1^2$$
.

A twisting-couple M applied to the same rod gives a shearing-stress whose greatest intensity

$$q_1=2M_t\div\pi r_1^3.$$

<sup>\*</sup> Encyc. Britannica, art. "Strength of Materials."

The two together give rise to a pair of principal stresses, as above,

$$r = \frac{P}{\pi r_1^2} \pm \sqrt{\left(\frac{2M}{\pi r_1^3}\right)^2 + \frac{P^3}{4\pi r_1^4}} \cdot \cdot \cdot \cdot \cdot (29)$$

59. Twisting combined with Bending.—This important practical case is realized in a crank-shaft.

Let P be the force applied to the crank-shaft; let R be the radius of the crank-shaft; let B equal the outboard bearing, or the distance between the plane of revolution of the centre of the crank-pin and the bearing.

If we neglect the shearing-force, there are two forces acting: a twisting-force  $M_1 = PR$ , and bending-moment  $M_2 = PR$ . The stresses per unit of area on the outer fibre would be  $p_t = 4M_1 \div \pi r_1$  (in which  $r_1$  is the radius of the crank-shaft) from formulæ for transverse strength, and  $p_t = 2M_1 \div \pi r_1$  from formula for torsion.

Combining these as in equation (27), we find for the principal stress

$$r = 2(M_0 \pm \sqrt{M_1^2 + M_0^2}) \div \pi r_1^2$$
.

By substituting values of  $M_1$  and  $M_2$ ,

$$r = 2P(B \pm \sqrt{B^2 + R^2}) \div \pi r_1^2 . . . . (30)$$

The greatest shearing-stress equals

$$p_s = 2P\sqrt{B^2 + R^2} \div \pi r_1^2 \dots \dots (31)$$

The axes of principal stresses are inclined so that

$$\tan 2\theta = M_1 \div M_2 = R \div B. \quad . \quad . \quad . \quad . \quad (32)$$

60. Thermodynamic Relations.\*—Thermodynamic theory shows that heat is absorbed when a solid is strained by opposing and is given out when it is strained by yielding to any elastic force of its own, the strength of which would diminish if the temperature were raised. example, a spiral spring suddenly drawn out will become lower in temperature, but when suddenly allowed to draw in will rise in temperature. With an india-rubber band the reverse condition is true, which indicates that the effect of heat is to contract instead of to expand the rubber. this theory the rise in temperature can be calculated for a given strain. Thus let t equal the absolute temperature of the body:  $\theta$  the elevation of temperature produced by sudden specific stress  $\phi$ ; let e equal the corresponding strain; J Joule's equivalent; k the specific heat of the body under constant stress; & its density. Then

$$\theta = \frac{tep}{/k\delta}. \qquad . \qquad . \qquad . \qquad . \qquad . \qquad (33)$$

in which both e and p are infinitesimal, or very small quantities.

<sup>\*</sup>See paper by Wm. Thomson in l'hilosophical Magazine 1877, also vol. III, page 814, ninth edition Encyc. Britannica.




FIG. 22.—THE EMERY TESTING-MACHINE AT THE UNITED STATES ARSENAL AT WATERTOWN.

### CHAPTER IV.

### STRENGTH OF MATERIALS—TESTING-MACHINES.

61. General Description.—The testing-machine consists essentially of a weighing device, head and clamps for holding the specimen, apparatus for applying the power to strain the specimen, and a frame to hold these parts together and to resist the stress caused by a rupture of the specimen. Some testing-machines have in addition, or as a substitute for the weighing device, means for producing an autographic record of the strain. The same machine is frequently adapted for tensile, compressive, and transverse strains.

The testing-machines of recent construction generally have a platform, to which is rigidly connected, by cast-iron columns, a fixed head in which is a rectangular opening, the platform and fixed head being a portion of the weighing system; intermediate between these and connected by rods to the power system is a head, which is adjustable, to accommodate specimens of different length. If the specimen is to be pulled apart, it is held by clamps between the upper fixed head and the movable one; if it is to be compressed or broken transversely, it is held by suitable supports between the movable head and the lower platform. In most machines the specimen is vertical for tension or compression tests, and such machines are termed vertical machines. Vertical machines are now generally preferred to horizontal ones, as they take less room and are somewhat more convenient in form.

62. Weighing System.—The weighing system in the present English machines, and in former ones built in this country, consists of a single lever or scale-beam, along which can be

moved a poise, and which can be connected by one or more levers to the test specimen. Such machines are objectionable principally from the space occupied.

The weighing device in nearly all recent machines consists of a series of levers, arranged very much as in platform-scales, finally ending in a graduated scale-beam over which a poise is made to move. The machines are usually so constructed that the effect of the strain on the specimen is transmitted into a downward force acting on the platform, and the effect of a given stress is just the same as a given load on the platform.

The weighing-levers usually consist of cast-iron beams carrying hardened steel knife-edges, which in turn rest on hardened-steel bearing plates. This is the system adopted by most scale-makers for their best scales.

In the Emery testing-machines, which are especially noted for their accuracy and sensitiveness, the knife-edges and bearing plates are replaced by thin plates of steel, the flexibility of which permits the necessary motion of the levers.

The weighing device should be accurate, and sufficiently sensitive to detect any essential variation in the stress. The amount of sensitiveness required must depend largely on the purposes of the test. An amount less than one tenth of one per cent will rarely make any appreciable difference in the result, and probably may be taken as the minimum sensitiveness needed for ordinary testing. Means should be provided for calibrating the weighing device. This can be done, in the class of machines under consideration, by loading the lower platform with standard weights and noting the corresponding readings of the scale-beams. Testing-machines may be calibrated with a limited number of standard weights, by the use of a testspecimen, which is not to be strained beyond the elastic limit. The weights are successively added and removed, and strain is maintained on the test-piece, equal to the reading on the calibrated portion of the scale-beam.

63. The Frame.—The frame of the machine must be sufficiently heavy and strong to withstand the shock produced

by a weight equal to the capacity of the machine suddenly applied.

The weighing levers must sustain all the stress or force acting on the specimen, without sufficient deflection to affect accuracy of the weighing, and the frame must be able to sustain the shock consequent upon the sudden removal of the load, due to breaking, without permanent set or deflection.

- 64. Power System.—The power to strain or rupture the specimen is usually applied through the medium of a train of gears or by a hydraulic press, operated by power or hand. The hydraulic machine is very convenient when the stress is less than 50,000 pounds; but if there is any leakage in the valves, the stress will be partially relieved the instant the pump ceases to operate, and difficulty may be experienced in ascertaining the stretch for a given load.
- 65. Shackles.—The shackles or clamps for holding the specimen vary with the strain to be applied. These clamps for tension tests usually consist of truncated wedges which are inserted in rectangular openings in the heads of the testing-machines, and between which the specimen is placed. The interior face of the wedges is for flat specimens plane and serrated, but for round or square specimens it is provided with a triangular or V-shaped groove, into which the head of the specimen is placed. When the strain is applied to the specimen these wedges are drawn closer together, exerting a pressure on the specimen somewhat in proportion to the strain and often injurious to its strength. In tensile testing it is essential to the correct determination of the strength of the specimen that the force shall be applied axially to the material; in other words, it shall have no oblique or transverse component. This requires that the wedge clamps shall be parallel to the specimen, and that the heads which contain the clamp shall separate in a right line and parallel to the specimen.

This construction is well shown in the following description of the clamps used in the Olsen and Riehlé testing-machines.

A plan and section of the draw-heads used with the Olsen machine is shown in Fig. 23. The small numbers refer to

the same part in each view, and also in Figs. 29 to 33, so that any part can be easily identified; 60, 59 is a counterbalanced lever used to prevent the wedges falling out when the strain is relieved; 63, 63, is a screw connected to a plunger for adjusting the space into which the wedge-clamps are drawn. A lateral motion of the specimen is obtained by unscrewing on one side and screwing up simultaneously on the other side:




FIG. 23.—DRAW-HEAD TO OLSEN'S TESTING-MACHINE.

this adjustment is of advantage in some instances in centering the specimen. For use of the other parts shown in Fig. 20, see Art. 64, page 91.

The clamps used by Riehlé Brothers for holding flat specimens are shown in Fig. 24 and Fig. 25, as follows:

Fig. 24 $\alpha$  is a plan of wedge-clamp, with specimens in position; CC, curve-faced wedges; D, specimens; e is a pin that is used to guide the specimen to the centre of the testingtools.




Fig. 25 is a sectional view of same. Fig. 24 is a view of the wedge-faced clamp. The inclination of the surfaces of the wedges are exaggerated in the drawings, so as to distinctly set forth their features.

Wedges have been made with spherical backs, and a portion of the draw-heads mounted on ball surfaces in order to insure axial strains. Special holders into which screw-threads have been cut have been used with success, and in many instances the specimens have been fastened to the draw-heads by right and left threaded screws.

66. Specifications for Government Testing-machine.— The large machine in use by the United States Government at the Watertown Arsenal was built by Albert H. Emery. The machine is not only of large capacity, but is extremely delicate and very accurate. A perspective view of the machine is shown in Fig. 22.

The requirements of the United States Government as expressed in the specifications, which were all successfully met, were as follows:




FIG. 26.—LONGITUDINAL SECTION OF END, WITH ELEVATION OF STRAINING-HOLDER.

- 1st. A machine with a capacity in tension or compression of 800,000 pounds, with a delicacy sufficient to accurately register the stress required to break a single horse-hair.
- 2d. The machine should have the capacity of seizing and giving the necessary strains, from the minutest to the greatest, without a large number of special appliances, and without special adjustments for the different sizes.
- 3d. The machine should be able to give the stresses and receive the shocks of recoil produced by rupture of the specimen without injury. The recoil from the breaking of a specimen which strains the machine to full capacity may amount to 800,000 pounds, instantly applied. The machine must bear this load in such a manner as to be sensitive to a load of a single pound placed upon it, without readjustment, the next moment.
  - 4th. The parts of the machine to be at all times accessible. 5th. The machine to be operated without excessive cost.
- 67. Description of Emery Testing-machine.—These machines are now constructed by Wm. Sellers & Co. of Philadelphia, under a license from the Yale & Towne Mfg. Co. of Stamford, Conn.

The following description will serve to explain the principle on which the machine acts:

The machine consists of the usual parts: 1. Apparatus to apply the power. 2. Clamps for holding the specimen. 3. The weighing device or scale.

- 1. The apparatus for applying power consists of a large hydraulic press, which is mounted on wheels as shown in the engravings, Fig. 22 and Fig. 26, and can be moved a greater or less distance from the fixed head of the machine. Two large screws serve to fix or hold this hydraulic press in any position desired, according to the length of the specimen: and when rupture is produced the shock is received at each end of these screws, which tend to alternately elongate and compress, and take all the strain from the foundation.
- 2. Clamps for holding the specimen. These are peculiar to the Emery machine, and are shown in Fig. 26 in section. This

figure also shows a section of the fixed head of the machine, and a portion of the straining-press, with elevation of the holder for the other end of the specimen.

The clamps, numbered 1484 in Fig. 26, are inserted between two movable jaws (1477), which are pressed together by a




Fig. 27.-Elevation of the Vertical Machine,

FIG. 28.-SCALE-BRAM AND CASE.

hydraulic press (1480), resting on the fixed support (1476). By this heavy lateral pressure force equal to 1,000,000 pounds can be applied to hold the specimen. The amount of this force is shown by gauges connected to the press cylinder, and can be regulated as required.

For the vertical machines these shackles or holders are arranged so as to have sufficient lateral motion to keep in the




FIG. 29.—THE BASE-FRAME AND ABUTMENTS.

line of the test-piece.

3. The weighing device. This is the especial peculiarity of

the Emery machine: instead of knife-edges, thin plates of steel are used, which are flexed sufficiently to allow the necessary motion of the levers. The steel used varies from 0.004 to




FIG. 30.- BEAM FOR PLATFORM-SCALE.

0.05 inch thick, and the blades are so wide that the stress does not exceed 40,000 to 60,000 pounds per square inch.

Fig. 31 shows the form of fulcrums used for light forces when the steel fulcrums are in tension.




FIG. 31.-CLAMPING SUSPENSION FULCRUMS.

The method of measuring the load is practically that of the hydraulic press reversed, but instead of pistons, diaphragms having very little motion are used. Below the diaphragm is a very shallow chamber connected by a tube to a second chamber covered with a similar diaphragm, but of a different diameter. Any downward pressure on the first diaphragm is transmitted to the second, giving a motion inversely as the squares of the diameters. This latter motion may be farther increased in the same manner, with a corresponding reduction in pressure, or it may at once be received by the system of weighing levers. The total range of motion given the first diaphragm in the 50-ton testing-machine is  $\frac{1}{400000}$  part of an inch, but the indicating arm of the scales has a motion of  $\frac{1}{100}$  of an inch for each pound. This increase of motion and corresponding reduction of pressure is accomplished practically without friction. These parts will be well understood by Figs. 28. 29, and 30, showing the Emery 100,000-pound vertical testing-machine.

Fig. 27 shows the elevation of the vertical machine arranged for transverse tests. Fig. 28 shows the scale-beam and case, and Fig. 29 is a section of the base-frame and hydraulic supports. In this last figure the diaphragm, filled with liquid, is placed between the frames EE. These frames are allowed the necessary but slight vertical motion by the thin fulcrum-strips b and c, but at the same time are held from lateral motion. The frame EE and diaphragms are supported by springs d, so as to have an initial tension acting on the test-piece. The diaphragm and its enclosing rings fill the whole space between the frame to within 0.005 inch, which is the maximum amount of motion permitted.

The pressure on the diaphragm between the frames EE is communicated by the tube f to a similar diaphragm in communication with the weighing-levers. Fig. 30 represents the weighing-levers for platform-scales. In case a diaphragm is used it is placed beneath the column A; the motion of the column A is communicated to the scale-beams by a system of levers as shown.

The scale-beam of the testing-machine is shown in Fig. 28, and is so arranged that by operating the handles on the outside of the case the weights required to balance the load can be added or removed at pleasure. The device for adding the

weights is shown in Fig. 32. a, b, c, d, e, and f are the weights, which are usually gold-plated to prevent rusting. These when not in use are carried on the supports A and B by means of pins. When needed, these supports can be lowered by the out-

side levers, and as many weights as are needed are added to the weighing-poise *CD*.

68. Riehlé Brothers' Hydraulic Testing-machines.—The testing-machines built by Riehlé Brothers of Philadelphia vary greatly in principles and methods of construction. In the machines built by this firm, power is applied either by hydraulic pressure or by gearing, and the weighing device consists of one or more levers working over steel knife-edges, as in the usual scale construction.

Machines have been built by this firm since 1876. The form of the first machine constructed was essentially that of a long weighing-beam suspended in a frame and connected by differential levers to the specimen, the power being applied by a hydraulic press. The later forms are more compact. The standard hydraulic machine as constructed by this firm is shown In this machine the cylinin Fig. 33. der of the hydraulic press, which is situated directly beneath the specimen. is movable, and the piston is fixed.




FIG. 32.—DEVICE FOR ADDING OR REMOVING WEIGHTS.

This motion is transmitted through the specimen, and is resisted by the weighing levers at the top of the machine, which are connected by rods and levers to the scale-frame. Two platforms connected by a frame are carried by the weighing levers: the upper one is slotted to receive the wedges for

holding the specimen: the lower one forms a plane table. The intermediate platform, or draw-head, can be adjusted in different positions by turning the nuts on the screws shown in the cut. For tension-strains the specimen is placed between the upper and intermediate head; for compression it is placed between the intermediate and lower heads. An attachment is often added to the lower platform, so that transverse strains can be applied.

The cylinder is connected by two screwed rods to the intermediate platform or draw-head, and when it is forced




FIG. 33.

downward by the operation of the pump this draw-head is moved in the same direction and at the same rate.

69. Riehlé Power Machines.—The machines in which power is applied by gearing are now more generally used than hydraulic machines. Fig. 34 shows the design of geared machine now built by Riehlé Bros., in sizes of 50,000, 100,000, and 200,000 pounds capacity. In this machine both the gearing for applying the power and the levers connected with the weighing apparatus are near the floor and below the specimen, thus giving the machine great stability. The heads for holding the specimen are arranged as in the hydraulic machine, and power is applied to move the intermediate platform up or down

as required. The upper head and lower platform form a part of the weighing system. The intermediate or draw-head may be moved either by friction-wheels or spur-gears at various




FIG. 34. -RIEHLE'S POWER TESTING-MACHINES.

speeds, which are regulated by two levers convenient to the operator standing near the scale-beam.

The poise can be moved backward or forward on the scale-

beam, without disturbing the balance, by means of a hand-wheel, opposite the fulcrum on which the scale-beam rests.

The scale-beam can be read to minute divisions by a vernier on the poise.

70. Olsen Testing-machine. - General Form. - The ma-




FIG. 35.—THE OLSEN TESTING MACHINE. FRONT VIEW.

chines of Tinius Olsen & Co. of Philadelphia are all operated by gearing, driven by hand in the machines of small capacity, and by power in those of larger capacity.

The general form of the machine is shown in Figs. 35 and 36, from which it is seen that the principles of construction are the same as in the machine last described.

The intermediate platform or draw-head is operated by four screws instead of by two, and there is a marked difference in the arrangement of the weighing-levers and in the gearing.

The machine can be operated at various rates of speed in either direction, and is readily controlled by convenient levers.





FIG. 36.-THE OLSEN TESTING-MACHINE, REAR VIEW.

71. The Olsen Autographic Apparatus.—This apparatus for drawing strain-diagrams is entirely automatic, and is operated substantially as follows:

The diagram is drawn on a drum (103), parallel to the scalebeam, by a pencil actuated by a screw-thread cut to a fine pitch on the end of the rod which actuates the poise (106), so that the pencil will move in a definite ratio to that of the poise. The drum is actuated by the stretch of the specimen. This is brought about by four fingers shown in Fig. 35, and on a larger scale in Fig. 38 by numbers 82 and 83. These fingers, shown in plan in Fig. 38, tend to separate and follow any motion of the collars (65) placed on the test-piece, as shown in Fig. 35; the motion of these fingers is multiplied five times,



and connected by steel bands to the drum, 102, in such a manner that the resultant force only is effective to rotate the drum.

The poise is moved by a friction device attached to the main power system, which is thrown into or out of gear automatically by an electric current, as required to keep the beam floating; the current passes through the scale-beam in opposite directions, according as the place of contact is above or below the beam. Finally, an alarm-bell is rung whenever the scalebeam operates beyond its normal amount, thus calling the attention of the operator.

Gauge-marking Device.—A special and very ingenious arrangement, shown in Fig. 39, is used to hold the test-piece and mark the extreme gauge-marks in any position desired.

72. Parts of Olsen Machine.—The following reference numbers to the parts of the Olsen machine will serve to show the construction:

- 1. Entablature.
- 2. Columns.
- 3. Platform supporting columns.
- 4. Pivots.
- 5. Lower moving head.
- 22. Sleeve on driving-shaft.
- 24. Rock-shaft operating lever shifting
- 25. Hand-lever operating 24.
- 26, 27. Pulleys rotating driving-shaft.
- 28, 29. Friction-clutches engaging 26 with driving-shaft.
- 30. Sleeve operating clutches.
- 31. Forked lever controlling sleeve 30.
- 33. Hand-lever operating 30.
- 34. Grooved wheel on driving-shaft.
- 40. Tilting bearing.
- 41. Band-wheel.
- 42. Endless band.
- 44. Helical spring.
- 46. Fulcrum of lever 117.
- 48. Specimen under test.
- 49. Gripping jaws.
- 50. Projecting flanges on jaws 49.
- 51. Block-slide.
- 52. Grooves in 51.
- 53. Slotted slide supporting 49.
- 54. Opening in 53.
- 55. Eye in 53.
- 56. Bolt connecting 53 and 57.
- 57. Lever to open and shut jaws.
- 58. Fulcrum of 57.
- 59 Counterweight.
- 60. Handle of lever 57.

- 61. Plungers for slides 51.
- 62. Screws for 61.
- 63. Screw-bolt.
- 64. Collars or clamps for caliper bearing.
- 72. Guiding-block.
- 73. Cam.
- 74. Lever moving 87.
- 75. Sliding-blocks.
- 78. Polygonal prism in 75.
- 82, 83. Calipers.
- 85. Arm of caliper.
- 86. Clamps.
- 95. Cord operating recording-cylinder
- 96. Pulley.
- 97. Lever.
- 98. Fulcrum to 97.
- 99. Pulley or sheave.
- 100. Drum or winding-barrel of 102.
- 101. Link.
- 102. Recording-cylinder.
- 103. Pencil.
- 104. Screw.
- 105. Screws shifting 106.
- 106. Poise or weight.
- III. Balancing pivot of beam.
- 117. Force multiplying lever.
- 118. Weighing-beam.
- 118'. Slide to small poise on 118.
- tto Tink
- 144. Endless band for moving poise.
- 145. Guiding-pulleys.
- 146. Grooved wheel.

73. Thurston's Torsion Testing-machine.—Both the breaking-strength and the modulus of rigidity can be obtained from the autographic testing-machine invented by Professor Thurston in 1872.



Fig. 40.—Thurston's Autographic Torsion Testing-machine.

In this machine the power is applied by a crank at one side, tending to rotate the specimen, the specimen being connected at the opposite end to a pendulum with a heavy weight.

The resistance offered by the pendulum is the measure of

the force applied, since it is equal to the length of the leverarm into the sine of the angle of inclination, multiplied by the constant weight P. A pencil is carried in the axis of the pendulum produced, and at the same time is moved parallel to the axis of the test-piece by a guide curved in proportion to the sine of the angle of deviation of the pendulum, so that the pencil moves in the direction of the axis of the specimen an amount proportional to the sine of this angle. A drum carrying a sheet of paper is moved at the same rate as the end of the specimen to which the power is applied. Now if the pencil be made to trace a line, it will move a distance around the drum which is equal to the angle of torsion ( $\alpha$ ) expressed in degrees or  $\pi$  measure, and it will move a distance parallel to the axis of the test-piece proportional to the moment of external forces,  $P\alpha$ .

The diagram Fig. 41, from Church's "Mechanics of Engineering," shows the working portions of the machine very clearly. In the figure P is the pendulum, the upper end of




FIG. 41.

which moves past the guide WR, and is connected by the link FA with the pencil AT. The diagram is drawn on a sheet of paper on the drum, which is rotated by the lever b. The

drum moves through the angle  $\alpha$ , relatively to the pendulum which moves through the angle  $\beta$ . The test-piece is inserted between the pendulum and drum.

The value of  $\alpha$  in degrees can be found by dividing the distance on the diagram by the length of one degree on the surface of the paper on the drum, which may be found by measurement and calculation.

Application of the Equations to the Strain-diagram.—For the breaking-load apply equation (23) of Chapter III., page 72.

$$P\alpha = p_s I_s \div e.$$
 . . . . . (23)

The external moment  $P\alpha$  equals  $Pr \sin \beta$ , in which P is the fixed weight, r the length of the pendulum,  $\beta$  the angle made with the vertical. Hence

Pr sin 
$$\beta = p_s I_s \div e$$
.

In this equation P and r are constant, and depend upon the machine;  $I_p$  and e are constant, and depend upon the test-piece.

 $\sin \beta$  is the ordinate in inches to the autographic strain-diagram, and can be measured; knowing the constant,  $\rho_*$  may be computed.

$$p_{\bullet} = Pr \sin \beta e \div I_{\bullet}$$
.

For the modulus of rigidity, apply equation (22a), Chapter III., page 72.

$$E_{\bullet} = p_{\bullet}l \div e\alpha = Plr \sin \beta \div I_{\bullet}\alpha$$
.

In this equation  $\sin \beta$  is the ordinate to the strain-diagram, and  $\alpha$  the corresponding abscissa, the other quantities are constant, and depend on the machine or on the test-piece.

The Resilience (see equation (25), page 73) is the area of the diagram within the elastic limit, expressed in absolute units.

$$U = \frac{1}{2}P\alpha\alpha = \frac{1}{2}Pr\sin\beta\alpha$$
.

The Helix Angle (see equation (22), page 72)  $\delta = e\alpha \div l$ , in which l is the length of the specimen in inches. The elongation of the outer fibre can be computed by multiplying l by secant  $\delta$ . The per cent of elongation is equal to secant  $\delta$ . (Sec  $\delta$  is equal to the square root of  $l + tan^2 \delta$ .)


74. Machine Constants.—To obtain the Constants of the Machine.—First, the external moment Pa. This is obtained on the principle that it is equal to any other external moment which holds it in equilibrium. Swing the pendulum until its centre-line is horizontal; support it in this position by a strut resting on a pair of scales; the product of the corrected reading of the scales into the distance to the axis on the arm will give Pa. Check this result by trials with the strut at different points. Correct for friction of journal. Second, the value of the scale of ordinates can be obtained by measuring the ordinate for  $\beta = 90^{\circ}$  and for  $\beta = 30^{\circ}$ , since sine  $90^{\circ} = 1$  and sine  $30^{\circ} = \frac{1}{2}$ . Third, the value of the scale of abscissæ can be obtained by dividing the abscissa on the diagram by the radius of the drum including the paper. This may be expressed in degrees by dividing by the length of one degree.

Constants of the Material are obtained by measuring the dimensions of the specimen. The values of I and e are given on page 68.

Conditions of Accuracy.—In obtaining these values, the fol lowing conditions are assumed: Firstly, the test-piece is exactly in the centre of motion of the pendulum and of the drum; secondly, the pencil is in line of the pendulum produced; thirdly, the curve of the guides is that of the sine of the angle of deviation; and, fourthly, the specimen is held firmly from rotation by the shackles or wedges, and yet allowed longitudinal motion. These constitute the adjustments of the machine, and must be carefully examined before each test. Any eccentricity of the axis of the specimen will lead to serious error.

75. Riehlé Torsion-machine.—This machine is shown in Fig. 42. Power is applied at various rates of speed by means of the gearing shown. The specimen is held by means of two chucks: the one on the left is rotated an amount shown by the

graduated scale in degrees; the one on the right is prevented from rotating by a lever connected with the scale-beam. The



external moment is the product of the reading of the scalebeam P into the fixed arm, which is taken as one foot, or unity.



## § 77.] STRENGTH OF MATERIALS—TESTING-MACHINES. 101

The angle of torsion  $\alpha$  is given by reading of the attached graduated arc.

The heads are movable, and the machine is adapted to specimens of varying length and cross-section.

Olsen's Torsion-machine differs from the above principally in details of construction.

76. Impact-testing Machine.—The Drop Test—Testing by Impact.—This test, see page 143, is recommended for material used in machinery, railroad construction, and generally whenever the material is likely to receive shocks or blows in use.

This test is usually performed by letting a heavy weight fall on to the material to be tested. The Committee on Standard Tests of the American Society of Mechanical Engineers recommend that the standard machine for this purpose consist of a gallows or framework operating a drop of twenty feet, the weight to be 2000 pounds, the machine to be arranged substantially like a pile-driver. The impact machine designed by Mr. Heisler consists of a pendulum with a heavy bob, which delivers a blow on the centre of a bar securely held on two knife-edge supports affixed to a heavy mass of metal. This machine is especially designed for comparative tests of castiron; it is furnished with an arc graduated to read the vertical fall of the bob in feet, and a trip device for dropping the ram from any point in the arc. A paper drum can be arranged for automatically recording the deflection of the test-pieces.

Let W = the weight of the bob;

h = the distance fallen through;

P = centre load;

 $\lambda = deflection.$ 

Then

$$Wh = \frac{1}{2}P\lambda$$
.

Hence

$$P = 2Wh \div \lambda.$$

77. Machines for Testing Cement.—Cement mortar can be formed into cubes, and after hardening can be tested in the

usual testing-machines for compression; but tensile tests are usually required, and for this purpose a delicate machine with special shackles is needed. In order that the tests may give correct results, it is necessary that the power be applied uni-




Fig. 43.—Fairbanks' Cement-testing Machine.

formly, and absolutely in the line of the axis of the specimen; and to make different tests comparable, the specimen, or as it is called, the briquette, must be always of the same shape and size, and made in exactly the same manner. The engraving (Fig. 43) shows Fairbanks' Automatic Cement Tester, in which the power is applied by the dropping of shot into the pail F. The specimen is held between clamps, which are regulated at the

proper distance apart by the screw P. At the instant of rupture the scale-beam D falls, closes a valve, and stops the flow of shot. In Fig. 43 M is a closed mould for forming a briquette, S the mould opened for removing the briquette, T a briquette which has hardened, and U one which has been broken.

Directions.—Hang the cup F on the end of the beam D, as shown in the illustration. See that the poise R is at the zeromark, and balance the beam by turning the ball L.

Place the shot in the hopper B, place the specimen in the clamps NN, and adjust the hand-wheel P so that the gradu-




FIG. 44.—OLSEN'S CEMENT-TESTING MACHINE.

ated beam D will rise nearly to the stop K. Open the automatic valve I so as to allow the shot to run slowly. Stand back and leave the machine to make the test.

When the specimen breaks, the beam D drops and closes the valve I. Remove the cup with the shot in it, and hang the counterpoise-weight G in its place. Hang the cup F on the hook under the large balance-ball E, and proceed to weigh the shot in the ordinary way, using the poise R on the graduated beam D and the weights H on the counterpoise-weight G. The result will show the number of pounds required to break the specimen.

An automatic machine designed by Prof. A. E. Fuertes has been in use a long time in the cement-testing laboratory at

Cornell University. In this machine water is supplied flowing from a constant head through a small glass orifice. The fall of the beam consequent on the breaking of the specimen instantly stops the flow of water; the weight of this water, multiplied by a known constant, gives the breaking-load on the briquette.

The Olsen Cement tester is shown in Fig. 44. The power is applied by the hand-wheel and screw, so that it strains the




FIG. 45.-RIEHLÉ BROS.' CEMENT-TESTING MACHINE,

briquette very slowly. The poise on the scale-beam is moved by turning a crank so that the beam can readily be kept floating. The peculiar method of mounting the shackles or holders to insure an axial pull is well shown in the engraving.

The Riehlé cement-tester is shown in Fig. 45. The briquette to be tested is placed between two shackles mounted on pivots so as to be free to turn in every direction.

Power is applied to the specimen by the hand-wheel below the machine, and is measured by the reading on the scale-beam at the position of the poise. Special crushing tools, consisting of a set of double platforms, which may be drawn together by application of the force, is furnished with this machine. The specimen to be crushed is placed between these platforms, and the power applied as for tension.

Besides the machines described, various machines for special testing are manufactured; these machines have a limited use, and do not require special description.

## TESTING-MACHINE ACCESSORIES.

78. General Requirements of Instruments for Measuring Strains.—In the test of materials it is necessary to measure the amount of strain or distortion of the body in order to compute the ductility and the modulus of elasticity. The ductility or percentage of ultimate deformation can often be obtained by measurement with ordinary scales and calipers, since the latter is usually a large quantity. Thus in the tension-test of a steel bar 8 inches long, it will increase in length before rupture nearly or quite 2 inches; if in the measure of this quantity an error equal to one fiftieth of an inch be made, the resulting error in ductility is only one half of one per cent. In the measure of deformation or strain oc-




FIG. 46 .- THE WEDGE SCALE.

curring within the elastic limit the case is very different, as the deformation is very small, and consequently a very small error is sufficient to make a great percentage difference in the result.

The instruments that have been used for this purpose are called *extensometers*, and vary greatly in form and in principle of construction. The instrument is generally attached to the test-piece, either on one or on both sides, and the strain is obtained by direct measurement with one or two micrometerscrews, or by the use of levers which multiply the deformation so that the results can be read on an ordinary scale. As a

rule, instruments which attach to one side of the test-piece will give erroneous readings if the test-piece either be initially curved, or strained so as to draw its axis out of a right line, and this error may be large or small, as the conditions vary.

79. Wedge-scale.—The wedge-shaped scale, Fig. 46, which

could be crowded between two fixed points on the test-piece, was one of the earliest devices to be used. In using the scale two projecting points were attached to the specimen, and as these points separated, the scale could be inserted farther, and the distance measured.

80. The Paine Extensometer.—This instrument, shown in Fig. 47, operates on the principle of the bell-crank lever, the long arm moving a vernier over a scale at right angles to the axis of the specimen. by the scale to thousandths of an inch, and by means of the vernier to one ten-thousandth of an inch. Points on the instrument are fitted to indentations in one side of the test-piece, and the instrument is held in place by spring clips. It is of historical importance, having been invented by Colonel W. H. Paine, and used in the tests of material for the Brooklyn Bridge, and also on the cables of the Niagara Suspension Bridge when, a few years since, the question of its strength was under investigation.

81. Buzby Hair-line Extensometer.—
This is an extensometer in which the strain is utilized to rotate a small friction-roller connected with a graduated disk as shown in Fig. 48. A projecting pin placed in the axis of the graduated disk is held between two parallel bars, each of which is connected



Fig. 47.

to the specimen. The strain is magnified an amount propor-

tional to the ratio of diameters of the disk and pin. The amount of strain is read by noting the number of subdivisions



Fig. 48.—Buzby Hair-line Extensometer.

of the disk passing the hair-line. To prevent error of parallax in reading, a small mirror is placed back of the graduations, and

readings are to be taken when the graduations, the cross-hair, and its reflection are in line. In the late styles of this instrument the disk is made of aluminium, with open spokes, to reduce its weight.

To operate this instrument it is only necessary to clamp it to the specimen, to adjust the mirror and cross-hair, and then to revolve the disk by hand until the zero-line corresponds with the cross-hair and its reflection. Strain is then applied to the specimen, and readings taken as desired in the manner described.

82. Thurston's Extensometer.—This extensometer was designed by Prof. R. H. Thurston and Mr. Wm. Kent, and




FIG. 49.-THURSTON'S EXTENSOMETER.

was the first to employ two micrometer-screws, at equal distances from the axis of the specimen. These were connected to a battery and an electric bell in such a manner that the contact of the micrometer-screws was indicated by sound of the bell. The method of using this instrument is essentially the same as that of the Henning and Marshall instrument, to be described later.

With instruments of this nature a slight bending in the

specimen will be corrected by taking the average of the two readings.

The accuracy of such extensometers depends on-

- 1. The accuracy of the micrometer-screws.
- 2. The screws to be compensating must be two in number, in the same plane, and at equal distances from the axis of the specimen.
  - 3. The framework and clamping device must hold the mi-




FIG. 50.—THE HENNING MICROMETER.

crometers rigidly in place, and yet not interfere with the application of stress.

83. The Henning Extensometer.—This instrument, which was designed by G. C. Henning and C. A. Marshall, is shown in Fig. 50. It is constructed on the same general principles as the Thurston Extensometer, but the clamps which are attached to the specimen are heavier, and are made so that they are held firmly in position by springs up to the instant of rupture. This extensometer is furnished with links connecting the two parts together. The links are used to hold the heads exactly eight inches apart, and are unhooked from the upper head

before stress is applied to the specimen. The micrometer is connnected to an electric bell in the same manner as the Thurston extensometer.




FIG. 51.—THE MARSHALL EXTENSOMETER.

84. The Marshall Extensometer.—This extensometer, shown in Fig. 51, is the latest design of the late Mr. C. A. Marshall. Its principal difference from the Thurston exten-

someter is in the convenient form of clamps, which are well shown in the cut, and in the spring apparatus for steadying the lower part.

The micrometer-screw used with this instrument has a motion of only one inch. When the motion exceeds the range of the micrometer-screws, the movable bars BP, B'P'




FIG. 52.

are changed in position, and a new series of readings taken with the micrometer-screw. To facilitate the change of position of these bars, and allow the micrometer-screw to return to zero at each change, the arrangement shown in Fig. 52 is adopted, which consists of a nut to which is attached a slotted taper-screw, on which

screws a second nut, which serves to clamp the lower nut to the bar; by turning the lower nut when clamped, the desired adjustment can be made.

The following are the directions for use:

Run wire (Fig. 51) from one terminal of battery to lower clamp at A, from B and B' to binding-post C on the electric bell, from the other binding-post marked D to switch E, and from there back to the other terminal of battery.

To measure strain, screw up micrometer-screws at P and P' until each of them makes connection and bell rings; then take the readings on both sides.

85. Boston Micrometer Extensometer.—This instrument consists, as shown in Fig. 53, of the graduated micrometer-screw, reading in thousandths up to one inch, and having pointed extension-pieces attached, for gauging the distance between the small projections on the collars fastened to the specimen at the proper distance. These collars are made partly self-adjusting by the springs which help to centralize them. They are then clamped in place by means of the pointed set-screws on the sides, and measurements are made between the projections on opposite sides of the specimen and compared, to denote any changes in shape or variations in the two sides.

The Brown and Sharpe micrometer can readily be used with

similar collars, thus forming an extensometer; the accuracy of this form is considerably less than those in which the micrometers are fixed, but it will, however, be found with careful handling to give good results.

Of the various extensometers described, the Paine, Buzby, Marshall, and Riehlé are manufactured by Riehlé Bros., Philadelphia; the Thurston, by Olsen of Philadelphia; the others, by the respective designers.

86. Combined Extensometer and Autographic Apparatus.—An extensometer designed by author, and quite extensively used in the tests of materials in Sibley College, is shown in Fig. 54 in elevation and in Fig. 55 in plan. this extensometer micrometers of the kind shown in Fig. 16, Article 42, p. 52, with the addition of an extension-rod for holding, are used. rod sets into a socket A, which holds the micrometer in position. ings are taken on the thimble B, as




FIG. 53.

explained on p. 52. Connections are made with bell and battery at m, n, and m', n', so that contact of the micrometer-screws is indicated by sound. The construction of the clamping device is fully shown in the plan view, Fig. 55.

The principal peculiarity of this extensometer consists in the addition of four pulleys,  $C_1$ ,  $C_2$ ,  $C_3$  and  $C_4$ , which are arranged so that a cord ab can be fastened at  $C_4$  and passed down and around the pulley  $C_4$ , thence over the guide-pulley W, Fig. 55, to pulley  $C_4$ , thence over the pulley  $C_4$ , and thence to a paper

drum. It is at once evident that any extension of the specimen SS' will draw in the free end of the cord at twice the rate of the extension; moreover, any slight swinging or rocking of the extensometer head will produce compensating effects on the length of the cord. By connecting the free end of the cord to a drum, the drum will be revolved by the stretch



of the specimen. As this work may be done against a fixed pull, there may be a uniform tension on the cord so that the motion of the drum would be uniform and proportional to the stretch. A pencil is moved along the axis of the drum proportional to the motion of the poise.

An autographic device constructed in this way has given excellent diagrams, and in addition has served as an extensometer for accurate measurements of strain within the elastic limits. Wire has been used to connect extensometer to drum in place of the cord with success. A suggested improvement is

to rotate the drum by the motion of the poise, and to move the pencil by the stretch of the material, using two pencils, one of which is to move at a rate equal to fifty times the strain, the other at a rate equal to five times the strain; thus producing two diagrams—one on a large scale, for use in determining the strains during the elastic limit; the other on a small scale, for the complete test.

87. Deflectometer for Transverse Testing.—Instruments for measuring the deflection of a specimen subjected to transverse stress are termed deflectometers.

The deflectometer usually used by the author consists of a light metal-frame of the same length as the test-piece, and arched or raised sufficiently in the centre to hold a micrometer of the form used in the extensometer described in Article 86. above the point to which measurements are to be taken. using the deflectometer it is supported on the same bearings as the test-piece, and measurements made to a point on the specimen or to a point on the testing-machine which moves downward as the specimen is deflected. This instrument eliminates any error of settlement in the supports. A steel wire is sometimes stretched by the side of the specimen, and marks made on the specimen showing its original position with reference to the wire. The deflection at any point would be the distance from the mark on the specimen to the corresponding point on the wire. The cathetometer, see Article 43. page 55, is very useful in determining the deflection in long specimens. The deflection is often measured from a fixed point to the bottom of the specimen, thus neglecting any error due to the settlement of the supports. One of the most useful instruments of this kind is made by Riehlé Bros., and is shown, together with the method of attachment, in Fig. 56.




FIG. 56.

## CHAPTER V.

## METHODS OF TESTING MATERIALS OF CONSTRUCTION.

Standard Methods.—The importance of standard methods of testing material can hardly be overestimated if it is desired to produce results directly comparable with those obtained by other experimenters, since it is found that the results obtained in testing the strength of materials are affected by methods of testing and by the size and shape of the test-specimen. To secure uniform practice, standard methods for testing various materials have been adopted by several of the engineering societies of Germany and of the United States, as well as by associations of the different manufacturers. The general and special standard methods adopted by these associations form the basis of methods described in this chapter.

88. Form of Test-pieces.—The form of test-pieces is found to have an important bearing on the strength, and for this reason engineers have adopted certain standard forms to be used. The form recommended by the Committee on Standard Tests and Methods of Testing, of the American Society of Mechanical Engineers is as follows:\*

"Specimens for scientific or standard tests are to be prepared with the greatest care and accuracy, and turned according to the following dimensions as nearly as possible. The tension test-pieces are to have different diameters according to the original thickness of the material, and to be, when expressed in English measures, exactly 0.4, 0.6, 0.8, and 1.0 inch in diameter; but for all these different diameters the angle, but not the length, of the neck is to remain constant. This neck is a cone, not a fillet connecting the shoulders and body. The length of the gauged or measured part to be 8 inches, of the cylindrical part 8.8 inches. The length of the coned neck to be  $2\frac{1}{2}$  times the diameter, increasing in diameter from the cylindrical part to  $1\frac{1}{2}$  times the cylindrical part. The shoulders to have a length equal to the diameter, and to be connected with a round fillet to a head, which has a diameter equal to twice that of the cylinder, and a length at least  $1\frac{1}{2}$  the diameter.

Fig. 57 shows the form of the test-piece recommended for tension; the numbers above the figure give dimensions in




FIG. 57 .- STANDARD TEST-PIRCE IN TENSION.

millimeters, those below in inches. For flat test-pieces the shape as shown in Fig. 58 is recommended: such specimens




FIG. 58.—TEST-PIECE FOR FLAT SPECIMENS.

are to be cut from larger pieces; the fillets are to be accurately milled, and the shoulders made ample to receive and hold the full grip of the shackles or wedges.

The length for rough bars is to remain the same as for finished test-pieces, but the length of specimen from the gaugemark to the nearest holder is to be not less than the diameter of the test-piece if round, or one and a half times the greatest side if flat.

For commercial testing the standard form cannot always be adhered to, and no form is recommended.\*

It is recommended in all cases that the specimens be held by true bearing on the end shoulders, as gripping or holding devices in common use produce undesirable effects on the cylindrical portion of the specimen.

The forms of test-specimens which have been heretofore used are somewhat different from the standards recommended. These forms are shown in Fig. 59, No. 1 to No. 5, and are as follows:




FIG. 50.—FORMS OF SPECIMEN FOR TENSILE STRAINS FORMERLY USED.

89. Test-pieces of Special Materials.—Wood.—Wood is a difficult material to test in tension, as the specimen is likely to be crushed by the shackles or holders. The author has had fairly good success with specimens, made with a very large bearing-surface in the shackles, of the form shown in Fig. 58,

<sup>\*</sup> A discussion of the effect of varying proportion of test-pieces is given in Thurston's "Text-book of Materials," pages 356-7.

page 117 for flat specimens, but with the breadth of the shoulders or bearing-surfaces increased an amount equal to one half the diameter of the specimen over that shown in Fig. 58.

Cast-iron.—Cast-iron specimens of the usual or standard forms are very likely to be broken by oblique strains in tension tests much before the true breaking-point has been reached. To insure perfectly axial strains Riehlé Bros. propose a form of specimen shown in Fig. 60, A, B, and C, cast with an enlarged







FIG. 60.—PROPOSED FORM FOR CAST-IRON SPECIMENS.

head, the projecting portion of which, as shown in C, has a knife-edge shape. The specimen is carried in holders or shackles, A and B, which rest on knife-edges extending at right angles to those of the specimen. This permits free play of the specimen in either direction, and renders oblique strains nearly impossible.

Chain.—In the case of chain, large links are welded at the ends, as shown in Fig. 61; these are passed through the heads of the testing-machine and held by pins.



Hemp Rope.—A similar method is used in testing hemp rope, the specimen being prepared as shown in Fig. 62.



Special hollow conical shackles have also been used for holding the rope with success.

Wire Rope.—Wire-rope specimens may be prepared as shown in Fig. 63, or they may be prepared by pouring a mass



of melted Babbitt metal around each end and moulding into a conical form, taking care that the rope is in the exact centre of the metal.

Cement.—Cement test-pieces for tension are made in moulds and permitted to harden for some time before being tested. It is found that the strength is affected by the form of the speci-




FIG. 64.—STANDARD SPECIMEN FOR CEMENT.

men, by the amount of water used, and by the method of mixing the cement. To get results which may safely be compared, it is necessary to have the test-specimens or briquettes of exactly the same form, and pulled apart in shackles or holders

which exert no side strain whatever, and the strain applied uniformly and without any jerky motion. Various standard forms of briquettes have been adopted, but the one in most common use is that adopted by the American Society of Civil Engineers, and shown full size in Fig. 64.

The form of the mould used in making the briquettes and the holders or shackles used in the Riehlé machine are shown in Fig. 65.



FIG. 65.—CEMENT MOULDS AND BRIQUETTES.

The form of briquette adopted in the standard German tests differs from the above in having a distinct necking or indentation at the points of least section. The German form applied to briquettes of the American size is used in the cementtesting laboratory of Cornell University.




FIG. 66.—STANDARD GERMAN BRIQUETTE.

This form of briquette is shown in Fig. 66, abcd. The form of the briquette is determined by arcs struck from various centres in order as follows: 0, 1, 2, 3, 4, 5, 6, 7 and 8. The radii of the arcs are as follows:  $0a = 0b = \infty = 0d = 1\frac{1}{2}$ 

inches, 1a = 2b etc.  $= \frac{1}{2}$  inch, 01 = 02 = 1 inch,  $05 = 06 = 1\frac{1}{2}$  inch,  $07 = 08 = \frac{8}{4}$  inch. The distance AB = 1 inch. The angle  $a0b = 60^{\circ}$ .

The enclosing mould E, F, G, H, is in two pieces, EG and HF, and is prevented from moving endwise by the pins shown in dotted lines at C and D. The two parts of the mould are held together when in use by spring clips, not shown in the figure.

- 90. Compression-test Specimens—Test-pieces.—Test-pieces are in all cases to be prepared with the greatest care, to make sure that the end surfaces are true parallel planes normal to the axis of the specimen.
- 1. Short Specimens.—The standard test specimens are to be cylinders two inches in length and one inch in diameter, when ultimate resistance alone is to be determined.
- 2. Long Specimens.—For all other purposes, especially when the elastic resistances are to be ascertained, specimens one inch in diameter and ten or twenty inches long (see No. 2, Fig. 59) are to be used. Standard length on which strain is to be measured is to be eight inches, as in the tension-tests. Greatest care must be taken in all cases to insure square ends, and that the force be applied axially.

The specimens are to be marked and the compression measured as explained for tension-test pieces, page 126.


or. Transverse-test Specimens.—For standard transverse tests, bars one inch square and forty inches long are to be used, the bearing blocks or supports to be exactly thirty-six inches apart, centre to centre. For standard or scientific tests of cast-iron, such bars are to be cut out of a casting at least two inches square or two and a quarter inches in diameter, so as to remove all chilling effect. For routine tests, bars cast one inch square may be used, but all possible precautions must be taken to prevent surface-chilling and porosity.

Test bars of wood are to be forty inches in length, and three inches square, in section.

92. Torsion-test Specimens.—For standard tests, cylindrical specimens with cylindrical concentric shoulders are to be used; the two are connected by large fillets. The specimen

is to be held in the chuck or heads of the machine by three keys, inserted in key-ways } inch deep, cut in the shoulder.

often affords important information regarding the material. The structure of the fractured surface should be described as coarse or fine, either fibrous, granular, or crystalline. Its form, whether plane, convex, or concave, cup-shaped above or below, should in each case be stated. Its location should be accu-



rately given, from marks on the specimen one half inch or less apart. The reduction of diameter which accompanies fracture should be accurately measured. Accompanying the report should be a sketch of the fractured specimen.

Fracture occurs usually as the result of a gradual yielding of the particles of the specimen. This at first, when the stress is well within the elastic limit, is distributed nearly uniformly over the specimen, but after the yield-point is passed the distortion becomes nearly local; a rapid elongation with a corresponding reduction in section is manifest as affecting a small portion of the specimen only. This action in materials with sensible ductility takes place some little time before rupture; in very rigid materials it cannot be perceived at all. This peculiar change in form is spoken of as "necking."

The drawing Fig. 67 shows the appearance of a test specimen in which the "necking" is well developed. Rupture occurs at b-b, a point in the neck which may be near one end of the specimen.

In order to measure the ductility of the specimen fairly, a correction should be applied, so that the reduced elongation shall be the same as though the stretch either side of the point

of rupture were equal. This can only be done by dividing up the original specimen into equal spaces, each of which is marked so that it can be identified after rupture.

Supposing that twenty spaces represent the full length between gauge-marks: then if the rupture be nearest the mark o, Fig. 67, three spaces from the nearest gauge-mark, the total length to compare with the original length is 0 to 3 on the right, plus 0 to 10 on the left, plus the distance 3 to 10 on the left. These spaces are to be measured, and the sum taken as the total length after rupture. The stretch is the difference between this and the original length; the per cent of stretch, or ductility, is the stretch divided by the original length. This method is stated in a general form as follows:

Divide the standard length into m equal parts, and represent the number of these parts in the short portion after rupture by s. Note two points in the long portion, A and B, at s and  $\frac{1}{2}m$  divisions respectively from the break. Lay the parts together, and measure from the gauge-mark in the short portion to point A. This distance increased by double the measured distance from A to B gives the total length after rupture. Subtract the original length to obtain the total elongation: thus the elongation of the standard m parts will be obtained as though the fracture were located at the middle division.

94. Strain-diagrams.—The results of measurements of the strain should be represented graphically by a curve termed a strain-diagram.

Strain-diagrams are drawn (see Art. 46, page 60) by taking the loads per square inch (p) as ordinates, and the relative stretch or strain  $(\epsilon)$  to a suitable scale as abscissæ. The curve so formed will be a straight line from the origin to the elastic limit, and the tangent of the angle that it makes with the axis of  $X(p \div \epsilon = E)$  will be proportional to the modulus of elasticity. The area included between the axis of X and that portion of the curve preceding the elastic limit will represent the Elastic Resilience or work done by the resistance of the material to that point.

Autographic Strain-diagrams are drawn automatically on a revolving drum. In most machines the drum is revolved by the stretch of the material and a pencil is moved parallel to its main axis and proportional to the motion of the weighing poise, although in some devices for drawing autographic diagrams the drum is actuated by the poise motion, the pencil by the stretch. The Olsen autographic apparatus is described in Article 71, Figs. 37 to 39, page 93. This apparatus is very perfect in all its details, and produces a diagram similar to that shown in Fig. 68.

The ordinates on this diagram are proportional to the load, the abscissæ to the strain. The lines are straight and nearly vertical until the yield-point; then for a time the strain rapidly increases, with little increase of stress as shown by the line of stress; this is followed by an increase of both stress and strain, until the point of maximum loading is reached. After passing the elastic limit the strain increases very rapidly, the stress but little.

The autographic attachment is a valuable addition to a testing-machine, especially if its use does not interfere with the measurement by micrometers; but if the scale of the diagram does not exceed five or ten times that of the actual strain, it is of value only in showing the general character of the strain, and is not to be considered of value in obtaining coefficients or moduli within the elastic limit.

#### TENSION . TESTS.

95. Objects of Tension Tests.—Tension tests are considered valuable as affording information of the qualities of material, and a certain tensile strength is required of nearly all materials used, even though in practice they may be subjected to different kinds of strain. The breaking-strength is frequently specified within limits, and is to be accompanied with a certain amount of ductility.

Directions for Tension Tests.—Examine the test-piece care-




FIG. 68.—AUTOGRAPHIC STRAIN-DIAGRAM

fully for any flaw, defect, irregularity, or abnormal appearance, and see that it is of correct form and carefully prepared. Indentations from a hammer often seriously affect the results. In wood specimens, abrasions, slight nicks at the corners, or bruises on the surface will invariably be the cause of failure.

Next, carefully measure the dimensions, record total length, gauge-length (or length on which measurements of strains are made), also form and dimensions of shoulders. Divide the specimen between the gauge-marks into inches and half inches, which may be marked with a special tool, or by rubbing chalk on the specimens and marking each division with a steel scratch.



FIG. 69 - LAYING-OFF GAUGE.

A special gauge as shown in Fig. 69 is convenient for this purpose. These marks serve as reference points in measuring the elongation after rupture, and this elongation should be measured, not from the centre of the specimen, but from the point of rupture either way, as explained in Art. 93, page 123.

See that the testing-machine is level and balanced before each test; insert the specimen in a truly axial position in the machine by measuring carefully its position in two directions, and by applying a level. Calculate from the known coefficients of the material the probable load at elastic limit. Take one tenth of this as the increment of load. The Committee on Standard Tests, American Society of Mechanical Engineers, recommend that the increment be one half or one third that of the probable load at the elastic limit, thus giving larger strains but fewer observations. Apply one increment of load to the specimen before measurements of elongation are made, since by loading specimens up to 1000 or 2000 pounds per square inch the effect of initial errors, such as occur generally at the commencement of each test, are lessened. The auxiliary apparatus

adjusts itself somewhat during this period of loading, and the specimen assumes a true position should any slight irregularity exist.

96. Attachment of Extensometer.—Attach the auxiliary apparatus for measuring stretch, or obtaining autographic diagrams. The method of attaching extensometers will depend on the special form used (see Articles 80 to 86), but this act should always be carefully performed, and the specimen exactly centred in the extensometer, and the gauge-points arranged 8 inches apart. The following directions for applying and using the Henning extensometer will serve to show the method to be used in all cases.

The Henning extensometer (see Article 83, Fig. 50, page 110) is attached and used as follows: Before attaching the instrument, adjust the knife-edges in the clamps by means of the two milled nuts so that they are equally distant from the frame and not so far apart as the diameter of the test-piece. Then, since the springs acting on the knife-edges are of equal strength, the instrument will adjust itself in the plane of the screws symmetrically with respect to the test-piece. Advance or withdraw the set-screws until their points are equally distant from the frame and far enough apart to admit the test-piece.

Separate the upper portion of the instrument, put it around the test-piece (already inserted in the machine) near the upper shoulder, with the smaller part to the right, force together and fasten securely. Advance the set-screws simultaneously until their points indent the test-piece. Separate the lower portion, put it around the test-piece with the vertical scales to the front, force together and secure. Hang the links on the proper bearings on both portions of the instrument. Then advance the set-screws as above. Throw the links out, take readings of the micrometers, apply the first increment of load, and proceed with the test as directed. To read the micrometers make the electrical connections; advance one micrometer until the bell rings announcing contact, back off barely enough to stop ringing, and advance the other until the bell rings. Back off as

before, and read both micrometers. The vertical scale and the micrometer head are graduated so that readings to  $\frac{10000}{1000}$  inch can be obtained directly.

- 07. Tension Test.—The test is made by applying the stress continuously and uniformly without intermission until the instant of rupture, only stopping at intervals long enough to make the desired observations of stretch and change of shape. The stress should at no time be decreased and reapplied in a standard test, but should be maintained continuously. The auxiliary apparatus for measuring strain must be removed before rupture takes place, except it is of a character not likely to be injured. It should usually be taken off very soon after the elastic limit is passed; although for ductile material it may be left in place for a longer time after the elastic limit has been passed than for hard and brittle materials. The material is then to be loaded until fracture takes place. keeping the beam floating, after which the distortion for each part is to be measured by comparison with the reference divisions on the test-piece, measured from the point of rupture as previously explained. It is to be noted that measurements within the elastic limit are of especial importance, since materials in use are not to be strained beyond that point.
- 98. Report.—Remove the fractured piece from the machine; make measurements of shape, external and fractured surface; give time required in making the test.\* When fracture is cupshaped, state the position of cup—whether in upper or lower piece.

In recording the results of tests, loads at elastic limit, at yield-point, maximum, and instant of rupture are all to be noted.

The load at elastic limit is to be that stress which produces a change in the rate of stretch.

The load at yield-point is to be that stress under which the rate of stretch suddenly increases rapidly.

<sup>\*</sup>See Report of Committee on Standard Tests, Vol. XI., Am. Society Mech. Engrs.

The maximum load is to be the highest load carried by the test-piece.

The load at instant of rupture is not the maximum load carried, but a lesser load carried by the specimen at the instant of rupture.

In giving results of tests it is not necessary to give the load per unit section of reduced area, as such figure is of no value; (1) because it is not always possible to obtain the load at instant of rupture; (2) because it is generally impossible to obtain a correct measurement of the area of section after rupture; (3) lastly, because the amount of reduction of area is principally dependent upon local and accidental conditions at the point of rupture. The modulus or coefficient of elasticity is to be deduced from measurements of strain observed between fixed increments of load per unit section; between 2000 pounds per square inch and 12,000 pounds per square inch; or between 1000 pounds per square inch and 11,000 pounds per square inch. With this precaution several sources of error are avoided, and it becomes possible to compare results on the same basis.

In the report describe the testing-machine and method of testing, form and dimensions of specimen, character and position of rupture. Calculate coefficients of elasticity, maximum strength, breaking-strength, strength at elastic limit, and resilience, and submit a complete log of test. Also, draw a strain-diagram on cross-section paper; make a sketch of surface of rupture. The curve of stress and strain is to be drawn as follows: Plot a curve of stress and strain up to a point beyond the elastic limit, using for ordinates values of p, on the scale I div. = 2000 lbs. per sq. in., and for abscissæ values of  $\epsilon$ , on the scale I div. = 0.0001"; compute E and p. Then plot the complete curve of stress and strain to the point of rupture, using scales of I div. = 10,000 lbs. per sq. in., and I div. = 0.01 inch for ordinates and abscissæ, respectively.

A blank form for the log is shown below, which is to be filled out and filed. On this log is to be entered, value of the

modulus of elasticity, load at elastic limit, character of rupture, area of least section, and measurements between each mark made on the specimen.

The following form is used by the author for both tension and compression tests:

Test of	by	 • • • •			 		
Kind of Test	-						
Material from		 • • • •	• • •		 • • • •		
Machine used		 	D	ate.	 		.189
Time of Testingn	nin.	Te	emp	t	 	degr	ees F.

No.	4 L	oad.	Micrometer- readings.				Modulus Elasticity.		
	Actual.	Per sq. in.	1	11	Mean.	Actual,	Difference. Δλ	Per in.	Elasticity.
						}			

Original length in. Diameterin. Areasq. in
Final "in. Diameterin. Area "
Form of section; character; character
Moduli: resilience; breaking-strength
Load per sq. inch: elastic limit max breaking
Equivalent elongation for 8 inchesinchesper cen
Ductility Reduction areaper cent. Local elongation each
half-inch, from top, 1st; 2d; 3d; 4th; 5th
6th; 7th; 8th; 9th; 1oth; 11th; 12th
12th : 14th : 15th : 16th

The following form, from Vol. XI. Trans. American Society Mech. Engineers, is excellent for reporting the principal results of a series of tests. Attention is called to the full descriptions accompanying the report.

REPORT OF TENSION-TESTS FOR THE AMERICAN SOCIETY OF MECHANICAL ENGINEERS,

Testing-machine built by ...... When procured, about 1880. Maximum capacity, 100,000 lbs. How driven, gear-BY C. A. MARSHALL, IN CHARGE OF TESTING LABORATORY OF CAMBRIA IRON Co., JOHNSTOWN, PA. ing drives nut on screw of lower head. Position of specimen (horizontal or vertical), vertical.

		Remarkt.	Tested on Emery 300,- 000-lb, machine.	Fracture, silky fibrous. See detail sheet.	Fracture, silky fibrous, See detail sheet,	Fracture, # cup. Fine silky. See detail sheet	Silky edges, dull, with specks crystalline. See detail sheet.	Full cup, fine silky. See detail sheet.
92		Duration of test.		52 min.	30 min.	29 min.	34 min.	30 min.
1.5	<u>#</u>	At time of rup- ture.			34580 28000	32800 25000	28000	36250 25300
7	Stress in 1be.	Maximum ob- served.		34035	34580	33800	35600	
ž.	Str	At elastic limit.		25960	25960	250go	28288	30800
22	-aeri io bas se	Distance of point of ture from neare of specimen.		4" from 8" mark.	Outside marks.	4" from 8" mark.	i"outside 8" mark.	Exactlyat 8" mark.
H	ıţıeı	Minimum section s fracture.	ij	o. 555 diam.		0.488 diam.	0.53r diam.	0.478 diam.
0	r cjss-	Minimum section s		:	i	•	:	
6		After rupture.	.e	8.87	89. 27.	9.03	80 82	86.58
•	Length between gauge-marks.	At elastic limit while under strain.	in.	8.008.017425	8.008.017300	8.01 8.026600	028275	8.00 8.019600
~	2 2	When starting test,	ig ·	8	8	2	80 10	8
•	rips or	Length between grafting	. <u>e</u> i	•	•	0	9	•
80	Dimensions be- fore test.	Section.	ë	.748 diam.	.748 diam.	.749 ( mean .748 ) .7485	.752 \ .750	.749 } = .748
+	ä	Total length.	] <u>.</u> g :	17	17	17	-	17
m		Form of specimen.		4" Rd. Straight.	¿" Rd. Straight.	t" Rd. Straight.	t" Rd. Straight.	t" Rd. Straight.
"		Kind of material.		Cold Rolled Iron.	Cold Rolled Iron.	Cold Rolled Steel.		Rolled Steel.
-	cimen.	No. or mark of spe	Iron, 2394	Iron, 2395	Iron, 2396	Steel, 2397	Steel,	Steel, *399

Prof. G. Lanza of the Massachusetts Institute of Technology uses the following forms for log and report of tensiontests:

## TENSION-TEST.

		• • • • • • • • •								
•		• • • • • • • • •								
Ler	igth betw	veen clamp	s	• • • • •	• • • • •	. Т	ested by	· · · · · · · ·	• • • • • • • • •	• • • • • • • • •
Ori	ginal sec	tion	• • • •	• • • • •		• • • • •	• • • • • •	· • • • • • • •	• • • • • • • • •	• • • • • • • • • • • • • • • • • • • •
					•					
	ļ ,	oads.	Min	romete			<u> </u>	Die	rences.	i i
		oads.	DA ICI	ТОШЕСЕ	r-read	ngs.	Mean.	Diffe	rences.	Remarks.
	Actual.	Per sq. in.	ı	2	1	2		Actual.	Per inch.	
				-		1—				
	ļ					l				
	<u> </u>	<u></u>			<u>.                                    </u>	<u> </u>	<u> </u>	·		<del></del>
		ection								
Rec	luction o	f area of cr	055-56	ection		• • •	Modul	is of elas	sticity	. <b></b> .
Ult	imate ex	tension		• • • • •	Mo	dulus	of elas	tic resilie	ence	
Cro	ss-sectio	n at maxir	num	load.		1	Modulus	s of ultin	nate resilie	nce
Ter	sile limi	it per sq. ir	ı			• • • • •			• • • • • • • • • •	
		-								
					REI	POR	r.			
No.			• • • •				Date			. <b></b>
•		veen clamp								
		tion,								<b></b>
•	•	t,								
		ad,								
	•	ection, .								• • • • • • • • • • • • • • • • • • •
		of area of c								
		tension, .								• • • • • • • • • •
		ress per sq		IUCU I	ractu					• • • • • • • • • •
Mo	aulus of	elasticity,	• •	• •	• •					• • • • • • • • • •
				Si	gned.	• • • •	• • • • • • •	•••••	• • • • • • • •	••••••

## COMPRESSION-TESTS.

00. Methods of Testing by Compression, I. Short Pieces: Method of Testing.-In case of short pieces, measurements of strain cannot be made on the test-piece itself, but must be made between points on the heads of the testingmachine. It is necessary to ascertain and make a correction for the error due to the yielding of the parts of the testing-This is done as follows: Lower the moving-head until the steel compression-plate presses on the steel block in the lower platform with a force of about 500 pounds. the micrometers to the special frame, which is supported by the upper platform, and read to a point on the movable head. With load at 500 pounds, read both micrometers. Apply loads by increments of 1000 pounds up to three fourths the limit of the machine, taking corresponding readings. Plot a curve of loads and deflections with ordinates I long division = 1000 pounds, and abscissæ I long division = 0.001 inch. this curve obtain corrections for the deflections caused by the loads used in the compression-test. In making the test calculate the increment of load as explained for tensile strain, Article 98. Conduct the experiment in the same manner as for tension, except that the stress is applied to compress instead of to stretch the specimen. If the material tested is hard or brittle, as in cast-iron, care should be taken to protect the person from the pieces which sometimes fly at rupture.

Report and draw curve as for tension-tests, and in addition show why brittle material breaks in planes, making angles of about 45° with the axis of the piece; compare the results obtained for wrought iron in compression with those obtained in tension.

2. Long Pieces: Method of Testing.—In this case the extensometers used for tension-tests can be connected directly to the specimen, and the measurements taken in substantially the same way, except that the heads of the extensometer will approach instead of recede from each other; this makes it

necessary to run the screws back each time after taking a measurement a distance greater than the compression caused by the increment of load. In case large specimens are tested horizontally, initial flexion is to be avoided by counterweighting the mass of the test-piece.

Calculate the increment of load as one tenth the breaking-load given by Rankine's formula, Article 51, page 64. Apply the first increment and take initial reading of micrometers; continue this until after the elastic limit has been passed, after which remove the extensometer, and apply load until rupture takes place. Protect yourself from injury by flying pieces. Compute the breaking coefficient C by Rankine's formula, and compare with the usual results.

Compute the modulus of elasticity by Euler's formula:

(1) 
$$P_0^{\prime\prime\prime} = EI\pi^2 \div l^{\prime\prime 2}$$
 (Church, "Mechanics of Materials," p. 366).

(2) 
$$E = l''^2 P_0'' \div \pi^2 I$$
.  $l'' = l - \lambda''$ . (3)  $E = (l - \lambda'')^2 P' \div \pi^2 I$ .

Also by the method used in testing short specimens.

In the above approximate formula the notation is the same as in Article 48, page 62.

Note in the report, load at elastic limit, yield-point, and ultimate resistance, as well as increase of section at various points, and total compression calculated as explained for tension.


Submit a strain-diagram, and follow the same general directions as prescribed in the report for tensile strain, Article 98.

#### TRANSVERSE TESTS.

100. Object.—This test is especially valuable for full-sized pieces tested with the load they will be required to carry in actual practice.

The deflections of such pieces, with loads at centre or in various other positions, afford means of computing the coefficients of elasticity and the form of the elastic curve.

Method of Testing .- Arrange the machines for such tests



by putting in the supporting abutments, and by arranging the head for such tests, or else by using the special transverse testing-machine.

In this experiment the test-piece is usually a prismatic beam, 3 feet long (see Article 91, page 121), and it is supported at both ends, the stress being applied at the centre. The same data are required to be observed as in the preceding experiment, viz., loads and deflections, or stresses and corresponding strains.

Sharp edges on all bearing-pieces are to be avoided, and the use of rolling bearings which move accurately with the angular deflections of the ends of the bars are recommended; otherwise the distance between fixed supports measured along the axis of the specimen is continually changing.

Place the test-bar upon the supports, and adjust the latter 36 inches apart between centres, and so that the load will be applied exactly at the middle. Obtain the necessary dimensions, and calculate the probable strength at elastic limit and at rupture by means of the formula  $p = Wle \div 4I$ . (See Article 52, page 66.) Adjust the specimen in the machine in a horizontal plane, and apply the stress at the centre normal to the axis of the specimen, and in a plane passing through the three points of resistance.

Measure the deflections at the centre from a fixed plane or base, allowing for the settling of the supports, or by the special deflectometer (see Article 87, page 114), from which compute the coefficient of resilience and the modulus of elasticity.

Balance the scale-beam with the test-bar in position and the deflectometer lying on the platform. Set the poise for one increment of load and apply stress until the beam tips. Place the poise at zero, and balance by gradually removing the load. Place the deflectometer in position on the supports, and with the micrometer at zero make contact and record zero-reading and zero-load.

Apply the load in uniform increments equal to about one fifth the calculated load for the elastic limit, stopping only

long enough to measure the deflections. Wrought-iron is to be strained only until it has a sensible permanent set, but castiron and wood are to be tested to rupture. Wood specimens generally rupture on one side only: in that case turn over and make complete test as in the first instance.

ioi. Form of Report.—In the report describe the machine, method of making test, form of cross-section, peculiarities of the section, and make a sketch showing position and form of rupture. Submit a complete log of the test, together with drawing of the elastic curve, to be filed for permanent record. The following is a form for data and results of a transverse test:

DATA OF TRANSVERSE TEST OF.....

F of		• • • • • • • • • • • • • • • • • • • •		
		ios		
		••••••••		nachine
	hrs			nacimilo.
Date		Observ	ers: {	•••••••
	Load	Deflec	tion.	D
No.	W.	Reading.	Net.	Remarks.
	REPOR	T OF TRANSV	ERSE TEST.	
Material		• • • • • • • • • • • • • • • • • • • •	Wt. per cu.	ftlbs.
Form	••••••			
Composition.		Sp	ecific Gravity.	• • • • • • • • • • • • • • • • • • • •
Load Applied	1	• • • • • • • • • • • • • • • • • • • •		
l'esting-mach	ine		••••	
	hrs			
Date	••••••	,189 . Observ	/ers: { · · · · · ·	

	Dime	nsions.		Sy	mbol.				
Diame: Breadt Height Max. fi	bre distance		••••	••••	. in. . in. . in. . in.	•	l D b k e		
	Load.			Actua	al.	Reduce in Ou	1 per sq. in. ter Fibre.		
	limit um								
	Defle	ction.							
Elastic Maxim	limit	••••	••••	• • • • •	••••			Fracture	cture.
	us of elasticity us of resilienc ks:							Description of Fracture.	Sketch of Fracture.
	he followin of the Instit test:								
					LOG	<b>.</b>			
Specim	en				· <b>· · · ·</b>	· · · · · · · · •			
	n of load						Wt. of	yoke,	etc
							• • • • • • • • • • • • • • • • • • • •	• • • • •	
	Loads.	Micr	omete	r-read	lin <b>gs</b> .				
		1	3	1	2	Mean,	Differences	F	lemarks.
Modul	us of elasticity						<del>'</del>	_ <u> </u>	
	us of rupture (								
	um intensity								

## REPORT.

No					•	-	D	ate	<i>.</i>	•••		• • •	•••	• • •	• •	• •	•	• •	٠.	•	•	٠.,	••	
Specimen	•••	•••	•••		• • •		•••	•••			•••	•••	• •											
Span,																								
Dimensions, .	•	•			•	•	٠.			•	•	•	•	•										
Weight of beam,							•				•	٠.	•		•									٠.
Weight of yoke,	etc	٠,												•				••				• • •		
Deflection, .																				٠.		• • •		
Modulus of elast	icit	у, .		•				٠.	•	÷												• • •		
Modulus of rupti	ure	(in	clu	ding	y w	eig	bt (	of t	ea:	m),							•					• • •		
Maximum intens	sity	of	lor	gitt	ıdiı	nal	sh	ear,			٠.							٠.				• • •		
					'C:~		41																	

102. Elastic Curve.—The object of this experiment is to determine the coefficient and moduli of the material, by loads less than that required at the elastic limit. The required general formulæ are to be found in Art. 52, page 67. A table of deflections corresponding to various centre loads is to be found on page 69. The beam is to be supported at both ends on rounded supports or on rollers. The loads consist of weights of known amount that can be suspended at various points.

Apparatus needed.—Cathetometer or other suitable instrument for measuring deflection.

Directions.—Obtain dimensions of beam, compute moment of inertia of cross-section; note material of beam, and compute probable deflection and corresponding load at elastic limit.

Carefully divide the length of the beam into equal parts, and mark these divisions on the centre-line of the beam. With no load on the beam, take cathetometer-readings of each point, then apply successive increment of loads, each equal to one fifth the probable load at the elastic limit, and take corresponding readings of the cathetometer. From readings, obtain the deflections for each point, and plot the elastic curve. Compute the deflections for the corresponding points from the formula, using tabulated values of E, and plot the corresponding theoretical curve. Make deductions concerning the relation of the two curves.

The above experiment is to be performed with the load at center, and again with the load at a point one fourth or one third the length of the beam.

Similar experiments may be performed on beams fixed at one end, or fixed at one end and supported at the other.

## TORSION-TEST.

103. Object.—The object of this experiment is to find the strength of the material to resist twisting forces, to find its general properties, and its moduli of rigidity and shearing-strength.


Thurston's Machine.—The special directions apply only to Thurston's torsion-machine (see Article 73, Figs. 40 and 41, page 96). In the use of the machine the constants are first obtained, the test-piece inserted between the jaws of the machine, stress applied, and the autographic strain-diagram obtained. This diagram is on a large scale, and gives quite accurate measures of the stresses or loads. The diagram is, however, drawn by attachment to the working parts of the frame, and consequently any yielding of the frame or slipping of the jaws appears on the diagram as a strain or yield of the specimen. The angular deformation  $\alpha$ , as obtained from the diagram, is likely to be too great, especially within the elastic limit. This error should be determined in each test by attaching index arms at each end of the specimen, and corrections made to the results obtained from the diagram.

The characteristic form of diagram given by the torsion-machine is shown in Fig. 70, in which the results of tests of several materials is shown. In the above diagrams \* the ordinates are moments of torsion  $(P\alpha)$ , the abscissæ are developments of the angle of torsion  $(\alpha)$ . The value of one inch of ordinate is to be found by measuring the ordinate corresponding to a known moment of torsion, and the abscissa corre-

<sup>\*</sup>See "Mechanics of Materials," page 240, by I. P. Church. Published by Wiley & Son. N. Y.

sponding to one degree of torsion is to be calculated from the known radius of the drum. Knowing these constants, numerical values can readily be obtained, and the coefficients of the strength of the material can be computed.

During the test, relax the strain occasionally: if within the elastic limit, the diagram will be retraced; but if beyond that



limit, a new path is taken, called an "elasticity" line by Thurston, which is in general parallel to the first part of the line, and shows the amount of angular recovery BC, and the permanent angular set OB.

# 104. Methods of Testing by Torsion with Thurston's Autographic Testing-machine. (See Articles 55 and 73.)

Method.—Determine first the maximum moment of the pendulum. This may be done by swinging the pendulum so that its centre-line is horizontal, supporting it on platform-scales and taking the weight and the distance of the point of support from the centre of suspension of the pendulum. The product of these two quantities is the maximum moment of the pendulum. Make three determinations, using different lever-arms, and take the mean for the true moment of the pendulum. A correction for the friction of the journal of the pendulum must be made. When hanging vertically, measure with a spring-balance, inserted in the eye near the bob, the force necessary to start the pendulum. Add this moment to that obtained above, and the result is the total maximum moment of the pendulum. From this the value of the moment for any angular position may be calculated.

RECORD OF TORSION-TESTS.

Testing-machine.....Thurston's Autographic.
Date.....May 25, 1891.

Dimensions of Test-piece..... Length one inch.

 $U = \frac{4P\alpha\alpha}{4P\alpha\alpha}$ Elastic Resilience. Inch-pounds. 35.6 27 28 Observer.....H. H. Wood. Modulus of Rigidity. Pounds. 13 056 000 11 720 000 000 068 6  $E_s = \frac{ip}{\alpha e^s}$ 3 54 740 109 496 80 878 Maxi-mum. Shearing-stress. Pounds. A Pa -=d (z) 47 270 Elastic Limit. 21 484 3019 .3697 .8676 Final. .056 Extension of Outer Fibre,  $\lambda = \left[ \sqrt{1 + \alpha^2 c^2} \right] - \mathbf{I}$ .0514 9298. .3697 Maxi-mum. Elastic Limit. .00013 9000 .00021 ٦ لا 62° 36′ Final. 300° **3**0° Angle of Torsion. Degrees. Maxi-mum.  $\alpha_{M}$ ွိ 30° Ş Elastic Limit. z'a <u>,</u>6 <u>,£</u> Maxi-mum. Pa<sub>M</sub> 2100 2604 5124 Moment of Torsion. Inch-pounds. Elastic Limit. 787 2212 1022 Dia.=0.6206, \ Bessemer steel, \ Dia. = 0.5025. Dia. =0.6233. Wrought-iron, Material. Tool steel,

Ip is the polar moment of inertia, and equals  $\frac{\pi \mathcal{C}}{2}$  for circular section. Weight, 147 lbs. Corresponding distance, 40.8 inches. Friction-pendulum, 1 pound. In formulæ (2), (3), and (4) use Pa in inch-pounds. In (1), (3), and (4) use  $\alpha$  in  $\pi$ -measure.

Value of 1° in \(\pi\)-measure is 0.01745. \(\epsilon\) = radius of specimen. Maximum moment, 5997.2 inch-pounds. Friction-moment,

Total moment, 6038.4 inch-pounds. Corresponding ordinate, 4.32 inches. Value 1 inch of ordinate, 140 inch-pounds. Value of 1 inch of abscissa, 10°, 40.8 inch-pounds.

Note the variation of the pencil-point between the vertical and the horizontal positions of the pendulum. This distance laid down on the Y-axis of the record-sheet corresponds to the maximum moment obtained above, whence calculate the value of one inch of ordinate. Calculate the length corresponding to one degree on the surface of the paper drum, parallel to the X-axis. This will be the unit to be used in calculating the angle of torsion. Fix the paper on the drum and draw the datum-line or X-axis. Insert the test-piece between the centres and screw in the centre until the neck of the test-piece is about midway between the jaws. Wedge the testpiece between the jaws as firmly as possible by hand, and then tap the wedges slightly with a copper hammer. Fasten an index-arm to each end of the specimen in such a manner that twisting or slipping of the specimen can be observed by reference to the centre of the pendulum on one end, and to a fixed point on the drum on the opposite end. Throw the worm into gear and turn the handle slowly and steadily until rupture occurs, only relaxing the stress once or twice during the test. Take the record of all the test-pieces on the same sheet with the same origin of co-ordinates.

Correct each diagram for amount of slipping of test-piece or yielding of frame by reference to index-arms carried by the test specimen.

The record of torsion-tests, page 142, is a numerical example, obtained from diagrams similar to those shown in Fig. 70.

# IMPACT TESTS.

105. Directions for Testing Cast-iron by Impact with Heisler's Impact Testing-machine. (See Article 76, p. 100.)

Method.—Take a transverse test-bar of cast-iron and place it in the machine, cope side out, so that the blow will be struck in the middle of its length. Arrange the autographic device so that it will register the deflection of the bar. Place the tripping device or "dog" for a fall of two inches. Catch the bob at this point, and trip at every notch above successively until the bar breaks. Note the maximum height of fall. Report on the experiment the behavior of the test-bar and character of its fracture, and the number of impacts and the force in inch-pounds of the last blow. Compute the resilience of the test-piece. Try a similar bar at same ultimate fall, and observe the number of blows required to break it. Draw conclusions. Write complete report, and give moduli and coefficients.

106. Drop-tests.—The following method of making droptests has been recommended by the Committee on Standard Methods of Testing appointed by the American Society of Mechanical Engineers, and is substantially the same as adopted by the German Engineers at Munich in 1888:

*Drop-tests* are to be made on a *standard drop*, which is to embody the following essential points:

- a. Each drop-test apparatus must be standardized.
- b. The ball (falling mass) shall weigh 1000 or 1500 pounds; the smaller is, however, preferable.
- c. The ball may be made of cast-iron, cast or wrought steel; the shape is to be such that its centre of gravity be as low as possible.
- d. The striking-block is to be made of forged steel, and is to be secured to the ball by dovetail and wedges in a rigid manner, and so that the striking-face is placed strictly symmetrical about and normal to its vertical axis passing through the centre of gravity. Special permanent marks are to indicate the correctness of the face in these respects.

Special marks should be made to indicate the centre of the anvil-block.

- e. The length of guides on the ball should be more than twice the width between the guides, which are to be made of metal; i.e., rails so placed that the ball has but a minimum amount of play between them. Graphite is recommended as lubricant.
- f. The detachment or shears must not cause the ball to oscillate between the guides, and must be readily and freely controllable, with the point of suspension truly above the

centre of gravity of the ball; and a short movable link, chain, or rope is to be fixed between the ball and shears or detachment.

- g. When a constant height of drop is used, an automatic detaching device is recommended.
- h. The bearings for the test-piece are to be rigidly attached to the scaffold or frame, and they should be, wherever possible, in one piece with it.
- i. The weight of frame, bearings, and anvil-block should be at least ten times that of the ball.
- k. The foundation should be inelastic, and consist of masonry, the magnitude of which is to be determined by the locality and subsoil.
- 1. The surface struck should always be accurately level; therefore proper shoes or bearing-blocks are to be provided for testing rails, axles, tires, springs, etc., etc., to insure a proper level upper surface; these blocks are to be as light as possible.

The exact shape of these bearing-blocks is to be given on each test report.

- m. The gallows or frame should be truly vertical and the guides accurately parallel.
- n. The height of fall of ball should be 20 feet clear, between striking and struck surfaces.
- o. Drops which by friction of ball on guides absorb two per cent of the work due to impact are to be discarded.
- p. For large tests a ball weighing 2000 pounds is to be used.
- q. A sliding-scale is to be attached to the frame, and in such a manner that the zero-mark can always be placed on a level with the top of the test-piece.

## SPECIAL TESTS OF MATERIALS.

107. The following comparative tests are often useful:

1. The Welding-test.—This is to be done with a hammer weighing eight to ten pounds, with a given number of blows.

The weld is to be a simple scarf weld, made in a coke or gas flame without fluxes. Each bar to be tested to be treated in the same way, using in each case two or three samples of iron; one sample to be tested on the tension-machine, the other to be nicked to the depth of the weld and then bent or broken, to show the character of the welded surfaces.

- 2. The Bending-test.—This affords a ready means of finding the ductility of metals. The test-piece is to be bent about a stud having a diameter twice that of the specimen. The piece is to be bent with a lever, and no pounding is permitted. If the plate holding the stud is graduated, the angular deflection at time of permanent set may be read at once. A modification of the bending-test is often used to determine the property of toughness, by bending the specimen, first hot and then cold, until it is doubled over on itself.
- 3. The Hardening-test is used in connection with the other tests to determine the qualities of the specimen; the material, one specimen of which, having been previously welded, is carefully heated to a red heat, and plunged in water having a temperature of 32-40 degrees. This specimen is tested by torsion and bending, the same as the unhardened specimen.
- 4. The Forging-test.—The material is brought to a red heat and hammered until cracks begin to show, the relative amount of flattening indicating the red-shortness of the material. Useful principally with rivet-rods.
- 5. Punching-tests.—Find the least material that will stand between the edge and the hole punched, by measurement.
- 6. Abrasion-tests.—Find the amount of wear from a given amount of work.
- 7. Hammer-test.—This is made with a light hammer, and the character of the material is determined by the sound emitted. Is useful in locating defects in finished products, but of little value on test specimens.

Fatigue of Metals, or the effect of repeated stresses, is a matter of great practical importance, and was investigated very extensively by Wöhler. These results are discussed in full in a work by Weyrauch. It is well established that the

breaking-point is lowered by a large number of applications of stress. The proportional loads for wrought-iron, according to Wöhler, being as follows: Breaking-load applied once, 4; tension alternating with no stress, 2; tension alternating with compression, I.

Rest of materials or removal of stress in some instances seems to restore both strength and elasticity.

Viscosity or the fluidity of metals under certain conditions is also well established.

The effect of temperature on the strength of metals has not been thoroughly investigated. The investigations at the Watertown Arsenal show that steel and wrought-iron bars increase slightly in tensile strength as the temperature increases to 600° F., and then decrease in proportion to increase of temperature, so that the breaking coefficients at 1600° F. lie between 10,000 and 20,000 pounds. See U. S. Report, Test of Metals, 1888.

108. Tests required for Different Material.—In general the material is to be tested in such a manner as to develop the same strains that will be called forth in the peculiar use to which it is devoted.

The table, page 148, shows the tests that are prescribed for materials for various uses, by the Committee on Standard Tests and Methods of Testing of the American Society of Mechanical Engineers.

Pipes and Pipe-fittings.—These should be subject to an internal hydraulic pressure.

Car-wheels.—Car-wheels are usually subjected to the droptest. The following method is employed by the Pennsylvania Railroad Company for testing cast-iron wheels:

For each fifty wheels which have been shipped, or are ready to ship, one wheel is taken at random by the railroad company's inspector, either at the railroad company's shops or at the wheel-manufacturer's, as the case may be, and subjected to the following test: The wheel is placed flange downward on an anvil-block weighing 1700 pounds, set on rubble masonry two feet down, and having three supports not more than five

## TABLE SHOWING TESTS REQUIRED.

Required Test denoted by x.

Material used for	Tension.	Compression.	Transverse.	Torsion.	Impact.	Welding.	Bending.	Hardening.	Forging.	Abrasion.	Punching.
Railroad rails	x				x		x				
" car-axles	x				x		x				٠.,
" " tires	x	· • • •			x						
Shafting	x		x	x							
Building-wrought-iron	x	x	x			x	x				
" low steel	x	x	x				x	x			
'' high steel	x	x	x				x	x			
Boiler-wrought-iron											
" plates	x		x				x		2		x
" shape-iron	x					$\mathbf{x}$	x		x		x
" rivet-rods	x	l	l. <b></b> .				x		x		
" low steels	x		١ ا				x	x	x		
A											
" plates	x						x				
" rivets	x						x		x		
Wire	x						*				
Wire rope	x				2+				•••		• • •
Cast-iron	x	x		'		'	x				
Copper and soft metals	x	x					$\bar{x}$				• • •
Woods	x	*	x								
Stones	. ~	*	x								• • •

<sup>\*</sup> Repeat in both directions-also by winding. 
† Longitudinal.

inches wide for the wheel to rest upon. This arrangement being effected, the wheel is struck centrally on the hub by a weight of 140 pounds, falling from a height of twelve feet. Should the wheel break in two or more pieces before nine blows or less, the fifty wheels represented by it are rejected. If the wheel stands eight blows without breaking in two or more pieces, the fifty wheels are accepted.

109. Methods of Testing Bridge-materials.—The following directions are abstracted from the standard specifications adopted by bridge-builders.\*

Wrought-iron. 1. Appearance.—All wrought-iron must be tough, ductile, fibrous, and of uniform quality for each class;

<sup>\*</sup> See Handbook published by Carnegie, Phipps & Co., Pittsburg.

straight, smooth, free from cinder pockets or injurious flaws, buckles, blisters, or cracks. When rolls are working at maximum thickness, poorer finish will be accepted.

- 2. Manufacture.—No special process of manufacture required.
- 3. Standard Test-piece.—The tensile strength, limit of elasticity and ductility shall be determined from a standard test-piece, not less than one quarter-inch in thickness, cut from a full-sized bar, and planed or turned parallel; if the cross-section is reduced, the tangent between shoulders shall be at least twelve times its shortest dimensions, and the minimum area of cross-section shall not be less than one fourth square inch in area and not more than one square inch. Whenever practicable, two opposite sides of the piece are to be left as they come from the rolls. A full-sized bar if less than the required dimensions may be used as its own test-piece.

The ductility, or per cent of strain, is obtained by measuring the elongation after breaking from the point of rupture both ways, on an original length, ten times the least cross-section, or at least five inches long.

In this length must occur the curve of reduction of area.

4. Strength.—The strength of the specimens to be a function of the size, and to be determined by the formulæ in the following table:

STRENGTH CT IRON REQUIRED FOR BRIDGE-BUILDING.

Character of the Iron.	Formulæ for Ulti- mate Strength. Pounds per sq. in. T	Strength at Elastic Limit. Per cent of Breaking.	Elongation at Rupture, Per cent.
Tension-iron, pins and bolts, and } plate-iron less than 8 inches wide. }	52000 7000A	50	20
Plate-iron 8 to 24 inches wide	48000	54.2	12
" 24 to 36 " "	46000	51.5	10
" 36 to 48 " "		"	5
" less than § inch thick	$50000 - \frac{7000A}{B}$	50	15
over <b>4</b> inch thick	"	66	12

In above formulæ A represents area in square inches, B circumference in inches.

- 5. Hot-bending.—All plates and angles must stand at a working heat a sharp bend at right angles without sign of fracture.
- 6. Rivet-iron.—Rivet-iron must be tough and soft, and capable of bending cold until the sides are in close contact.
- 7. Cold-bending.—All tension-iron pins, bolts, and plate less than 8 inches wide, must bend cold 180°, to a curve whose inner radius equals the thickness, without sign of fracture.
- 8. Specimens of full thickness, from plate-iron or from flanges or webs of shaped iron, must bend cold through 90° to a curve whose inner radius is 1½ times its thickness.
- 9. Number of Test-pieces.—Four standard test-pieces to be tested free of cost on each contract, with one additional for each 50,000 pounds of iron, and as many more as the contractor will pay for at \$5 each. If any test-piece gives results more than 4 per cent below the requirements, the particular bar from which it was taken may be rejected, but the results shall be included in the average. If any test-piece have a manifest flaw, its test shall not be considered. Two test-bars out of ten falling more than 4 per cent below the requirements shall be a cause for rejecting the whole lot from which they were taken as a sample.

A variation of more than 2½ per cent of weight will also be a cause for rejection.

Steel.—The requirements as for manufacture, finish, number of test-pieces and method of testing as for iron.

- I. Test-pieces.—Round test-pieces are to be obtained from three separate ingots of each cast, not less than three quarters of an inch in diameter and of a length not less than eight inches between the jaws of the testing-machine. These bars are to be truly rounded, finished at a uniform heat, and arranged to cool uniformly, and from these test-pieces alone the quality of the material shall be determined.
- 2. Strength.—All the above-described bars are to have a tensile strength, not less than 4000 pounds of that specified, an

elastic limit not less than one half the tensile strength of the test-bar, a percentage of elongation not less than 1,200,000, divided by the tensile strength in pounds per square inch; and a percentage of reduction of area not less than 2,400,000 divided by the tensile strength in pounds per square inch. The elongation should be measured after breaking on a specimen, with length at least ten times the least diameter of the cross-section, in which length must occur the entire curve of reduction from stretch.

Directions for testing and rejecting specimens same as for iron.

3. Rivet-steel.—The required strength is 60,000 pounds tensile strength, with elastic limit, elongation, and fracture as in clause 2. To be rejected if under 56,000 pounds, and to stand the same bending-test as rivet-iron.

Cast-iron.—All castings, except where chilled iron is specified, shall be tough gray iron, free from cold-shuts or blow-holes, true to pattern and of workmanlike finish. Sample pieces I inch square, cast from the same heat of metal in sand-moulds, shall sustain on a clear space of 4 feet 6 inches a central load of 500 pounds.

Workmanship.—Workmanship must be first-class; finished surfaces protected by white-lead and tallow; rivet-holes accurately spaced, and truly opposite before the rivets are driven.

Rivets must completely fill the holes, and be of a height not less than 0.6 diameter of the rivet.

Eye-bars and Pin-holes.—Pin-holes must be accurately bored, and within  $\frac{1}{82}$  inch of position shown on drawing; its diameter not to exceed that of the pin by 0.02 inch if under  $3\frac{1}{2}$  inches, or by 0.03 inch if over  $3\frac{1}{2}$  inches.

Eye-bars must be straight, with holes in centre-line and in centre of head, and no welds in the body of the bar. All chord eye-bars from the same panel must permit pins to be easily inserted when placed in a pile.

Tests of Eye-bars.—Tests are to be made on full-size

specimens, rolled at the same time as those required for the structure.

The lot to which the sample test-bars belong shall be accepted when—

- a. Not more than one third the bars tested, break in the eye.
- b. Or if more than one third break in the eye, the tensile strength is within 5 per cent required by the formula,

$$T = 52000 - \frac{7000A}{B} - 500$$
 (width of bar); all in inches.

Steel bars must show a strength within 4000 pounds of that required in clause 13.

A variation in thickness of heads will be allowed, not exceeding  $\frac{1}{32}$  inch small, or  $\frac{1}{16}$  inch large, from the specifications.

Annealing.—If a steel piece is partially heated during the progress of the work, the whole piece must be subsequently annealed. All bends in steel must be made cold, or the piece must be subsequently annealed.

110. Admiralty Tests.

## Tests for Iron Plate.

Hot, to bend without fracture from 90° to 125°. Cold, to bend without fracture to the following angles:

1-inch plate...lengthwise 10° to 15°, crosswise 5°

<u>8</u> − "	"	"	20° to 25°,	"	5° to 10°
1/2- "	"	"	30° to 35°,	66	10° to 15°
<del>1</del> - "	"	66	55° to 70°,	"	20° to 30°

## Tests for Plate Steel.\*

1. Strength.—Strips cut lengthwise or crosswise of the plate to have an ultimate tensile strength of not less than 26 and not exceeding 30 tons per square inch of section, with an elongation of 20 per cent in a length of 8 inches.

<sup>\*</sup> See "Manual of the Steam-engine," Vol. II., page 488, by R. H. Thurston.

- 2. Temper.—Strips cut lengthwise of the plate 1½ inches wide, heated uniformly to a low cherry-red and cooled in water of 82° F., must stand bending in a press to a curve of which the inner radius is one and a half times the thickness of the plates tested.
- 3. The strips are to be cut in a planing-machine, and have sharp edges removed.
- 4. The ductility of every plate is to be tested by the application of the shearing or bending tests on the contractor's premises and at his expense. The plates are to be bent cold with the hammer.
- 5. All plates to be free from lamination and injurious surface defects.
- 6. One plate out of every fifty or fraction thereof to be taken for testing by tensile and tempering test from every invoice.
- 7. The pieces cut out for testing are to be of parallel width from end to end, or for at least 8 inches in length. A latitude or variation in thickness will be permitted of 10 per cent for plates less than one half-inch thick, and of 5 per cent for plates over that thickness.

# Tests for Angle, Bulb, or Bar Steel.

- 1, 2. Strength and Temper.—The requirements the same as for plate steel.
- 3. Number of Tests.—Cross ends to be cut off, and one piece for each fifty or fraction thereof to be tested in each invoice.
- 111. Lloyd's Tests for Steel used in Ship-building.\*

  1. Strength.—Strips cut lengthwise or crosswise of the plate, and also angle and bulb steel, to have an ultimate tensile strength of not less than 27 and not exceeding 31 tons per square inch of section, with an elongation corresponding to 20 per cent on a length of 8 inches before fracture.
  - 2. Temper. -Tempering test the same as the Admiralty

<sup>\*</sup>See Thurston's "Steam-engine," Vol. II.

test, except that inner radius of bend is three times the thickness.

Rivets to be same size as required for iron.

- 112. Standard Specifications for Cast-iron Water-pipe Adopted by the American Water-works Association, Philadelphia, 1891. (Abstract from Transactions.)
- I. Length.—Each pipe shall be of the kind known as "socket and spigot," and shall be 12 feet long from bottom of the socket to the end of the pipe.
- 2-7. Metal.—The metal shall be best quality neutral pigiron, with no admixture of cinder, cast in dry-sand moulds, placed vertically, numbered and marked with name of maker and date of making. The shell to be smooth and round, without imperfections, and of uniform thickness.
- 8-10. Test-bars.—Test-bars to be 26 inches long, 2 inches wide, and 1 inch thick, and to be tested for transverse strength. These bars shall stand, when carried flatwise on supports 24 inches apart, a centre load of 1900 lbs., and show a deflection of not less than 0.25 inch before breaking. Test-bars are to be cast when required by the inspector, and to be as nearly as possible the specified dimensions.
- 12-16. All pipes to be thoroughly cooled when taken from the pit, afterward thoroughly cleaned without the use of acid, then heated to 300° F., and plunged into coal-pitch varnish. When removed, the coating to fume freely and set hard within an hour.
- 17. Testing.—The pipes to be tested after the varnish hardens with hydrostatic pressure of 300 lbs. per square inch for all sizes below 12 inches diameter, and 250 lbs. for all above that diameter, and simultaneously to be struck with a 3-lb. hammer.
- 18-20. Templates to be furnished by the maker; the weight of pipe to vary not over 3 per cent from the standard; all tests to be made at expense of maker.
- 113. Tests of Stone, Brick, Cements.—These materials are principally used in walls of buildings and for foundations. For this use they are subjected principally to compression

or crushing stresses. The important properties are strength and durability. Stone is usually tested for compressive and transverse strength, brick for compressive strength, and cement and mortar for tension.

strength are cubes of various sizes, depending principally on the capacity of the testing-machine. These cubes are to be nicely made with the opposite sides perfectly parallel to provide a uniform bearing-surface. It is found that the larger the blocks the greater the strength per unit of area.\*

To test Stone for Compressive Strength.—Have the specimen dry and dressed, and ground to a cube — inches on each edge, and with the opposite faces parallel planes. This is important, as imperfect or wedge-shaped faces concentrate the stress on a small area. In testing, use a layer of wet plaster-of-Paris between the specimen and the faces of the machine, to distribute the stress.

To test Stone for Transverse Strength.—In this case the specimen is dressed into the form of a prism 8 inches long and 2 by 2 inches in section. It is supported on bearings 6 inches apart, and a centre load applied. The strength is computed as explained under head of Transverse Testing, page 68.

Durability of stone is tested accurately only by actual trial. Some idea can be formed by noticing the effect of the weather on the exposed rocks in the quarry from which the specimen came.

In the method of standard tests adopted in Munich in 1887 the following additional tests are recommended:

1. Trial method with (a) a jumper or drill, (b) by rotary boring. The amount of work done by the drill to be determined by the momentum of drop, its velocity of rotation, and the shape or cutting angle of the drill or cutting tool. These qualities are to be determined by comparison with a standard

<sup>\*</sup> See Unwin, "Testing of Materials."

156

drill working under definite conditions. 2. Examine the stone for resistance to shearing as well as to boring.

Report the results of the boring test on the following form:

### STANDARD REPORT BLANK FOR BORING TEST.

- 1. Description of stone in its geological and mineralogical relations.
- 2. Miner's classification (hard, very hard, or extremely hard).
- Texture \(\text{t. e., coarse-grained, fine-grained, parallel, normal to or inclined to axis of drill-hole).
  - 4. Specific gravity of the stone.
  - 5. Diameter of hole drilled.
  - 6. Diameter of hole and core when boring.
  - 7. Straight or curve edged drills.
  - 8. Angle of edge of drills.
  - 9. Number of blows per revolution of drill.
  - 10. Effective weight of drill.
  - 11. Mean effective drop of drill.
  - 12. Number of blows required to drill the depth of hole.
  - 13. Number and form of teeth of borer.
  - 14. Statement of pressure on and velocity of borer while boring.
  - 15. Actual or total depth of bore-hole.
- 16. Calculated or indicated work done during boring stated in meter-kilograms per c. m. of hole bored. (When using a hollow borer the annulus of stone cut away is alone to be considered.)
- 3. Find when possible the position in the quarry originally occupied by the specimen tested.
- 4. Find out the intended use of the stone, and determine the character of tests largely from that. 5. Dry the stone until no further loss of weight occurs at a temperature of 30° C. (86° F.), and test in a dry condition.

Make the tests for strength as described, using as large specimens as possible. Also, test by compression rectangular blocks. Test also for tension and bending.

- 6. Obtain the specific gravity, after drying at a temperature of 86° F.
- 7. Examine the specimen for resistance to frost by using samples of uniform size, 7 cm. (2.76 inches) on each edge.
  - 8. The frost-test consists of:
- a. The determination of the compressive strength of saturated stones, and its comparison with that of dried pieces.

- b. The determination of compressive strength of the dried stone after having been frozen and thawed out twenty-five times, and its comparison with that of dried pieces not so treated.
- c. The determination of the loss of weight of the stone after the twenty-fifth frost and thaw. Special attention must be had to the loss of those particles which are detached by the *mechanical* action, and also those lost by solution in a definite quantity of water.
- d. The examination of the frozen stone by use of a magnifying-glass, to determine particularly whether fissures or scaling occurred.
  - g. For the frost-test are to be used:

Six pieces for compression-tests in dry condition, three normal and three parallel to the bed of the stone, provided these tests have not already been made, in which it is permissible, on account of the law of proportions, to use cubical test-blocks larger than 7 cm. (2.76 inches).

Six test-pieces in saturated condition—not frozen, however; three tested normal to and three parallel to bed.

Six test-pieces for tests when frozen, three of which are to be tested normal to and three parallel to bed of stone.

- 10. When making the freezing-test the following details are to be observed:
- a. During the absorption of water the cubes are at first to be immersed but 2 cm. (0.77 inch) deep, and are to be lowered little by little until finally submerged.
- b. For immersion, distilled water is to be used at a temperature of from 15° C. (59° F.) to 20° C. (68° F.).
- c. The saturated blocks are to be subjected to temperatures of from  $-10^{\circ}$  to  $-15^{\circ}$  C. (14° to 5° F.). This can be done in a vessel surrounded with melting ice and salt.
- d. The blocks are to be subjected to the influence of such cold for four hours, and they are to be thus treated when completely saturated.
- e. The blocks are to be thawed out in a given quantity of distilled water at from 59° F. to 64° F.

- 11. An investigation of weathering qualities—stability under influences of atmospheric changes—can be neglected when the frost-test has been made. However, the effects in this respect, in nature, are to be carefully observed and compared with previous experience in the use of similar material. Observe—
- a. The effect of the sun in producing cracks and ruptures in stones.
- b. The effect of the air, and whether carbonic-acid gas is given off.
  - c. The effect of rain and moisture.
  - d. The effect of temperature.
- 115. Bricks or Artificial Building-stone.—Brick are tested for strength, principally by compression.
- I. They should be ground to a form with opposite parallel faces, and are tested between layers of thin paper; or, without grinding, between thin layers of plaster-of-Paris, as explained for stone. The variation in size of specimen, and whether the brick is tested on end, side-ways, or flat-ways, will make a great difference in the results. The test, to be of any value, must state the method of testing. Whole bricks are stronger per unit of area than portions of bricks, and should be used when practicable.
- 2. It is also recommended that brick be tested for compression in the shape of two half-bricks superimposed, united by a thin layer of Portland cement, and covered on top and bottom with a thin layer of such paste to secure even bearing-surfaces.\*
- 3. The transverse test for brick is believed to be a valuable index to its building properties. Support the brick on knife-edges 6 inches apart, and apply the load at the centre. Compute the modulus of rupture:

$$R = \frac{3}{2} \frac{Wl}{bd^n},$$

<sup>\*</sup>See Vol. XI. (Standard Method of Testing), Transactions of American Society Mechanical Engineers, regarding Articles 114-118.

in which W equals the centre-load, I the length, b the breadth, d the depth, all in inches.

- 4. Dry as for stone, and determine the specific gravity.
- 5. Test hard-burned and soft-burned from the same kiln.
- 6. Determine the porosity of the brick as follows:

Thoroughly dry ten pieces on an iron plate; weigh these pieces; then submerge in water to one half the depth for twenty-four hours; then completely submerge for twenty-four hours, dry superficially, and weigh. Determine porosity from the weight of water absorbed, which should be expressed as per cent of volume. Express absorption as per cent of weight.

- 7. Determine resistance against frost, as previously explained for stones, using five specimens, and repeating the operation of freezing and thawing twenty-five times for each specimen. Observe the effect with a magnifying-glass. After freezing, test for compression, and compare the results with that obtained with a dry brick.
- 8. To test brick for soluble salts, obtain samples from an underburned brick and grind these to dust. Sift through a sieve 4000 meshes per square cm. (31,360 per square inch). The dust sifted out is lixiviated in 250 c.c. of distilled water, boiled for about one hour, filtered, and washed. The amount of soluble salts is then determined by boiling down the solution and bringing the residue to a red heat for a short time. The amount is determined by weight and expressed in percentage; its composition is determined by a chemical analysis.
- 9. Determinations of the presence of carbonate of lime, mica, or pyrites are to be made by chemical analysis.
- 116. Tests of Paving Material, Stones, and Ballast, Natural and Artificial.—In this case the following observations and tests should be made:
- I. Information in regard to petrographic and geologic classification, the origin of the samples, etc., etc.; also:
  - 2. Statement in regard to utilization of same.
  - 3. Specific gravity of the samples is to be determined.
- 4. All materials used in the construction of roads, provided they are not to be used under cover or in localities without

frost, are to be tested for their frost-resisting qualities by similar test to those prescribed for natural stone.

5. Stones or brick used for paving are tested most satisfactorily in a manner representing their mode of utilization by determining the wearing qualities by an abrasion-test described by Prof. I. O. Baker as follows:\* The abrasion-tests are made by putting the bricks and a number of pieces of iron into a revolving horizontal cylinder. The cylinder used by Prof. Baker was a foundry-rattler 45 inches long, 26 inches in diameter, and revolved at rate of 24 revolutions per minute. The iron used consisted of 546 pieces of "foundry-shot," weighing about \$\frac{1}{2}\$ pounds.

In making the test, the "brick" is inserted in the rattler, which is put in motion and the loss determined by weighing at the end of each run. Three runs are made, each one half-hour in length; the comparisons are all made from the loss during the third run, expressed in percentages. Granite and various stones treated in the same way afford a valuable basis for comparison.

The uniformity of wearing qualities of brick for parts more or less distant from the exterior surface is determined by repeating the trial on the same piece, and not merely testing one, but a greater number of pieces. It is, moreover, necessary to test samples of the best, the poorest, and the medium qualities of bricks in any one kiln.

- 6. Obtain the transverse strength as explained.
- 7. Obtain the per cent of water absorbed after the bricks have been thoroughly dried at 30° C. (83° F.), as explained Arts. 91-95.
  - 8. Test materials for ballast in a similar manner.
- 9. In some cases it may be desirable to test stones as to the capacity for receiving a polish.
- 10. Examinations of asphalts can only be made in an exhaustive manner by the construction of trial roads. An

<sup>\*</sup> See Clay-worker, August and September 1891.

opinion coinciding with the results of such trial may be formed by—

- (a) Determination of the quantity and quality of the bitumen contained therein (whether the bitumen be artificial or natural).
  - (b) By physical and chemical determination of the residue.
- (c) By determination of the specific density of test-pieces of the material used by a needle of a circular sectional area of 1 sq. mm., carrying a weight of 300 grams. (See Art. 118, p. 163.)
- (d) By the determination of the wear of such test-pieces by abrasion or grinding trials.
- (e) By the determination of the resistance to frost of these test-pieces. (See Art. 119, page 163.)
- TI7. Hydraulic Cements and Mortars—Definitions.— The standard scientific methods of testing cements depend principally upon researches conducted in the German laboratories. The standard method as here given is that recommended by the Committee on Standard Methods of Testing at Munich in 1888.

The following definitions will serve to distinguish the different classes of hydraulic bond materials:

- I. Common limes are produced by roasting or burning limestones containing more or less clay or silicic acid, and which when moistened with water become wholly or partly pulverized and slaked. According to local circumstances, these are sold in shape of lumps or in a hydrated condition in the shape of a fine flour.
- 2. Water-limes and Roman cements are products obtained by burning clayey lime marls below the temperature of decrepitation, and which do not disintegrate upon being moistened, but must be powdered by mechanical means.
- 3. Portland cements are products obtained by burning clayey marls or artificial mixtures of materials containing clay and lime at decrepitation temperature, and are then reduced to the fineness of flour, and which contain for one part of hydraulic material at least 1.7 parts of calcareous earth. To regulate

properties technically important, an admixture of 2 per cent of foreign matter is admissible.

- 4. Hydraulic fluxes are natural or artificial materials which in general do not harden of themselves, but do so in presence of caustic lime, and then in the same way as a hydraulic material; i.e., puzzuolana, santorine earth, trass produced from a proper kind of volcanic tufa, blast-furnace slag, burnt clay.
- 5. Puzzuolana cements are products obtained by most carefully mixing hydrates of lime, pulverized, with hydraulic fluxes in the condition of dust.
- 6. Mixed cements are products obtained by most carefully mixing existing cements with proper fluxes. Such bond materials are to be particularly stated as "Mixed Cements," at the same time naming the base and the flux used.

Mortar is made by mixing three or four parts of sharp sand with one part of quick-lime or cement, and adding water until of the proper consistency. Mortar made from quick-lime will neither set nor stay hard under water; that made from hydraulicor water-lime, if allowed to set in the air, will not be softened by water; while that made from cement will harden under water.

118. Method of Testing Cements.—The principal properties which are necessary to know are: (1) its fineness; (2) time of setting; (3) its tensile strength; (4) its soundness or freedom from cracks after setting; (5) its heaviness or specific gravity; (6) its crushing strength; (7) its toughness or power to resist definite blows.

Of these the first four are of principal importance.

1. The fineness is determined by finding the per cent of cement that will not pass through sieves with meshes of a given size. Large particles of cement are as inert as sand.

The fineness is to be determined by the use of sieves of 900 and 4900 meshes per sq. cm. (5732 and 31,170 per sq. in.) for Portland cements, and of 900 and 2500 meshes per sq. cm (5732 and 15,900 per sq. in.) for the other hydraulic bond materials, and for each test a quantity of 1000 grm. (2.22 lbs.)

is to be used. The wires used in the above sieves shall have

```
diameters of 0.05, 0.07, and 0.1 mm.
(0.00197, 0.002758, and 0.00395 in.)
for sieves having 4900, 2500, and 900 meshes per sq. cm.
(5732, 15,900, and 31,170 meshes per sq.in.);
```

and it is recommended to always procure the sieves from the same makers.

The American Society of Civil Engineers recommend sieves with 2500, 5476, and 10,000 meshes per sq. in.

2. Consistency of the Mortar.—It is important to have the mortar always of the same "standard consistency." This is determined by the "consistency-meter," which is a rod 1 cm. diameter, weighing 300 grm. (0.66 lb.), and a cylindrical vessel 4 cm. high and 8 cm. in diameter (1.576 × 3.152 in.) inside, made of hard rubber. The consistency is determined as follows: Stir 400 grm. of the material, with sufficient water, at a temperature of from 59° to 65° F. for a stiff paste, with a spoon-shaped spatula, for exactly three minutes for slow-setting and one minute for quick-setting materials. Fill this into the vessel without shaking, stroke the surface of the paste, carefully insert the rod in the "consistency-meter," while maintaining it in a vertical position; when this rod remains standing 6 mm. (0.2364 in.) above the bottom of the vessel the paste is of "standard consistency."

The conditions of set are determined by a standard needle 1 sq. mm. (0.000157 sq. in.) cylindrical section, and a weight of 300 grm. (0.66 lb.), using the same vessel as before.

Mix the materials as explained for standard consistency; carefully insert the needle from time to time. The beginning of set is indicated when the needle will not penetrate to the bottom of the vessel. With quick-setting cements this is also indicated by a change of temperature. Every hydraulic bond material can be said to have set when the needle no longer

[§ 119.

makes any impression on it. The time of setting is to be noted.

The setting test may also be made by spreading the paste, to a thickness of 2 cm., when mixed to standard consistency, on a glass slab; the time of setting is determined by its resistance to the finger-nail under a light pressure.

- 3. Specific Gravity.—This is obtained in the Cornell cement-testing laboratory by measuring the displacement of a known weight of cement in spirits of turpentine, as follows: A vessel with a long stem, which is graduated in c.c., is used; turpentine is poured in until it rises to the lower graduations of the tube; a weight of 100 grm. of the cement is then slowly poured in at the top of the tube and allowed to settle to the bottom. The displacement of the turpentine is shown in c.c. by the difference between the first and last readings on the graduated tube. The specific gravity is computed from the known weight and volume.
- 4. Constancy of Volume is determined by the cake test on glass plates, which is executed as follows: 100 grm. (0.22 lb.) is made into a paste of normal consistency and a cake thereof of about 2 cm. (0.788 in.) thickness is made on a plate of glass. Two of these cakes, protected from drying by keeping in an air-space filled with saturated water vapor for 24 hours, are submerged in water after 24 hours or when set, and the material is said to have a constancy of volume when the cakes after 28 days' submersion show neither warping nor cracking of the edges. This operation is facilitated with Portland cement after the cake has set by baking in an oven at a temperature of from 230° to 248° F. for one hour, or until no steam is given off. If the cakes show no warping or cracks on the edges, it may be considered to have constancy of volume.
- 119. Tests of Strength.—a. The tests of strength are to be made with a mixture of standard consistency as explained, and with pure (neat) cement, or with mixtures of sand equal in weight, or three times that of the cement.
  - b. The sand to be used is to be standard sand, obtained

from the purest quartz sand, the fineness of which is to be determined by using three sieves,—64, 144, and 225 meshes per sq. cm. (407, 916, 1431 per sq. in.),—so that one half passes the first and remains on the second, and the other half passes the second and remains on the third sieve.

The wires of these sand sieves are to be as follows:

Sieves of	64	144	225	meshes	per	sq.	cm.
	(407	916	1431	meshes	per	sq.	in.)
Diam. of wire,	0.40	0:30	0.20	mm.			
(0	.0157	0.01182	0.00788	in.)			

In American practice the sieves used are two in number, containing 400 and 900 meshes per square inch. The sand is crushed quartz, as used by makers of sand-paper. All of the sand used must pass the first, none must pass the second sieve.

- c. The compression-test is the deciding test of resistance, determining its value; this is to be made with cubes of 50 sq. cm. (7.75 sq. in.) section.
- d. The tension-test is the usual test of quality: this is made on test-pieces of the German standard form, having a section of 5 sq. cm. (0.775 sq. in.) at the part to be ruptured. The dimension of the American standard briquette is exactly 1 sq. in. in section at the part to be ruptured. (See Article 89, Fig. 66, page 119.)

The method of testing in tension is as follows (in this connection read Article 77, page 101, describing the various machines for this purpose): Prepare the briquette by mixing 400 grm. of the mortar, of standard consistency, as explained, the mixing to be done with a spatula, or by placing in a vessel and giving a definite number of shakes. The mortar when thoroughly mixed is then placed in the mould and rammed with short wooden rammers. To insure constant density the German laboratories use a machine, made very much like a trip-hammer, which delivers 150 blows automatically on each specimen.

The specimen is to be kept in a saturated air-space for 24 hours, after which it is submerged in water of a temperature of 59° to 65° F., where it remains until required for testing. The water is to be changed once every seven days.

The critical tension-test for all bond materials is to be the 28-day test. To judge of the quality in less time in the case of Portland cement, the resistance may be determined upon mortar of the composition of 3 sand, I cement, after setting 7 days.

e. Adhesion-test is to be determined by the standard testing-machine, using test-pieces enclosed in frames placed on dull ground-glass prisms. The test-surface is to be  $5 \times 5 = 25$  sq. cm. The tension-holders must be perfectly mobile.

It is absolutely necessary that all test-pieces of hydraulic bond materials be kept in a space saturated with water or submerged, as prescribed for tension-tests.

In order to determine the adhesion of bond materials correctly, all accidental effects of the material upon the surfaces united must be excluded. Bricks, therefore, are never to be used when testing limes, and hydraulic limes and cements in particular, as they would form with lime a puzzuolana cement, which extends into the substance of the brick.

other Methods of Testing Cements.—Various other methods of testing cements are used in different laboratories; the American Society of Civil Engineers have adopted a method, which differs from the one given principally in the sieves used and in the method of mixing the cement. The sieves required for the cement have 2500, 5476, and 10,000 meshes, respectively, per square inch; that for the sand has 400 and 900 meshes, respectively, per square inch. In mixing, the cement is placed loosely in the mould and not rammed. The cement-testing laboratory, College of Civil Engineering, Cornell University, uses the German methods of mixing and handling the cement. The briquettes are, however, dried in the air of the laboratory for the first twenty-four hours after mixing, and then put into water.

The following observations are taken with respect to each briquette:

Brand of	cement
Tempera	ure of air at mixing
	ure of water at mixing
Percenta	e of sand
"	" water
"	" cement
	ixing
Time of	nixing

In the log of the tests the following are the headings for the columns: No.; Time of Testing; Weight of Water; Ten sile Strength; and Remarks.

Prof. Lanza of Boston requires a report of the following form:

## CEMENT TEST.

Date of test,		•					•	•	•	•	•	•	•	•	•	•				• •	• • •		•••	
Date of mixing	g,					•					•				•				• •					
No. of days se	ŧ,										•						•		٠.		• • •	٠.,	•••	
Manner of set	tin	g (	in	air	or	in	wa	ter)	, .	•					•									
Kind of cemer	ıt,					•				•				•		•			٠.		• • •		•••	
Brand,	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	• •		• •	. • •	•••	
					(	Cem	ent		•		San	d.			,	Wat	er.					Li	me.	
Mixture (by w	t.),	•						.%					۶.		••			.9	6				• • •	9
Breaking-strer	ngt	h p	er	sq	. in	. (t	en	sion	1),												• • •		•••	
Crushing-load	•				•																			
							C:-		1															

The cement-testing laboratory of Berlin, which has perhaps the best reputation for this line of work, makes observations as shown on the following schedule, which gives the results of eleven tests, as given in a paper by P. M. Bruner, before the Engineers' Club of St. Louis:

1	,	i i	, i	<b>'</b> •	:		12.13	SS			'n		'n	ڼ	1		
Tensile Strength per		i.g	28 days.	9.5		\$6.6		13.55	23	8	28.5	2,	27.5	17.9	_		
1.3 Normal Sand.	Ter	20 .c.	7 days.	22.75	25 4	22.7	:	<u>:</u>	17.5	2	ï	9	<u>:</u>	12.7			
1.3		tsiw .r.	Mixed Wate	\$2 6	52 6	9	ę.	9.5	6	9.75	8.6	11.5	2	•			
at.	Tensile Strength per sq. cm. in		th per		days. 28 days.	8		8.7	39.8	:	35	37.5	33	92		ŝ	
Neat Cement.	Ten	8. C. C.	7 days.	8	8	51.7	₹.	:	S	33	<u>چ</u>	ä		33	ei		
Z		with:	Mıxed Vate	ž,	9	17.5	9		17	17.5	19.75	33	<u>:</u>	15.5	sq. in. = 6.4514 sq. cm.		
Ų,	ġ,		091,1	8	۰	۰	10	۰	۰	۰	۰	۰	۰	۰	6.45		
Sie	ř.		2,100	Ä,	۳	۰	2.7	S	0	0	•	0	0	1.5	ë		
Rejected by Sieve	<b>8</b>		078,€	, X	н	ë.	'n	<b>∞</b>	.2	۰	•	•	•	4	ġ		
Secto	de de		5,800	À	+	•	11.5	19.5			۰	•	0	7	] -		
ž	Jo		33,250	24.8	7	8	æ	去	9	7	12	9	+	4			
king	i	Humid-	Air was	888	*	3	8	٤	8	R	8	ê	٤	72	g. in.		
At Test-making	pera-		of Water was	16°C.	15	13	16.8	16.8	15	15 5	9	13	15	S.	1 Kilo. 8q. cm. = 14.22275 8q. in.		
Ψŧ	The T		of Air	21°C.	18.7	82	22	23.5	81	82	£	81	82	<b>6</b> 2	Si u		
enre!	ypera 1	Ter Jaitt	lo sei A se ni	3°C	w	•	2.	8:	9.1	9.6	6.1	o.	•	1.1	0.80		
			Time o	E 9	*	3 6	•	٥	Į.	. Š	*	11 11	‡	m	1 Ki		
equired		Setting	Glass.	<b>302</b>	92	ģ	8	2	<b>T</b>	8	8	25	ĝ	ž.			
Water required		ducing	ity.	30,	ዶ	*	31	ý	31	25	38	3	36	8,			
•;			Weigh	1.986	1.918	1.754	1.491	1.60	1.956	1.972	1.720	0.753	99:	1.932			
			Brand.	4	∢	<	A	Α	А	А	i	Puzz.	Ħ	H			
		Ž		\$	8	124	27	31	0	105	38	127	25	8	1		

1 Kilo. 8q. cm. = 14.22275 8q. in.

advance of the test the probable load the material under investigation will safely bear, in order that increments of stress may be so proportioned as to make a reasonable number of observations. It is also often desirable to know how the results obtained compare with the standard values for the material under investigation. To provide this information a brief statement of the results of various tests are tabulated in the Appendix. These results are mainly obtained from "Materials of Construction," by R. H. Thurston (3 vols.; N. Y., Wiley & Son); and from "Applied Mechanics," by Prof. G. Lanza (N. Y., J. Wiley & Son); and "Materials of Engineer ing," by Prof. W. H. Burr (N. Y., J. Wiley & Son). These books will be found of great value for reference in the testing-laboratory.

## CHAPTER VI.

## FRICTION—TESTING OF LUBRICANTS.

122. Friction.—This subject is of great importance to engineers, since in some instances it causes loss of useful work, and in other instances it is utilized in transmission of power. The subject is intimately connected with that of measurement of power by dynamometers, treated in Chapter VII.; in connection with these two chapters, the student is advised to read "Friction and Lost Work in Machinery and Mill-work," by R. H. Thurston; N. Y., J. Wiley & Sons.

Definitions.—Friction, denoted by F, is the resistance to motion offered by the surfaces of bodies in contact in a direction parallel to those surfaces.

The *normal force*, denoted by R, is the force acting perpendicular to the surfaces, tending to press them together.

The coefficient of friction, f, is the ratio of the friction, F, to the normal force, R; that is,  $f = F \div R$ .

The total pressure, P, is the resultant of the normal pressure, R, and of the friction, F, and its obliquity or inclination to the common perpendicular of the surfaces is the *angle of repose*, or *friction*, whose tangent is the coefficient of friction.

The angle of repose or friction,  $\phi$ , is the inclination at which a body would start if resting on an inclined plane. It is easy to show \* that for that condition, if W is the weight of the body,

 $W\cos\phi=R$ ; also,  $W\sin\phi=F$ ;

<sup>\*</sup> See Mechanics, by I. P. Church; p. 164.

and since  $f = F \div R$ ,

$$f = \frac{W \sin \phi}{W \cos \phi} = \tan \phi.$$

It has been shown by experiment that for sliding friction (1) the coefficient f is independent of R; (2) it is greater at the instant of starting than after it is in motion; (3) it is independent of the area of rubbing surfaces; (4) it is diminished by lubrication; (5) it is independent of velocity.

- 123. Classification and Notation.—The subject of friction is naturally divided into the following sub-heads, all of which are intimately connected with methods of lubrication:
- A. Friction of rest, occurring when a body is about to start. It is the resistance to change of position.
- B. Friction of motion, occurring during uniform motion, and being less than the friction of rest.

The second kind, or friction of motion, is of principal importance, and consists of—

- 1. Sliding friction.
  - a. Bodies sliding on a plane.
  - b. Axles or journals rolling in boxes.
  - c. Pivots turning on a plane step.
- 2. Rolling friction.
  - a. One body rolling over a plane.
  - b. One body rolling over another.

# 124. Formulæ and Notation.

```
lpha = 	ext{angle of inclination of plane;}
\phi = 	ext{angle of friction;}
\theta = 	ext{arc of contact on journal;}
\beta = 	ext{inclination of force with plane;}
R = 	ext{normal force on a plane;}
f = 	ext{coefficient of friction;}
r = 	ext{radius of journal;}
l = 	ext{length of journal;}
l = 	ext{length of journal;}
l = 	ext{space passed through;}
l = 	ext{inclination of pressure per sq. in.;}
l = 	ext{length of pressure per sq. in.;}
l = 	ext{length of pressure per sq. in.;}
l = 	ext{length of journal;}
l = 	ext{length of journa
```

The most important formulæ relating to friction can be tabulated as follows:

## TABLE OF USEFUL FORMULÆ.

On a Plane.	Force of friction	F f ± D F	$fW = W \tan \alpha = W \tan \phi.$ $Tan \alpha = \tan \phi = \sqrt{W^{2} - R^{2}} + R.$ $W (\sin \alpha \pm f \cos \alpha) + (\cos \beta \pm f \sin \beta).$ $fR = W \sin \phi = fW + \sqrt{1 + f^{2}}.$
Loose- fitting Journal.	Square of reaction of bearing.  Weight on journal (squared)	N <sup>2</sup>	$W^{2} - F^{2} = W^{2}(t - \sin^{2} \phi) = W^{2}$ $\cos^{2} \phi.$ $N^{2} + F^{2} = N^{2}(t + f^{2}) = F^{2}(t + f^{2})$ $+ f^{2}.$
Loftting	Moment of friction	M U	$Fr = Wr \sin \phi = fWr + \sqrt{1+f^2}.$ $War \sin \phi = 2\pi nrW \sin \phi = 2\pi nrfW + \sqrt{1+f^2}.$
Perfectly fitting Journal.	Weight on journal (general)  Intensity of pressure at $\theta = 90^{\circ}$ Weight, perfect fit of journal  Pressure per square inch  Maximum pressure per sq. inch  Total pressure on bearing  Total force of friction  Work of friction  Moment of friction per minute	t' W p pm P' F U' M	$\int_{-\theta}^{+\theta} plr \cos \theta d\theta.$ $p + \cos \theta.$ $p' lr \int_{-\frac{1}{2} l\pi}^{\frac{1}{2} l\pi} \cos^{2} \theta d\theta = 1.57 p' lr.$ $0.64 W \cos \theta + lr.$ $0.64 W + lr.$ $0.64 W \int_{-\theta}^{\theta} \cos \theta d\theta = 1.27 W.$ $fP' W = 1.27 f W.$ $1.27 f W \text{ (space)}.$ $P' fr = 1.27 f Wr.$ $Ma = 1.27 f Wr = 2.54 \pi f nr W.$
Uniform press- ure on Journal.	Maximum pressure per sq. inch Total pressure Total force of friction Moment of friction Work of friction per minute	P'	W + 2ir. $p'l\pi r = \frac{1}{2}\pi W = 1.57 W$ . P'f = 1.57f W. P'fr = 1.57f Wr. $Ma = 1.57af Wr = \pi^3 f Wrn$ .

- 125. Friction of Journals in V or Triangular Bearings.—Force of friction  $F = P \cos \phi \sin \phi \div \cos \alpha$ , in which P equals the force transmitted through the shaft. When  $\cos \phi = 1$ ,  $F = P \sin \phi \div \cos \alpha$ .
- 126. Friction of Pivots on Flat Rotating Surfaces.— Intensity of pressure = p; total pressure = P. Moment of

friction,  $M = \frac{3}{5}fPr$ . Work of friction,  $U = \frac{4}{5}\pi nfPr$ . For a conical pivot,  $M = \frac{4}{5}fPr \div \sin \alpha$ .  $\alpha = \frac{1}{2}$  angle of cone.

For Friction on a Flat Collar.—Moment of friction,  $M = \frac{2}{8}fP(r^3-r'^3)\div(r^3-r'^3)$ ; r = radius of collar; r' = radius of shaft on which it is fitted.

127. Friction of Teeth—Rolling Friction.—Work lost in a unit of time, U = nFPs, in which s equals the sliding or slipping; n, number of teeth; other terms as before. For in volute teeth, in which  $C_1$  = length of arc of approach,  $C_1$  that of arc of recess,  $\theta$  the obliquity of action,  $r_1$  and  $r_2$  respective pitch-radii, we have for involute teeth

$$U = nfPs = nfP(C_1^2 + C_1^2) \left(\frac{1}{r_1} + \frac{1}{r_2}\right) \div 2 \cos \theta.$$

This is nearly accurate for any teeth. (See article "Mechanics," Encyc. Britannica.)

128. Friction of Cords and Belts—Sliding Friction.— Let  $T_i$  be the tension on driving side of belt,  $T_i$  on the loose side, T the tension at any part of the arc of contact; let  $\theta$  be the length of the arc of contact divided by the radius, i.e., expressed in circular measure; let e equal the ratio of the arc of contact to the entire circumference; let e equal the number of degrees in the arc of contact, e the base of the Napierian logarithms = 2.71828, e the modulus of the common logarithms = 0.434295; let e equal the force of friction.

$$\theta = \frac{\pi r}{180} \frac{d}{r} = \frac{\pi d}{180}, \quad . \quad . \quad . \quad . \quad (a)$$

$$c = \frac{d}{360} = \frac{\theta}{2\pi}, \qquad (b)$$

$$d = \frac{180\theta}{\pi} = 360c. \quad . \quad . \quad . \quad (c)$$

The tension at any point, dT, is equal to the resistance  $Tfd\theta$ . Hence

$$dT = Tfd\theta$$
, . . . . . (d)

or

$$fd\theta = \frac{dT}{T}.$$

This integrated between limits  $T_1$  and  $T_2$  gives

$$f\theta = \log_{\epsilon} \frac{T_1}{T_2} = \frac{1}{m} \text{ (common) } \log \frac{T_1}{T_2}; \dots (\epsilon)$$

hence

$$\frac{T_1}{T_1} = e^{f\theta} = 10^{f\theta m} = 10^{\frac{f\pi dm}{180}} = 10^{2\pi fcm} = B_1 . . . (f)$$

From the nature of the stress,

 $\frac{T_1}{T_2}$  = the number corresponding to the logarithm, which is equal  $f\theta m$ , or  $\frac{f\pi dm}{180}$ , or  $2\pi fcm$ .

Substituting numerical values,

 $f\theta m = 0.434 f\theta$ ,  $\frac{f\pi dm}{180} = 0.00758 fd$ , and  $2\pi fcm = 2.7288 fc$ . From equations (f),

common 
$$\log\left(\frac{T_1}{T_2}\right) = 0.434f\theta = 2.7288fc.$$

By solving equations (f) and (g),

$$T_{\bullet} = F_{\overline{B-1}}^{1} \dots \dots (k)$$

129. Friction of Fluids (1) is independent of pressure; (2) proportional to area of surface; (3) proportional to square of velocity for moderate and high speeds and to velocity for low speeds; (4) is independent of the nature of the surfaces; (5) is proportional to the density of the fluid, and is related to viscosity.

The resistance to relative motion in case of fluid friction,

$$R = fAV^{2} = 2ghfA = f'hwA;$$

the work of friction,

$$U = Rs = RVt = fAV^{*}t = f'AhwVt.$$

In the above formulæ R = resistance of friction, A = area of surface, V = velocity of slipping, h = head corresponding to velocity, w = weight, f the resistance per unit of area of surface, f' = coefficient of liquid friction,  $f' = \frac{2gf}{m}$ .

Viscosity and density of fluids do not affect to any appreciable extent the retardation by friction in the rate of flow, but have some influence upon the total expenditures of energy. Molecular or internal friction also exists.

- 130. Lubricated Surfaces.—Lubricated surfaces are no doubt to be considered as solid surfaces, wholly or partially separated by a fluid, and the friction will vary, with different conditions, from that of liquid friction to that of sliding friction between solids. Dr. Thurston \* gives the following laws, applicable to perfect lubrication only:
- 1. The coefficient of friction is inversely as the intensity of the pressure, and the resistance is independent of the pressure.
  - 2. The coefficient varies with the square of the speed.
- 3. The resistance varies directly as the area of journal and bearing.
- 4. The friction is reduced as temperature rises, and as the viscosity of the lubricant is thus decreased.

Perfect lubrication is not possible, and consequently the laws governing the actual cases are likely to be very different from the above. The coefficient of friction in any practical case is likely to be made up of the sum of two components, solid and fluid friction.

### TESTING OF LUBRICANTS.

- 131. Determinations required.—The following determinations are required in a complete test of lubricants:
  - 1. The composition, and detection of adulteration.
  - 2. The measurement of density.

<sup>\*</sup> See Friction and Lost Work, by Thurston,

- 3. The determination of viscosity.
- 4. The detection of tendency to gum.
- 5. The determination of temperatures of decomposition, vaporization, ignition, and solidification.
  - 6. The detection of acids.
  - 7. The measure of the coefficient of friction.
- 8. The determination of durability and heat-removing power.
- 9. The determination of its condition as to grit and foreign matter.
- 132. Adulteration of Oils.—Adulteration can be detected only by a chemical analysis.\*

Animal oils may be distinguished from vegetable oils by the fact that chlorine turns animal oil brown and vegetable oil white.

133. Density of Oils .-- The density or specific gravity is usually obtained with a hydrometer (see Fig. 71) adapted for this special purpose, and termed an oleometer. The distance

> that it sinks in a vessel of oil of known temperature is measured by the graduation on the stem; from this the specific gravity of the oil may be found.

> The density is usually expressed in Beaumé's hydrometer-scale, which can be reduced to corresponding specific gravities as compared with water by a table given in the Appendix.

Beaumé's hydrometer is graduated in degrees to accord with the density of a solution of common salt in water; thus, for liquids heavier than water the zero of the scale is obtained by immersing in pure water; the five-degree mark by immersing in a five-per-cent solution; the ten-degree mark in a ten-FIG. 71. per-cent solution; etc. For liquids lighter than

water the zero-mark is obtained by immersing in a ten-per-cent solution of brine; the ten-degree mark by immersing in pure water. After obtaining the length of a degree the stem is graduated by measurement.

<sup>\*</sup> See Friction and Lost Work, by R. H. Thurston.

The density may be found by obtaining the loss of weight of the same body in oil and in distilled water. The ratio of loss of weights will be the density compared with water.

It may also be obtained by weighing a given volume on a pair of chemical scales. The *density of animal oils* varies from .62 to .89; sperm-oil at 39° F. has a density of .8813 to .8815; rape-seed oil has a density of .9168; lard-oil (winter) has a density of .9175; cotton-seed oil a density of .9224 to .9231 for ordinary, and of .9128 for white winter; linseed-oil, raw, has a density of .9299; castor-oil, pure cold-pressed, a density of .9667.

134. Method of finding Density.—A. With Hydrometer Thermometer, and Hydrometer Cylinder.

Method.—1. Clean the cylinder thoroughly, using benzine fill first with distilled water. Set the whole in a water-jacket, and bring the temperature to 60° F. Obtain the reading of the hydrometer in the distilled water and determine its error.

2. Clean out the cylinder, dry it thoroughly, and fill with the oil to be tested; heat in a water-jacket to a temperature of 60° F., and obtain reading of hydrometer; also obtain reading, at temperatures of 40°, 80°, 100°, 125°, and 150°, and plot a curve showing relation of temperature and corrected hydrometer-reading.

Reduce hydrometer-readings to corresponding specific gravities, by table given in Appendix.

- B. Weigh on a chemical balance the same volume of distilled water at 60° F., and of the oil at the same temperature; and compute the specific gravity.
- C. Weigh the same metallic body by suspending from the bottom of a scale-pan of a balance: 1. In air; 2. In water; 3. In the oil at the required temperature. Carefully clean the body with benzine after immersing in the oil. The ratio of the loss of weight in oil to that in water will be the density.
- 135. Viscosity.—Viscosity of oil is closely related but not proportional to its density. It is also closely related, and in many cases it is inversely proportional, to its lubricating prop-

erties. The relation of the viscosities at ordinary temperatures is not the same as for higher temperatures, and tests for viscosity should be made with the temperatures the same as those in use. The less the viscosity, consistent with the pressure to be used, the less the friction.

The viscosity test is considered of great value in determining the lubricating qualities of oils, and it is quite probable that by means of it alone we could determine the lubricating qualities to such an extent that a poor oil would not be accepted nor a good oil rejected. It is, however, in the present method of performing it, to be considered rather as giving comparative than absolute results.

There are several methods of determining the viscosity It is usual to take the viscosity as inversely proportional to its




FIG. 72.-VISCOSITY OF OILS.

flow through a standard nozzle while maintained at a constant or constantly diminishing head and constant temperature, a comparison to be made with water or with some well-known oil, as sperm, lard, or rape-seed, under the same conditions of pressure and temperature.

136. Viscosimeter.—A pipette surrounded by a waterjacket, in which the water can be heated by an auxiliary lamp and maintained at any desired temperature, is generally used as a viscosimeter. Fig. 72 shows the usual arrangement for this test. E is the heater for the jacket-water, BB the

jacket, A the pipette, C a the mometer for determining the temperature of the jacket-water. The oil is usually allowed to run partially out from the pipette, in which case the head diminishes. Time for the whole run is noted with a stop-watch.

In the oil-tests made by the Pennsylvania R. R. Co. the pipette is of special form, holding 100 c.c. between two marks, - one drawn on the stem, the other some distance from the end of the discharge-nozzle.

137. Tagliabue's Viscosimeter.—In Tagliabue's viscosim-

eter, shown in Figs. 73 and 74, the oil is supplied in a basin C, and trickles downward through a metal coil, being discharged at the faucet on the side into a vessel holding 50 c.c. The oil is maintained at any desired temperature by heating the water in the vessel B surrounding the coil; cold water is supplied from the vessel A, as required to maintain a uniform temperature. The temperature of the oil is taken by the thermometer D.

138. Gibbs' Viscosimeter. — In the practical use of viscosimeters it is found that the time of flow of 100 c.c. of the same oil, even at the same temperature, Fig. 73.--TAGLIABUE'S VISCOis not always the same,—which is probably



SIMPTED

due to the change in friction of the oil adhering to the sides of the pipette.

To render the conditions which produce flow more constant, Mr. George Gibbs of Chicago surrounds the viscosimeter, which is of the pipette form, with a jacket of hot oil. A circulation of the jacket-oil is maintained by a force-pump. The oil to be tested is discharged under a constant head, which is insured by air-pressure applied by a pneumatic trough. The temperature of the discharged oil is measured near the point of discharge.

139. Perkins' Viscosimeter.—The Perkins Viscosimeter consists of a cylindrical vessel of glass, surrounded by a water or oil bath, and fitted with a piston and rod of glass. The edges of this piston are rounded, so as not to be caught by a slight angularity of motion. The diameter is one-thousandth of an inch less than that of the cylinder. In practice the cylinder is filled nearly full of the oil to be tested, and the piston inserted.




FIG. 74.—TAGLIABUE'S VISCOSIMETER.

The time required for the piston to sink a certain distance into the oil is taken as the measure of the viscosity.\*

140. Stillman's Viscosimeter.—Prof. Thomas B. Stillman of Stevens Institute uses a conical vessel of copper,  $6\frac{1}{6}$  inches in length and  $1\frac{1}{4}$  inches greatest diameter, surrounded by a water-bath, and connected to a small branch tube of glass, which is graduated in cubic centimeters; the time taken for 25 c.c. to flow through a bottom orifice  $\frac{3}{64}$  of an inch in diameter is taken as the measure of the viscosity, during which time the head changes from 6 to 5 inches. Prof. Stillman makes all comparisons with water, which is the most convenient and uniform standard. The temperature of the oil is taken at about the centre of the viscosimeter.

141. Standard-orifice Viscosimeter.—A form of viscosimeter designed by the author is in the form of a frustum of a cone, with an internal diameter at the bottom of 1.25 inches, and of 1.95 inches at a height of 6 inches from the bottom.

<sup>\*</sup> See paper by Prof. Denton, Vol. IX., Transactions of Am. Society of Mechanical Engineers.

The flow takes place through a sharp-edged orifice in the centre of the bottom  $\frac{1}{16}$  inch in diameter. The whole height is  $6\frac{1}{8}$  inches. The instrument when made of copper requires a glass oil-gauge, showing the height of the oil in the viscosimeter. This should be connected to the viscosimeter 3 inches from the bottom. The time for the flow of 100 c.c. is taken as the measure of the viscosity, during which time the head changes from 6 to about 3.5 inches, the area of exposed surface diminishes at almost exactly the rate of decrease of velocity of flow, so that the fall of level is very nearly constant. The instrument is surrounded with a jacket that can be supplied with water or oil at any required temperature, and is designed to eliminate the friction on the sides of the viscosimeter, and to secure the advantages due to the flow of oil through a standard orifice that can be exactly reproduced.

142. Viscosity Determinations of Oil, by Prof. Thomas B. Stillman.

Fluid.	Time of	f Flow i ough Orif	Viscosity compared with water at 20° C. (68° F.).		
	20° C. 68° F.	50° C.		150° C.	
Water	15			- 1	1.0
Prime lard-oil	55	20	19	. 16	3.6
No. 1 " "	70	3ó	18	16	4.6
Gelatine-oil		-	<b></b>	360	•
Rosin-oil, 1st run	240	80	19	15	16.0
" " 2d run	70	23	15	14	4.6
Sperm-oil	33	22	16	15	2.2
Castor-oil	39	24	17	16	2.6
Cotton-seed oil-winter	51	26	27	15	3.4
" " summer	57	27	18	15	3.8
Rape-seed oil	71	26	20	16	4.2
Olive-oil	63	24	18	16	4.7

143. Method of measuring Viscosity.—Apparatus. Stopwatch and viscosimeter. Fill the jacket of the viscosimeter with water and arrange for the maintenance of the same at any desired temperature. This is most conveniently done by circulation from a water-bath. Fill the viscosimeter with the oil

to a point above the upper or initial mark. Allow the oil to run out, noting accurately with the stop-watch the exact time required to discharge a given amount. Make determinations at 60°, 100°, and 150° F., two for each temperature. Clean the apparatus thoroughly at the beginning and end of the test, using benzine or alkali to remove any traces of oil.

143. Gumming or Drying.—Gumming or drying is a conversion of the oil into a resin by a process of oxidation, and occurs after exposure of the oils to the air. In linseed and the drying oils it occurs very rapidly, and in the mineral oils very slowly.

Methods of Testing.—Nasmyth's Apparatus.—An iron plate six feet long, four inches wide, one end elevated one inch. Six or less different oils are started by means of brass tubes at the same instant from the upper end: the time taken until the oil reaches the bottom of the plane is a measure of its gumming property.

Bailey's Apparatus consists of an inclined plane, made of a glass plate, arranged so that it may be heated by boiling water. A scale and thermometer is attached to the plane. Its use is the same as the Nasmyth apparatus.

This effect may also be tested in the Standard Oil-testing Machine by applying fresh oil, making a run, and noting the friction; then exposing the axis to the effect of the air for a time, and noting the increase of friction. In all cases a comparison must be made with some standard oil.

144. The Flash-test.—The effect of heat is in nearly every case to increase the fluidity of oils and to lessen the viscosity; the temperature at which oils ignite, flash, boil, or congeal is often of importance.

The Flash-test determines the temperature at which oils discharge by distillation vapors which may be ignited. The test is made in two ways.

Firstly. With the open cup.—In this case the oil to be tested is placed in an open cup of watch-glass form, which rests on a sand-bath. The cup is so arranged that a thermometer can be kept in it. Heat is applied to the sand-bath, and as the oil

becomes heated a lighted taper or match is passed at intervals of a few seconds over the surface of the oil, and at a distance of about one half-inch from it. At the instant of flashing the temperature of the water-bath is noted, which is the temperature of the "flash-point."

Fig. 75 shows Tagliabue's form of the open cup, in which heat is applied by a spirit-lamp to a water or sand bath surrounding the cup containing the oil.

The method of applying the match is found to a have great influence on the temperature of the flash-point, and should be distinctly stated in each case. When the vapor is heavier than








FIG. 76.—CLOSED CUP FOR FLASHING-POINT.

air, a lower flash-point will be shown by holding near one edge of the cup.

Secondly. With the closed oil-cup.—Fig. 76 is a view of Tagliabue's closed cup for obtaining the flash-point; in this instrument the oil is heated by a sand-bath above a lamp. The thermometer gives the temperature of the oil, and the match

applied from time to time at the orifice d, which in the intervals can be covered with a valve, determines the flash-point.

The open cup is generally preferred to the closed one as giving more uniform determinations, and it is also more convenient and less likely to explode than the closed one.

Method of Testing.—Put some dry sand or water in the outer cup and some of the oil to be tested in the small cup. Light the lamp and heat the oil gently—at the rate of about 50° F. in a quarter of an hour. At intervals of half a minute after a temperature of 100° F. is attained, pass a lighted match or taper slowly over the oil at a distance of one half inch at the surface. The reading of the thermometer taken immediately before the vapor ignites is the temperature of the flash-point.

With the closed cup the method is essentially the same. The lighted taper is applied to the tube leading from the oil vessel, the valve being opened only long enough for this purpose.

145. Method of Determining the Burning-point.—The burning-point is determined by heating the oil to such a temperature, that when the match is applied as for the flash-test the whole of the oil will take fire. The reading of the thermometer just before the match is applied is the burning-point.

With Open Cup.—Apparatus: Open cup of watch-glass form; thermometer suspended so that bulb is immersed in cup; outer vessel filled with sand or water, on which the open vessel rests; lamp to heat the outer vessel.

Method.—The burning-point is found in the same manner as the flash-point, with the open cup, the test being continued until the oil takes fire when the match is applied. The last reading of the thermometer before combustion commences is the burning-point.

146. Evaporation.—Mineral oil will lose weight by evaporation, which may be ascertained by placing a given weight in a watch-glass and exposing to the heat of a water-bath for a given time, as twelve hours. The loss denotes the existence of volatile vapors, and should not exceed 5 per cent in good oil. Other oils often gain weight by absorption of oxygen.

147. Cold Tests.—Cold tests are made to determine the behavior of oils and greases at low temperatures. The method of test is to expose the sample while in a wide-mouthed bottle or test-tube to the action of a freezing mixture, which surrounds the oil to be tested. Freezing mixtures may be made with ice and common salt, with ice alone, or with 15 parts of Glauber's salts, above which is a mixture of 5 parts muriatic acid and 5 parts of cold water. The temperature is read from a thermometer immersed in the oil. The melting-point is to be found by first freezing, then melting.

Tagliabue has a special apparatus for the cold test of oils shown in section in Fig. 77. The oil is placed in the glass




FIG. 77.-TAGLIABUE'S COLD-TEST APPARATUS.

vessel, which is surrounded with a freezing mixture. The glass containing the oil can be rocked backward and forward, to insure more thorough freezing. A thermometer is inserted into the oil and another in the surrounding air-chamber; the oil is frozen, then permitted to melt, and the temperature taken.

In making this test considerable difficulty may be experienced in determining the melting-point, since many of the oils do not suddenly freeze and thaw like water, but gradually soften, until they will finally run, and during this whole change the temperature will continue to rise. This is no doubt due to a mixture of various constituents, with different melting-points. In such a case it is recommended that an arbitrary chill-point be assumed at the temperature that is indicated by a thermometer inserted in the oil, when it has attained sufficient fluidity to run slowly from an inverted test-tube. The temperature at the beginning and end of the process of melting is to be observed.

148. Method of Finding the Chill-point.—Apparatus.— Test-tube thermometer, and dish containing freezing mixture.

Method.—Pour the sample to be tested in the test-tube, in which insert the thermometer; surround this with the freezing mixture, which may be composed of small particles of ice mixed with salt, with provision for draining off the water. Allow the sample to congeal, remove the test-tube from the freezing mixture, and while holding it in the hand stir it gently with the thermometer. The temperature indicated when the oil is melted is the chill-point.

In case the operation of melting is accompanied with a distinct rise of temperature, note the temperature at the beginning and also at the end of the process of melting.

In report describe apparatus used and the methods of testing.

149. Oleography.—An attempt has been made to determine the properties of oil by cohesion-figures, by allowing drops of oil to fall on the surface of water, noting the time required to produce certain characteristic figures, also by noting the peculiar form of these figures.

Electrical Conductivity is different for the different oils, and this has been proposed as a test for adulteration.

150. Acid Tests.—Tests for acidity may be made by observing the effects on blue litmus-paper; or better by the following method described by Dr. C. B. Dudley: Have ready (1)

a quantity of 95 per cent alcohol, to which a few grains of carbonate of soda have been added, thoroughly shaken and allowed to settle; (2) a small amount of turmeric solution; (3) caustic-potash solution of such strength that 31½ cubic centimeters exactly neutralize 5 c.c. of a solution of sulphuric acid and water, containing 40 milligrams H<sub>2</sub>SO<sub>4</sub> per c.c. Now weigh or measure into any suitable closed vessel—a four-ounce sample bottle, for example—8.9 grams of the oil to be tested. To this add about two ounces No. 1, then add a few drops No. 2, and shake thoroughly. The color becomes yellow. Then add from a burette graduated to c.c., solution No. 3 until the color changes to red, and remains so after shaking. The acid is in proportion to the amount of solution (3) required. The best oils will require only from 4 to 30 c.c. to be neutralized and become red.

#### COEFFICIENT OF FRICTION OF LUBRICANTS.

151. Oil-testing Machines.—Measurements of the coefficients of friction are made on oil-testing machines, of which various forms have been built. These machines are all species of dynamometers, which provide (1) means of measuring the total work received and that delivered, the difference being the work of friction; or (2) means of measuring the work of friction directly. Machines of the latter class are the ones commonly employed for this especial purpose.

Rankine's Oil-testing Machine.—Rankine describes two forms of apparatus for testing the lubricating properties of oil and grease.

I. Statical Apparatus.—This consists of a short cylindrical axle, supported on two bearings and driven by pulleys at each end. In the middle of the axle a plumber-block was rigidly connected to a mass of heavy material, forming a pendulum. The lubricant to be tested was inserted in the plumber-block attached to the pendulum, and the coefficient of friction determined by its deviation from a vertical. In this machine the axle was provided with reversing-gears, so that it

could be driven first in one direction and then in the opposite. With this class of machine, if r equal the radius of the journal, R the effective arm of the pendulum, P the total force acting on the journal,  $\phi$  the angle with the vertical, we shall have the product of the force W into the arm  $R \sin \phi$  equal to the moment of resistance Fr. That is,

$$Fr = WR \sin \phi$$
,

from which

$$f = \frac{F}{P} = \frac{WR \sin \phi}{Pr}.$$

II. Dynamic or Kinetic Apparatus.—In this case a loose fly-wheel of the required weight is used instead of the pendulum. The bearings of journals and of fly-wheel are lubricated; then the machine is set in motion at a speed greater than the normal. The driving-power is then disengaged, and the fly-disk rotates on the stationary axis until it comes to rest. The coefficient of friction is obtained by measuring the retardation in a given time. Thus, let W equal the weight of the fly-wheel, k its radius of gyration, so that  $Wk^2 \div g$  equals its moment of inertia. Let n equal number of revolutions at beginning, and n' at end of period t. Then the retardation in angular velocity per second is

$$2\pi(n-n')\div t;$$

the moment producing retardation,

$$M = \frac{2\pi(n-n')}{gt^2}Wk^2.$$

If we neglect the resistance of the air, this must equal the moment of friction fWr.

Equating these values,

$$f=\frac{2\pi(n-n')}{gt^3}k^3.$$

In case the moment of inertia and radius of gyration are unknown, they may be found as in Article 53, page 70.

152. Thurston's Standard Oil-testing Machine.—This machine permits variation in speed and in pressure on the journal; it also affords means of supplying oil at any time, of reading the pressure on the journal, and the friction on graduated scales attached to the instrument.




Fig. 78.—Section of Thurston's Oil-testing Machine.




FIG. 79.—PERSUBCTIVE VIEW OF THURSTON'S
OIL-TESTING MACHINE.

This machine, as shown in the above cuts, Figs. 78 and 79, consists of a cone of pulleys, C, for various speeds carried between two bearings, B, B', and connected to an overhanging axis, F; on this overhanging part is a pendulum, H, with plumber-block in which the axis is free to turn; the pendulum is supported by brasses which are adjustable and which may be set to exert any given pressure by means of an adjusting screw, K', acting on a coiled spring within the pendulum. The pressure so exerted can be read directly by the scale M, attached to the pendulum; a thermometer, Q, in the upper brass gives the temperature of the bearings. The deviation

of the pendulum is measured by a graduated arc, PP', fastened to the frame of the machine. The graduations of the pendulum scale M show on one side the total pressure on the journal P, and on the other the pressure per square inch, p; those on the fixed scale, PP', show the total friction, F; this divided by the total pressure, P, gives f, the coefficient of friction.

From the construction of the machine, it is at once perceived that the pressure on the journal is made up of equal pressures due to action of the spring on upper and lower brasses, and of the pressure due to the weight of the pendulum, which acts only on the upper brass. This latter weight is often very small, in which case it can be neglected without sensible error.

153. Thurston's Railroad Lubricant-tester. — The Thurston machine is made in two sizes; the larger one, having axles and bearings of the same dimensions as those used in standard-car construction, is termed the "Railroad Lubricant Testing-machine." A form of this machine is shown in the following cut, arranged for testing with a limited supply of lubricant. (See Fig. 80.)

Explanation of symbols:

T, thermometer, giving temperature of bearings.

R, S, rubber tubes for circulation of water through the bearings.

N, burette, furnishing supply of oil.

M, siphon, controlling supply of oil.

P, candle-wicking, for feeding the oil.

H, copper rod, for receiving oil from G.

The Railroad Testing-machine, which is shown in section in Fig. 81, differs from the Standard Oil-testing Machine principally in the construction of the pendulum. This is made by screwing a wrought-iron pipe, J, which is shown by solid black shading in Fig. 81, into the head K, which embraces the journal and holds the bearings aa in their place. In this pipe a loose piece, b, is fitted, which bears against the under journal-bearing, a'. Into the lower end of the pipe J a piece, cc, is screwed, which has a hole drilled in the centre, through which

a rod, f, passes, the upper end of which is screwed into a cap, d; between this cap and the piece cc a spiral spring is placed. The upper end of the rod bears against the piece b, which in turn bears against the bearing a'. The piece b has a key, l, which passes through it and the pipe f. This key bears




FIG. 80.-THURSTON'S RAILROAD-LUBRICANT TESTING-MACHINE.

against a nut, o, screwed on the pipe. By turning the nut o the stress on the journal produced by screwing the rod f can be thrown on the key l, and the bearing relieved of pressure, without changing the tension on the spring. A counterbalance above the pendulum is used when accurate readings are de-

sired. The "brasses" are cast hollow, and when necessary a stream of water can be passed through to take up the heat, and maintain them at an even temperature.

The graduations on the machine show on the fixed scale,




FIG. 81.-SECTION OF RAILROAD LUBRICANT TESTING-MACHINE,

as in the standard machine, the total friction; and on the pendulum, the total pressures (1) on the upper brasses, (2) on the lower brasses, and (3) the sum of these pressures.

154. Theory of the Thurston Oil-testing Machines.— The mathematical formulæ applying to these machines are as follows: Let P equal the total pressure on the journal; p the pressure per square inch on projected area of journal; T the tension of the spring; T the weight of the pendulum; T the radius of the journal; T the effective arm of the pendulum;

 $\theta$  the angle of deviation of the pendulum from a vertical line; F the total force of friction; f the coefficient of friction; l the length of bearing-surface of each brass.

Since in this machine both brasses are loaded, the projected area of the journal bearing-surface is 2(2r)l = 4lr. We shall evidently have

$$p = \frac{P}{4lr} = \frac{2T+W}{4lr}. \quad . \quad . \quad . \quad . \quad (2)$$

By definition  $f = F \div P$ .

Since the moment of friction is equal to the external moment of forces acting,

$$Fr = Pfr = f(2T + W)r = WR \sin \theta$$
. (3)

From which

$$f = \frac{F}{P} = \frac{WR \sin \theta}{rP}. \quad . \quad . \quad . \quad . \quad . \quad (4)$$

In the machines  $WR \sin \theta \div r$  is shown on the fixed scale, and the graduations will evidently vary with  $\sin \theta$ , since  $WR \div r$  is constant.

P, the total pressure, is shown on the scale attached to the pendulum.

In the standard machine the weight of the pendulum is neglected, and P = 2T; but in the Railroad Oil-testing Machine the weight must be considered, and P = 2T + W, as in equation (1).

Constants of the Machine.—As the constants of the machine are likely to change with use, they should be determined before every important test, and the final results corrected accordingly.

- 1. To determine the constant WR, swing the pendulum to a horizontal position, as determined by a spirit-level; support it in this position by a pointed strut resting on a pair of scales. From the weight, corrected for weight of strut, get the value of WR; this should be repeated several times, and the average of these products obtained.
- 2. Obtain the weight of the pendulum by a number of careful weighings.
- 3. Measure the length and radius of the journal; compute the projected bearing-surface 2(2lr).
- 4. Compute the constant  $\frac{WR}{r}$ , which should equal twice the reading of the arc showing the coefficient of friction when the pendulum is at an angle of 30°, since sine of 30° equal  $\frac{1}{2}$ .

The following are special directions for obtaining the coefficient of friction with the Thurston machine.

155. Directions for obtaining Coefficient of Friction with Thurston's Oil-testing Machines.—Cleaning.—In the testing of oils great care must be taken to prevent the mixing of different samples, and in changing from one oil to another the machine must be thoroughly cleaned by the use of alkali or benzine.

In the test for coefficient of friction the loads, velocity, and temperature are kept constant for each run; the oil-supply is sufficient to keep temperature constant, the journals being generally flooded. The load is changed for each run.

The following are the special directions for the test of *Coefficient of Friction*, as followed in the Sibley College Engineering Laboratory.

Apparatus.—Thurston's Standard Lubricant Testing-machine; thermometer; attached speed-counter. (See Art. 151, page 189.)

Method.—Remove and thoroughly clean the brasses and the steel sleeve or journal by the use of benzine. Put the sleeve on the mandrel; place the brasses in the head of the pendulum and see that the pressure spring is set for zero and pressure as indicated by the pointer on the scale. Slide the pendulum carefully over the sleeve, put on the washer, and secure it with the nut. See that the feeding apparatus is in running order. Belt up the machine for the high speed and throw on the power, at the same time supplying the oil at a rate calculated to maintain a free supply. By deflecting the pendulum and using a wrench on the nut at the bottom increase the pressure on the brasses gradually until the pointer indicates 50 lbs. per square inch.

Determine the constants of the machine as explained in Article 149, page 194; measure the projected area of journal bearing-surface, and the weight and moment of the pendulum. Ascertain the error, if any, in the graduation of the machine, and correct the results obtained accordingly.

Make a run at this pressure, and also for pressures of 100, 150, and 200 lbs.; but do not in general permit the maximum pressure in pounds per square inch to exceed  $44.800 \div (v+20)$ . Begin by noting the time and the reading of the revolution-counter; take readings, at intervals of one minute, of the arc and the temperature until both are constant. At the end of the run read the revolution-counter and note the time.

The velocity, v, in rubbing surface in feet per minute should be computed from the number of revolutions and circumference of the journal.

Make a second series of runs, with constant pressure and variable speed.

In report of the test state clearly the objects, describe apparatus used and method of testing.

Tabulate data, and make record of tests on the forms given. Draw a series of curves on the same sheet, showing results of the various tests as follows:

- I. With total friction as abscissæ, and pressure per square inch as ordinates; for constant speed.
- 2. With coefficient of friction as abscissæ, and pressure per square inch as ordinates; for constant speed,
- 3. With coefficient of friction as abscissæ, and velocity of rubbing in feet per minute as ordinates; pressure constant.

156. Instructions for Use of Thurston's R. R. Lubricanttester. (See Article 152, page 190.)—Follow same directions for coefficient of friction-test as given for the standard machine, applying the pressure as explained in Article 155, page 194.

Water or oil of any desired temperature can be forced through the hollow boxes by connecting as shown in Fig. 80, page 191, and the temperature of the bearings thus maintained at any desired point. With this arrangement the machine may be used for testing cylinder-stocks, as explained in directions for using Boult's machine (see Article 161, page 203). The concise directions are:

- I. Clean the machine.
- 2. Obtain the constants of the machine; do not trust to the graduations.
- 3. Make run under required conditions, which may be with each rate of speed.
  - a. With flooded bearings, temperature variable.
  - b. With flooded bearings, temperature regulated by forcing oil or water through hollow brasses.
  - c. Feed limited, temperature variable or temperature regulated.

In all cases the object will be to ascertain the coefficient of friction.

157. Riehlé's Oil-testing Machine.—This machine consists of an axis revolving in two brass boxes, which may be clamped more or less tightly together. The machine as shown in Fig. 82 has two scale-beams,—the lower one for the purpose of weighing the pressure put upon the journal by the hand-screw on the opposite side of the machine, the upper one for measuring the tendency of the journal to rotate. The upper scale-beam shows the total friction, or coefficient of friction, as the graduations may be arranged. A thermometer gives the temperature of the journal; a counter the number of revolutions.

Let P equal the total pressure applied to the bearings. Let B equal the projected area of the journal-bearings, p equal the pressure per square inch; F equal the total friction; f equal




FIG. 82.-RIEHLE'S OIL-TESTING MACHINE.

the coefficient of friction; n equal the arm of the bearing; a the arm of the total pressure. Then do we have

$$p = \frac{P}{B}, \qquad f = \frac{F}{P},$$

$$Fn = aP = aBp$$

$$Bfn = aP$$
,

and

$$f = \frac{aP}{Bn} = \frac{ap}{n}.$$

If p be maintained constant, and  $a \div n$  be made the value of the unit of graduation on the scale-beam

f = graduation.

158. Durability of Lubricants.—In this case the amount of oil supplied is limited, and it is to be used for as long a time as it will continue to cover and lubricate the journal and prevent abrasion. To give satisfactory results, this requires a limited supply or a perfectly constant rate of feed, an even distribution of the oil, and the restoration of any oil that is not used to destruction; these difficulties are serious, and present methods do not give uniform results.\* The method at present used is to consider the endurance or durability proportional to the time in which a limited amount, as one fourth c c. will continue to cover and lubricate the journal without assuming a pasty or gummy condition, and without giving a high coefficient of friction. The average of a number of runs is taken as the correct determination. In this test care must be taken not to injure the journal, and it must be put in good condition at the end of the run.

The time or number of revolutions required to raise the temperature to a fixed point—for instance, 160 F.—is in some instances considered proportional to the durability.

The Ashcroft (see Article 159, page 199) and the Boult (see Article 160, page 200) machines are especially designed for determining the durability of oils—from the former by noting the rise in temperature, from the latter by noting the change in the coefficient of friction. The difficulty of properly making this test no doubt lies in the loss of a very slight amount of oil from the journals, which is sufficient, however, to make the results very uncertain.

<sup>\*</sup>See paper by Professor Denton, Vol. XI., p. 1013, Transactions of American Society of Mechanical Engineers.

159. Ashcroft's Oil-testing Machine.—This machine (Fig. 83) consists of an axle revolving in two brass boxes; the pressure on the axle is regulated by the heavy overhanging counterpoise shown in the engraving. The tendency to rotate is resisted by a lever which is connected to the attached gauge. The gauge is graduated to show coefficient of friction.




FIG. 83.-ASHCROFT'S OIL-TESTING MACHINE.

The temperature is taken by an attached thermometer, and the number of revolutions by a counter, as shown in the figure.

In this machine the weights and levers are constant, the rariables being the temperature and coefficient of friction.

It is used exclusively with a limited supply of oil, the value of the oil being supposed to vary with the total number of revolutions required to raise the temperature to a given degree,—for instance, to 160° F.

160. Boult's Lubricant-testing Machine.—This machine, designed by W. S. Boult of Liverpool, is a modification of

the Thurston oil-tester, yet it differs in several essential features. A general view of the machine is shown in Fig. 84, and a section of its boxes and the surrounding bush in Fig. 85.




FIG. 84.-BOULT'S LUBRICANT-TESTER.

The machine is designed to accomplish the following purposes: 1. Maintaining the testing journal at any desired temperature. 2. Complete retention on the rubbing surfaces of the oil under test. 3. Application of suitable pressure to the rubbing surfaces. 4. Measurement of the friction between the rubbing surfaces.

To secure the complete retention of the oil, a complete bush with internal flanges is used instead of the brasses employed in

other oil-testing machines. the inside of the bush is an expanding journal, DD, Fig. 85, the parts of which are pressed outward against the surrounding bush by the springs E, or they may be drawn together by the set-screws BB, compressing the springs E. A limited amount of oil is fed from a pipette or graduated cylinder on the journal, with the bush removed. This oil, it is claimed. will be maintained on the outer surface of the journal and on the interior surface of the metallic bush, so that it may be used to destruction. The bush is hollow. and can be filled with water, oil. or melting ice and brine.

or melting ice and brine.

The oil to be tested can be FIG. 85.—SECTION OF BOULT'S LUBRICANTmaintained at any desired temperature by a burner, F, which heats the liquid CC in the surrounding bush. The temperature of the journal can be read

The friction tends to rotate the bush; this tendency is resisted by a lever connected by a chain to an axis carrying a weighted pendulum, G, Fig. 84.

by a thermometer whose bulb is inserted in the liquid CC.

The motion of the pendulum is communicated by gearing to a hand, passing over a dial graduated to show the total friction on the rubbing surfaces.

The formulæ for use of the instrument would be as follows: Let f equal coefficient of friction; G the weight of the bob on the pendulum, R its lever arm;  $\alpha$  the angle made by the pendulum with the vertical; a the length of the connecting lever; c the radius of the axis to which the pendulum is attached; r the radius of the journal; A the projected area of the journal; P the total pressure on the journal. Then

$$\frac{a}{r} \cdot \frac{R}{c} \cdot G \sin \alpha = fAP,$$

from which

$$f = \frac{aGR \sin \alpha}{rcAP} = \frac{\sin \alpha}{P}$$
, (constant.)

In this instrument the total pressure P is usually constant and equal to 68 lbs., so that the graduations on the dial must be proportional to  $\sin \alpha$ .

If the graduations are correct, the coefficient is found by dividing the readings of the dial by P (68 lbs.). The work of friction is the product of the total space travelled into the total friction, and this space in the Boult instrument is two thirds of a foot for each revolution, or two thirds of the number of revolutions.

The instrument cannot be used with a constant feed of oil, nor can the pressures be varied except by changing the springs E.

- 161. Directions for Durability Test of Oils with Boult's Oil-testing Machine.—To fill cylindrical oil-bath, take out the small thumb-screw in cylindrical bath and insert a bent funnel. Pour in oil—any sort of heavy oil may be used—until it overflows from the hole in which funnel is inserted, and replace thumb-screw.
- I. See that the friction surfaces are perfectly clean. These can be examined by tightening the set-screws in order to depress the spring. This will enable the cylindrical bath to be lifted away. After seeing that the surfaces are perfectly clean, pour on a measured quantity of the lubricant to be tested, and reset the cylinder-bath in position. Slacken set-screws so as to allow the spring to have full pressure. The set-screws should not be removed entirely when slackening.

- 2. Light the Bunsen burner.
- 3. The thermometer indicates the temperature to which the lubricant has to be subjected in the steam-cylinder, being graduated in degrees Fahrenheit, and their equivalent in pounds pressure. Thus, if the working steam-pressure is 60 lbs., the thermometer shows that the heat of steam at that pressure is 307° Fahr.; whilst at 100 lbs. pressure its temperature is 358° Fahr., etc. Run the tester, say, until there is a rise of 50 per cent; in some cases it is preferable to run the tester until there is a rise of 100 per cent of the friction first indicated. There does not appear to be any advantage in going beyond this, as the oil is then practically unfit for further use, and there is danger of roughening the friction surfaces.
- 4. When it is considered desirable to ascertain the distance travelled by the friction surfaces during a test, read off the counting-indicator before and after the test, and subtract the lesser from the greater total, and the difference will represent the number of revolutions made during the test. As the friction surfaces travel two thirds of a foot during each revolution, the number of feet travelled is arrived at by simply deducting from the number of revolutions made, one third thereof.

The value of the oil is proportional to the number of feet travelled by the rubbing surfaces.


The speed at which the tester should be run should be about five to six hundred revolutions per minute. For quick-speed engine-oil the speed may be increased to about a thousand per minute.

162. Experiment with Limited Feed.—The object of this experiment is to ascertain the variation in the coefficient of friction due to a change in the rate of feed.

The experiment is to be made with the feeding apparatus arranged so that the supply can be regulated. Different runs are made with different rates of feed, and the variation in the coefficient of friction determined. Fig. 80, p. 191, represents the Thurston R. R. Lubricant tester as arranged for the experiment, with a constantly diminishing rate of feed, by Professor G. W. Bissel. In this case oil is obtained by the siphon

M from the burette N, and conveyed by the candle-wicking P to a copper rod H inserted in the bearings. The rate of flow will depend upon the height of the oil in the burette N above the end of the siphon-tube M, and as the head gradually diminishes from loss of oil, the rate of flow will decrease.

The quantity of oil used is to be determined by graduations on the burette. The increase in coefficient of friction due to the constantly diminishing rate of feed is shown in Fig. 86, the coefficients of friction being shown by the dotted lines, corresponding to a given rate of feed and a given time in minutes.



The experiment with head and feed maintained constant during each run would represent very closely the usual conditions of supplying lubricants.

In this case, provided there was no loss of oil from the journals, the experiment might show—

- 1. The laws of friction for ordinary lubrication.
- 2. The most economical rate of feed for a given lubricant.

3. The value of the lubricants on the joint basis of amount consumed and coefficient of friction.

A few tables showing coefficients of friction which has been obtained in various trials are given in the Appendix for reference.

163. Forms for Report.—The following are the forms used in Sibley College for data and results of lubricant test:

### REPORT OF LUBRICANT TEST.

									· · • • • • • • •
Mark		•••••	Lab.	No		Date	:	• • • • • •	• • • • • • • •
Sourc	e	• • • • • • • •		• • • • • • • •	• • • • •	Obser	ver	• • • • • •	• • • • • • • •
Inves	tigation.	••••	•••••	••••••	••••	• • • • • • •	• • • • • • • • • • • • • • • • • • • •	• • • • • •	••••••
				sa. iach					
Total	pressure	e on jour	nal, lbs.	<del>.</del>				• • • • • •	
Amou	ant of oi	l used on	journa	l, m. g	••• •••	• • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	• • • • • •	• • • • • •
Minir	num coeu	fficient of	friction.	n					
No. o	f revolu	tions	. <b></b>						
				ng surface					
Ficas	tion of t	emperati	re		••• •••	•••••	••••	• • • • • •	
						i			
Time. Min- utes.	Total Revolu- tions.	Temper- ature.	Read- ing on Arc.	Coeffi- cient of Friction,	Time. Min- utes.	Total Revolu- tions.	Temper- ature.	Read- ing on Arc.	Coefficient of Friction.
				_					
				ND RES					
Kind	of oil	• • • • • • • •		• • • • • • •	••••	Date			.189
Recei	ived from	n				· • • • • • •	• • • • • • •		• • • • • • •
Color				• • • • • •			Ash		%
Speci	fic gravit	<b>y</b>		•••••	B.		Tar		%
•	"						Chill-pt		° F.
Flash	ing pt						r 3 hrs		%
	• •	• • • • • • •					-		
		.,	. = •					כיד כ	

## VISCOSITY TEST.

No.	Time of	Flow of 100 c.c. i	Temperature	Lubricating Value Lard-oil						
	Sample.	Lard-oil.	Water.	Temperature Degrees F.	value Lard-oil					
		.								
			1							

# RESULTS OF FRICTION TEST.

Date.	· · · · I. · · · ·							II.								-	III. · ·										• -			_	_								
189 .	Temp.		Ārc.				Temp.												Arc.					Average.															
Highest reading Lowest reading Average reading Drops per min	1		_	_	_	-		-		_	1			_	_	١	-	_			-	_	_	_	_	-	_		_	_	1	_	_	_	_	_	_	_	_
Highest reading	ŀ	•	• •	•	•	ŀ	•	•	• ,	• •	1		٠.•	•	•	1	•	• •	•	•	٠١	•	• •	•	٠	٠	•	• •	•	•	٠١	• •	•	•	• •	•	•	٠,	• •
Lowest reading	ŀ	•	• •		•	ŀ	٠.	٠	•		I		•.•	•	•	٠Į			•	• •	٠١	•		•	•	٠	•		•	•	٠١	٠.	٠	•		. •	•	٠.	•
Average reading	١.					ı.					1					.J					٠l					٠					٠.								
Drops per min	١.					ľ.					1		٠.			. 1					١.					١.						٠.							
Time of run, min	١.					l.					.[					.1	:				. 1					١.					.								
Speed: Rev. per min Miles per hour	1					ŀ	•	•	_		١	•				١					١										1							•	
Miles per hour	Ι.	•	•	• •	3	ı.	•	•	•	• •	1	•	•	•	•	١.	•	• •	٠.	•	.	•	• •	•	•	•	•	• •	•	•	١.	••	•	•	• •	•	٠	•	•
Pressure:	1	•	•	•	•	١.	•	•	•	• •	١	•	٠.	•	•	١.	•	• •	•	•	١.	•	• •	•	•	٠,	•	• •	•	•	١.	•	•	•	٠.	•	•	• •	•
Total lbs	1										ı					1					ı										1								
lotai ibs	١.	•	• •	•	•	ŀ	•	•	•	• •	1	•	• •	•	٠	۰	•	• •	•	•	٠I	•	• •	•	٠	٠	٠	• •	•	٠	٠	٠.	•	•	٠.	•	٠	•	٠
Per sq. in., lbs	١.			٠.		ŀ					.					٠l					٠ ا										٠l	٠.							
Coefficient of friction	1.					ı.					١.					١.					١.										ı١	٠.							
	1					ľ					1					1									-		ľ		-						•				

### TEST FOR RESINS.

Flow on plane inclined	.degrees.
Kind of plane	
Time in hrs., Sample, Lard-oil	l Water
*** ** * * * * * * * * * * * * * * * * *	
••	

#### CHAPTER VII.

# MEASUREMENT OF POWER—DYNAMOMETERS—BELT-TESTING MACHINES.

164. Classes.—Dynamometers are instruments for measuring power. They are of two classes: I. Absorption; 2. Transmission. In the first class the work received is transformed by friction into heat and dissipated; in the second class the dynamometer absorbs only so much force as is necessary to overcome its own friction, the remainder being transmitted.

165. Absorption Dynamometer.—The Prony Brake.\*— The Prony brake is the most common form of absorption dynamometer. This brake is so constructed as to absorb the work done by the machine in friction, this friction being produced by some kind of a surface connected to a stationary part, and which rubs on the revolving surface of the wheel with which it is used. The brake usually consists of a portion which can be clamped on to a wheel (see Fig. 87, page 211), with more or less pressure, and an arm or its equivalent. The part exerting pressure on the wheel is termed the brakestrap; the perpendicular distance from the line of action of the weight, G, to the centre of the wheel is termed the arm of the brake. The brake is prevented from turning by a definite load which we term G, applied at a distance equal to the length of the arm (a) from centre of motion. The work of resistance would then evidently be equal to the product of the weight of resistance, G, into the distance it would pass through

<sup>\*</sup>See Engine and Boiler Trials, by R. H. Thurston, page 157; Mechanics of Materials, by I. P. Church, page 269; Du Bois' Weisbach's Mechanics of Engineering, page 13.

if free to move. If n be the number of revolutions per minute, the horse-power shown by the brake would evidently be

$$2\pi Gan \div 33000.$$
 . . . . . (1)

Brakes are made with various rubbing surfaces, and with various devices to maintain a constant resistance.

166. Stresses on the Brake-strap.—Formulæ.—The strains on the brake-strap are essentially the same as those on a belt, as given in Article 128, page 173.

That is, if  $T_1$  represent the greatest tension,  $T_2$ , the least tension, c the percentage that the arc of contact bears to the whole circumference, N the normal pressure, F the resistance of the brake, f coefficient of friction,

$$T_1 - T_2 = F$$
;  $N = F \div f$ ;

$$\frac{T_1}{T_2} = 10^{2.788/c} = \text{Number whose log is } 2.7288 fc = B.$$

$$T_1 = \frac{FB}{B-1} \dots \dots \dots (2)$$

167. Designing a Brake.\*—The actual process of designing a brake is as follows: There is given the power to be absorbed, number of revolutions, diameter and face of the brake-wheel. In case a special brake-wheel is to be designed, the area of bearing surface is to be taken so that the number obtained by multiplying the width  $\boldsymbol{w}$  of the brake in inches by the velocity of the periphery  $\boldsymbol{v}$  of the wheel in feet per minute, divided by

<sup>\*</sup>See "Engine and Boiler Trials," by R. H. Thurston, pages 260 to 282; also, "Friction and Lubrication."

the horse-power H, shall not exceed 500 to 1000.\* Call this result K. Then

$$K = \frac{wv}{H}$$
.

400 to 500 is considered a good average value of K.

The value of the coefficient of friction f should be taken as the lowest value for the surfaces in contact (see table of coefficient of friction in Appendix). This coefficient is about 0.2 for wood or leather on metal, and about 0.15 for metal on metal.

Let H be the work to be transmitted in horse-power, n the number of revolutions of the brake-wheel, D its diameter; then the resistance F of the brake must be

$$F = \frac{33000H}{\pi Dn}. \quad . \quad . \quad . \quad . \quad (4)$$

The arc of contact is known or assumed, and may be expressed as convenient (see Article 128) in circular measure  $\theta$ , degrees  $\alpha$ , or in percentage of the whole circumference c.

Example.—Assume the arc of contact as 180 degrees (c = 0.5), the diameter of brake-wheel 4 feet, coefficient of friction (f = 0.15), face of brake-wheel 10 inches, revolutions 90, horse-power 70. Find the safe dimensions of the brake-strap and working parts of the brake.

Then, from page 208,

$$B = 10^{2.7288/c} = 10^{0.2046}$$

That is, B equals the number whose logarithm is 0.2046; or,

$$B = 1.602$$
.

<sup>\*</sup> See also "Engine and Boiler Trials," by R. H. Thurston, pp. 272 and 279.

Thus if the brake-wheel is 4 feet diameter revolving at 90 revolutions per minute: from equation (4)

$$F = \frac{(33000)(70)}{(\pi)(4)(90)} = 2043$$
 pounds.

Taking B as above, and substituting in equations (2) and (3), we have

$$T_1 = 2043 \left(\frac{1.602}{.602}\right) = 5436;$$
  
 $T_2 = \frac{2043}{.602} = 3395;$   
 $N = \frac{2043}{.15} = 13620.$ 

From the value of  $T_1$ , the maximum tension, we compute the required area of the brake-straps, using 10,000 pounds as the safe-working strain.

Section of brake-straps =  $5436 \div 10000 = 0.55$  square inch. The assumed width of brake-wheel is 10 inches; this gives for the value of K, by equation page 209.

$$K = (10)(1132) \div 70 = 162$$
; a low value.

If it is proposed in this brake to use 3 straps, each 2 inches wide, the thickness will then be

$$0.55 \div 6 = 0.001$$
 inch.

To determine a convenient length of the brake-arm, consider equation (1) for work delivered in horse-power.

$$H=2\pi Gan \div 33000.$$

By dividing both terms by  $2\pi$ ,

$$H = Gan \div 5252;$$


$$\frac{G}{H} = \frac{5252}{GR}.$$

168. Brake Horse-power.—The following table will often be convenient for determining the delivered horse-power from a brake.

HORSE-POWER	PER TO	o REVOLUTIONS	FROM A	BRAKE.
TIONSE'I OWEN		O VEACECITORS	I KOM A	DAARE.

Length of Brake-arm, feet.	Factor to multiply scale-reading to give horse-power, $H + G$ .	Ratio of scale-reading to horse-power, $G+H$ .
I	0.019	52.52
2	.038	26.26
3	057	17.51
4	.076	13.13
5 5.252	.090 .100 .114	10.50 10.00 8.75
7	.133	7.50
8	.152	6.56
9	.172	5.83
10.504	.200	5.00

169. Different Forms of Prony Brakes.—Various forms of brakes are made. Fig. 87 shows a very simple form of



Prony brake, in which the rubbing surfaces are made by two wooden beams clamped together by the bolts CC. Weight is applied to the arm E at the point G; the stops DD prevent a great range of motion of the arm; the projection F is used to hang on sufficient counterbalance to prevent the brake from

revolving by its own arm-weight when the screws C C are very loose. The net load acting on the brake-arm is the difference between the weight at G and that at F, reduced to an equivalent weight acting at G.

Brakes are usually constructed by fastening blocks of wood, on the inside of flexible bands of iron, so as to encircle a wheel. The inside of the blocks should be fitted to the wheel, and the spaces between the blocks should be at least equal to one third the area of the block. The iron bands are connected to the brake-arm in such a manner that the tension on the wheel can readily be changed. The form of such a brake is shown in Fig. 88 attached to a portable engine.




FIG. 88.—BRAKE APPLIED TO PORTABLE ENGINE.

170. Strap-brakes.—Brakes are sometimes made by taking one or more turns of a rope or strap around a wheel, as shown




FIG. 89.—STRAP-BRAKE.

in Fig. 89. In this case weights must be hung on both sides, and since the arm of action is equal, the resultant force acting is the difference between the two weights: that is, in the figure the resultant force is A-B; the equivalent space passed through is the distance travelled by any point of the circumference of the wheel in a given time. The work done is the product of these quantities.

171. Self-regulating Brakes.—Brakes with automatic regulating devices are often made; in this case the direction of motion of the wheel must be such as to lift the brake-arm. If the tension is too great the brake-arm rises a short distance, and this motion is made to operate a regulating device of some

sort, lessening the tension on the brakewheel; if the tension is not great enough, the brake-beam falls, producing the opposite effect.

172. Brake with oblique Arm.—A very simple form of self-regulating brake is shown in Fig. 90: in this case the arm is maintained at an angle with the horizontal. If the friction becomes too great, the weight G rises, and the arm of the brake swings from A to E, thus increasing the lever-arm from BC to LC; if





Fig. 90.—Self-regulating Brake.

the friction diminishes, the lever-arm is correspondingly diminished, thus tending to maintain the brake in equilibrium.

173. Alden Brake.—The Alden brake see (Figs. 91 to 94) is an absorption dynamometer in which the rubbing surfaces are separated by a film of oil, and the heat is absorbed by water under pressure, which produces the friction. It is constructed by fastening a disk of cast-iron, A, Fig. 91, to the power-shaft; this disk revolves between two sheets of thin copper E E joined at their outer edges, from which it is separated by a bath of oil. Outside the copper sheets on either side is a chamber which is connected with the water-supply at G. The water is received at G and discharged at H, thus maintaining a moderate temperature. Any pressure in the chamber causes the copper disks to press against the revolving plate, producing friction which tends to turn the copper disks. As these

are rigidly connected to the outside cast-iron casing and brakearm P, the turning effect can be balanced and measured the same as in the ordinary Prony brake. The pressure of water is automatically regulated by a valve V, Fig. 94, which is par-



tially closed if the brake-arm rises above the horizontal, and is partially opened if it falls below; this brake with a constant head gives exceedingly close regulation.

174. Hydraulic Friction-brake.—The author has designed a hydraulic friction-brake that can be applied to the surface of an ordinary brake-wheel. The brake consists of a tube of copper with an oval or rectangular cross-section, which very nearly encircles the brake-wheel, and has both ends closed. The greatest dimension in its cross-section is equal to the width of the brake-wheel, and its least dimension is one half to three fourths of an inch. One end of the tube is connected with the water-supply, the other to the discharge, which can be throttled as required. Outside is a band of iron completely encircling the tube and the brake-wheel, and held rigidly together by means of bolts. To this band is fastened the brake-arm, and also one end of the copper tube. When water-pres-

MEASUREMENT OF POWER.

§ 176.]

sure is applied to the tube, it tends to assume a round cross-section, the shorter diameter increasing and the greater diameter diminishing. As these changes cannot take place because of the outer band of iron, pressure is exerted on the surface of the brake-wheel, and motion of the brake-wheel tends to revolve the tube and band of iron. This is resisted by the weight on the arm of the brake. The water-pressure is regulated automatically by a slight motion of the brake-arm, which closes or opens the supply-valve as is required. The arm may be permitted to act downward on a pair of scales, by interposing a spring of the requisite stiffness between it and the platform of the scales. To prevent wear of the copper tube thin sheets of iron may be interposed. A lubricant is applied by means of lubricators fixed near the ends of the tube.

175. Removal of the Heat generated by the Brake.—Various devices have been adopted to secure the removal of the heat. One method is to cast the outer rim of the brake-wheel hollow, and connect this by a tube with a cavity in the centre of the axis, so that water can be received at one end of the axis and discharged at the other. Another way is to leave a deep internal flange on the brake-wheel, and in using the brake, to supply water by means of a crooked pipe on one side and to scoop it out by a pipe with a funnel-shaped mouth bent to meet the current of water near the opposite side of the wheel. Water is sometimes run on to the surface through a hose, but aside from the inconvenience due to flying water, if any of the rubbing surfaces are of wood it is likely to make sudden and irregular variations in the coefficient of friction that are difficult to control.

176. Applying Load.—In applying the load, care must be taken that its direction is tangent to the circle that would be described by the brake-arm were it free to move. In other words, the virtual brake-arm must be considered as perpendicular to this force. If a vertical load or weight is applied, the brake-arm must be horizontal, and equal in length to the distance from this vertical line to the centre of the motion.

36

It will be found in general safer and more satisfactory to have the motion of the brake-wheel such as to produce a downward force, which may be measured by a pair of scales, rather than the reverse, which requires a weight to be suspended on the brake-arm. There should be a knife-edge between the brake-arm and the load; in case of downward motion, the support upon the scales, should be made the proper length to hold the brake-arm horizontal.

177. Constants of Brake.—All brakes with unbalanced arms have a tendency to turn, due to weight of the arm. This amount must be ascertained and added to or taken from the scale or load readings as required by the rotation, in order to give the correct load. To ascertain this amount, the brake may be balanced on a knife-edge, with a bearing point directly over the centre of the wheel, and the correction to the weight obtained by readings on the scale. It is obtained more accurately by making the brake loose enough to move easily on the wheel; then apply a spring-balance at the end of the arm; first pull the arm upward through an arc of about 3° either side of its central position, moving it very slowly and gradually: the reading will be the weight plus the friction. Then let it back through the same arc very slowly and gradually, and the reading will be the weight less the friction. The sum of these two results will be twice the correction for the brake-arm. this three times for an average result. In case the friction is greater than the weight this second result will be negative, but the method will remain the same.

The weight of the brake, as generally mounted, is carried on the main bearings of the wheel, from which the power is obtained, and virtually increases its weight. This may in some instances increase perceptibly the friction of the journals of the wheel, but is generally an imperceptible amount. This weight can be reduced when desired, by a counterbalance connected to the brake by means of guide-pulleys.

- 178. Directions for Using the Prony Brake.—1. See that the brake-wheel is rigidly fastened to the main shaft.
  - 2. Provide ample means of lubrication.

- 3. If the brake-wheel has an internal rim, provide means for supplying and removing water from this rim.
- 4. Find the equivalent weight of brake-arm to be taken from or added to the load, depending on the direction of motion of the wheel.
- 5. In applying the load, tighten the brake-strap very slowly, and give time for the friction to become constant before noting readings of the result.
- 6. Note the time, number of revolutions, length of brakearm, corresponding load, and calculate the results.
- 179. Pump Brakes.—A rotary pump which delivers water through an orifice that can be throttled or enlarged at will, has been used with success for absorbing power.

If the casing of the pump is mounted so as to be free to revolve, it can be held stationary by a weighted arm, and the absorbed power measured, as in the case of the Prony brake. If the casing of the pump is stationary, the work done can be measured by the weight of water discharged multiplied by the height due to the greatest velocity of its particles multiplied by a coefficient to be determined by trial.\*

A special form of the pump-brake, with casing mounted so that it is free to revolve, has been used with success on the Owens College experimental engine by Osborne Reynolds. In this case the brake is practically an inverted turbine, the wheel delivering water to the guides so as to produce the maximum resistance. The water forced through the guides at one point is discharged so as to oppose the motion of the wheel at another point.

180. Fan-brakes.—A fan or wheel with vanes revolved in water, oil, or air will absorb work, and in many instances forms a valuable absorption-dynamometer.

The resistance to be obtained from a fan-brake is expressed by the formula †

$$Rl = lKDA \frac{V^*}{2g'}$$

<sup>\*</sup> See Rankine, Machinery and Mill-work, page 404.

<sup>†</sup> Ibid., page 406.

in which RI equals the moment of resistance, V the velocity in feet per second of the centre of vane, A the area of the vane in square feet. I equals the distance from centre of vane to axis in feet, D the weight per cubic foot, of fluid in which the vane moves, K a coefficient, found by experiment by Poncelet to have the value

$$K = 1.254 + \frac{1.6244 \sqrt{A}}{l - s},$$


in which s is the distance in feet from the centre of the entire vane to the centre of that half nearest the 'axis. When set at an angle i with the direction of motion the value for RI must be multi-

plied by 
$$\frac{2 \sin^2 i}{1 + \sin^2 i}$$
.


181. Traction-dynamometers.—Dynamometers for simple traction or pulling are usually constructed as in Fig. 95. Stress is applied at the two ends of the spring, which rotates a hand in proportion to the force exerted.



FIG. 95.-DYNAMOMETER FOR TRACTION.



Recording Traction-dynamometers.—These are constructed in various forms. Fig. 96 shows a simple form of a recording traction-dynamometer, designed by C. M. Giddings. Paper is placed on the reel A, which is operated by clock-work; a pencil is connected at K to the band, and this draws a diagram, as shown in Fig. 97, the ordinates of which represent pounds



of pull, the abscissæ the time. The drum may be arranged to be operated by a wheel in contact with the ground: then the abscissa will be proportional to the space, and the area of the diagram will represent work done.

182. General Types of Transmission-dynamometers.\*

—Transmission-dynamometers are of different types, the object in each case being to measure the power which is received without absorbing any greater portion than is necessary to move the dynamometer. They all consist of a set of pulleys or gear-wheels, so arranged that they may be placed between the prime movers and machinery to be driven, while the power that is transmitted is generally measured by the flexure of springs or by the tendency to rotate a set of gears, which may be resisted by a lever.

183. Morin's Rotation-dynamometer.—In Morin's dynamometer, which is shown in Fig. 97a, the power is transmitted through springs, FG, which are thereby flexed an amount proportional to the power. The flexure of the springs is recorded on paper by a pencil z (astened to the rim of the

<sup>\*</sup>See Thurston's Engine and Boiler Trials, page 264; also Weisbach's Mechanics, Vol. II., pages 39-73; also Rankine's Steam-engine, page 42.

wheel. A second pencil is stationary with reference to the frame carrying the paper. The paper is made to pass under the pencil by means of clock-work driven by the shafting, which can be engaged or disengaged at any instant by operating the lever R. The springs are fastened at one end rigidly to the main axle, which is in communication with the prime mover, and at the other end to the rim of the pulley, which otherwise is free to turn on the main shaft. The power is taken from this last pulley, and this force acts to bend the




FIG. 97a.-MORIN ROTATION-DYNAMOMETERS.

springs as already described. In the figure A is a loose pulley B is fixed to the shaft.

The autographic recording apparatus of the Morin dynamometer consists essentially of a drum, which is rotated by means of a worm-gear, UK, cut on a sleeve, which is concentric with the main axis. This sleeve slides longitudinally on the axis, and may be engaged with or disengaged from the frame at any instant by means of a lever. When this sleeve is engaged with the frame and made stationary the recording apparatus is put in motion by the concentric motion of the gearing, SV, with respect to the axis. The pencil attached to the spring will at this instant trace a diagram on the paper whose ordi-

nates are proportional to the force transmitted. The rate of rotation of the drums carrying the paper, with respect to the main axis, is determined in the same manner as though the gears were at rest—by finding the ratios of the radii of the respective wheels. Thus the amount of paper which passes off from one drum on to the other can be proportioned to the space passed through, so that the area of the diagram may be proportional to the work transmitted.

To find the value of the ordinates in pounds the dynamometer must be calibrated; this may be done by a dead pull of a given weight against the springs, thus obtaining the deflections for a given force; or, better, connect a Prony brake directly to the rim of the fixed pulley B, and make a series of runs with different loads on the brake, and find the corresponding values of the ordinates of the card.

- 184. Calibration of the Morin Dynamometer.—Apparatus.—Speed-indicator, dynamometer-paper, and Prony brake.
- 1. Fasten paper on the receiving drum, wind off enough to pass over the recording drum, and fasten the end securely to the winding drum. See that the gears for the autographic apparatus are in perfect order, and that both pencils give legible lines. Adjust the pencil fixed to the frame of the clock-work, so that it will draw the same line as the movable pencil, when no load is applied.
- 2. With the apparatus out of gear apply the power. Take a card with no load. This card will be the friction work of the dynamometer.
- 3. Apply power and load, take cards at intervals: these cards will represent the total work done. This, less the friction work, will be the power transmitted. The line traced by the pencil affixed to the frame of the clock-work must in all cases be considered the zero-line, or line of no work.
- 4. To calibrate the dynamometer, attach a Prony brake to the same shaft and absorb the work transmitted. This transmitted work must equal that shown by the Prony brake. Find constants of brake as explained Article 177, page 178.
  - 5. Draw a calibration-curve, with pounds on a brake-arm,

reduced to an equivalent amount acting at a distance equal to the radius of the driving-pulley of the dynamometer, as abscissæ, and with ordinate of the diagram as ordinate. Work up the equation of this curve.

- 6. In report of calibration make record of time, number of revolutions brake-arm, equivalent brake-load for arm equal to radius of dynamometer-pulley, length of ordinate, scale of ordinate. Describe the apparatus.
- 7. In using it, insert it between the prime mover and resistance to be measured. Determine the power transmitted from the calibration.
- 185. Form of Report.—The following form is useful in calibrating this dynamometer:

#### CALIBRATION OF MORIN DYNAMOMETER.

Weig Radi	ht of bus of d	rake-arr riving-p	n	lbs.	Zero-re Observe	eading	of scal	es			
	1			18	, 						
No.	Up.	Down.		Effective Brake-load, lbs.	Equivalent Load on Driving- pulley, ibs.	Up.	Down.	<del></del>	Brake H. P.		
	Remari	<u> </u>		Fanatio	n of Curve						
	Venn <b>a</b> Li	-		•	Y						

186. Steelyard-dynamometer.—In this dynamometer the pressure of the axle of a revolving shaft is determined by shifting the weight G on the graduated scale-beam AC.

The power is applied at P, putting in motion the train of gear-wheels, and is delivered at Q.

Denote the applied force by P, the delivered force by Q,

the radius KM by a, KE by r, LF by r, NL by b, the force delivered at E by R, that at F by R,.

We shall have

$$Rr = Pa$$
, also  $R_1r_1 = Qb$ .

But

$$R(ED) = R_1(FD);$$

and since


$$ED = FD$$
,

$$R=R_{1}$$

The resultant force  $Z = R + R_1 = 2R$ .

$$\therefore R = \frac{1}{2}Z; \qquad P = \frac{1}{2}Zr \div a; \qquad Q = \frac{1}{2}Zr, \div b.$$

If we know the number of revolutions, the space passed through by each force can be readily calculated, and the work found by taking the product of the force into the space passed through.



Consideration of Friction.—The friction of the axle and gear-teeth will increase the force R and decrease the force R, Let  $\mu$  be the experimental coefficient expressing this friction. Then

$$P = \frac{1}{2}(1 + \mu)Zr \div a;$$

$$Q = \frac{1}{2}(1 - \mu)Zr_1 \div b;$$

$$\mu = \frac{Par_1 - Qbr}{Par_1 + Qbr}.$$

187. Pillow-block Dynamometer.—The pillow-block dynamometer operates on the same principle as the steelyard




Fig. 97c.—Pillow-block Dynamometer.

dynamometer, but no intermediate wheel is used. This dynamometer, shown in Fig. 97c, consists of the fixed shaft L, which is rotated by the power Q applied at N. The power rotates the gear-wheel EL, which communicates motion to the wheel KE on the same shaft with the wheel KM. This shaft is sup

ported on a pair of weighing-scales so that the downward force Z acting on the bearing can be weighed. Let P equal the force delivered, let  $\alpha$  equal the angle this force makes with the horizontal, let KM equal  $\alpha$  and KE equal r; G equal the weight of shaft and wheel. The weight on the pillow-block at K must be

$$Z = G + P \sin \alpha + \frac{a}{r}P = G + P\left(\sin \alpha + \frac{a}{r}\right)$$

From which

$$P = \frac{Z - G}{\sin \alpha + \frac{a}{2}}$$

When the belt is horizontal,

$$\alpha = 0$$
 and  $P = (Z - G)^{\alpha}$ 

188. The Lewis Dynamometer.\*—This transmission-dynamometer is a modified form of the pillow-block dynamometer, arranged in such a manner that the friction of the gearing or journals will not affect the reading on the weighing-scales. This dynamometer is shown in Fig. 97d, and also in Fig. 97k, Article 195, page 237. The dynamometer consists of two

<sup>\*</sup> See Vol. VII., page 276, Trans. Am. Society Mechanical Engineers.

gear-wheels A and C, whose pitch-circles are tangent at B; the gear-wheel A is carried by the fixed frame T, the wheel C is carried on the lever BD: the lever BD is connected to the fixed frame T by a thin steel fulcrum, as used in the Emery Testing-machines (Article 67, page 87). The point D, the centre of wheel C, and the fulcrum are in the same right line. The fulcrum B permits vertical motion only of the point D. The point D rests on a pillar, which in turn is supported by a pair of scales. The shaft leading from the wheel C is furnished with a universal joint (see Fig. 97k), so that its weight does not affect that on the journal C. In Fig. 101, A is the




FIG. 97d.—THE LEWIS DYNAMOMETER.

driving and C the driven wheel, the force to be measured being received on a pulley on the shaft a, transmitted through the dynamometer, and delivered from a pulley on the shaft c. From this construction it follows, that no matter how great the friction on the journals of the shaft c, there will be no pressure at the point D except what results from torsion of the shaft c. This will be readily seen by considering:

1. That any downward force acting at B will be resisted by the fixed frame T, and will not increase the pressure at D.

2. A downward force acting on the lever between B and D will produce a pressure proportional to its distance from B.

3. If the driven wheel C were firmly clamped to its frame, no force acting at B would change the pressure at D; and since

journal-friction would have the effect of partially clamping the wheel to the journal c, it would have no effect on the scale-reading at D.

Denote the transmitted torsional force by Z; the radius of the driven pulley by r; the length of lever BD by a; the scale-reading at D by W. Then from equality of moments

$$Wa = Zr$$
,  $Z = \frac{Wa}{r}$ 

The effective lever-arm BD is to be obtained experimentally as follows: Disconnect the universal joint, shown in Fig. 108, so as to leave the wheel C, free to turn; block the driving-pulley A; fasten a horizontal arm, ef (dotted lines, Fig. 101), to the shaft c, parallel to the line DB and carrying a weight G; balance the scales in this position, then move the weight out on the lever, until the reading of the scales is increased an amount equal to the weight moved. The distance moved by the weight will equal length of the lever DB.

Thus let ef, shown in dotted lines, represent the lever clamped to the axis c; let e represent the first position of the weight G, and f the second position; let W and W' represent the corresponding scale-readings, after balancing scales without G on the lever, ef.

Then we have

$$W=G^{(eB)}_{\overline{DB}};$$

$$W + G = W' = G\frac{(fB)}{DB}.$$

Hence

$$G = \frac{W' - W}{DB} = G\frac{(fB - eB)}{DB} = G \cdot \frac{ef}{DB}.$$

Then will

$$DB = ef.$$

189. The Differential Dynamometer.—This is often called the Bachelder, Francis, or Webber dynamometer; was invented by Samuel White, of England, in 1780, and brought to this country by Mr. Bachelder in 1836.

The dynamometer portion consists of four bevel-gears, shown in plan in Fig. 97e.

Power is applied to the pulley M, which carries the bevel-




FIG. 976.-THE DIFFERENTIAL DYNAMOMETER.

wheel  $EE_1$ ; the resistance is overcome by the pulley N, which carries the bevel-wheel  $FF_1$ . Both wheels run loosely upon the fixed shaft  $XX_1$ , and are connected by the wheels EF and  $E_1F_1$ . By the action of the force P and the resistance Q, the pressure of the wheels  $EE_1$  and  $FF_1$  is downward at E and F, and upward at  $E_1$  and  $F_1$ , tending to swing the lever  $GG_1$  around the axis  $XX_1$ , one half as fast as the pulley M. The weight which holds the lever-arm stationary, multiplied by the space it would pass through if free to move, is the measure of the work of the force P. A dashpot is usually attached to the lever  $GG_1$  at  $G_1$ , to lessen vibrations and act as a counterbalance. Let Z equal the vertical force acting at B and  $B_1$ ; R, the vertical pressure between the teeth at each point of contact; b, the distance of B and  $B_1$  from the centre C; a, the distance, AC, to the weight.

Then we have evidently

$$2Z = 4R$$
, or  $Z = 2R$ ;

also

$$Ga = 2Zb = 4Rb$$
.

If a' is the radius of the driving-pulley M, and r the radius of each bevel-gear,

$$Pa' = 2Rr$$
, or  $P = \frac{2Rr}{a'} = \frac{G}{2} \frac{r}{b} \frac{a}{a'}$ .

If friction is considered,

$$P = (\mathbf{1} + \mu) \frac{G}{2} \frac{r}{b} \frac{a}{a'}.$$

The mechanical work received is equal to P multiplied by the space passed through in the given time.

This instrument has been improved by Mr. S. Webber, as shown in Fig. 97f.



FIG. 97/.-THE WEBBER DYNAMOMETER.

These dynamometers are used in substantially the same way as the Morin dynamometers.

- 190. Calibration of the Differential Dynamometer.—
  1. See that it is well oiled, in good condition, its axis horizontal, and also that the weighing arm is horizontal for no load.
- 2. Observe constants of the apparatus; obtain weight of small poise; of large poise; of amount to balance beam  $W_{\epsilon}$ . Measure the arm of each, and calculate the foot-pounds per 100 revolutions corresponding to weights and graduations.

- 3. Make a preliminary run without load, and note the reading of the poise required to balance the arm. This will determine the friction of the dynamometer without load. Determine the length of the arm, and the value of each subdivision in foot-pounds.
- 4. Attach a strap-brake (see Art. 170, p. 212) to the delivery pulley of the dynamometer, and absorb all the force transmitted. Make a series of ten runs, each ten minutes in length, and during each of which the load on the Prony brake-arm is kept as constant as possible, but which is increased by equal increments, in the different runs. Take observations each minute during the run.
- 5. The difference between the work absorbed by the brake and that shown by the dynamometer should be carefully determined. It is the error of the dynamometer.
- 6. Note whether this error is a constant quantity, or is a percentage of the work delivered.
- 7. In your report, describe the apparatus, give the results of the calibration, and draw a curve, using brake foot-pounds as ordinates, and dynamometer foot-pounds as abscissæ.
- 8. To use the dynamometer insert it between the prime mover and the machinery to be run.

# Special Directions for Calibrating the Webber Differential Dynamometer.

# Apparatus required:

- Ten small tension-weights.
   Spring-balance or platform-scales.
   Measuring-scale.
   Calipers.
   Stop-watch.

  Measurements:
  - a. Weight of small tension-weights.
  - b. " "fixed poise-weights.
  - c. " dynamometer-arm.
  - d. " " sliding poise.
  - e. Length of dynamometer-arm to fixed poise.
  - f. Length of dynamometer-arm to sliding poise.
  - g. Diameter of brake-pulley.
  - h. Thickness of brake-strap.

- I. Friction-run.—Remove brake. Find time, in seconds, of 1000 revolutions (10 rings of bell). Balance dynamometerarm; the reading is the "zero-reading" by the beam, and must be corrected to get the true friction-reading.
- II. Test-runs.—Put on brake; hang one weight on its slack side. Time, 1000 revs. Read simultaneously dynamometer-arm and platform cales. Repeat the same with successive weights added.
- III. To Weigh Dynamometer-arm.—Run by hand, first forward and then backward, weighing in each case the turning effect, with the platform-scale applied at the knife-edge of the dynamometer-arm, and s'iding-poise set at the zero-mark.
- 191. Form of Report.—The following blank is used in the exercises with the differential dynamometer in Sibley College:
  MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNI-

VERSITY.

Calibration of		Differential	Dynamometer.
Kind of Brake used	• • • • • • • • •	****	• • • • • • • • • • • • • • • • • • • •
Length of Brake-armft.	Weight of	Brake-arm	lbs.
Zero-reading of Brake-scales	lbs.	ſ	
Zero-reading of Brake-scales  Date189	Observers -	{	• • • • • • • • • • • • • • • • • • • •

	su s	Brake	tensions, L	bs.	Wo	rk in ft	lbs. per 10	Revolu	tions.	نز
Number.	e of 100 Revolutions.	Tight Side.	Slack Side.	Effective Load.	Observed on Dynamome-ter-beam.	Calculated of from Machine Constants.	Transmitted as shown by Beam, = W.	Obtained from Brake.	Error of the Dynamometer.	Brake Horse-pow
Z Z	Time	<i>T</i> <sub>1</sub>	T <sub>2</sub> T <sub>1</sub>	- T <sub>2</sub>	$W_d$	$W_d W_c W_{d-W_o}$		W <sub>b</sub> W <sub>!</sub> -W		D.H.P.
I										
2				• • • • •	• • • • • •		. <b></b>			• • • • • •
3	ļ. <b></b> .			••••	• • • • • •					• • • • •
4			• • • • • • • • •	••••	• • • • • •		• • • • • • •		····	• • • • •
5		[		• • • • '	• • • • •	•••••				• • • • • •
6	• • • • •		• • • • • • • • • • • • • • • • • • • •	••••	• • • • • •		· • • • • • • • •			
7 8	• • • • •			••••	• • • • •					
-				••••	• • • • • •		•••••			
9				• • • • •	• • • • • •	j		· · · · · ·		· • • • • • • • • • • • • • • • • • • •
10	·····			••••	• • • • •	1		1		

#### CONSTANTS OF MACHINE.

	Moment	Armft.	i	Sliding Weight	Sliding Poise, Weightlbs.		
Loads at Knife-edge.	Weight, lbs.	Value, ft lbs. per 100 Revs.	Data for Beam.	Moment Arm, Feet.	Value, ft lbs. per 100 Revs.		
Large Poise	l		First Notch Last Notch Increase per Notch.	l			
Wo=Zero-reading b	y Beam.	ftlbs.	Wo-We=Friction-	reading=	ftlbs.		

- 192. Emerson's Power-scale.—One of the most complete transmission-dynamometers is shown in Fig. 97g, with attached numbers showing the dimensions of the various sizes manufactured. In this instrument the wheel C is keyed or fastened to the shaft; the wheel B is connected with the wheel C near its outer circumference by projecting studs; the amount of pressure on these studs is conveyed by bent levers to a collar, which in turn is connected with weighing-levers. Small weights are read off from the scale D, and larger ones by the weights in the scale-pan N. A dash-pot is used to prevent sudden fluctuations of the weighing-lever.
- 193. Form of Report.—The following forms for report and log of tests on Webber Dynamometer and Emerson's Power-scale are used by the Massachusetts Institute of Technology.

# 




FIG. 978.—EMERSON'S POWER-SCALES.

					BR	AKE.						
No.	of to	est				1	ī	1		2	1	3
			• • • • • • • •									
$T_1$						<b>.</b>						• • • • •
			brake									• • • • • •
Arc	of c	ontact					•					• • • • • •
Coe	fficie	nt of frict	ion	• • • • •	• • • • •		• • • •	•• •	• • • •	• • • • •		• • • • •
No.	of to	est				1	2		3	1-2	1-3	2-3
н. :	P. by	y dvnamo	meter			<b> </b>	<b> </b> .			.		ļ -
н.	P. by	y power-s	cale							• ••••		• • • • • •
н. —	P. by	y brake		••••	• • • • •			••••	• • • •	• [ • • • • • •	1	
					Signe	d			• • • •			
					L	OG.						
	Tes	t on	• • • • • • • • •	• • • • •	• • • • •	•••••	• • • •	• • • •	• • • •	• • • • • •	•••••	• • • • • •
		• • • • • • • •	• • • • • • • • •	••••	• • • • •	•••••	••••	••••	••••	• • • • • •	• • • • • •	• • • • • •
No.		• • • • • •				Date	• • • •	••••	••••	• • • • • • •	•••••	• • • • • •
	W	ebber Dyna	mometer.	Em	erson l	Power-s	cale.			Bra	ke.	
No. of Gong.	Time.	Time of	Ftlbs. per	Time.	Readings of Counter.	Revolutions per Minute.	Load.	Time.	Readings of Counter.	Revolutions per Minute.		
Н. Н.	P. b	y dynamo y power-s	meter			· • • • • • •				I-2	1-3	2-3

Constants and Remarks.

194. The Van Winkle Power-meter.—The Van Winkle Power-meter is shown in Fig. 97h, complete, and with its parts

separated, in Fig. 97i. It consists of a sleeve with attached plate, B, that can be fastened rigidly to the shaft; and a plate, A, which is revolved by the force communicated through




FIG. 974.-VAN WINKLE POWER-METER.

the springs ss. The angular position of the plate A with reference to B will vary with the force transmitted. This angular motion is utilized to operate levers, and move a loose sleeve




Fig. 971.—Parts of the Van Winkle Power-meter.

longitudinally on the shaft. The amount of motion of the sleeve, which is proportional to the force transmitted, is indicated by a hand moving over a graduated dial. The dial is graduated to show horse-power per 100 revolutions.

195. Belt-dynamometers.—Belts have been used in some instances instead of gearing in transmission-dynamometers, but because of the great loss of power due to stiffness of the

belts, and to the uncertainty caused by slipping, they have not been extensively used. The following form, from Church's "Mechanics of Materials," is probably as successful as any that has been devised. It consists of a vertical plate, carrying four pulleys and a scale-pan, as shown in Fig. 97h. The scale-beam is balanced, the




FIG. 975.-A BELT-DYNAMOMETER.

belt then adjusted, and power turned on; a sufficient weight, G, is placed in the scale-pan to balance the plate again. Let b be the arm of the scale-pan, and a that of the forces P and P'. Then, for equilibrium,

$$Gb = Pa - P'a$$
, . . . . . (1)

since P and P' on the right have no leverage about C, as the line of the belts produced intersects C. From (1)

$$P-P'=\frac{Gb}{a}. \quad . \quad . \quad . \quad (2)$$

The work transmitted in foot-pounds per minute is equal to (P-P')v, in which v is the velocity of the belt in feet per minute to be obtained by counting. Another form employs two quarter-twist belts to revolve a shaft at right angles to the main shaft. (See Vol. XII., Transactions Am. Soc. Mechanical Engineers.)

196. Method of Testing Belts.\*—The object of this test is to determine the coefficient of friction, and the power transmitted by various kinds of belting running under different conditions.

The required formulæ are given in Article 128, page 173, as follows:  $\Gamma_1$ , maximum tension;  $\Gamma_2$ , minimum tension;  $\Gamma_3$ , the force of friction;  $\Gamma_4$ , the percentage of arc of contact to whole circumference;  $\Gamma_4$ , the arc of contact in circular measure. We have

$$T_1 - T_2 = F;$$
 
$$\frac{T_1}{T_2} = c^{f\theta} = 10^{0.434^{f\theta}} = 10^{2.7288/c};$$
 Common  $\log \frac{T_1}{T_2} = 0.434^{f\theta} = 2.7288^{fc}.$ 

From which

$$f = \log\left(\frac{T_1}{T_2}\right) \frac{1}{0.434\theta} = \log\left(\frac{T_1}{T_2}\right) \frac{1}{2.7288c};$$

or


$$f = \text{Napierian log} \left( \frac{T_i}{T_j} \right) \frac{\mathbf{I}}{\theta}.$$

Belt-testing machines must be arranged so that measures of  $T_1$ ,  $T_2$ ,  $\theta$ , and c can be made. To determine loss due to resistance, it is necessary to supply the power by a transmission-dynamometer, and absorb that delivered by a brake.

197. The Sibley College Belt-testing Machine.—The belt-testing machine illustrated in Fig. 97k is used in the Mechanical Laboratory of Sibley College. It was designed by Wilfred Lewis of Philadelphia, and used in the tests described in Vol. VII. of Transactions of American Society of Mechanical Engineers.

The belt to be tested is placed on the pulleys E, F; power is transmitted through the pulleys P to the Lewis transmitting-

<sup>\*</sup> The student is referred to papers in Transactions of American Society of Mechanical Engineers, Vol. VII., by Wilfred Lewis and Prof. G. Lanza; also to paper in Vol. XII., by Prof. G. Alden; and to the Holman tests in the Journal of the Franklin Institute, 1885.



dynamometer (see Article 188, page 224), and thence through the shaft H to the pulley E. The power transmitted is absorbed by a Prony brake on the shaft M. The slip of the belt is measured by transmitting the motion of the pulley E by gearing to the shaft I, and thence to a disk S, whose edge is graduated. The pulley F is connected to the gear-wheel L, shown in a larger scale in centre of Fig. 96. The wheel L is so proportioned that if there is no slip it will revolve at the same rate as the disk S; if there is slip it will fall behind S. The amount that it falls behind is read by the scale V, which may be clamped to the hub of L by the screw T. As this device moves only one one-hundredth as fast as the main shafts, the amount of slip can be easily read. The pulley F and the brake M are mounted on a carriage, which can be drawn back by the screw N. The pulley E is mounted in a frame, supported on knifeedges below, R. The shaft H is fitted with a universal joint, to eliminate the effect of transverse strains on the dynamometer.

Weighing-scales are placed at A, B, and C, respectively, that at A is termed the dynamometer-scales; that at B, the brake-scales that at C, the tension-scales. The reading on the tension-scales C, multiplied by the horizontal arm K, divided by the height d of the pulley E upon the knife-edge, gives the total tension on the belts  $T_1 + T_2$ . The reading on brake-scales B, divided by the arm b of the brake, and multiplied by the radius D of the pulley F, gives the difference of tensions,  $T_1 - T_2$ . The brake-scale reading, multiplied by the brake-arm b, and by  $2\pi n$ , n being the number of revolutions, gives the delivered work in foot-pounds. The dynamometer-arm a and by a, multiplied by the equivalent dynamometer-arm a and by a, gives the work received in foot-pounds. The dynamometer-arm a is to be found as described in Article 188, page 225.

## 108. Directions for Belt-test.

- 1. Before starting:
  - (a) Get speed-indicator and log-blanks.
  - (b) Oil all bearings and loose pulley under main belt.

- (c) Balance scales A and C, and note their "zero-readings."
  - 2. With test-belt off:
- (d) Take friction-reading on scales A for driving-shaft, counting its revolutions.
- (e) Weigh brake-arm (see note below) to get zero-reading of scale B and then remove brake from brake-pulley.
  - 3. With brake off:
- (f) Put on test-belt (while loose), first moving brakeshaft frame by unscrewing hand-wheel next the floor. Tighten belt to read while at rest 75 lbs. net, on scales C.
- (g) Take friction-reading again on scales A. Count revolutions of driving-shaft and read "per cent of slip," from which the speed of brake-shaft can be calculated.
  - 4. Run I.
- (h) For tension of belt: Set scales C to read 50 lbs. net with belt at rest, by screwing up hand-wheel next the floor, which should not be changed during the run. Take reading of scales C for each load added on brake-scales B.
- (i) For power given out by belt: Set scales B to read 5 lbs. "net" or effective "load," and balance by tightening brake while running. Feed a light stream of water into rim of brake-pulley. Count its revolutions.
- (k) For power put into belt: Read scales A and take speed of driving-shaft.
- (1) For slip of belt: Read graduated "slip-disk," which has 100 equal divisions. When vernier is set, it turns with the disk, and shows one per cent of slip when falling back one division during one turn of the slip-disk.
- (m) Thus continue to increase brake-load by 5 lbs. of increments on scales B. Each time keep it carefully balanced, and take simultaneous readings on scales A, scales B, scales C, slip-disk, and revolution-counter.
  - 5. Runs II., III., and IV.
- (n) For run II., set tension-scales to read 75 lbs. net with belt at rest, and proceed as in run I. Increase this initial tension-reading by 25 lbs. each, for runs III. and IV.

#### 6. Measurement of machine-constants:

- (0) Get length in feet of (1) brake-arm, (2) dynamometer-arm, (3) arms of bell-crank acting on tension-scales, and (4) circumferences of test-belt pulleys,—latter with steel tape. Calculate diameters.
- (p) If the pulleys differ in diameter, the reading on slip-disk, obtained while running "light" (see (g), above), will be the "zero" of all the slip-readings.
  - N.B. Shut off water at brake-pulley when it stops.
- Note.—To weigh brake-arm: Loosen brake and oil face of pulley. Balance arm on scales while turning pulley first backward and again forward. The mean of the two readings will be the weight required.

199. Form of Log and Reports as used in Sibley College.

		ulley.	ıt.	act,	Scale	e-read lbs.	ings,			Belt,	Belt,		<u></u>	er,	
Number.	Time.	Revolutions, Driving pulley.	Slip, per cent.	Arc of Contact, per cent.	Dynamom- eter.	Brake.	Tension.	$Bb+\frac{1}{4}D_1$ .	Ck+4	Tension on Belt, Driving side	Tension on Belt, Driven side.	Ratio of Ten- sions.	Coefficient of Friction.	Dynamometer, Horse-power,	Brake H. P.
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 Avg		Ħ	5	С	A	В	c	71-72	T1+T1	<i>T</i> 1	Ta	T1+T2	7		

### CONSTANTS OF MACHINE.

Symbol.		Results.
a '	Arm of transmission-dynamometer ft. Arm of Prony brake. " Hor. arm on tension-scales " Ver. arm on tension-scales " Diameter driving pulley. in. Diameter driving pulley. " Face driving pulley " Face driven pulley " Area of bearings, driving wheel sq. in. " " driven wheel " Weight on bearings, driving wheel bbs. " " driven wheel " Kind of pulley used "	
b	Arm of Pronv brake	<b></b>
k	Hor arm on tension-scales	l
ã	Ver arm on tension-scales	
D	Diameter driving pulley	
$D_1$	Diameter driven pulley	
$D_1$	Face driving puller	
	Face driving pulley	
	race driven pulley	
	Area of bearings, driving wheel sq. in.	
	driven wheel	
	Weight on bearings, driving wheel lbs.	
	· " " " driven wheel "	
	Kind of pulley used	

### FORM OF REPORT.

Results of Test of	Belting.
Made by	189

Average of Results.	Test No.	Test No.	Test No.	Test No. IV.	
				1	
Quration of trial					
Revolutions driven shaft					
Belt-speed, feet per minute	. <b>.</b>				
Dynamometer-scales, lbs					
Brake-scales, lbs	. <i></i>	1			
Tension-scales, lbs					
Circumference driving pulley					
Circumference driven pulley					
Dynamometer horse-power					
Brake, horse-power					
Difference					
Slip of belt, per cent				•••••	
Slip of belt, feet per minute	· • • · · • •		[·····]		
Horse power per inch in width		}			
Maximum tension, 7'1	· · · · · · · ·				
Minimum tension, T2					
$T_1 - T_2 \cdots \cdots$					
$T_1 + T_2 \dots \dots$	<b></b>				
Arc of contact, degrees	<b></b> .	l	1	l. <b></b>	
Coefficient of friction, per cent					
Loss due to stiffness					
Loss due to journal-friction					

#### CHAPTER VIII.

#### MEASUREMENT OF LIQUIDS AND GASES.

200. Theory of the Flow of Water.—General Formulæ of Discharge.—The theory of the flow of water is fully investigated in Weisbach's Mechanics, Vol. I.; in Church's Mechanics of Engineering; and in the article "Hydromechanics," Encyclopædia Britannica. A very concise statement of the principles involved and formulæ required are given here, preceding the actual methods of measurement of the flow, but students are advised to consult the foregoing works. In the flow of water the particles are urged onward by gravity, or an equivalent force, and move with the same velocity as bodies falling through a height equal to the head of water exerting the pressure. If this head be represented by h, and the corresponding velocity in feet per second by v, we have, neglecting friction losses,

$$v = \sqrt{2gh}$$
. . . . . . . . (1)

If we denote the area in square feet of the discharge orifice by F, the quantity discharged in cubic feet per second by Q, then, neglecting contraction.

$$Q = vF = F\sqrt{2gh}. \qquad (2)$$

It is found, however, in the actual discharge of water, that, except in rare cases, I. The actual velocity of discharge is less than the theoretical; 2. The area of the stream discharged is less than the area of the orifice through which it passes. These losses are corrected by introducing coefficients. The coefficient

of velocity is the ratio of the actual to the theoretical velocity, and is represented by  $c_r$ . The coefficient of contraction is the ratio of the least area of cross-section of the discharged stream to the area of orifice of discharge, and is denoted by  $c_c$ . The coefficient of efflux or discharge is the product of these two quantities, and is represented by  $c_c$ .

If  $v_a$  denotes the actual velocity of discharge, we shall have

$$v_a = c_v \sqrt{2gh}$$
. . . . . . . (3)

The coefficient  $c_*$  is to be determined by experiment; it is nearly constant for different heads with well-formed simple orifices. It often has the value 0.97. The difference between the velocity of discharge and that due to the head may be expressed in terms of the equivalent loss of head. Thus the total head producing outflow consists of a part,  $h_a$ , producing the actual velocity  $v_a$ ; and a second part,  $h_r$ , expended in overcoming velocity and friction. Denote the ratio of these parts by  $c_r$ . Then

We also have

$$h = h_r + h_a = h_a(c_r + 1)$$
. . . . . (5)

Hence

Since ha is the head-producing velocity,

$$v_a = \sqrt{2gh_a} = \sqrt{2g\frac{h}{c_r + 1}}. \quad . \quad . \quad . \quad (7)$$

By equating (7) and (3) we obtain the relation of  $c_r$  to  $c_s$  as follows:

The actual discharge

$$Q_a = cQ = cvF = cF\sqrt{2gh}......(9)$$

Since  $c = c_x c_c$ ,

$$Q_a = c_r c_r F \sqrt{2gh} = c_c F \sqrt{2g\frac{h}{c_r + 1}}. \quad . \quad (10)$$

From equation (9),

$$c = Q \div Q_a$$
.

201. Formulæ for Flow of Water over Weirs.\*—A weir is primarily a dam or obstruction over which the water is made to pass; but the term is often applied to a notch opening to the air on one side, through which the water flows. In cases where the opening is entirely below the surface, it is spoken of as a submerged weir. The head of water producing the flow is the distance to the surface of still water from the centre of pressure of the issuing stream. The depth of the weir is measured from the surface of still water to the bottom or sill of the notch.

Rectangular Notch.—Denote the coefficient of efflux by e, the depth of the weir in feet by h, the area in sq. feet enclosed by the wetted perimeter by F, and the number of cubic feet per second by Q. We have, as a formula applicable to open rectangular notches,

$$Q = \frac{3}{8}Fc\sqrt{2g}h. \qquad . \qquad . \qquad . \qquad . \qquad . \qquad . \qquad (11)$$

<sup>\*</sup>See Church's Mechanics, page 684; Rankine's Steam-engine, p. 90; Encyc. Britannica, Vol. XII. p. 470; Bulletin on Irrigation and Use of Weirs, by Prof. L. G. Carpenter, Fort Collins, Colorado.

With most areas c increases slightly with the length and diminishes with the head; it probably depends on the ratio of wetted perimeter to area, although it is not quite constant for triangular notches, in which this ratio is a constant one. Very complete and extensive experiments were conducted by J. B. Francis at Lowell, Mass., and from these experiments he deduced the value of the coefficient of contraction to equal one tenth the head, and consequently for rectangular weirs

$$Q = \frac{9}{8}c(b - 0.1nh)h\sqrt{2gh}, \dots (12)$$

in which n = number of contractions. Applying this correction to an ordinary rectangular notch with two contractions we have the well-known *Francis formula* for rectangular weirs,

$$Q = \frac{3}{8}c(b - 0.2h)h \sqrt{2gh} = 5.35c(b - 0.2h)h^{\frac{3}{2}}. \quad (13)$$

For heads ranging from three inches to two feet it has been found by experiment that

$$c = 0.62$$
 and  $Q = \frac{10}{8}(b - 0.2h)h^{\frac{3}{2}}$ .

Triangular Notch.—For the triangular notch in which apex is down, b the base at water-level, h the depth,

$$Q = (4 \div 15)cbh \sqrt{2gh} = 4.28cbh^{\frac{1}{6}}$$
. . . . (14)

If the angle is 60°,

$$b = 2h \tan 30^{\circ} = 1.1547h$$
 and  $Q = 2.47ch^{\frac{1}{2}}$ .

If the angle is 90°,

$$b=2h$$
 and  $Q=\frac{8}{18}ch^2\sqrt{2gh}$ .

Trapezoidal Notch.—To avoid the corrections for contractions, Cippoletti of Milan in 1886 proposed to use a trape-

zoidal notch of such dimensions that the area of the stream flowing through the triangular portion should be just sufficient to correct for the contraction of the stream in a rectangular weir. The proportions of such a weir, in terms of the length at bottom of the notch, is as follows: height equal to six tenths the bottom length, width of top equal to the bottom plus one fourth the height added to either side; the tangent of the angle of inclination of the sides equal to 0.25. It is asserted that such a weir will give the discharge with an error less than one half of one per cent. The formula for the use of such a notch would be simply

$$Q = \frac{1}{8}cbh \sqrt{2gh} = 3.33bh^{\frac{1}{2}}.$$
 . . . (15)

Submerged orifices, rectangular or circular, are sometimes used for the measurement of water. The required formulæ are given in the table following.

From table in Weisbach's Mechanics, c =on the average 0.6. For small areas it diminishes with increase of head from 0.7 to 0.6, and for large areas it increases with increase of head from 0.57 to 0.60.

These formulæ are conveniently tabulated as follows: 202. Table of Formulæ for Flow over Weirs.

Form of Notch.	Depth o over sill or bottom.	Depth o over top of notch or orifice.	Width o of notch at water- level.	Average value of coefficient of discharge c.	Formula for discharge in cubic feet per second.
Rectangular:					
Usual form	À	o	b	.63 to .58	ich Vagh
Francis	À	0	ь	.622	$\frac{3}{6}ch\sqrt{2gh}(b-0.1nh)$
Submerged	h	h'	ь		$\frac{1}{2}cb\sqrt{2g}(h^{\frac{3}{2}}-h'^{\frac{3}{2}})$
[]	h	h'	ь	.62	$cb(h-h')\sqrt{g(h+h')}$
Triangular:	h	0	6'	.617	Acb'h Vagh
{	h	0	2h tan α	.617	Schhi tan a Vagh
Ang. at b. 120°	h	0	1.1547h	.617	2.47ch
Ang. at b. 90°	h	0	2 h	.617	1x6h2 4/2gh
Trapesoidal:		İ	1		1, , , ,
Cippoletti's	ħ.	0	b+ 1/2 h	0.62	ich 4/2gh

When still water cannot be found above the weir, and we have a velocity of approach that can be measured and is equal  $v' = \sqrt{2gh'}$ , we can compute h'. Then

$$Q = 5.35cb[(h + h')^{3} - h'^{3}].*$$
 . . . (16)

In above formula Q = discharge in cubic feet per second, b the length of sill at bottom of notch.

203. Efflux of Water through Nozzles, or Conical Converging Orifices.—In this case, if we denote least area in square feet by F, in which c'' is the coefficient of contraction, c' that of velocity, and c that of discharge,

$$Q = c'c''F\sqrt{2gh} = cF\sqrt{2gh}. \quad . \quad . \quad (17)$$

In this case the head is to be measured by a pressure-gauge attached close to the nozzle.

The value of c is a maximum when the sides of the nozzle make an angle of 13° 24′, attaining a value of 0.946. When the angle of the nozzle is 3° 10′, c = 0.895, and when 49°, c = 0.895. (See Church's Mechanics, page 692; "Hydromechanics," Encyc. Brit., page 475.)

204. Efflux of Water through Venturi Tubes or Bellmouthed Orifices.—A conically divergent orifice, with rounded entrance to conform to the shape of the contracted vein, is now termed, from the first experimenter, Venturi's tube. The dimensions of such a tube, as given in Encyc. Britannica, Vol. XII., page 463, are as follows, in terms of the small diameter (d). Large diameter (D) at opening equals 1.25d; length equals .625d, or .5D. The sides are in section a circular arc, struck with a radius of 1.625d, from a centre in the line of (a) produced.

<sup>\*</sup> Rankine's Steam-engine.

The formula of discharge is

in which F is the least area, h the head to be measured by a pressure-gauge attached to the pipe before the area of cross-section is reduced, c' the coefficient of velocity. The coefficient of contraction in this case is equal to one. Weisbach gives the value of c' as .959, .975, and .994 for heads respectively 2 feet, 40 feet, and 160 to 1000 feet.

Prof. Church, in his Mechanics, page 694, describes an experiment on a conically divergent tube 3 inches long, .8 inch diameter at least section.

Coefficient of discharge with heads from 2 to 4 feet varied from .901 to .914.

205. Flow of Water under Pressure.—The pressure exerted by flowing water in pipes is very different from that due to still water under the same head. The pressure follows more or less closely the law enunciated in the theorem of Bernouilli, which may be stated in a general form as follows: "The external and internal work done on a mass is equal to the change of kinetic energy produced;" that is, the total energy of a flowing stream remains constant except for losses due to friction.

In the flow of water through a pipe with varying cross-section the velocity of flow will be very nearly inversely as the area of cross-section. Since the energy or product of pressure and velocity is nearly constant by Bernouilli's theorem, as the velocity increases the pressure must diminish, and we shall find least pressure at the points where the cross-sections are least. From some experiments made by the author, the same law of varying pressure with varying cross-section applies in a less degree to the flow of steam through a pipe.\* The formula expressing Bernouilli's theorem, neglecting friction, is

$$\frac{v^*}{2g} + \frac{p}{\gamma} + z = \text{constant};$$

<sup>\*</sup>See "Hydromechanics," Encyc. Britannica, page 468.

in which  $v^1 \div 2g$  is the velocity-head, p is the pressure per square foot, p the weight per cubic foot; so that  $p \div p$  is the pressure-head, and z the potential head, or vertical distance from any horizontal reference line.

206. Flow of Water in Circular Pipes.\*—In this case there is a loss of head, h', due to friction. Denote the sine of the angle of inclination by i, diameter by d, length by L, loss of head by  $h_{i}'$ , all in feet coefficient of loss of head by  $\zeta$ .

From experiments of Darcy,

$$\zeta = 0.005 \left(1 + \frac{1}{12d}\right)$$
 for clean pipes;  
 $\zeta = 0.01 \left(1 + \frac{1}{12d}\right)$  for incrusted pipes;  
 $\zeta = 0.a \left(1 + \frac{1}{12d}\right)$  in general;  
 $v = \sqrt{\frac{g}{2\zeta}di}$ ; . . . . . . . . (20)  
 $Q = \frac{\pi}{4}d^3v$ . . . . . . . . . (21)

Loss of Head at Elbows.—In this case the loss is principally due to contraction. Weisbach gives the following formulæ:

$$h_{\bullet}' = \zeta_{\bullet} \frac{v^{\bullet}}{2g}.$$
 . . . . (22)

If  $\phi$  equal the exterior angle,

$$\zeta_s = 0.9457 \sin^2 \frac{\phi}{2} + 2.047 \sin^4 \frac{\phi}{2}$$
. (23)

From this are deduced the following values:

φ	20°	40°	60°	80°	90°	100°	110°	120°	130°
ζ.	0.046	0.139	0.364	0.740	0.984	1.26	1.556	1.861	2.158

For pipes neatly bent the value of  $\zeta_{\bullet}$  is much less.

By equating  $h_{\rho}'$  and  $h_{\epsilon}'$  in equations (19) and (22), a length of pipe can be found which will produce a loss of head equivalent to that produced by any given elbow. We shall have this additional length:

$$L = \frac{\zeta_{c}d}{4\zeta} \dots \dots \dots \dots (24)$$

On substituting the values of  $\zeta$ , as above, and  $\zeta$  as equal to 0.006, this additional length will be found not to vary much from 40 diameters for each 90° elbow, and 7 diameters for each 45° elbow.

Loss of Head on entering a Pipe.—This loss is very small when a special bell-mouthed entrance is used, but is great in other cases. The loss of head in entering a straight tube is expressed by the formula

$$h_a' = \zeta_c \frac{v^a}{2g}. \qquad (25)$$

Weisbach found  $\zeta_c = 0.505$ . By making  $h_{p'}$  of equation (19) equal to  $h_{a'}$ , and reducing, we find the additional length, L, of straight pipe producing the same loss of head.

$$L=\frac{\zeta_c d}{4\zeta}.$$

Assuming  $\zeta$  has an average value of 0.006, and  $\zeta$  as above,

$$L = 20d$$
.

Loss of Head by abrupt Contraction of Pipe.—In this case Weisbach found

$$h_{m}' = 0.316 \frac{v^{s}}{2g},$$

which would correspond to an additional length of pipe equal to about 13 diameters. When the mouth of the contracted pipe is reduced by an aperture smaller than the pipe, Weisbach found the following values of  $\zeta_c$ . In the table,  $F_1$  is area of orifice,  $F_2$  that of pipe into which the flow takes place.

							0.1 0.016 231.7							
Ľ	•	•	•	•	•	•	950d	212d	82 <i>d</i>	40 <i>d</i>	22 <i>d</i>	13 <i>d</i>	5 <i>d</i>	2 <i>d</i>

Globe valves produce about one half more resistance than a right-angled elbow, or an amount equal to an additional length of about 60 diameters.

207. Loss of Head in flowing through a Perforated Diaphragm in a Tube of Uniform Section.—Let  $F_1$  be the area of the orifice, F that of the pipe in square feet,  $\zeta$  the coefficient of discharge, c the coefficient of contraction.

The loss of head in feet

$$h_c = \left(\frac{F}{cF_1} - 1\right)^2 \frac{v_1}{2g} = \zeta \frac{v^2}{2g}; \qquad (26)$$

$$\zeta = \left(\frac{F}{cF_1} - 1\right)^2.$$

Weisbach gives the following values as the results of experiments:

$F_1$	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.0	1.0
C <sub>C</sub>	0.624									
ς 	225.9	47 - 77	30.83	7.801	1.753	1.790	0.797	0.290	0.000	0.0

208. Volume flowing through a Perforated Diaphragm.—Let  $H_a$  represent the head in feet on side of greatest pressure, and  $H_b$  that on the opposite side.

The loss of head

$$h_c = H_a - H_b.$$

From equation (26), by transposing and substituting,

$$v = \sqrt{\frac{2gh_c}{\zeta}} = \sqrt{\frac{2g}{\zeta}(H_a - H_b)}. \quad . \quad . \quad (27)$$

The quantity discharged in cubic feet per second,

$$Q = F_1 v = F_1 \sqrt{\frac{2g}{\zeta}(H_a - H_b)}$$
. (28)

From this

$$\zeta = \frac{2F_1 g}{Q^2} h_c. \qquad (28a)$$

209. Measurements of the Flow of Water.—General Methods.—The measurement of the flow of water is of importance in connection with efficiency-tests of pumps, water-meters, and steam-engines, as well as in determining the amount of water that can be obtained from a given stream.

The methods used for measurement of the flow usually consist in making the water pass through open notches over weirs, through standard orifices or nozzles, or through meters.

The coefficients that have been given are in every case to be considered approximations only, and should be tested by actual measurement under the conditions of use.

The head of water is the distance from the centre of pressure to the surface of still water under atmospheric pressure. In case the water is under pressure and at rest, this head can be measured by a calibrated pressure-gauge. The gauge is usually graduated to show pressure in pounds per square inch, each pound being equivalent to a head of 2.307 feet of water at a temperature of 70° Fahr., or to 2.037 inches of mercury.

In case the water-pressure is read in inches of mercury, one inch of mercury corresponds to a head equal to 1.113 feet.

A convenient table, showing relation of pounds of pressurehead in feet of water or inches of mercury, will be found in Article 260.

210. Flow of Water over Weirs.—Methods of measuring the Head.—The head is measured most accurately by the use of the hook-gauge, used first by Mr. U. Boyden of Boston in 1840. Many of the English engineers still depend on the use of floats. The head in all cases is to be measured at a distance sufficiently back from the weir to insure a surface which is unaffected by the flow. The channel above the weir must be of sufficient depth and width to secure comparatively still water. The addition of baffle-plates, some near the surface and some near the bottom, under or over which the water must flow, or the introduction of screens of wire-netting, serves to check the current to great extent. Such an arrangement is sometimes called a tumbling-bay.

The object of the baffle-plates is to secure still water for the

accurate measurement of height of the surface above the sill of the weir. The same object can be accomplished by connecting a box or vessel to the water above the weir by a small pipe

entering near the bottom of the vessel; the water will stand in this vessel at the same height as that above the weir, and will be disturbed but little by waves or eddies in the main channel. The height of water is then obtained from that in the vessel. Prof. I. P. Church has the connecting-pipe pass over the top of the vessel and arranged so as to act as a siphon.

The Hook-gauge.—This consists of a sharp-pointed hook attached to a vernier scale, as shown in Fig. 98, in such a manner that the amount it is raised or lowered can be accurately measured. To use it, the hook is submerged, then slowly raised to break the surface. The correct height is the reading the instant the hook pierces the surface. To obtain the head of water flowing over the weir, set the point of the hook at the same level as the sill of the weir. The reading taken in this position will correspond to the zero-head, and is to be subtracted from all other readings to give the head of the water flowing over the weir.

In some forms of the hook-gauge the zero of Fig. 98.—Hook- the main scale can be adjusted to correspond to the zero-head, or level of the sill of the weir.

Floats.—Floats are sometimes used: they are made of hollow metallic vessels, or painted blocks of wood or cork, and carry a vertical stem; on the stem is an index-hand or pointer that moves over a graduated scale.

- 211. Conditions affecting the Accuracy of Weirs.—

  1. The weir must be preceded by a straight channel of constant cross-section, with its axis passing through the middle of the weir and perpendicular to it, of sufficient length to secure uniform velocity without internal agitation or eddies.
  - 2. The opening itself must have a sharp edge on the up-

stream face, and the walls cut away so that the thickness shall not exceed one tenth the depth of the overflow.

- 3. The distance of the sill or bottom of the weir from the bottom of the canal shall be at least three times the depth on the weir, and the ends of the sill must be at least twice the depth on the weir from the sides of the canal.
- 4. The length of the weir perpendicular to the current shall be three or four times the depth of the water.
- 5. The velocity of approach must be small; for small weirs it should be less than 6 inches per second. This requires the channel of approach to be much longer than the weir opening.
- 4. The layer of falling water should be perfectly free from the walls below the weir, in order that air may freely circulate underneath.
- 5. The depth of the water should be measured with accuracy. at a point back from the weir unaffected by the suction of the flow and by the action of waves or winds.
- 6. The sill should be horizontal, the plane of the notch vertical.
- 212. Effect of Disturbing Causes and Error in Weir Measurements.—I. Incorrect measurement of head. This may increase or decrease the computed flow, as the error is a positive or negative quantity.
- 2. Obliquity of weir; the effect of this or of eddies is to retard the flow.
- 3. Velocity of approach too great, sides and bottom too near the crest, contraction incomplete, crest not perfectly sharp, or water clinging to the outside of the weir, tend in each case to increase the discharge.

The causes tending to increase the discharge evidently outnumber those decreasing it, and are, all things being taken into account, more difficult to overcome.

213. Water-meters.—The water-meter is an instrument for measuring the amount of water flowing through a pipe. Knight makes seven distinct classes of water-meters, as follows:\*

<sup>\*</sup> Knight's Mechanical Dictionary, Vol. III.

- 1. Those in which the water rotates a horizontal case, or a horizontal wheel in a fixed case, delivering a definite amount at each rotation.
- 2. A piston or wheel made to rotate by the pressure of the water, the meter in this case being the converse of the rotary engine or pump.
  - 3. A screw made to rotate by the motion of the water.
- 4. A reciprocating piston in a cylinder of known capacity driven backward and forward by the pressure of the water.
- 5. The pulsating diaphragm, in a vessel of known capacity, which is moved alternately as the side chambers are filled and emptied.
- 6. The bucket and balance-beam, in which the buckets of known capacity on the ends of the beam, are alternately presented to catch the water and are depressed and emptied as they become filled.
- 7. The meter-wheel, in which chambers of known capacity are alternately filled and discharged as the wheel rotates.

Besides these seven classes, it is evident that any machine may be used in which the motion is proportional to the velocity of flow of water.

These classes can be united into two general classes: I. Positive; II. Inferential. In class I. the water cannot pass without moving the mechanism, and meters of this kind are considered more delicate and accurate than those in class II.

Each class of meter has a registering apparatus, which in general consists of a series of gear-wheels, so arranged as to move a hand continuously around a graduated dial, from which the volume can be read.

214. Errors of Water-meters.—In addition to the constant errors of graduation, meters are liable to be clogged by dirt, to be affected by air in the water, and by change in the temperature, head, or quantity of discharge of the water passing through.

While the meter is no doubt of sufficient accuracy for commercial purposes, it should be used with caution in the measurement of water for tests or for purposes of scientific investigation. Before and after such tests a careful calibration of the meter should be made under the exact conditions of the test.

The following directions explain the method of calibrating the weir notch and meter, arranged in series. In this experiment the water is to be weighed. Either instrument may be calibrated separately. In case the weir has been calibrated, the meter could be calibrated by direct comparison, without the use of weighing-scales.

215. Directions for Calibrating the Weir Notch and Meter.—The object of this experiment is to determine the coefficient c of formula (9), Article 200, page 201, and the accuracy of previous determinations.

Apparatus needed.—Hook-gauge, pair of scales, thermometer, spirit-level, pressure-gauge, weir, and meter.

- 1. Accurately level the sill of the weir, and see that the notch is in a truly vertical plane.
- 2. Take the zero-reading of the hook-gauge, by setting the point of the hook with a spirit-level, at the same height as the sill of the notch. In case the form of the notch is such as to prevent the use of the spirit-level, grease the edge of the notch and set the hook by the water-level; being sure that the water surface does not, through capillary action, rise above the lower edge of the notch.
- 3. Start the water flowing, and after it has obtained a constant rate, take measurements of weights and of head. The commencement of the experiment to be determined by the rising of the poise on the scale-beam, which previously must be set at a given weight. Note the time, scale reading, thermometer-reading, reading of the hook-gauge at the beginning and once in five minutes during the run. As the experiment approaches the end set the poise of the scale-beam in advance of the weight, terminate the run when the beam rises, accurately noting the time, weight, thermometer reading, and reading of the hook-gauge. Make direct measurements of the coefficient of contraction. Calculate coefficient of discharge.
- 4. If the water to the weir first passes through a meter, take corresponding readings of the meter-dial. Note the pressure

and temperature at the meter. Calculate the number of cubic feet.

- 5. Draw on cross-section paper a curve of discharge, in which cubic feet per second are taken as abscissæ and the corresponding heads as ordinates. Also draw in dotted lines on the same sheet a curve of coefficients, of discharge in which coefficients are taken as abscissæ, and corresponding heads as ordinates. Also, draw a curve showing error of meter for each head.
- 216. Form of Report.—The following form has been used by the author for calibration of the weir notch and meter:

CALIBRATION OF WEIR NOTCH AND METER.

Date...... Number of Run. I. II. III. IV. v. " End of run......lbs. " Cubic feet per second......Q. End......ft., ..... Contracted section.....sq. ft. ..... Discharge, c..... End..... Difference........ Cubic feet per second..... Constants of Weir, Form ...... Length... ....ft. Angle of sides...... Remarks ..... Meter, manf. by ...... General class ...... No.... Formula:  $c = c_0 c_0$ ,  $c_r = \frac{1}{c_0} - 1$ . Remarks.....

- 217. Calibration of Nozzles and Venturi Tubes.—These are often more convenient to use than weir-notches, in the measurement of the efflux of water. Before using these they should be carefully calibrated by measurements of the head and discharge. The Venturi tube is sometimes inserted in a length of pipe; in this case the pressure should be observed on either side of the tube, and the discharge measured. The special directions for calibrating when discharging into the air would be as follows:
- 1. Arrange the nossle or Venturi tube, so that the discharge can be caught in tanks and measured or weighed.
- 2. Attach a pressure-gauge, which has been previously cali brated, to the pipe near the nozzle. Since the pressure is a function of the area of cross-section, the position of the gauge should be described and the area of the cross-section at that point measured.
- 3. Make careful measurements of least and greatest internal diameters of nozzles, of length of nozzle, and note condition of interior surface. Make sketch showing the form.
- 4. Make five runs, as explained in directions for calibrating weir-notches, Article 215, page 258, obtaining weight of water by the same method. In case it is not convenient to weigh the water, discharge into tanks which have been carefully calibrated by weighing, arranged so that one is emptying while the other is filling.
- 5. Observe during run, reading of pressure-gauge, temperature of discharge-water, weight of discharged water. Compute corresponding head producing flow, volume of discharged water, and the coefficient of discharge in the formula

$$Q = cF\sqrt{2gh}$$
.

- 6. Draw a curve showing relation of discharge in cubic feet to head, as explained for weir-notches, page 258; also one showing relation of coefficient to head.
- 218. Measurement of Efflux of Water through an Orifice in End of Tube of Uniform Section.—A cap can often

be arranged over the end of a tube, and an orifice made in this cap with a sharp edge on the side toward the current. This will be found to give very uniform coefficients of discharge. The special method of calibrating this orifice would be as follows:

- 1. Arrange the tube with a cap in which is an orifice, the area of which is one third that of the pipe. Ream the sides of the orifice so that a sharp edge will be presented to the outflowing water. Attach a calibrated gauge at a distance of two diameters of the pipe back from the orifice. Arrange to weigh or measure the discharged water. Measure the orifice.
- 2. Make runs as explained for other calibrations with five different heads, and note reading of pressure-gauge, temperature of discharged water, weight or volume of discharged water, and least diameter of stream discharged. The least diameter of the discharged stream can be measured by arranging two sharppointed set-screws in a frame, so that they can be screwed toward each other. These screws can be made to touch the outflowing stream, and the distance between their points measured.
- 3. Compute head producing the flow, coefficient of contraction, which is ratio of area of stream to area of orifice, coefficient of discharge, and loss of head. See equations (1) to (10), Article 200, page 201.
- 4. Draw curves on cross-section paper showing the relations of these various quantities.
  - 5. Repeat the experiment with orifices of different sizes.
- 219. Measurement of the Flow of Water in Pipes by use of a Perforated Diaphragm or of a Venturi Tube.—In this case the loss of head flowing through the orifice in the diaphragm or the *Venturi tube* must be measured; then, knowing the coefficient of efflux and area of cross-section, the volume discharged can be computed by equation (28), Article 208, page 252.

$$Q = F_1 \sqrt{\frac{2g}{\zeta}(H_a - H_b)}. \qquad (28)$$

The difference of head is measured accurately by inserting tubes at a distance of two diameters on each side of the orifice, connecting each of these tubes to a U-shaped glass tube partly filled with water, very much as shown in Fig. 104, page 266, except that the ends of the tubes A and B are in each case perpendicular to the pipe, and are on opposite sides of the diaphragm. The difference in the height of the water in the two branches of the U-shaped tube will be the loss of head  $(H_a - H_b)$  caused by the orifice. It is essential that the tubes be connected into pipes having equal areas of cross-section, since the pressure, even in the same line of pipe, increases with the area (see Article 205). The coefficient  $\zeta$  should be determined by calibration, following essentially the same method as that prescribed for nozzles and Venturi tubes in Article 217.

220. Measurement of the Flow of Water in Streams.\*—This is done by (1) Floating bodies; (2) Tachometer; (3) Pitot's tube; (4) Hydrometric pendulum.

Floating bodies, when used, should be small, and about the density of the water. A floating body with a volume about one tenth of a cubic foot is better than larger. They can be made of wood and weighted, or of hollow metal and partially filled with water. A coat of paint will serve to render them visible. To obtain the velocity for different depths, the surface velocity is first found, the float is then connected with a weighted ball that can be adjusted to float at any depth, and the joint velocity observed.

Call the surface velocity  $v_{\bullet}$ , the joint velocity  $v_{m}$ ; then will the velocity of the submerged ball be

$$v_{\scriptscriptstyle 1} = 2v_{\scriptscriptstyle m} - v_{\scriptscriptstyle 0} \, .$$

A floating staff that remains vertical in still water is sometimes used.

In case floats are used, the velocity is obtained by noting the time of passing over a measured distance. The measured distance should be marked by sights, so that the line of begin-

<sup>\*</sup> See Weisbach's Mechanics, Vol. I.

ning and ending can be accurately determined. The float is put in above the initial point, and the instant of passing the




FIG. 99.-THE TACHOMETER.

first and last lines of the course is to be determined by a stop-watch.

221. The Tachometer, or Woltman's Mill, consists of a small water-wheel connected to gearing so as to register the

number of revolutions. The wheel is anchored at the required depth in the stream, and at a given instant, the time of which is noted on a stop-watch, the gearing is set in motion by pulling on a lever; at the instant of stopping the experiment, the gears are stopped by a trip. The machine is removed, and the number of revolutions multiplied by a constant factor gives the total space moved by the water; this divided by the time gives the velocity.

The shape of the vanes of the revolving wheel are varied by different makers, and the wheel is made to revolve either in a horizontal or a vertical plane.

Fig. 99 shows a form used extensively, in which the gearing for registering the number of revolutions is operated by an electric current, and can be seen at any instant.

The electric register shown in Fig. 100 can be located at any distance from the tachometer convenient to the observer.

Calibration.—The constant factor, which multiplied into the dial-reading gives the velocity, is obtained by calibration. The calibration is performed by attaching the instrument to a float or a boat, and towing it past fixed marks at a known distance from each other. The velocity is obtained as for floating bodies, and the constant is found by comparing this with the readings of the instrument. One method of calibrating the




FIG. 101.

instrument is as follows (see Fig. 101): The instrument is attached to the bow of a boat, so as to remain in a vertical position; the water being still, and little or no current. The boat is propelled by a cord, which may be wound up by a windlass; the motion must be in a right line, and over a known

distance. Several trials are to be made, and the average results taken, and reduced by the method of Least Squares, as explained in Chapter I.

The tachometer is the most convenient, and if properly constructed the most accurate, method of measuring the velocity of running water.

222. Pitot's Tube.—This is a bent glass tube, held in the water in such a manner that the lower part is horizontal and opposite the motion of the current. By the impulse of the current a column of the water will be forced into the tube and



held above the level of the water in the stream; this rise, DE (see Fig. 102) is proportional to the impulse or to the velocity of the water that produces it. If the height DE above the surface of the water equal h and the velocity of the water equal v, we have

$$v = c \sqrt{2gh}$$

in which c equals the coefficient to be determined by experiment.

To determine the coefficient c, the instrument is either to be held

in moving water whose velocity is known, or else moved through the water at a constant velocity. From the known value of v and the observed value of h the coefficient c can be calculated.

Weisbach found that with fine instruments, when the velocities were between 0.32 and 1.24 meters (1.04 and 4.068 feet) per second, that

$$v = 3.545 \sqrt{h}$$
 meters per second,

or, in English measures,

$$v = 6.43 \sqrt{h}$$
 feet per second.

Pitot's tube, as ordinarily used, is shown in the diagram Fig. 103. It consists of two tubes, one, AB, bent as in Fig. 102, the other, CD, vertical. The mouth-pieces of both tubes are slightly convergent, to prevent rapid fluctuation in the




FIG. 103.-SKETCH OF PITOT'S TUBE.

tubes. These tubes are so arranged that both can be closed at any instant by pulling on the cord ss leading to the cock R. Between the glass tubes dD and bB is a scale which can be read closely by means of the sliding verniers m and n. The tubes are connected at the top, and a rubber tube with a mouth-piece O is attached.

In using the instrument it is fastened to a stake or post by the thumb-screws EF; the bent tube is placed to oppose the current of water, the cocks K and R opened. The difference in height of the water in the tubes will be that due to the velocity of the current. The water in the column dD will not rise above the surface of the surrounding water, and the instrument may be inconvenient to read. In that case some of the air may be sucked out at the mouth-piece O, and the cock K closed; this will have the effect to raise the water in both

columns without changing the difference of level, so that the readings can be taken in a more convenient position; or by closing the cock K, by pulling on the strings ss, the instrument may be withdrawn, and the readings made at any convenient place.

223. Pitot's Tube for High Pressures.—A modified form, as shown in Fig. 104, of Pitot's tube is useful for obtaining the velocity of liquids or gases flowing under pressure. The arrangement is readily understood from the drawing. The difference of pressure is shown by the difference in heights




FIG. 104 -SKETCH OF PITOT'S TUBE FOR GREAT PRESSURES.

of the liquid in the branches of the U-shaped tube eGH; this difference is due entirely to the velocity, since both branches are under equal pressure. Thus, if the liquid stand at m on one side and at n on the other, the velocity is that due to the height of a column of liquid equal to the distance that m is above n. Call this distance h; then

$$v = c \sqrt{2gh}$$
.

The coefficient c is to be determined by experiments made on a tube in which the velocity of flow is known.

224. Hydrometric Pendulum.—This instrument consists of a ball, two or three inches in diameter, attached to a string. The ball is suspended in the water and carried downward by the current; the angle of deviation with a vertical may be measured by a graduated arc supported so that the initial or zero-point is in a vertical line through the point of suspension. If the current is less than 4 feet per second an ivory ball can be used, but for greater velocities an iron ball will be required. The instrument cannot give accurate determinations, because of the fluctuations of the ball and consequent variations in the The formulæ for use are as follows: Let G equal theweight of the ball, D equal the weight of an equal volume of water: then G-D is the resultant vertical force. Let F equal area of cross-section of the body, v the velocity of the current, c a coefficient to be determined by experiment; then we have the horizontal force  $P = cFv^2$ . Let angle of deviation be  $\delta$ ; then

$$\tan \delta = \frac{P}{G - D} = \frac{cFv^2}{G - D},$$

from which

$$v = \sqrt{\frac{(G-D)\tan \delta}{cF}}.$$

The best results with this instrument will be only approximations.

225. Flow of Compressible Fluids through an Orifice.—
General Case.—In this case, as heat is neither given nor taken up, the flow is adiabatic. The formulæ are deduced by principles of thermodynamics, and their derivation can be studied in treatises devoted to those subjects.\*

Denote the velocity by v, the weight per cubic foot by G, the pressure per square foot in the vessel from which the flow

<sup>\*</sup> See Peabody's Thermodynamics, p. 132; also, art. "Hydromechanics," Encyc. Britannica.

takes place by  $p_1$ , the pressure against which the flow takes place by  $p_2$ , the volume of one pound in cubic feet by C, the absolute temperature corresponding to pressure  $p_1$  by  $T_1$ , the ratio of specific heats by  $\gamma$ .

$$\frac{v_{\bullet}^{2}}{2g} = p_{\bullet}C\left(\frac{\gamma}{\gamma - 1}\right)\left\{1 - \left(\frac{p_{\bullet}}{p_{\bullet}}\right)^{\frac{\gamma - 1}{\gamma}}\right\} = \frac{p_{\bullet}}{G_{\bullet}}\frac{\gamma}{\gamma - 1}\left\{1 - \left(\frac{p_{\bullet}}{p_{\bullet}}\right)^{\frac{\gamma - 1}{\gamma}}\right\}; \quad (29)$$

also,

$$\frac{p_1 v_1}{T_1} = \frac{p_0 v_0}{T_0} \quad \text{and} \quad \frac{p_1}{G_1 T_1} = \frac{p_0}{G_0 T_0}. \quad . \quad . \quad (30)$$

226. Flow of Air.—For air,  $p_0 = 2116.8$ ,  $G_0 = 0.08075$ ,  $T_0 = 492.6$  at 32° Fahr.,  $\gamma = 1.405$ . Inserting these numerical values, we have the following equation for the theoretical velocity of flow of air through an orifice:

$$\frac{v_i^2}{2g} = 183.6T_1 \left\{ 1 - \left( \frac{p_i}{p_i} \right)^{0.29} \right\}^*. \quad . \quad (31)$$

Volume of Air discharged.—The volume of air discharged, in cubic feet per second at pressure of discharge, is to be computed by multiplying the area of the orifice  $F_1$  in square feet, by the velocity  $v_1$ , by a coefficient of discharge c. Then

$$Q_{s} = cF_{1}v_{s} = cF_{1}\sqrt{183.6T_{1}(2g)}\left\{1 - \left(\frac{p_{s}}{p_{1}}\right)^{0.29}\right\}^{*}$$

$$= 108.7cF_{1}\sqrt{T_{1}\left\{1 - \left(\frac{p_{s}}{p_{1}}\right)^{0.29}\right\}}. \quad (32)$$

Substituting numerical values for the ratio of  $p_i$  to  $p_i$ , we have

$$Q_1 = 108.7cF_1 \sqrt{0.1695T_1}$$
. . . . (33)

<sup>\*</sup> See article "Hydromechanics," Encyc. Britannica, Vol. XII, page 481.

To express this in terms of the volume discharged from the reservoir  $Q_1$ , in which  $p_1$  is reservoir pressure and  $p_2$ , pressure of discharge, we have

$$Q_{\scriptscriptstyle 1} = \left(\frac{p_{\scriptscriptstyle 2}}{p_{\scriptscriptstyle 1}}\right)^{\frac{1}{\gamma}} Q_{\scriptscriptstyle 2}.$$

Substituting numerical values for free flow,

$$Q_{1} = (0.527)^{\frac{1}{1.405}}Q_{9} = 0.6339Q_{2};$$

$$Q_{1} = 108.7cF_{1}\left(\frac{p_{2}}{p_{1}}\right)^{\frac{1}{\gamma}}\sqrt{T_{1}\left\{1 - \left(\frac{p_{2}}{p_{1}}\right)^{0.29}\right\}}...(34)$$

Substituting values of  $p_1 \div p_1$ ,

$$Q_1 = 68.8cF_1 \sqrt{0.1695} T_1 \dots (35)$$

227. Velocity of Flow of Air through an Orifice.—The velocity of flow is obtained by substituting numerical values in the preceding equations. We have, denoting by  $T_1$  the absolute temperature in the reservoir as the greatest velocity of flow of air,

$$\frac{v_i^2}{2g} = 183.6 T_i (1 - 0.8305)... (36)$$

Solving equation (36), we have the following theoretical results:

Temperature of Air in Reservoir,		Velocity of	
Degrees Fahr.	Absolute.	Flow in Feet per Sec.	
32	492.6	991	
70	530.6	1030	
100	560.6	1058	
150	610.6	1105	
200	660.6	1148	
300	760.6	1233	
400	860.6	1312	
500	960.6	1386	

228. The Weight of Air discharged.—This is to be computed by multiplying the volume of discharge by the specific weight.

Thus the weight of air is

$$G_1 = \frac{p_1}{53.2T_1}$$
 pounds per cubic foot,

when  $p_1$  and  $T_1$  are, respectively, pressure and absolute temperature in the reservoir. Hence the weight of air discharged is

$$W_{1} = Q_{1}G_{1} = 108.7cF_{1}G_{1}\left(\frac{p_{2}}{p_{1}}\right)^{\frac{1}{p_{2}}}\sqrt{T_{1}\left(1-\left(\frac{p_{2}}{p_{1}}\right)^{\alpha.sg}}\right). \quad (37)$$

Weisbach has found the following values of c, the coefficient of discharge:

Conoidal mouth-piece of the form of the contracted vein, with effective pressures of

· · · · · · · · · · · · · · · · · · ·			
0.23 to 1.1 atmospheres	0.97	to	0.99
Circular sharp-edged orifices	0.563	to	0.788
Short cylindrical mouth-pieces	18.0	to	0.84
The same rounded at the inner end	0.92	to	0.93
Conical converging mouth-pieces	0.90	to	0.99

In the general formula for the flow of air, the weight delivered becomes a maximum when

$$\frac{p_3}{p_1} = \left(\frac{2}{\gamma+1}\right)^{\gamma-1}.$$

This equals 0.527 for air and 0.58 for dry steam. This has been verified by experiment, and tends to prove that the pressure of the orifice of discharge is independent of the back-pressure. In the flow of air from a higher to a lower pressure

through a small tube or orifice, the pressure in the orifice may be less than the back-pressure.

229. Flow of Air in Pipes.—When air flows through a long pipe, a great part of the work is expended in overcoming frictional resistances. This friction generates heat, which is largely used in increasing the pressure in the pipes, the only loss being from radiation, which is small.

The expansion then is isothermal, the heat generated by friction exactly neutralizing the heat due to work.

For pipes of circular section, when d is the diameter, l the length,  $p_0$  the greater and  $p_1$  the less pressure, T the absolute temperature,  $\zeta$  the coefficient of discharge,  $c_p$  (= 53.15 foot-lbs.) the specific heat, we have the velocity

$$u_{\bullet} = \sqrt{\left\{ \frac{gc_{*}Td}{4\zeta l} \frac{p_{\bullet}^{2} - p_{1}^{2}}{p_{\bullet}^{2}} \right\}}. \qquad (38)$$

This may be reduced to

$$u_{\bullet} = \left(1.1319 - 0.7264 \frac{p_{\bullet}}{p_{\bullet}}\right) \sqrt{\frac{gc_{\bullet}Td}{4\zeta l}}.$$

It has been found from recent experiments that fair values of the coefficient are as follows:\*

$$\zeta = 0.005 \left( 1 + \frac{3}{10d} \right)$$

in ordinary pipes for velocities of 100 feet per second;

$$\zeta = 0.0028 \left(1 + \frac{3}{10d}\right)$$

for pipes as smooth as those at the St. Gothard Tunnel.

<sup>\*</sup> See "Hydromechanics," Encyc. Britannica, Vol. XII, p. 491.

Weight of air flowing per second in circular pipes in pounds is given by the equation

$$W = \frac{\pi}{4} \sqrt{\left\{ \frac{gd^3}{\zeta L_i T} (p_i^3 - p_i^3) \right\}}$$
$$= 0.611 \sqrt{\left\{ \frac{d^3}{\zeta L_i} (p_i^3 - p_i^3) \right\}}.$$

Approximately,

$$W = (0.6916p_{\bullet} - 0.4438p_{1}) \left(\frac{d^{\bullet}}{\zeta lt}\right)^{\frac{1}{4}}. \quad . \quad . \quad (39)$$

230. Flow of Steam through an Orifice.—Velocity.—In this case, as in Article 226, the expansion is supposed to be adiabatic.

Denote by A the reciprocal of the mechanical equivalent of one B. T. U. corresponding to the quantity 778; by  $x_1$  the quality or percentage of dry vapor in the reservoir, corresponding to the pressure per sq. foot  $p_1$ , and by  $x_2$  the quality in the tube, corresponding to pressure  $p_2$ ; by  $r_1$  the latent heat per pound in reservoir,  $r_2$  the same in the tube;  $r_2$  and  $r_3$  the respective absolute temperatures,  $r_3$  and  $r_4$  the respective entropies of the liquids,  $r_4$  the specific heat of the liquid,  $r_4$  and  $r_5$  the sensible heat of the liquid in reservoir and tube; the reciprocal of the weight of a cubic foot of the liquid by  $r_4$ . Then

$$\frac{Av^{2}}{2g} = x_{1}r_{1} - x_{2}r_{2} + q_{1} - q_{2} + A\sigma(p_{1} - p_{2}). \quad . \quad (40)$$

x, can be determined from the relation expressed in the equation

If no tables are at hand for  $\theta_1$ , its approximate value can be deduced, since

$$\theta_i - \theta_i = c \log_i \frac{T_i}{T_i} \dots$$
 (42)

So that

$$\frac{x_1r_2}{T_2} = \frac{x_1r_1}{T_1} + c\log_e \frac{T_1}{T_2}.$$

Eliminating  $x_s$  in equations (40) and (41),

$$\frac{Av^{3}}{2g} = \frac{x_{1}r_{1}}{T_{1}}(T_{1} - T_{2}) - T_{2}(\theta_{1} - \theta_{2}) + (q_{1} - q_{2}) + A\sigma(p_{1} - p_{2}).$$
(43)

The following table, condensed from Peabody's steam tables, gives the value of the entropy of the liquid:

TABLE OF E	INTROPY OF	THEL	.IQUID.
------------	------------	------	---------

Absolute Steam- pressure,	Entropy of the Liquid,	Absolute Steam- pressure,	Entropy of the Liquid,
1	0.1329	65	0.4337
10	0.2842	70	0.4402
15	0.3143	75	0.4464
20	0.3363	8o	0.4522
25	0.3539	85	0.4579
30	0.3685	90	0.4633
35	0.3811	95	0.4686
40	0.3921	100	0.4733
45	0.4020	105	0.4780
50	0.4109	110	0.4826
55	0.4191	115	0.4869
60	0.4267	120	0.4911

In the above equations A has a numerical value of  $1 \div 778$ ,  $\sigma$  is nearly equal to 0.016, g to 32.16.

<sup>\*</sup> See Thermodynamics, by Peabody, page 138.

It has been shown that in the flow of saturated steam  $p_*$  will not fall below 0.58 of  $p_1$ , because at that point there is the maximum weight of discharge. In the actual trials this seems to be nearer 0.61 than 0.58. If we assume  $p_*$  equal to 0.6 $p_1$ , the velocity will be found to be nearly constant, and to vary but little from 1400 feet per second.

231. Weight of Steam discharged through an Orifice.

—This was determined experimentally by R. D. Napier, and expressed by the formula

$$W=\frac{Fp_1}{70},$$

in which W = weight discharged in pounds per second, F = area of orifice in square inches, and  $p_1$  is the absolute pressure of the steam, pounds per square inch, which is equal to or greater than  $1\frac{3}{4}$  that of the atmosphere.

This formula has been verified by experiments made in the Laboratories of Sibley College and also at the Massachusetts Institute of Technology, and is found to vary but little from the actual results.

232. Measurement of the Flow of Gas.—Gas.meters.— In the measurement of gas the product of absolute pressure, p, by volume, v, divided by absolute temperature, T, is a constant quantity. Thus


$$\frac{pv}{T} = \frac{p_1v_1}{T_1}.$$

If p and T can be kept constant, the quantity discharged will vary as the volume; if p and T are known, the quantity discharged can be computed.

Gas-meters are instruments for measuring the volume of gas passing them. They are constructed on various plans and are known as *Wet* or *Dry*, depending on whether water is used. The volume is usually measured in cubic feet.

Meter-prover.—This is the name given to a sort of gasometer arranged as shown in Fig. 105. It consists of an open vessel,

DE, partly filled with water, into which a vessel, AF, of somewhat smaller diameter is inverted. The weight of the vessel AF is counterbalanced by a weight W which descends into a vessel of water CK at such a rate as to keep the sum of the displacements of the two vessels constant, in which case the pressure



on the confined gas in the vessel AF will remain constant. The gas flows out through the pipe T, its pressure being taken by a manometer at m, its temperature by a thermometer at t.

Fig. 106 shows a form of meter-prover made by the American Meter Co., in which the counterweight lifts an additional weight moving over an involute wheel, so calculated that the pressure on the outflowing gas remains constant. These instruments are used principally to calibrate meters; they give very accurate results, but are not suited for continuous measurements.

Wet-meter.—The wet-meter works on the same principle as the meter-prover, but is arranged with a series of chambers which are alternately filled and emptied with gas. These chambers are usually arranged like an Archimedean screw, as shown in section in Fig. 107.



Fig. 106.-METER-PROVER.

Gas is admitted just above the surface of the water, and raises the partition of the chamber, bringing it above the water and filling it. The outlet-pipe is submerged until the chamber is filled. It is connected with the case of the meter, as shown in the figure. The gas is completely expelled as the cylinder revolves.

The wet-meter is a very accurate measure of the gas passing, provided the water-level be maintained at the constant standard height. Any change of the water-level changes the size of the chambers accordingly. The motion of the cylinder actuates the recording mechanism.



FIG. 107.-THE WET-METER:

The Dry Gas-meter.—The dry gas-meter possesses the advantage of not being affected by frost, nor of increasing the amount of moisture in the gas. The dry-meter is made in various forms, and generally consists of two chambers separated from each other by partitions. Each chamber is divided into two parts by a flexible partition which moves backwards and forwards, and actuates the recording mechanism as the gas flows in or out. This motion is regulated by valves somewhat similar to those of a steam-engine. The gas-meter is calibrated by comparing with a meter-prover as already described. These meters are not supposed to be instruments of great accuracy.

233. Anemometers.—Instruments that are used to measure the velocity of gases directly are termed anemometers. They consist of flat or hemispherical vanes mounted like arms of a light wheel so as to revolve easily. The motion of the wheel actuates a recording mechanism. Robinson's Anemometer, which consists of hemispherical cups revolving around a vertical axis, is much used for meteorological observations.

A form shown in Fig. 108 with flat vanes, and with the



FIG. 108 - BIRAM'S PORTABLE ANEMOMETER.

dial arranged in the centre as shown, or on top of the case in various positions, is much used as a portable instrument.

The dial mechanism of the anemometer can be started or stopped by a trip arranged convenient to the operator; in some instances the dial mechanism is operated by an electric current similar to that described in connection with the tachometer, Article 221, page 262. It is also made self-recording, by attaching clock-work carrying an endless paper strip which is moved under a pencil operated by the anemometer mechanism.

234. Calibration of Anemometers.—Anemometers are calibrated by moving them at a constant velocity through still air and noting the readings on the dials for various positions. This is usually done by mounting the anemometer rigidly on a long horizontal arm which can be rotated about a vertical axis at a constant speed. The distance moved by the anemometer in a given time is computed from the known distance to the axis and the number of revolutions per minute; from these data the velocity is computed.

In performing this experiment care must be taken that the axis of the anemometer is at right angles to the rotating arm. Readings should be taken at various speeds, since the correction is seldom either a constant quantity or one directly dependent on the velocity.

## CHAPTER IX.

## HYDRAULIC MACHINERY.

235. General Classification.—Hydraulic machinery may be divided into the two classes, hydraulic motors and pumps. In the first class a quantity of water descending from a higher to a lower level, or from a higher to a lower pressure, drives a machine which receives energy from the water. In the latter class a machine driven by some external source of energy is employed in lifting water from a lower to a higher level.

The student is advised to consult the following authorities on the subject:

Rankine's Steam-engine; article "Hydromechanics," Encyc. Britannica; Weisbach's Mechanics, Vol. II. (Hydraulics); "Systematic Turbine-testing," by Prof. Thurston, Vol. VIII. Transactions Mechanical Engineers; "Notes on Hydraulic Motors," by Prof. I. P. Church.

- 236. Hydraulic Motors—Classification.—The following classes of hydraulic motors are usually recognized:
- I. Water-bucket Engines, in which water poured into suspended buckets causes them to descend vertically, so as to lift loads and overcome resistances.
- II. Water-pressure Engines, in which water by its pressure drives a piston backward and forward.
- III. Vertical Water-wheels, in which the water acts by weight and impulse to rotate them on a horizontal axis.
- IV. Turbines, in which the water acts by pressure and impulse to rotate them around a vertical axis.
- V. Rams and Jet-pumps, in which the impulse of one mass of fluid is used to drive another.

237. Energy of Falling Water.—Hydraulic motors are driven either by the weight, pressure, or impulse of moving water. Neglecting the losses due to friction or other causes, the energy of falling water is the same whether it act by (I.) weight, (II.) by pressure, or (III.) by impulse. This is proved as follows:

Let h equal the head or total height of fall, Q the discharge in cubic feet per second, G the weight per cubic foot, p the pressure in pounds per square foot, v the velocity in feet per second, P the pressure in pounds per square inch. Since the work done is equal to the product of the force acting into the space moved through, we have for the work done per second in the several cases (I.) GQh, (II.) (pQ), (III.)  $GQ\frac{v^3}{2g}$ ; but since p=Gh and  $h=\frac{v^2}{2g}$ , we have by substitution

$$GQh = pQ = GQ\frac{v^3}{2g} = 144PQ.$$
 (I.)

- 238. Parts of an Hydraulic Power-system.—The hydraulic power-system in general requires—
- 1. A supply-channel or tube leading the water from the highest accessible level.
- 2. A discharge-pipe or tail-race conveying the water away from the motor.
- 3. Gates or valves in the supply-channel, and a waste-channel or weir to convey surplus water away from the motor.
- 4. The motor, which may belong to any of the classes described in Article 236, and suitable machinery for transmitting the energy received from the motor to a place where it can be usefully applied.
- 239. Water-pressure Engines.\*—Water-pressure engines are well adapted for use where a slow motion is required and a great pressure is accessible.

<sup>\*</sup> See Weisbach's Hydraulics, Vol. II, p. 558.

These engines resemble in many respects a steam-engine, water being the motive force instead of steam. They consist of a cylinder (Fig. 109) in which a piston T is worked alter-




FIG. 100.-WATER-PRESSURE ENGINE

nately forward and backward, water being admitted alternately at the two ends of the cylinder by the moving slide-valve S. While water is passing into one end of the cylinder through the passages D, E, C, it is being discharged through the pipe E, G, H, which is proportioned so as to afford a free exit to the water. Near the end of the stroke of the piston the slidevalve S closes both admission-ports, and the pressure in the cylinder C, is increased by the diminution of volume caused by the motion of the piston. When the pressure in the chamber C, exceeds that in the supply-pipe the valve W, opens, and the water passes into the supply. Simultaneously the valve V is opened by suction, and water passes into the chamber C from the discharge-pipe. The effect of this action is to gradually arrest the motion of the piston at the end of the stroke by reducing the pressure on one side and increasing the resistance on the other. When the piston reaches the end of the stroke the slide-valve is reversed in position and a new stroke is commenced.

- 240. Vertical Water-wheels.—There are four classes of vertical water-wheels:
  - 1. Overshot, in which the water is received on the top of

the wheel and discharged at the bottom, the water acting principally by weight.

- 2. Breast, in which the water is received on the side of the wheel and held in place by a guide or breast, the water acting both by impact and weight.
- 3. Undershot, in which the water acts only on the under side of the wheel, the water acting principally by impact.
- 4. Impact, in which the water is delivered to the wheel by a nozzle, acting generally on the top or bottom, and by impulse only.
- 241. Overshot Water-wheels.—The overshot water-wheel shown in section in Fig. 110 is well adapted to falls between 10

and 70 feet and to a watersupply of from 3 to 25 cubic
feet per minute. On the
outside of the wheel is built
a series of buckets, which
should be of such a form as
to receive the water near the
top at D without spilling or
splashing, to retain the water
until near the bottom, and to
empty completely at the bottom. The number of buckets
must be such that there shall
be no spilling by overflow at
the top. The head of water




FIG. 110.—Section of Overshot Waterwheel.

above the wheel must be sufficient to give the falling water greater velocity than the periphery. The peripheral velocity in practice is from 5 to 10 feet per second, that of the falling water from 9 to 12 feet per second, corresponding to a height of from 16 to 27 inches above the wheel.

These wheels are not adapted to run in back water, and have the greatest efficiency for a given head when revolving just free from the discharged water.

The principal formulæ relating to the overshot-wheel are as follows:

Let d equal the depth of the buckets, b the width of the wheel, r the radius of the wheel, n the number of revolutions per second, v the peripheral velocity in feet per second, v the water-supply in cubic feet per second, v the capacity of that part of the wheel that passes in one second, v the ratio of the water actually carried to the capacity of the buckets—v being usually about one fourth—v the number of buckets.




FIG. 111.—SECTION OF BREAST-WHEEL.

Then, supposing the wheel to be set just free of the back water,

$$h = 2r + (1\frac{1}{8} \text{ to } 2) \text{ all in feet;}$$

$$N = \frac{2\pi r}{d} = \text{, usually, } 6r;$$

$$Q_1 = \frac{bv}{2r}(2rd - a^2) = bdv, \text{ nearly;}$$

$$Q = mQ_1 = mbdv;$$

$$v = 2\pi nr.$$

The efficiency is the ratio of the work delivered to the energy received from the falling water.

The efficiency of the best wheels of this class reaches 75 per cent.

242. Breast-wheels.—The form of breast-wheel is shown in Fig. 111. The water is received at a height slightly above or below the centre C of the wheel, and is prevented from falling away from the wheel by the curved breast ABE; the water acts on the radial or slightly curved buckets, thus tending to revolve the wheel partly by weight and partly by impulse.

The flow of water is regulated by a gate at S.

The formulæ applying to breast-wheels are essentially the same as those for overshot-wheels. The efficiency of the best wheels of this class varies from 58 to 62 per cent.

243. Undershot-wheels.—The undershot-wheel differs from the breast-wheel in receiving the water at or near the bottom; the water flows in a guide under the wheel, which guide

in some cases extends some distance up the sides. The usual form of such wheels is shown in Fig. 112; the buckets or floats are often radial, sometimes, however, of concave or bent form.

If we let c equal the velocity of water as it strikes the wheel, v the peripheral velocity of the wheel, Q the quantity of water in cubic feet




FIG. 112.-UNDERSHOT-WHEEL.

per second, G the weight per cubic foot, h, the portion of the head corresponding to the elevation of the entering water as it strikes the wheel over that of the discharge, P the force delivered at the circumference of the wheel; then will the efficiency  $\eta$  be obtained by the following formulæ:\*

$$\eta = \frac{Pv}{QG\left[\frac{(c-v)v}{g} + h,\right]}.$$

<sup>\*</sup> See Weisbach's Hydraulies, page 201.



From experiments of Morin it was found that when  $v \div c$  was less than 0.63, the efficiency  $\eta$  was 0.41. When  $v \div c$  was between 0.63 and 0.8,  $\eta$  was 0.33. The efficiency obtained from the best form of these wheels is 0.55.

Poncelet's Wheel.—When the floats of the undershot wheel are curved in such a manner that the entering jet of water is allowed to flow along the concave sides and press against them without causing shock, a greater effect is obtained than when the water strikes more or less perpendicularly against plane floats. Such wheels are called, after their inventor, Poncelet wheels. The efficiency of such wheels in some instances has reached 68 per cent.

244. Impulse-wheels.—In this class of wheels a single jet of water impinges on the buckets of the wheel as they are successively brought into position by the rotation. This class is very efficient for high heads and a small supply of water. The efficiency to be obtained by the action of a jet of water on a moving bucket is fully discussed in Vol. II., Church's "Mechanics of Engineering," page 808.

Denote by c velocity of the jet, v the peripheral velocity of the vane,  $\alpha$  the angle of total deviation relatively to the vane of the stream leaving the vane from its original direction, G the weight per cubic foot of water, F the area of the stream, Q the volume of flow per unit of time over the vane. The work done per unit of time,

$$L = Pv \frac{QG}{g}(c - v)v[1 - \cos \alpha].$$

This is maximum when  $v = \frac{1}{2}c$ .

In case a hemispherical vane is used,  $\alpha$  will equal 180°, and  $1 - \cos \alpha = 2$ . For that case,  $\alpha = 180^{\circ}$  and  $v = \frac{1}{2}c$ , we have

$$L=\frac{QG}{g}\cdot\frac{c^2}{2}.$$

In case the absolute velocity of the particles leaving the vane equal zero, an efficiency equal to unity would be possible.

Various forms of impulse-wheel are used. Fig. 113, from Weisbach's Hydraulics, shows an inward-flow tangential wheel of this class.

In this case the water is delivered to the wheel by the conical pipe BC, and is received by the curved buckets FF, and finally discharged on the inside of the wheel. In the figure G, G is the outer casing of the wheel, N the support.




FIG. 113.-HORIZONTAL IMPULSE-WHEEL,

Most of the small motors are of this class; the Backus motor using a jet at the top of the wheel and small curved buckets, the Pelton using a jet at the bottom of the wheel and a hemispherical bucket, with a centre partition which divides the jet into two portions, The efficiency of the Pelton wheel, which is also made in large sizes, has exceeded in some instances 0.92.

245. Turbines.—The turbine-wheels receive water constantly and uniformly, and usually in each bucket simultaneously. The buckets are usually curved, and the water is guided into the buckets by fixed plates. The name was originally applied in France to any wheel rotating in a horizontal plane, but the wheels are now frequently erected so as to revolve in vertical planes. The turbine was invented by Fourneyron in 1823, the original wheel being constructed to receive water near

the axis, and to deliver it by flow outward at the circumference. Turbines are now built for water flowing parallel to the axis, and also inward from the circumference toward the centre; they are also constructed double and compound. In some of the turbines the wheel-passages or buckets are com pletely filled with water, in others the passages are only partly filled.

The following classes are usually recognized:

- I. Impulse Turbines.
- II. Reaction Turbines.

In both these classes the flow may be axial outward, inward, or mixed, and the turbine may be in each case simple, double, or compound.

In the *Impulse turbines* the whole available energy of the water is converted into kinetic energy before it acts on the moving part of the turbine. In these wheels the passages are never entirely filled with water. To insure this condition they must be placed a little above the tail-water and discharge into free air.

In the Reaction turbines a part only of the available energy of the water is converted into kinetic energy before it acts on the turbine. In this class of wheels the pressure is greater at the inlet than at the outlet end of the wheel-passages. The wheel-passages are entirely filled with water, and the wheel may be, and is generally, placed below the water-level in the tail-race.

246. Theory of the Turbine.\*—The water flowing through a turbine enters at the admission-surface and leaves at the discharge-surface of the wheel, with its angular momentum relative to the wheel changed. It must exert a couple -M, tending to rotate the wheel, and equal and opposite to the couple M which the wheel exerts on the water. Let Q cubic feet enter and leave the wheel per second,  $c_1$ ,  $c_2$ , be the tangential components of the velocity of the water at the receiving and discharging surfaces of the wheel,  $r_1$ ,  $r_2$ , the radii of these surfaces. Then

$$-M = \frac{GQ}{g}(c_1r_1 - c_1r_1). \qquad (1)$$

<sup>\*</sup>See "Hydromechanics," Encyc. Britannica.

If  $\alpha$  is the angular velocity of the wheel, the work done on the wheel is

$$T = M\alpha = \frac{GQ}{g}(c_1r_1 - c_2r_2)\alpha \text{ foot-pounds per second.}$$
 (2)

The total head of the water  $h_t$  is reduced by friction and resistances  $h_t$  in the channels leading to the wheel, so that the effective head h which should be used in calculating the efficiency is

$$h = h_t - h_t . \qquad . \qquad . \qquad . \qquad . \qquad . \qquad (3)$$

In case the construction of the turbine requires that it set above tail-race d feet, the velocity of water in the turbine should be calculated for a head of h-d, but the efficiency for a head of h feet. The work of the turbine is partially absorbed in friction.

Let T equal the total work,  $T_d$  the useful work, and  $T_t$  the work used in friction. Then

The gross efficiency

The hydraulic efficiency

The hydraulic efficiency is of principal importance in the theory of turbines. Substituting this value of T in equation (2).

$$\eta = \frac{(c_1 r_1 - c_2 r_2)\alpha}{gh}; \quad . \quad . \quad . \quad . \quad (7)$$

which is the fundamental equation in the theory of turbines.

For greatest efficiency the velocity of the water leaving should be 0, in which case  $c_1 = 0$  and

But  $r_1\alpha$  is the lineal velocity of the wheel at the inlet surface; if we call this  $V_1$ ,

$$\eta = \frac{c_1 V_1}{gh}. \qquad (9)$$

The efficiency of the best turbines is 0.80 to 0.90.

Speed of the Wheel.—The best speed of the wheel depends on frictional losses which have been neglected in the preceding formulæ. The best values are the ones obtained by experiment. Let  $V_{\bullet}$  equal the peripheral velocity at outlet,  $V_{i}$  at inlet,  $r_{\bullet}$  and  $r_{i}$  the corresponding radii of outlet and inlet surfaces. Then we shall have as best speeds\* for

axial-flow turbine  $V_0 = V_i = 0.6 \sqrt{2gh}$  to 0.66  $\sqrt{2gh}$ ;

radial outward-flow turbine  $V_i = 0.56 \sqrt{2gh}$ ;  $V_0 = V_i \frac{r_0}{r_i}$ ;

radial inward-flow turbine  $V_i = 0.66 \sqrt{2gh}$ ;  $V_{\bullet} = V_i \frac{r_{\bullet}}{r_i}$ .

247. Forms of Turbines.—Fourneyron's Turbine.—This is an outward flow turbine, with a horizontal section as shown in Fig. 114. C is the axis of the wheel, which is protected from the water by vertical concentric tubes shown in section. On the same level with the wheel and supported by these tubes is a fixed cylinder, with a bottom but no top, containing the curved guides F F. The wheel AA is supplied with curved buckets bd,  $b_1d_1$ , so arranged as to absorb most of the energy of the water; the water enters the wheel at the inner edges of the buckets and is discharged at the outer circum-

<sup>\* &</sup>quot; Hydromechanics," Encyc. Britannica.

ference. Gates for regulating the supply of water are shown in section between the ends of the guides and the wheel.




FIG. 114.—OUTWARD-PLOW TURBING.

248. Reaction-wheels.—The simple reaction-wheel is shown in Fig. 115, from which it is seen to consist of a vertical cylinder, CB, which receives the water, and two cylindric arms,

G and F; on opposite sides of each arm is a circular orifice through which the water is discharged. The effect of this arrangement is to reduce the pressure on the sides toward the orifices, thus producing an unbalanced pressure which tends to make the wheel revolve. If we denote by h the available fall measured from the level of the water in the vertical pipe to the centre of the orifices, r the radius of rotation measured from the axis to the Fig. 115.—The Reaction-wheel.



centre of each orifice, v the velocity of discharge,  $\alpha$  the angular velocity of the machine, F the area of the orifices,—when at rest the velocity would equal  $\sqrt{2gh}$ , but when in motion the water in the arms moves with a velocity  $\alpha r$ , which corresponds to an increased head due to centrifugal force of  $\alpha^2 r^2 \div 2g$ .

Hence the velocity of discharge through the orifices is

$$v = \sqrt{2gh + \alpha^2 r^2};$$

the quantity discharged

$$Q = Fv = F\sqrt{2gh + \alpha^3 r^3}.$$

Since the orifices move with a velocity  $\alpha r$ , the velocity with reference to a fixed point is  $v - \alpha r$ .

If G be the weight per cubic foot, the momentum or mass times the velocity is

$$\frac{GQ}{g}(v-\alpha r)$$


This mass moves with an angular velocity  $\alpha$  and arm r, hence the work done per second in rotating the wheel is

$$\frac{GQ}{g}(v-\alpha r)\alpha r \text{ foot-pounds.}$$

The work expended by the water-fall is GQh. Hence the efficiency

$$\eta = \frac{(v - \alpha r)\alpha r}{gh}$$

This increases as  $\alpha r$  increases, or the maximum efficiency is reached when the velocity is infinite. The friction considerably reduces these results, and experiment indicates the greatest



the wheel.

efficiency when  $\alpha r = \sqrt{2gh}$ . In which case, by substitution, we should have

$$\eta = 0.828$$
.

The best efficiency realized in practice with these wheels is about 0.60.

The Scottish turbine, shown in Fig. 116 in section, is a reaction-wheel with three discharge-jets, the water being supplied from a tube filled with water under pressure beneath

249. The Hydraulic Ram.—The hydraulic ram is a machine so arranged that a quantity of water falling a height h forces a smaller quantity through a greater height h'.




FIG. 117.-HYDRAULIC RAM.

The essential parts of the hydraulic ram are: 1. The air-chamber C, connected with the discharge-pipe eD, and provided with a clack or check-valve o, opening into the chamber C from the pipe ss.

- 2. The waste-valve, Bd, is a weighted clack or check-valve, opening inward and connected to a stem df; on the stem is a nut or cotter at f to regulate the length of stroke, i.e., amount of opening of the waste-valve.
- 3. The supply-pipe ss, that leads to a reservoir from which the supply is derived, should be of considerable length. If it is very short when laid in a straight line, bends must be made to secure additional length, and also to present some resistance to the backward wave-motion; its length must not be less than five times the supply-head. The working parts of the ram are the check-valve o and the waste-valve dB; these parts move in opposite directions, and alternately.

The action of the ram is explained as follows:

Water is supplied the ram by the pipe ss; the waste-valve dB being open, the water escapes with a velocity due to the height h. The water escaping at d suddenly closes the waste-valve. The acquired momentum of the moving column of water in the pipe ss is sufficient to raise the valve o and discharge a portion of its weight to a height h'. As soon as the pressure is reduced the valve o closes, the waste-valve dB opens and the water again flows down the pipe ss. These motions are produced with regularity, and the water acquires a backward and forward wave-motion in the pipe ss. A small air-chamber at p, with a small check-valve opening inward at c to supply the chamber with air, are found to add to its efficiency.

The wave-motion has been utilized to operate a piston backward and forward beyond the waste-valve, the piston being utilized as a pump in raising water from a different supply.

Formulæ.—Let h equal the height of the reservoir above the discharge-valve of the ram, h' the height to which the water is raised in the discharge, Q the total water supplied to the ram per second, q the amount raised to the height h', G the weight per cubic foot. Then the useful work equals Gqh'; the work which the water is capable of doing equals GQh.

The efficiency

$$\eta = \frac{qh'}{Qh}.$$

Rankine (see Steam-engine, page 212) gives the following formulæ for obtaining the dimensions of a ram:

Let L equal length of supply-pipe, D the diameter of supply-pipe in feet; other symbols as above. Then

$$D = \sqrt{1.63Q}, \qquad L = H + h + \frac{2h}{H}.$$

Volume of air-chamber C equals volume of feed-pipe. 250. Methods of Testing Water-motors.—The methods of testing hydraulic motors require in all cases the measurement (1) of volume or weight of the water discharged, (2) of the net head, or pressure acting on the motor, or (3) the velocity of discharge. From these measurements may be computed the *energy received* by the motor, by the formulas already given.

1. Measurement of the Water may be made in the case of small motors by receiving the discharge in tanks standing on scales; two tanks will be required, one of which is filling while the other is emptying. Temperature observations must be taken, and from the known weight and temperature the volume (Q) may be computed, if required. The tanks may be previously calibrated by filling to a known point, and be so connected that any excess will pass into the tank recently emptied, in which case a method similar to the above may be used without scales.

The measurement will usually have to be made by discharging over weirs (see page 246) or through nozzles or Venturi tubes; this will be especially true for large motors.

With water-pressure engines an approximate measurement may be made by the piston-displacement, corrected for slip. A discussion of the effect of slip is to be found on page 302.

2. Measurement of the Head (h) may be made, in the first place. by taking a series of levels from standing water in the tank or dam above, to the level of the water in the tail-race. Inis measurement must be corrected for loss of head by friction in the pipes, or by flowing over obstructions, etc., this at best can be made only in an approximate manner. To secure the full effects of the head, some turbine-wheels are set with draught or suction tubes leading from the wheel to the waterlevel in the tail-race; this will not affect the method of measuring the head. The head acting on the wheel is measured most accurately by a calibrated pressure-gauge, placed in the supplypipe near the motor. The reading of this gauge if merely attached to the supply-pipe in the usual manner, would be that due to the pressure-head only, and would be less than the true head acting on the pipe. By inserting a tube well into the current, and bent so as to face the current, thus forming a Pitot

tube (Article 222, page 265), the pressure will be increased the amount due to the velocity-head, and the gauge if attached to this tube will give the pressure corresponding to the actual head. To the head so obtained must be added the distance from the centre of the gauge to the level of the water in the tail-race. In case the draught-tube is used, a vacuum gauge or mercury manometer can be attached, and the suction-head calculated from the gauge-reading may be compared with the measured distance. In case two gauges are used, the vertical distance between them must be measured, and considered a portion of the head.

To obtain the head corresponding to a given pressure, in pounds per square inch, multiply the gauge-reading by the height, in feet, of water corresponding to one pound of pressure.

One pound of pressure per square inch corresponds to 2.308, 2.309, 2.31, 2.312, 2.315, 2.319, and 2.32 feet of head of water at the temperatures of 40°, 50°, 60°, 70°, 80°, 90°, and 100° F., respectively.

The head of one inch of mercury corresponds to 1.13 feet of water at 70° F.

Knowing the quantity or weight of discharge and the head, the *energy received* may be computed by any one of the four forms in equation (1), Article 237, p. 281.

3. The velocity of discharge can seldom be measured directly; it can be computed from measures of the pressure or net head, since the velocity  $V = \sqrt{2gh}$ . It is rarely of importance.

In case the motor is supplied with water through a nozzle, its least area may be determined by measurement; then the quantity discharged may be computed as the product of velocity, least area, and coefficient. (See Article 204, p. 247.)

251. Special Tests.—Backus or Pelton Motors.—Apparatus needed.—Pressure-gauges, two receiving tanks on scales or small weirs, Prony brake, pipes to remove water, thermometer.

Testing Directions.—Measure nozzle; note its position and the angle at which jet will strike buckets; attach pressure-gauge, and arrange to measure discharged water; attach Prony brake. Vary the head of water by throttling the supply; if

heads are required greater than will be given by the water-works pressure, they must be supplied by pumping with a steam-pump. Take four runs of one half-hour each, with heads varying by one fourth, the greatest to be attained. Obtain corrections to head for position of gauge. Make running start. Take observations once in five minutes of water discharged, temperature, gauge-readings, weight on Prony brake-arm, and number of revolutions.

In report, describe motor, with dimensions, method of testing; compute energy received in foot-pounds per minute and in horse-power; compute work done in the same units; compute efficiency of each run, also for varying velocity of perimeter.

Make a plot on cross-section paper, with work delivered in foot-pounds per minute as abscissæ, and heads as ordinates. Compare theoretical with actual efficiency.

Turbine Water-wheels.—Large weirs must be arranged with which the discharged water can be measured. A Prony brake is to be arranged to absorb the power from the wheel, or a large transmitting dynamometer may be provided to receive the power developed by the wheel. Measurements to be made as explained in Article 250.

Water-pressure Engines are to be tested essentially as described for the hydraulic ram: When used to operate a pump, indicator-diagrams are to be taken from both engine and pump ends, as explained in the chapter on steam-engine testing. From these can be computed the energy received by the pistons of the water-engine and that delivered from the piston of the pump. The quantity of water received will have to be measured independently.

Hydraulic Ram.—Apparatus as before, with additional pressure-gauge for discharge-pipe, means of measuring the water delivered and the water wasted.

Testing.—Measure head of water acting on the ram and of that delivered as explained. Make runs of one half-hour each, with varying heads of supply and delivery. Take observations once in five minutes of gauge on supply-pipe, on

delivery-pipe, of weir-readings or weights of water wasted, and of water delivered. Compute the energy received and work done expressed in foot-pounds per minute, and also the efficiency for each run.

In Report.—Describe the ram, method of testing, and draw a curve, with heads as ordinates and foot-pounds of work as abscissæ.

252. Forms for Tests of Hydraulic Motors.—The following form for log and results has been used by the author:

									_	D. H	ī. P.	
Q =	••••		• • • • •	•		DA	TA.		E	$=\frac{\mathrm{D. H}}{\mathrm{W}}$	₹H	× 33,000.
				À	ď	Q	w	P	D	D.H.P.	E	city of loc- sad.
		ing.	Hea Wh	d on eel.	8 .	Water	used.	-load et).	Revolutions per minute.	de- ed by	ncy, ent.	Ratio of velocity of periphery of wheel to velocity due to head.
No.	Time.	Gate Opening.	Lbs.	Ft.	Depth on Weir.	Cu. ft. per sec.	Lbs. per min.	Brake-load (net).	Revol per in	H. P. de- veloped by Wheel.	Efficiency, per cent.	Ratio of p
						<u> </u>						

The following form for test of the Swain turbine is used at the Massachusetts Institute of Technology:

### TEST ON SWAIN TURBINE.

No.		Date188							
	Time. Read-ling of Counter.				Height of Water in Tank.	10	Read- ing of Hook-	Hook- gauge Read- ing.	Tem- pera- ture in Wheel- pit.
Total Average Corrected.	<b> </b>	<b></b>							
Diameter o	of whe	el	• • • • • • •	ft.	Radi	us of b	rake		
Crest of we	ir abo	ve floo	r of pit.						ft.
Width of w	eir an	d pit	• • • • • • •						ft.
Correction	for ho	ook-gau	ge						ft.
									,
					_				
Observed d	lepth (	on weir	(correct	ed)	• • • • • •	• • • • • • •	• • • • • • •	• • • • • • • • •	ft.
Total head	acting	g on wh	eel			• • • • • •		• • • • • • • •	∴ft.
Weight of	ı cubi	c foot v	vater at.		° Fahr.		•••••	• • • • • • • • •	lbs.
Revolution	s of w	heel pe	r minute		• • • • • •		<i>.</i>		
Quantity of	f wate	r passi	ng weir (	uncorre	cted)	• • • • • •			cu. ft.
4.6	**	**	" (	(correct	<b>e</b> d)			• • • • • • • •	cu. ft.
Available v	vork.			• • • • • •			••••	ftlbs.	per sec.
Work at br									•
Efficiency.				`	• • • • • •			р	er cent.
Horse-pow	er of	wheel.	• • • • • • •				• • • • • •	• • • • • •	
Velocity du	ie to l	iead ac	ting on w	heel	•••••			ft.	per sec
Velocity of	outsi	de of w	heel	· · · · ·			• • • • • • •		per sec
			Signe	i	• • • • • •				• • • • • • ·

253. Classification of Pumps.—The different classes of pumps correspond almost exactly to the different classes of water-motors, with the mechanical principles of operation reversed.

Ordinary reciprocating pumps correspond to water-engines; chain- and bucket-pumps, to water-wheels in which the water acts principally by weight. Scoop-wheels are similar to undershot water-wheels, and centrifugal pumps to turbines. The various classes of pumps are as follows:

A. Reciprocating, divided according to the method of construction into lift, force, combined lift and force, double-acting, and diaphragm.

B. Rotary, divided into: (1) inferential, in which the water is urged forward by the velocity of the working parts of the pump, as in the centrifugal pump; (2) positive, in which all the water that passes the pump is lifted or forced by the working parts of the pump to a higher level; the working parts of these pumps are usually gears or cams meshing together. These pumps are often spoken of as rotary, in distinction from centrifugal.

Pumps are also classified by the power used to drive them. Thus, pumps driven directly by attached engines are termed steam pumping-engines or steam-pumps; those driven from running machinery by belts or gears are termed power-pumps; those operated by hand, hand-pumps.

254. Duty and Capacity.—The term duty is applied to the work done by steam-pumps. This term originally signified the number of pounds of water lifted one foot by the consumption of one bushel (94 pounds) of coal; more recently it has been the water lifted one foot by the consumption of 100 pounds of coal. It has, in recent tests, been customary to assume that each pound of coal evaporates ten pounds of water, from and at 212°, under atmospheric pressure. As each pound of water evaporated under such conditions requires 965.7 British thermal units,\* and each B. T. U. is equivalent to 778 foot-pounds of work, a definite amount of work is done by 100 pounds of coal, equivalent to 965,700 B. T. U., or to 751,314,600 foot-pounds.

The duty of a power-pump, expressed in the same manner,

<sup>\*</sup> A British thermal unit, symbol B. T. U., is the heat absorbed in raising one pound of water one degree Fahr, in temperature.

is the number of foot-pounds of water raised by 751,314,600 foot-pounds of energy expended on the pump and accessories.

A committee appointed by the American Society of Mechanical Engineers (see Vol. XI. of Transactions American Society Mechanical Engineers, p. 668) recommend that in a standard method of conducting duty trials, 1,000,000 thermal units, or 778,000,000 foot-pounds, be taken as the basis from which the duty is computed. This is equivalent to the evaporation of 10.35 pounds of water per pound of coal, from and at 212°, and is likely to be adopted in future trials, in which case the duty becomes the number of foot-pounds of water delivered for 1,000,000 British thermal units of energy supplied the plant.

The capacity of a pump is usually expressed as the number of gallons of water that can be raised against a specified head in 24 hours of time; a gallon being considered as equivalent to 8.3389 pounds at a temperature of 39.2°.

255. Measurement of Useful Work.—The useful work done by a pump is the product of the number of pounds of water delivered into the head through which it is raised.

The head is the total vertical distance in feet from the surface of the water-supply to the discharge, increased by friction. It is measured most accurately by pressure-gauge connected to a Pitot's tube (p. 265) with its nozzle facing the current inserted in the discharge pipe, near the pump, and by a vacuum gauge or manometer connected to the suction pipe. The head in feet is equal to the distance between these gauges plus the total readings of the gauges, reduced to equivalent heads of water (see p. 296).

The water delivered may be measured by discharging over a weir, or through a nozzle or tapering pipe called a Venturi tube. (See Article 204, p. 247.)

The discharge through a *Venturi tube* may be taken as 98 per cent of the theoretical discharge, that through a straight conical nozzle as 97.7 per cent.\*

<sup>\*</sup> See papers before Am. Soc. Civil Engineers, by Clemens Herschel, Nov. 1887 and Jan. 1888, and by J. R. Freeman, Nov. 1889.

Delivery measured from Piston-displacement.—Slip.—The water delivered in the case of piston-pumps is often computed by multiplying the total piston-displacement during the test by I, minus the slip. The total piston-displacement is equal to the product of area of piston by length of strokes, by total number of single strokes. In piston-pumps the length of stroke is often variable, in which case especial means must be adopted to find the average length. The slip is the percentage that the actual delivery is less than the total piston-displacement; it can only be determined accurately by comparing the volume actually discharged with the total displacement. The slip is caused by air in suction-pipe, leakage past piston, leakage past valves in either suction- or discharge-pipe, and imperfect port-openings. The principal cause probably comes from leakage past the piston, and this leakage can often be determined by removing the cylinder-head, blocking the piston, subjecting it to the water-pressure for at least one hour, and measuring all the water that leaks past it. This test should be repeated for various positions in the stroke. The valve leakage can often be determined by a similar test. No air should be admitted to the suction-pipe.

A table of percentage of slip is given in Hill's Manual, published by the Harris-Corliss Engine Co., from which it is seen that the slip for large pumps is about two per cent, and that it varies from one to five per cent.

256. Efficiency-tests of Pumps.—An -efficiency-test will require in each case measurements of, firstly, the energy or work supplied the pump; secondly, the useful work; thirdly, the lost work.

The difference in methods of testing the various classes of pumps, as described in Article 253, simply extends to the measurement of the power supplied the pump.

The steam-pump, or steam pumping-engine, is to be considered as a combination of the steam-engine with a pump. The power received by the pump is that delivered by the engine, and is determined by a steam-engine test. The method of testing steam pumping-engines, and standard method

of making duty-trials, as adopted by the American Society of Mechanical Engineers, will be given under special applications of the method of testing engines.

The power-pump receives its energy from machinery in operation; the energy received may be measured by a standardized transmitting-dynamometer (see Chapter VII.), or, in the case of a rotary or centrifugal pump, by mounting in a frame having a free angular motion, which is unaffected by the tension on the driving-belt. The resistance to rotation is obtained by a known weight on a known arm, and the power supplied in foot-pounds is the product of the circumference that might be described by the arm as radius, number of revolutions, and the weight. Such a framework is termed a cradle-dynamometer.

257. Special Efficiency-tests—Power-pumps.—Efficiency-test of Centrifugal Pumps—Directions.

Apparatus needed.—Pressure-gauge for delivery, manometer for suction, transmission-dynamometer, thermometer, weir for discharge.

Directions.—Connect suction pipe to supply-tank, and arrange discharge with throttle-valve to deliver water over a weir. Connect delivery-gauge to an elongated air chamber, which in turn is connected with the delivery-pipe, provided with a water gauge-glass opposite the pressure-gauge, and means of changing water-level and air-level.\* Connect manometer or vacuum-gauge to suction-pipe; obtain vertical distance between these gauges. Arrange a standardized transmission-dynamometer to receive the power, and drive the pump.

During the test maintain the water in the air chamber at height of centre of the gauge.

Testing.—Set the machinery in operation; arrange the throttle-valve to give an approximate head of 50 feet. After uniform conditions are assumed, start the run; take readings once in five minutes of hook-gauge at weir, of temperature of water, of discharge-gauge, of suction-guage, of dynamometer-

<sup>\*</sup> See Test of Steam Pumping-engines.

or power-scale. Continue the run for one hour with uniform pressure on discharge-gauge.

Make a second run with an approximate head of 75 feet, and a third run with an approximate head of 100 feet.

Report.—In report, calculate efficiency, duty, and capacity for each head; draw a curve of each test, using power in footpounds as ordinates, and total water delivered as abscissæ. Describe the pump and method of testing.

Efficiency-test—Rotary Pump—Directions.—Apparatus and connections as for centrifugal pump, the power transmitted being measured either by a transmission-dynamometer, or by a balanced cradle-dynamometer; the water may be measured by a weir, or it may be delivered into two weighing tanks, one of which is filling, the other emptying, and the water weighed. Directions for the test are as in the preceding.

258. Form for Log and Report of Pump-tests.—The following form for data and report is used at the Massachusetts Institute of Technology for log and data of test on Webber centrifugal pump and on rotary power-pump:

TEST ON WEBBER CENTRIFUGAL PUMP.

		!	Wäter			He	Emerson Power-scale.				
		Read-	8	ä	ins.	ε <u>.</u> .	.g	.s	Pumpi	ng.	Tare.
No. of Gong.	Time.	Hook-gauge R ing.	Depth of Water Weir in feet.	Temperature Weir.	Suction-gauge, of mercury.	Discharge-gauge,	Actual Suction feet.	Actual Head feet.	Scale-reading.	per minute.	Revolutions
Fotal					<u>····</u>						

*No....* 

Crest of weir above bottom of channelft.
Width of weirft.
Revolutions of pump per minute
Water pumped inlbs.
Duration of testmins.
b ( Depth of water on weir
Temperature at weir (corrected)° C° F.
Suction-gauge (corrected)insft.
Discharge-gauge (corrected)
Actual suction
Actual headft.
မှ ြင်္သ Scale-readinglbs.
Scale-reading
Scale-readinglbs.
Revolutions per minute
Water pumped in minuteslbs.
Capacity in gallons per minute
Total work by power-scale (pumping)
TareH. P.
Work given to pump
Work delivered by pumpH. P.
Efficiencyper cent.
Duty (ftlbs. per 1,000,000 B. T. U.)
Signed
•

# LOG OF TEST ON ROTARY PUMP.

			Power-scale.				Gauges.		Orifices.		
No of Gong.	Time.	Pumping.		Tare.		Suction,	Deliv-	Head,	Tomos		
-		Counter	Revolu- tions.	Weight.	C.	R.	w.	inches mercury	Der	in feet.	Temper- ature.
				!	1						
	 				_	_	! ¦—			 	
Total Av Cor.									 		

# RESULTS OF TEST ON ROTARY PUMP.

No	Dale	
Duration of test		min.
Power-scale, pumpin	g, revolutions per minute	•••
"	weight	.lbs.
" tare,	revolutions per minute	
" " w	eight	.lbs.
Suction-head by gaug	geft.	H.0
Discharge-head by ga	augelbs. per sq. in	••
	•	"
Temperature	° C,	• F.
Revolutions of pump	per minute	
Area of discharge at	gaugeso	ą. ft.
Vertical distance bets	ween gauges	fL
Diameter of orifices,	a, b, c, d, e, f, g, k, s	i
Coefficients,	a, b, c, d, e, f, g, h,	
Constant for power-s	cale	ft.
Power-pumping, by	scaleH	. P.
Tare	н	. P.
Power given to pump	p	. P.
	harge	
Total head == press.	heads + vel. head + vert. dist. bet. gauges	. ft.
	lbs. per	
Work done by pump		i. P.
Efficiency of pump	per (	ent.
·Capacity of pump in	gallons per minute	••••
	s. per 1,000,000 B. T. U.)	
	C: J	

# PART II.

# METHODS OF TESTING THE STEAM-ENGINE.

#### CHAPTER X.

#### DEFINITIONS OF THERMODYNAMIC TERMS.

259. General Remarks.—The methods of testing the steam-engine which are given here presume an accurate knowledge of the principles of action of the engine, an acquaintance with the details of its mechanism, and a knowledge of the thermodynamic principles which relate to the transformation of heat energy into work. In connection with the methods of testing, the student is advised to read one or more of the following books:

Manual of the Steam-engine, by R. H. Thurston. 2 vols. N. Y., J. Wiley & Sons.

Manual of Steam-boilers. Ibid.

Engine and Boiler Trials. Ibid.

Étude Expérimentale Calorimétrique de la Machine à Vapeur, par V. Dwelshauvers-Dery. Paris, Gauthier-Villars et Fils.

Steam-engine, by D. K. Clark. 2 vols. N. Y., Blackie & Co.

Steam-engine, by C. V. Holmes. 1 vol. London, Longmans, Green & Co.

Steam-engine, by J. M. Rankine. 1 vol. London, Chas. Griffin & Co.

Steam-making, by C. A. Smith. 1 vol. Chicago, American Engineer.

Steam-using. Ibid.

Steam-engine, by James H. Cotterill. London, E. & F. N. Spon. Thermodynamics, by C. H. Peabody. N. Y., J. Wiley & Sons. Thermodynamics, by De Volson Wood. N. Y., J. Wiley & Sons.

Thermodynamics, by R. Clausius. N. Y., Macmillan. Steam-tables, by C. H. Peabody. N. Y., J. Wiley & Sons. Handy Tables, by R. H. Thurston. N. Y., J. Wiley & Sons.

260. Relations of Units of Pressure.—The term pressure, as employed in engineering, refers to the force tending to compress a body, and is expressed as follows: (1) In pounds per square inch; (2) In pounds per square foot; (3) In inches of mercury; (4) In feet or inches of water.

The value of these different units of pressure are as follows:

TABLE SHOWING RELATION BETWEEN PRESSURE EXPRESSED IN POUNDS, AND THAT EXPRESSED IN INCHES OF MERCURY, OR FEET OF WATER.

Pressure in	Pressure in	70° Fah.						
pounds per sq. inch.	pounds per sq. foot.	Inches of mer- cury.	Feet of water.	Inches of water				
1	144	2.0378	2.307	27.68				
2	288	4.0756	4.614	55.36				
3	432	6.1134	6.921	83.04				
4	j 576	8.0512	9.23	110.72				
5	720	10.1890	11.54	138.40				
6	864	12.2268	13.85	166.08				
7	1008	14.2646	16.15	143.76				
8	1152	16.3024	18.46	221.44				
9	1296	18.3402	20.76	219.12				
10	1440	20.3781	23.07	276.80				

The barometer pressure is that of the atmosphere in inches of mercury reckoned from a vacuum. At the sea-level, latitude of Paris, the normal reading of the barometer is 29.92 inches, corresponding to a pressure of 14.7 pounds per square inch.

Gauge or Manometer pressure is reckoned from the atmospheric pressure.

Absolute pressure is measured from a vacuum, and is equal to the sum of gauge-pressure and barometer readings expressed

in the same units. Absolute pressure is always meant unless otherwise specified.

Pressure below the atmosphere is usually reckoned in inches of mercury from the atmospheric pressure, so that 29.92 inches would correspond to a perfect vacuum at sea-level, latitude 49°.

261. Heat and Temperature.—The term *heat* is used sometimes as referring to a familiar sensation, and again as applying to a certain form of energy which is capable of producing the sensation. In this treatise it is used in the latter sense only.

Temperature is essentially different from heat, and is merely one of its qualities; it is difficult to define, but two bodies are of equal temperature when there is no tendency to the transfer of heat from one to the other. Temperature is measured by the expansion of some substance in an instrument termed a thermometer. Two points, that of melting ice and of steam from water boiling at atmospheric pressure, are fixed temperatures on all scales of thermometry. The expansion between these points is divided into various parts according to the scale adopted, and each part is termed a degree.

The following thermometric scales are in use in different portions of the world:

Fixed Po	ints, Temp	erature (	of Water.	Fahrenheit.	Centigrade,	Réaumur
Degrees be ing point Temperatu	tween fre	ezing	and boil- }	. 180	100	80
Temperatu	re at freez	ing po	nt	32	0	0
Comparativ	ve length	ı degre	e	1	1	2
	ei.	"		<b>₹</b>	1	Ī
**	**	"		1 1	4	, ,

Degrees of temperature taken on one scale can easily be reduced to any other; thus, let  $t_f$  be the temperature of a body on the Fahrenheit scale,  $t_c$  on the Centigrade scale, and  $t_r$  on the Réamur scale. We shall have, from the preceding table,

$$t_f = \frac{9}{8}t_c + 32^\circ;$$
  
 $t_c = \frac{5}{8}(t_f - 32^\circ);$   
 $t_f = \frac{9}{4}t_r + 32^\circ.$ 

The Fahrenheit thermometer is used principally by Englishspeaking people, and unless otherwise mentioned is the one used in this treatise.

The *Thermometric Substances* principally used are mercury, alcohol, and air, from the expansion of which the temperature is obtained.

Absolute Zero.—This quantity is fixed by reasoning as the point where gaseous elasticity or expansion would be zero. This is 492°, more exactly 491.8°, of the Fahrenheit scale or 273° +\* of the Centigrade scale below the freezing-point of water, so that in the Fahrenheit scale the absolute temperature is 460° + the reading of the thermometer, and on the Centigrade scale 273° + the reading of the thermometer.

Absolute Temperature, on any scale, is temperature reckoned from absolute zero.

262. Specific Heat.—Specific heat is the ratio of that required to raise a pound one degree in temperature compared with that required to raise one pound of water from 60° to 61° Fahr.

Specific heat of water is not quite constant, but varies as follows: †

Centigrade.	Fahrenheit.	Specific Heat.	Centigrade.	Fahrenheit.	Specific Heat.
0°	32°	1.0072	30°	86°	0.9954
5°	41°	1.0044	35°	95°	0.9982
10°	50°	1.0016	40°	104°	1.0000
15°	59°	1.0000	45°	113°	1.008
20°	68°	0.9984	155°	311°	1.046
25°	77°	0.9948	200°	392°	1.046

Specific heat of saturated steam at atmospheric pressure was found by Regnault to equal 0.478. Investigations made at Sibley College would seem to indicate that the specific heat of steam increases with the pressure and temperature.

The heat contained in different bodies of the same tempera-

<sup>\*</sup> Encyc. Brit., Vol. XI. p. 573.

<sup>†</sup> See Peabody's Steam-tables.

ture, or in the same body in its liquid and gaseous condition, is quite different and cannot be measured by the thermometer. Thus in equal weights of water and iron at the same temperature, the heat in the water is several times that in the iron. This is known because in cooling a degree in temperature, water will heat a much greater weight of some other substance.

263. Mechanical Equivalent of Heat.—The experiments made by Rumford and Joule established the fact that heatenergy could be transformed into work, or vice versa. The results of Joule's latest determination gave the mechanical work equivalent to the heating of one pound of water one degree Fahr. in temperature as 774 foot-pounds, while the later and more refined determinations of Rowland, reduced to 45° of latitude and to the sea-level, make the mechanical work equivalent to the raising the temperature of one pound of water from 62° to 63° Fahr. to be 778 foot-pounds. The heating of one pound of water one degree, from 39° to 40° Fahr., is termed a British thermal unit, B. T. U., and this is equivalent in mechanical work to 778 foot-pounds. This number is represented by J and its reciprocal by A throughout this work.

The heat needed for raising one kilogram of water one degree Centigrade is termed a *calorie*, and this is equivalent to 426.9 foot-pounds.

In some treatises a British thermal unit is the heat required to raise one pound of water from 62° to 63° Fahr., which differs little from that defined above.

264. Relations of Pressure and Temperature of Steam.—There is a definite relation between the temperature and pressure of steam in its normal or saturated condition. This relation was very carefully investigated 1836–42 by M. V. Regnault in Paris by a series of careful experiments made on a large scale. These experiments form the basis of our experimental knowledge of the properties of steam.

The properties of steam are also shown by the thermodynamic laws, and are given in tables of Rankine, Clausius, M. V. Dwelshauvers-Dery, Peabody, and Buel.

The following empirical formula, deduced from Regnault's

experiments, gives the relation between the temperature and pressure of steam at a latitude of 45°:

For steam\* from 32° to 212° Fahr. pressure in pounds per square inch,

$$\log p = a - ba^T + cB^T,$$

in which a = 3.025908,  $\log b = 0.61174$ ,  $\log c = 8.13204 - 10$ ,  $\log a = 9.998181015 - 10$ ,  $\log B = 0.0038134$ ,  $T = t - 32^\circ$ .

For steam from 212° to 428° Fahr.,

$$\log p = a_1 - b_1 a_1^T + c_1 B_1^T,$$

in which  $a_1 = 3.743976$ ,  $\log b_1 = 0.4120021$ ,  $\log c_1 = 7.74168 - 10$ ,  $\log a_1 = 9.998561831 - 10$ ,  $\log B_1 = 0.0042454$ ,  $T = t - 212^\circ$ .

- 265. Properties of Steam.—Definitions.—Steam occurs in two different conditions: 1, saturated; 2, superheated.
- I. Saturated Steam.—This can exist only in contact with the water from which it was generated, although the quantity of water present may be very small.

Saturated steam of any pressure is at the lowest temperature and possesses the least specific volume and the greatest density consistent with that pressure. The slightest decrease in temperature results in partial condensation, forming what is termed moist or wet steam, in distinction from dry steam. Thus saturated steam may be either wet or dry. The percentage of dry steam in a mass of wet steam is termed its quality.

2. Superheated steam cannot exist in contact with the water from which it was generated. Its temperature is higher, its specific volume greater and its density less than saturated steam of the same pressure.

Steam-tables give the properties of dry saturated steam only and usually arranged with absolute pressure as the argument or given quantity. The important properties are as follows:

(a) Total Heat (symbol, λ).—This is the amount of heat required to convert one pound of water from 32° into saturated

<sup>\*</sup> Steam-tables, by Prof. Cecil H. Peabody.

steam at a pressure P. If t is the temperature of the steam, the total heat,  $\lambda$ , is calculated by an empirical formula based on the experiments of Regnault. Expressed in English units,

$$\lambda = 1081.4 + 0.305t.$$

(b) Heat of the Liquid (q) is the number of thermal units used in heating one pound of water from 32° Fahr. to the temperature required to generate steam. According to Regnault,

$$q = t + 0.00002t^2 + 0.0000003t^3$$

for Centigrade units. And according to Rankine for English units when t, is the initial and t the final temperature,

$$q = t - t_1 + 0.000000103[(t - 39^{\circ}.1)^2 - (t_1 - 39^{\circ}.1)^3].$$

(c) Internal Latent Heat  $(\rho)$ .—This is the work done, measured in thermal units, in separating the molecules of the steam beyond the range of mutual attraction. It is calculated from the formula

$$\rho = 1061 - 0.791t.$$

(d) External Latent Heat (APu).—This is the work, expressed in heat-units, of expanding the steam against an external pressure which is equal to that of the steam generated. Thus, let  $u = s - \sigma$  be the difference in volume of a pound of steam, s, and a pound of water,  $\sigma$ , at any pressure per square foot, P. Then the work of expansion will be Pu foot-pounds or APu thermal units. According to Zeuner,

$$APu = .20.91 + 1.096(t - q)$$
.

(e) Heat of the Steam (L).—This is the heat which the steam actually contains; it is the total heat less the external latent heat. In thermal units,

$$L = \lambda - APu = q + \rho$$
, since  $\lambda = q + APu + \rho$ .

(f) Heat of Vaporization, or total latent heat, (r,) is that portion of the total heat which is required to convert one pound of water at any temperature into saturated steam at the same temperature and at a pressure P; it is the sum of external and internal latent heats, or the total heat less the heat of the liquid. That is,

$$r = \rho + APu = \lambda - q$$
.

A formula for calculating r is

$$r = 1081.4 + 0.305t - q$$

(g) Specific Volumes and Density of Steam.—These quantities are usually calculated from thermodynamic equations.

$$s = \frac{r}{AT} \cdot \frac{1}{\frac{dp}{dt}} + \sigma.$$

s =volume of one pound of steam,  $\sigma =$ volume of one pound of water.

It will be noticed that the different steam tables differ principally in respect to these quantities.

# THERMODYNAMIC CONDITIONS, TEMPERATURE AND ENTROPY.

266. Isothermal is a term used to denote a condition in which the temperature remains constant; the total amount of heat, or the pressure, may vary.

Adiabatic is a term used to denote the condition in which the total quantity of heat is unchanged by heat-transfer. It may, however, be changed by transformation into work and vice versa.

Temperature is the scale used to determine the relative values of different isothermal conditions; and change of tem

perature is the change which occurs in passing from one isothermal condition to another.

Entropy is the scale used to determine the relative values of different adiabatic conditions; and change of entropy is the change which occurs in passing from one adiabatic condition to another.

Change of temperature can be measured by the expansion of some thermometric substance; but change of *entropy*, which is just as real, cannot be measured or represented in any simple manner. If we represent the entropy by  $\phi$ , the absolute temperature by T, the heat at any adiabatic condition by Q, then by the second law of thermodynamics

$$d\phi = \frac{dQ}{T}. \quad . \quad . \quad . \quad . \quad . \quad . \quad (1)$$

In case of a liquid, dQ = cdq, in which c is the specific heat, and q the temperature. In this case denote the entropy by  $\theta$ . Then

$$\theta = \int_{0}^{t} \frac{cdq}{T}. \quad . \quad . \quad . \quad . \quad (2)$$

For water this is readily calculated.

In the case of steam the entropy, or change of entropy from water at the freezing-point to steam at any pressure is equal to the entropy of the liquid,  $\theta$ , plus that of the steam,  $\frac{xr}{T}$ . In which x is the quality of the steam, or per cent of dry

In this case

steam.

$$\phi = \frac{xr}{T} + \theta = \frac{xr}{T} + \int_0^{\infty} \frac{cdt}{T}.$$

In any other case

$$\phi_{\scriptscriptstyle 1} = \frac{x_{\scriptscriptstyle 1}r_{\scriptscriptstyle 1}}{T_{\scriptscriptstyle 1}} + \theta_{\scriptscriptstyle 1}.$$

Change of entropy,

$$\phi - \phi_1 = \frac{xr}{T} + \theta - \frac{x_1r_1}{T_1} - \theta_1.$$

A short table giving the value of the entropy of steam is to be found in Article 230, page 273.

267. Steam-tables.—The numerical values representing the various properties of steam, in relation to its pressure, are arranged in the form of tables termed steam-tables. tive accuracy of these various steam tables is discussed at length by Prof. D. S. Jacobus in Vol. XII. Transactions of American Society Mechanical Engineers, page 590, from which it is seen that the table compiled by Mr. Chas. T. Porter represents the experimental investigations of Regnault most accurately; but that possibly for scientific investigations the tables of Peabody, Dery, and Buel, which are founded on thermodynamical laws, are somewhat more accurate. Practically the tables are accordant for all working pressures and temperatures of steam; the difference is principally in the values given for the density. The tables of Chas. T. Porter\* have been adopted as the tables to be used in reporting results of boiler trials and of duty trials of pumping engines, by the American Society of Mechanical Engineers (see Transactions, Vol. VI., and also Vol. XII.), and for such tests the standard reports should be calculated from those tables. These tables are, however, deficient for scientific purposes, since they omit values of some of the important properties of steam. In the Appendix are printed the table by Porter, and also the table by Buel as printed in Weisbach's work on the steam-engine and in Vol. I. of Thurston's Manual of the Steam-engine.

<sup>\*</sup> The Richards Steam-engine Indicator, by Chas. T. Porter.

#### CHAPTER XI.

#### MEASUREMENT OF PRESSURE.

268. Manometers.—The term manometer is frequently applied to any apparatus for the measurement of pressure,

although it is the practice of American engineers to use this term only for short columns filled with mercury or water and used to measure small pressures. The pressure is measured, in all manometers used for engineering purposes, above the atmospheric pressure, and this determination must be increased by the pressure equivalent to the barometer-reading to give absolute pressure. The manometers in common use are glass or metal tubes, either U-shape in form as in Fig. 118, or straight and connected to a cistern of large cross-section as shown in Fig. 120.


Pressures below the atmosphere can be measured equally well by connecting to the long branch of the tube and leaving the short branch open to the atmosphere.



FIG. 118.—U-SHAPED MA-NOMETER-TUBES.

269. U-shaped Manometer.—In the U-shaped tube, with any form as shown in Fig. 118 or Fig. 119,

water or mercury is poured in both branches of the tube, the



corresponds to a pressure of 0.033 pound; an inch of mercury, to 0.493 pound. The principle of action of the U-shaped manometer-tubes is as follows: Consider the atmospheric pressure as acting on one side of the tube, and the pressure which is to be measured and which is greater or less than

atmospheric as acting on the other side. absolute pressure in each branch of the tube must be equal, consequently enough liquid will flow from the side of the greater to the side of the less to maintain equilibrium. let p be the atmospheric pressure;  $p_1$ , the absolute pressure to be measured, expressed in inches of water or mercury; h, the height of the column on the side of the atmosphere;  $k_1$ , the height on the side of the pressure. Then

$$p+h=p_1+h_1,$$

from which

$$p_1-p=h-h_1.$$

The U-shaped tube can be used with two liquids of different densities, using the heavier liquid on the side of the lighter Let  $d_1$  denote the density of the lighter liquid, and d that of the heavier;  $h_1$  and h, the corresponding

heights of the columns. We shall have as before, taking all measurements from the lower surface of the heavier liquid,

$$p_1 + hd = p + h_1d_1$$

from which

$$p_1 - p = h_1 d_1 - h d.$$

This instrument is much more delicate and is better suited for measuring small differences of pressure than when a single liquid is used; the reason for which will be readily seen if we consider an example. Suppose that water be used as the heavier liquid, of which the specific gravity is 1, and that crude olive-oil be used as the lighter liquid, of which the specific gravity is 0.916. Suppose that all pressures are measured in equivalent height of a water column expressed in inches, and that h = 6 inches,  $p_1 - p = \frac{1}{4}$  inch; then  $h_1$ , which is the difference of level of the water in the two branches, will be  $\frac{1}{2} + 6.(0.916) = 6.0$  inches, whereas it would have been but one-half inch had there been only water, or 0.545 if the liquid had been olive-oil. By making the density of the liquids more and more nearly equal the instrument will become more and more delicate. A dilute mixture of water and alcohol of which the density must be determined (see Article 134, page 177), for the heavier, and of crude olive-oil for the lighter, gives excellent results. If the instrument can be so manipulated that  $h_1 = h$ 

$$p_1 - p = h(d_1 - d),$$


and the calculation becomes very simple, as in that case the reading would have to be multiplied only by the differences of the densities of the two liquids.

270. Cistern-manometer, In the case of a manometer of the form of Fig. 120 or Fig. 121, the cistern or vessel into

which the tulie is connected has a large area relative to

that of the tube. Pressure is applied to the top of the liquid in the cistern, the surface of which will be depressed a small amount, and the liquid in the tube will be raised an amount sufficient to balance this pressure. The pressure corresponds to the vertical distance from the surface of the liquid in the tube to that in the cistern. As the liquid is not usually in sight in the cistern, a correction is necessary to the readings in order to find the correct height corresponding to a given pressure. This correction is calculated as follows: Let A equal the area of surface of the liquid in the cistern, a the area of the manometer-tube, H the fall of liquid in the cistern, h the corresponding rise of liquid in the tube, b the height required for one pound of pressure (see Article 260, page 308), p the number of pounds of pressure. We have then

$$\frac{H+h}{b}=p;$$



and since the tube is supplied by liquid from the cistern,

$$HA = ha$$
.

Eliminating H in the two equations,

$$h = \frac{Apb}{A+a}.$$

If p =one pound,

$$h = \frac{Ab}{A + a},$$

which is the length the graduation should be made to allow for fall of mercury in the cistern and give a value equal to one pound of pressure.

To make this correction uniformly applicable the area of cross-section of both tube and cistern should remain uniform.

271. Mercury Columns.—Mercury columns, as used in the laboratories, are usually made on the principle of the cistern-manometer. The tube is very long and made of glass or steel carefully bored out to a uniform diameter. If the tube is of glass, the height of mercury can be readily perceived and read; if of steel, the height of the mercury is usually obtained by a float, which in some instances is connected to a needle which moves around a graduated dial.

In some of these instruments electric connections are broken whenever the mercury passes a certain point, and an automatic register of the reading is made. Fig. 121 shows the usual form of the mercury column, in which the pressure is applied in the upper part of the cistern, so as to come directly on the top of the mercury. In the case of a glass column the graduations are usually made on an attached scale, and are corrected as explained in Article 270 for the fall of mercury in the cistern.

272. Corrections to the Mercury Column.—The mercury column is usually the standard by which all pressure-gauges are compared, and its accuracy should be thoroughly established in every particular.

The requirements for an accurate mercury column are:




FIG. 121.—MERCURY COLUMN.

- I. Uniform bore in cistern and tube.
- 2. Accurate graduations, spaced as explained in Article 270. As it is impossible to make the graduations perfectly accurate, the error in this scale should be carefully determined, and the readings corrected accordingly.

The corrections to the readings are:

 For expansion of the mercury and tube due to increase of temperature.

The method of correcting for expansion of the mercury and the material enclosing it would be as follows:

Let  $\lambda$  equal the coefficient of lineal expansion of the mercury, and  $3\lambda$  that of the cubical expansion per degree Fahr.; let  $\delta$  equal the coefficient of lineal expansion of the metal of the cistern, and  $\delta'$  that of the metal of the tube. Let H' equal the depression in the cistern, h' the corresponding elevation in the tube corresponding to a pressure of one pound, and a difference of level of  $\delta'$ . Let  $\delta$  equal the difference of level corresponding to a pressure of one pound at a temperature of  $\delta$ 0° Fahr. Then, as before,

$$h' = \frac{A'b'}{a' + A'} = \frac{A(1 + 2\delta)b(1 + 3\lambda)}{a(1 + 2\delta') + A(1 + 2\delta)}.$$

Correction for the capillary action of the tube. This force
depresses the mercury in the tube a distance which decreases
rapidly as the diameter increases.

The amount of this depression is given in Loomis's Meteorology as follows:

-	
0.40	0.015
0.45	0.012
0.50	0.008
0.60	0.004
0.70	0.0023
0.80	0.0012
; : .	
	0.45 0.50 0.60 0.70

- 3. There might also be considered a very slight correction due to the fact that the force of gravity in different latitudes varies somewhat. Since the weight of a given mass of mercury is equal to the product of the mass into the force of gravity, it will vary directly as the force of gravity, or, in other words, the assumed weight of mercury may not be exactly correct. This correction is a refinement not necessary in usual tests.
- 4. Difference of barometer-readings at top and bottom of the tube might make some difference.

While it is well to give all these corrections their true weight, yet a false impression should not be incurred concerning their importance. It is hardly probable that the corrections for change in temperature, or corrections for the difference in the force of gravity from that at the sea-level on the equator, would in any event make a sensible difference in the readings.

273. Direct-reading Draught-gauges.—The ascending force which causes smoke or heated air to rise in a chimney is called the draught. The pressure in such a case is below that of the atmosphere, and is usually measured in inches of water. Draught-gauges are U-shaped manometers adapted to measure pressures less than that of the atmosphere. See Figs. 118 and 119. To use this manometer water is poured into the tube until it stands at the point marked 0, Fig. 119; one side is then connected by a pipe to the flue or chimney of which the draught is to be measured. The difference of level of the water, as shown by the manometer-tubes, is the draught expressed in inches of water. An inch of water at a temperature of 70° Fahr. corresponds to 0.033 pound.

Allen's Draught-gauge.—A very complete draught-gauge of the U-shaped manometer type, with attached thermometer and a movable scale the zero of which can be set to correspond to the lower water-surface, is shown in Fig. 122 as designed by J. M. Allen of the Hartford Boiler Insurance Co.

As the draught is often a small fraction of an inch, it is sometimes of importance to be able to read smaller variations in height than could be obtained by direct measurement; this is secured by arranging the manometer so that the surface in the tube shall move a greater distance than that due to the




FIG. 122.-ALLEN'S DRAUGHT-GAUGE.

difference of level, or by using liquids of different densities, as explained in Article 269, page 319.

274. Draught-gauges in which Surface in Measuring-tube moves farther than that due to Difference in Pressures.—Peclet's Draught-gauge.—A simple draught-gauge, in which the distance moved by the surface in the tube is greater than that due to fall of level, is shown in Fig. 123. It consists of a bottle, A, with a mouth-piece near the bottom into which a tube, EB, is inserted with any convenient inclination, as one in five. The upper end of the tube is bent upward, as at BK, and connected with a rubber tube, KC, leading to the chimney. The tube is fastened to a convenient support,

and a level, D, is attached. To use the instrument, first level it, note reading of scale, then attach it to the chimney, and take the reading, which will be, if the inclination is one to five,



FIG. 123.-DRAUGHT-GAUGE,

five times the difference of level in the bottle and tube. The scale should be graduated to show differences of level in the bottle, and thus give the pressure directly in inches of water.

Higgins's Draught-gauge.—Another form of this class of draught-gauges is shown in Fig. 124, as designed by Mr. C. P.

Higgins of Philadelphia. The gauge is filled with water above the level of the horizontal tube, in such a manner as to leave a bubble of air about one-half inch long near one end of the horizontal tube when the water is level in the side tubes. The inside diameter



FIG. 124.—HIGGINS'S DRAUGHT-

of the vertical tubes being the same, say one-half inch, and that of the horizontal tube one eighth of an inch, a draught equivalent to one inch in water, or which will cause the water-level in the vertical tubes to vary one inch, will cause the bubble in the tube to move eight inches in the horizontal tube. In general the air-bubble moves a distance inversely proportional to the area of the tubes, and hence it can be read more accurately than in case of the ordinary draught-gauge.

275. Hoadley's Draught-gauge.—This gauge was used in the trials of a warm-blast apparatus described in Vol. VI. Transactions American Society Mechanical Engineers, page 725. It consists of two glass tubes, as shown in Fig. 125, about 30 inches long, and about 0.4 inch inside diameter and 0.7 inch outside, joined at each end by means of stuffing-boxes to suitable brass tube connections, by which they are secured to a

backing of wood. The glass tubes can be put in communication with each other at top and bottom by opening a cock in each of the brass connections. Directly over each tube is a brass

drum-shaped vessel 4.25 inches in diameter and with heads formed of plate-glass. These drums are connected to the tubes, and also provided with stop-cocks and nipples to which rubber tubes can be attached. Two sliding-scales are arranged along the tubes, one to measure the depression, the other the elevation, of the surface of a liquid filling the lower halves of the tubes. the use of the instrument two liquids of different densities were used, a mixture of water and alcohol with specific gravity about 0.93 being used for the heavier liquid, and crude olive-oil with a specific gravity of 0.016 for the lighter. In using the instrument the heavier liquid was first put into the tubes, care being exercised to avoid wetting the top attachments; then the top connection between the tubes was opened and the olive-oil poured in. In using the instrument one branch was connected to the chimney, the other being opened to the air, the bottom connection opened and the top connection The liquid would rise in the tube with the lighter pressure a distance inversely proportional to the respective areas of exposed surface of the tube and drum. The bottom connection was then closed, the connection to the flue removed, and the top connection opened; the surface of the olive-oil would then become



FIG. 125,—HOAT-LEY'S DRAUGH:\* GAUGE.

level in the two tubes, that of the water remaining at different heights. It was then attached to the flue and these operations repeated, until the heavier liquid would no longer flow to the side of the lighter pressure; in that case we should have the condition of equilibrium between two liquids of different densities, Article 269, page 319, in which the lengths of columns

of the two liquids are equal. Hence, noting that p is here the greater, the difference of pressure in inches of water is

$$p-p_1=h(d_1-d),$$

in which  $d_1$  and d are the respective specific gravities of the liquids used.

276. Mercury Manometers with Pistons.—Mercury cistern-manometers are made in which the pressure acts on a piston, and this force is transmitted by a rod to a piston of larger area on which the mercury rests. In this case the height of the mercury column for a given pressure will be less than that required when the pressure is direct, in the ratio that the area acted on by the pressure bears to that acted on by mercury. Fig. 126 shows the form of such a column as manufactured by Thomas Shaw of Philadelphia. In this case the pistons are included between two diaphragms, to lessen the friction indispensable to tight pistons.

Thus the pressure is received by the diaphragm f, thence it acts on the small piston directly above it, and is transmitted by the rod h to the larger piston; between this piston and the mercury i, is a second diaphragm. The action of the gauge is as follows: Let A equal area of larger piston, a the area of smaller piston, 2.037 inches the height of mercury corresponding to one pound of direct pressure, x the required height of column corresponding to one pound of pressure. We have

Hence

$$x=\frac{2.037a}{A}.$$

By properly proportioning the areas of the piston, the graduations on this instrument can be so arranged that very great pressures may be measured by a short column. In such a case the column cannot be read to minute subdivisions accurately.

With this instrument the friction of pistons or stiffness of diaphragms is likely to constitute the principal source of




FIG. 126.-SHAW'S MERCURY-GAUGE.

error. It should be compared from time to time with a standard mercury column.

277. Steam-gauges.—The steam-gauges in general use are of two classes, known respectively as the *Bourdon* and *Diaphragm* Gauges.

The Bourdon Gauge.—In the Bourdon gauge the pressure is exerted on the interior of a tube, oval in cross-section, bent to fit the interior of a circular case; the application of pressure tends to make the cross-section round and thus to straighten the tube. This motion communicated by means of racks and gears rotates an arbor carrying a needle or hand.

The various forms of levers used for transmitting the motion of the tube to the needle are well shown in the accom-



FIG. 127.—CROSBY BOURDON GAUGE.

panying figures, 127 to 131. The levers are in general adjustable in length so that the rate of motion of the needle with respect to the bent tube can be increased or diminished at will. Thus in Fig. 127, and also in Fig. 128, the lever carrying the sector is slotted where it is pivoted to the frame; by loosening a set-screw the pivot can be changed in position, thus altering the ratio of motion of hand and spring in different parts of the dial.

Fig. 128 shows a gauge with a steel tube or diaphragm for use with ammoniacal vapors which attack brass.




FIG. 128.—SCHAEFFER & BUDENBERG AMMONIA-GAUGE.



FIG. 129.-BOURDON GAUGE.

In nearly all these gauges lost motions of the parts are to some extent taken up by a light hair-spring wound around the needle-pivot. 278. The Diaphragm Pressure-gauge. — In the diaphragm-gauge the pressure is resisted by a corrugated plate, which may be placed in a horizontal plane, as in Fig. 130, or in a vertical plane, as in Fig. 131. The motion given the plate is transmitted to the hand in ways similar to those just explained.




FIG. 130.- DIAPHRAGM-GAUGE.

In Fig. 130 the pressure is exerted on the corrugated diaphragm below the gauge, and the motion is transmitted to the hand by the rods and gears shown in the engraving.

The construction shown in Fig. 131, in which the diaphragm is vertical, is as follows: the lever is in two parts which are pivoted at the centre; one end is fixed to the frame, the other connected to the sector. The centre pivot is pressed outward by the action of the diaphragm, drawing the free end downward and rotating the sector, which in turn moves the needle.

In gauges of usual construction of either class, when there is no pressure on the gauge, the needle rests against a stop, which is placed somewhat in advance of the zero-mark, so that

minute pressures are not indicated by the gauge. In the use of the instrument the needle sometimes gets loose on the pivot, or turned to the wrong position with reference to the graduations; in such a case the needle is to be removed entirely, and set when the gauge is subjected to a known pressure. These



FIG. 131.-DIAPHRAGM-GAUGE.

gauges are also affected by heat. Hence, when set up for use a bent tube, termed a siphon, or a vessel which will always contain water, should be interposed between the gauge and the steam.

279. Vacuum-gauges.—Vacuum-gauges are constructed in the same method as the Bourdon or diaphragm gauges; the removal of pressure from the interior of the bent tube or diaphragm causes a motion which is utilized to move the needle. These are graduated to show pressure below that of the atmosphere corresponding to inches of mercury, zero being at atmospheric pressure, and 29.92 a perfect vacuum. The difference between the reading by such a gauge and that of the

barometer would be the absolute pressure in inches of mercury.



FIG. 132.-EUSON'S SPEED AND PRESSURE RECORDING GAUGE AND ALARM.

The principal makers of steam-gauges in this country are the Crosby Steam Gauge and Valve Co., Boston; American Steam Gauge Co., Boston; Ashcroft Steam Gauge Co., New York; Schaeffer & Budenberg, New York; Utica Gauge Co., Utica, N. Y.

280. Recording-gauges.—Recording-gauges are arranged so that the pressure moves a pencil parallel to the axis of a revolving drum which is moved at a uniform rate by clockwork. The Edson recording-gauge is shown in Fig. 132. In this gauge the steam-pressure acts on a diaphragm which oper-

ates a series of levers giving motion to a needle moving over a graduated arc showing pressure in pounds; also to a pencilarm moving parallel to the axis of a revolving drum.

This instrument has an attachment, which is furnished

when required, to record fluctuations in the speed, and consists of a pulley on a vertical axis below the instrument that is put in motion by a belt to the engine-shaft. On the small pulley-shaft are two governor-balls which change their vertical position with variation in the speed, giving a corresponding movement up or down to a pencil near the lower part of the drum. A diagram is drawn on which uniform speed would be shown by a straight line.

Fig. 133 shows Schaeffer & Budenberg's recording-gauge. This consists of a pressure-gauge below the recording mechanism. The drum B is operated by clock-work, the piston-rod C, which carries the pencil, being moved by the pressure. The pencil-movement is much like that on the Richards steam-engine indicator.




FIG. 133.—RECORDING PRESSURE-

Fig. 134 shows a portion of a diagram made by a recordinggauge. The drum is operated by an eight-day clock, and ar-




Fig. 134.—DIAGRAM FROM PRESSURE-RECORDING GAUGE.

ranged to rotate once in twenty-four hours. In the diagram the ordinates show pressure, and the abscissæ time in hours and fractions of an hour.

281. Apparatus for Testing Gauges.—Apparatus for testing gauges consists of a pump or other means of obtaining pressure, and some method of attaching the gauge to be tested, and the standard with which it is to be compared. The form of pump usually employed for producing the pressure is shown in Fig. 135. The gauge is attached at E, the standard at  $E_1$ ; the hand-wheel D is run back, and water is supplied by filling the cup between the gauges and opening the cock; after the cylinder C is filled the cock below the cup is closed; if the hand-wheel D is turned, an equal pressure will be put on the standard and on the gauge.

The standards used for testing may be manometers or calibrated gauges, or apparatus for lifting known weights by the pressure acting on a known area. Of these various standards, the mercury column, as described in Article 271, page 321, is to be given the preference, since the only errors of any practical importance are those due to graduation. The readings given by the mercury column are on a larger scale than those given by any other instrument, and no corrections for friction are required. The other standards, of which the short mercury columns have been described (see Article 264), will be found to give excellent results in practice, since the graduations on the gauges to be tested are usually so close together that the friction of the moving parts of the apparatus is inappreciable.

Apparatus for Testing Gauges with Standard Weights.

There are two forms of this apparatus on the market, in one of which the pressure is received on a round piston, and in the other on a surface exactly one square inch in area. The friction in both cases is practically inappreciable; the errors in areas can be determined by comparison with a standard mercury column.

The Crosby Steam-gauge Testing Apparatus.—This is shown in Fig. 136, from which it is seen to consist of a small cylinder




FIG. 135.—TEST-PUMP FOR GAUGES.

in which works a nicely fitted piston; this cylinder connects with a U-shaped tube ending in a pipe tapped and fitted for




FIG. 136.—CROSBY STEAM-GAUGE TESTING APPARATUS.

attaching a gauge. The tube is filled with glycerine, in which case a known weight added to the piston produces an equal pressure on the gauge, less the friction of the piston in the tube. This is almost entirely overcome by giving the weight and piston a slight rotary motion.

The Square-inch Gauge.—This apparatus consists of a tube the end of which has an area of one square inch enclosed with sharp edges. This is connected to the test-pumps in place of the standard (see Fig. 135, page 336); a given weight is suspended from the centre of a smooth plate which rests on the square inch orifice. The gauge to be tested is connected at E, and the pressure applied until the plate is lifted and water escapes from the orifice.

# 282. Calibration and Correction of Pressure-gauges.— The correctness of gauges is determined in each case by comparison with apparatus known to be correct, the apparatus being subject to a fluid pressure of the same intensity. The calibration may be done by comparison with any of the standards described.

### Calibration of Gauges with the Mercury Column.

First, with Steam-pressure.—In this case attach the gauge with a siphon connection to a steam-drum, making the center of the gauge the height of the zero of the column. This drum is to be connected at one end to the mercury column, and the steam-pressure is to be applied to it so that it can be regulated by throttling the admission or discharge. pressure to the gauge and the mercury column; adjust the pressure to a given reading by throttling the valves. Starting at five pounds of pressure on the gauge, note the corresponding reading of the mercury column, temperature of the mercury and of the room. Increase the pressure and take readings once in five pounds. In no instance allow the pressure to exceed that at the time of making the reading. In case the pressure is made too great at any time, run it some distance below the required amount and make a new trial, it being necessary to keep the mercury column and gauge hand moving continually upward or downward. Repeat the same operation in the reverse direction, commencing with the highest pressures; the average reading of the mercury column, corrected for error as explained in Article 272, page 322, and reduced to pounds of pressure, is the correct pressure with which the gauge-reading is to be compared.

Second, with Water-pressure.—In this case a hand forcepump (see Article 281) must be used after the limits of pressure of the water-main have been reached. Proceed as follows:

Run out the piston of the pump attached to the mercury column to the end of its travel; close drip-cock and open the connecting-valve. Attach the gauge to be tested with its centre opposite the zero of the column. Open the cock

Draw water from the mains until the gauge indicates 5 lbs. Shut off the water and adjust the pressure exactly at 5 lbs. by using the displacer. Note the height of the mercurv in the tube. Increase the pressure to 10 lbs. and take readings. Carry the pressure as far as desired by increments Use the pump alone when water-pressure fails. of 5 lbs. From the maximum pressure attained descend by increments of 5 lbs., taking readings as before. Tabulate data and plot a curve, using gauge-readings as ordinates and actual pressures as By inspection of the curve determine the fault in abscissæ. the gauge and give directions for correcting it.

In these tests it may not be possible to set the centre of the gauge as low as the zero of the column. In that case the reading on the mercury column should be greater than that at the centre of the gauge by a pressure due to the length of a column of water equal to the elevation of the centre of the gauge above the zero of the mercury column. This is a constant amount: it should be obtained and the readings of the column corrected accordingly.

The method of calibrating gauges with other standards is to be essentially the same, except as to the manipulation of the apparatus. Further directions do not seem necessary.

Correction of Gauges.—If an error appears as a result of calibration, it may generally be corrected; if the error is a constant one, the hand may be removed with a needle-lifter, and moved an amount corresponding to the error, or in some gauges the dial may be rotated. If the error is a gradually increasing or diminishing one, it can be corrected by changing the length of the lever-arm between the spring and the gearing by means of adjustable sleeves or the equivalent. It is to be noted that the pin to stop the motion of the hand is not placed at zero, but in high-pressure gauges is usually set at U-SHAPED N three to five pounds pressure.

283. Calibration of Vacuum-gauges.—This is best done by a comparison with a U-shaped mercury manometer, as shown in Fig. 137, of which each branch of the tube should exceed 30 inches in length. Before calibrating, the manometer is filled with mercury to one half the length of the tubes, and is attached near the gauge to be tested to the receiver of an air-pump. In case a condensing engine is used, both the gauge and the standard may be connected to the condenser. A comparison of the readings of the vacuum-gauge with the difference of level of mercury in the two tubes will determine the error of the gauge.

# 284. Forms for Calibration of Gauges.

CALIBRATION OF STEAM-GAUGE BY COMPARISON WITH THE MERCURY COLUMN.

Date.	·•········		. 189 .	Observers	. {	•••••••	•••••
			Mercury	Column.			
No.	Gauge.		Inches.		Pounds.	Gauge. lbs.	Error. lbs.
		Up.	Down.	Mean.	Pounds.		

Correction to column reading .... lbs.

CALIBRATION OF STEAM-GAUGE BY COMPARISON WITH THE

	189 .	Observers,	}	
No.	Load in lbs. on Valve.	Gauge.	Error.	Remarks

### CHAPTER XII.

### MEASUREMENT OF TEMPERATURE.

285. Mercurial Thermometers.—Measurements of temperature are determined by the expansion of some thermometric substance, mercury, alcohol, or air being commonly employed.

The mercurial thermometer is commonly used; this consists of a bulb of thin glass connected with a capillary glass tube; on the best thermometers the graduations are cut on the tube, and an enamelled strip is placed back of them to facilitate the reading. When the mercury is inserted, every trace of air must be removed in order to insure perfect working. There are certain defects in mercurial thermometers due to permanent change of volume of the glass bulb, with use and time, that results in a change of the zero-point. This defect is so serious as to render the mercurial thermometer useless for very minute subdivisions of a degree. In a good thermometer the bore of the tube must be perfectly uniform, which fact can be tested by separating a thread of mercury and sliding it from point to point along the tube, and noting by careful measurement whether the thread is of the same length in all portions of the tube: if the readings are the same, the bore is uniform or graduated by trial. In most thermometers the graduations are made with a dividing engine; in some thermometers the principal graduations are obtained by the thread of mercury, as described; in the latter case change in diameter of bore would be compensated. To determine the accuracy of temperature

measurements thermometers used should be frequently tested for freezing-point and boiling-point. The accuracy of intermediate points should be determined by comparison with a standard mercurial or air thermometer.

The mercurial-weight thermometer which was employed by Regnault, but is now very little used, consists of a glass vessel with a large bulb and capillary tube, open at the top; it is filled with mercury when at the temperature of the freezing-point; it is then heated to the temperature of boiling water, and the amount of mercury that runs out is carefully weighed, and determines the value of the thermometric scale. The temperature of any enclosure is then found by placing in it the thermometer, previously filled when at freezing-point and weighing the amount that escapes; from this the temperature can be calculated by simple proportion.

The expansion of mercury is not perfectly uniform for all temperatures, so that mercurial thermometers are never perfect for extreme ranges of temperature.

- 286. Rules for the Care of Mercurial Thermometers.— The following rules for handling and using mercurial thermometers, if carefully observed, will reduce accidents to a minimum:
  - 1. Keep the thermometer in its case when not in use.
- 2. Avoid all jars; exercise especial care in placing in thermometer-cups.
- 3. Do not expose the thermometer to steam heat unless the graduations extend to or beyond 350° F.
- 4. In measuring heat given off by working-apparatus, or in continuous calorimeters, do not put the thermometers in place until the apparatus is started, and take them out before it is stopped. Be especially careful that no thermometer is overheated.
- 5. In general do not use thermometers in apparatus not fully understood or which is not in good working condition.
  - 6. Never carry a thermometer wrong end up.
- 7. See that the thermometer-cups are filled with cylinderoil or mercury. If cylinder-oil is used, keep water out of the cups or an explosion will follow.

- 8. After a thermometer is placed in a cup, keep it from contact with the metal by the use of waste.
- 287. Alcohol-thermometers.—Other liquids, as alcohol or spirits of wine, are better suited for low temperatures than mercury, but on account of the tension of their vapors are not suited for high temperatures, and are probably subject to the same objections in a less degree as mercurial thermometers.
- 288. Air-thermometers.—Air-thermometers, in which either air or hydrogen may be used, are not open to the objections which hold with the mercurial thermometer, as the expansion for uniform increments of heat is under all conditions the same.

There are two plans of these thermometers:

- I. Increase of volume of air at constant presssure.
- II. Increase of pressure at constant volume.

The latter plan was found to give better results by Regnault, and constitutes the principle of the "Normal Air-thermometer."

The air-thermometer in construction is a U-shaped tube, one branch enlarged into a bulb for the air, the other open for the mercury. Adjacent to the tube for the mercury is a graduated scale which can be read by a vernier to small divisions of an inch; a single mark is placed in the air branch, at a distance of eight or ten inches from its top. This mark serves to define the limit of volume used.

There are various forms of instrument in use; the one adopted at Sibley College was designed by Mr. G. B. Preston and is shown in Fig. 138. The air-bulb, C, is approximately 1 $\frac{1}{8}$  inches by 6 inches; the bulb is joined by a capillary tube, F, straight or bent into any convenient form as may be required. In order that the bulb may be conveniently located for heating, this capillary tube is joined to a tube of glass about  $\frac{1}{16}$  inch bore, the end of which is bent at right angles ground true, and joined by a short piece of rubber tubing to a glass tee at B. The tee has a branch provided with a cock, and connection for rubber tubing. The opposite side of this tee is joined in a similar way to a tube, BE, of the same bore, which is given a length sufficient to measure the required temperatures. A mark

a is made on the glass near F, at the junction of the capillary tube with the larger one for the mercury, and serves to determine the limit of volume of air used. The bottle, C, is filled with mercury, and connected by a rubber tube to the cock B. By opening the cock and elevating the bottle, mercury will




FIG. 138.—PRESTON AIR-THERMOMETER.

pass into the tubes: when it reaches the height of the mark a, the connecting cock B is closed, and the amount that the column BE extends above the level of this mark, or fails of reaching this level, is read on the scale.

Hoadley Air-thermometer.—The Hoadley air-thermometer, as described in the Transactions of the American Society of Mechanical Engineers, Vol. VI., page 282, is shown in Fig. 139, with all the dimensions marked. It differs from the preceding one in having no means provided for introducing or removing mercury to maintain the volume of air constant. The tube connected to the air-bulb, instead of being capillary, is about 16 inch diameter. The instrument consists of a U-tube about

# inch external diameter, 1 bore, having a short leg about 39 inches long, and the other leg longer by 12 inches or more, the latter surmounted by a bulb blown out of the tube 14 inches in diameter, 64 inches in extreme length. The branches of the U-tube are 2 inches apart and vertical; these are separate tubes, each one bent to a right angle by a curve of short radius, ground square and true at the ends and united by a short coupling of rubber tubing, ea, firmly bound on each branch with wire. After it is filled with dry air according to the directions in Article 200, page 348, it is fastened on a piece of board by annealed wire staples, and paper scales affixed as shown in the figure. The difference in height of the two columns of mercury is taken as the reading of the thermometer, and no correction is made for slight variations in the volume of air, as shown by variation in the position of the height of the mercury column in the branch The error caused in this way is very small and amounts to only 0.0030 inch per inch of height. This is equivalent to an error of about five degrees in a range of temperature of 600 degrees F.

The Jolly Air-thermometer.—An exceedingly simple form of the air-thermometer, and one also very accurate, consists of the air-bulb C, and a capillary stem attached to three or four feet of rubber tubing, which replaces the U-tube in Fig. 139; in the other end of the rubber tubing is inserted a piece of glass tube 8 to 12 inches long and about  $\frac{1}{16}$  inch bore; on this glass tube, and also on the capillary tube, is etched a single mark; the rubber tube is filled with mercury, which extends up the glass tube on the other branch. A fixed scale, similar to DE




Fig. 139.—The Hoad-Ley Air-Thermometer,

in Fig. 139, is located near the instrument. To use the instrument the tube is manipulated until the air is brought to its limit of volume, then the other end of the tube is held opposite the scale, and the reading corresponding to the height of the mercury is taken. This is repeated for several temperatures, and, if the constant of the instrument is known, gives the data for computing the temperature.

289. Formulæ for the Air-thermometer of Constant Volume.—The pressure exerted by the confined air, added to the weight of mercury, in the branch BF, Fig. 138, will equal the weight of mercury in the other branch plus the weight of the atmosphere. Thus let p equal the pressure expressed in inches of mercury of the confined air, v its volume, m the height of the mercury in the branch of the tube on the side of the airbulb, m' the height in the other branch, b the pressure of the atmosphere expressed in inches of mercury, T the absolute temperature, t the thermometer-reading, t the height of mercury in the tube t00 above the mark t00 and mercury being above the point t00 in the tube t00 and t01 are equal constant ratio of t00 are tube are equal,

From physics,

$$\frac{pv}{T}$$
 = constant; . . . . . . . (4)

and if v be made constant, p will vary as T; also

$$T = 460 + t$$
; . . . . . . (5)

$$p = T(\text{constant}) = (460 + t)\alpha; \quad . \quad . \quad . \quad (6)$$

hence

$$(460+t)\alpha = b + h$$
. . . . . . (7)

Let the same symbols with primes denote other values of the corresponding quantities. Then

By comparing equations (7) and (8),

$$\frac{460+t}{460+t'} = \frac{b+h}{b'+h'}. \quad . \quad . \quad . \quad . \quad (9)$$

From which, by solving,

$$t' = \left[\frac{b' + h'}{b + h}(460 + t)\right] - 460.$$
 (10)

To apply the formula, take readings of the instrument at  $32^{\circ}$  F., or some known temperature, and ascertain the constants of the instrument. Thus suppose the air-bulb to be packed in ice and the temperature reduced to  $32^{\circ}$  F. In this case  $t = 32^{\circ}$ ; b and h are to be observed and recorded.

If  $t = 32^{\circ}$  in equation (10),

$$t' = \frac{49^2}{b+h}(b'+h') - 460; \dots (11)$$

which is an equation to determine any temperature. If b and h are constant,  $492 \div (b + h)$  is constant and equals K.

$$t = K(b' + h') - 460; . . . . . . (12)$$

which is the practical equation for use in determining temperatures.

If the height of the mercury in the column EB, Fig. 138, is less than that in FB, h will be negative, and is to be so considered in the preceding formulæ.

In the use of the air-thermometer the mercury must be maintained constantly at the point a in the branch FB; this will require the addition of mercury to the U-tube as the pressure increases, which is readily done by raising the bottle A and opening the connecting-cock B. By a reverse process mercury may be removed as the pressure decreases.

290. Construction of the Air-thermometer.—The bulb of the air-thermometer must be filled with perfectly dry air, as any vapor of water will vitiate the results.

To accomplish this, the bulb is provided with a small opening opposite the capillary tube, which is fused after the dry air is introduced. To effect the introduction of dry air, all the mercury is drawn into the bottle A, Fig. 138; the end of the tube E is connected to a U-tube about 6 inches long in its branches and about  $\frac{a}{4}$  inch internal diameter, filled with dry lumps of chloride of calcium and surrounded by crushed ice; the opening in the end of the air-chamber is connected by a rubber tube to an aspirator (a small injector supplied with water would act well as an aspirator), and air is drawn through

for three or four hours: at the end of this time the bulb and tube should be filled with dry air. While the current of air is still flowing, the  $\operatorname{cock} B$  is opened and mercury allowed to pass into the tubes until it rises to the point a in the tube BF; the opening in the air-chamber is then hermetically sealed with a blow-pipe, and the connections to the chloride-of-calcium tube removed. This operation fills the bulb with air at atmospheric pressure. By closing the  $\operatorname{cock} B$  before the mercury has risen to the point a the pressure will be increased; by closing it after it has passed the point a it will be diminished. Packing the bulb C in ice, or heating it, will also increase or diminish the pressure as required.

- 291. Corrections to Determinations by the Air-thermometer.—The corrections to the air-thermometer are all very small, and affect the results but little if considered. They are:
- 1. Capillarity, or adhesion of the mercury to the glass. In general the mercury in the two tubes BF and BE (Fig. 138) is moving in opposite directions, and the effect of adhesion is neutralized. For error in other cases see table on page 272.
- 2. Expansion of the glass. This is a small amount, and may usually be neglected. The coefficient of surface expansion of glass is 0.00001 per degree F.; it is entirely neutralized if the column of mercury is not reduced in area at the point of meeting the air from the bulb.
- 3. Expansion of the mercury should in every case be taken into account by reducing all observations to 32° F., the coefficient of expansion being 0.0001 per degree F. Reduce all observations before applying formulæ.
- 4. Errors in the fixed scale should be determined and observations reduced before applying formulæ.
- 292. Practical Uses of the Air-thermometer.—The air-thermometer may be used as a standard with which to compare mercurial thermometers; in this case the bulb of the air-thermometer is surrounded with a non-conducting chamber (Fig. 138), in which the thermometer to be compared is inserted. For low temperatures water may be circulated through this chamber, and simultaneous readings taken; for higher tem-

peratures steam may be used. Time must in each case be given to permit the fluid in the air-thermometer to arrive at the true temperature.

In comparison with mercurial thermometers, an exact agreement may be found at freezing and boiling points; but at other places a slight disagreement may be expected, which will increase rapidly for high temperatures.

The air-thermometer may also be used to measure temperatures directly. When the bulb is connected with a long capillary stem it may be introduced into flues, and temperatures below the melting-point of glass measured. The melting point will vary from 600 to 800 degrees F. By using porcelain bulbs extremely high temperatures can be measured.

# 293. Directions for Use of the Air-thermometer.

First. To obtain the Constants of the Instruments.—Enclose the air-bulb with crushed ice, arranged so that the water will drain off. Note the reading of the mercury column of the air-thermometer h and of the barometer b; by means of the attached thermometers reduce these readings for a temperature of the mercury corresponding to  $32^{\circ}$  F. Correct for errors of graduation. Divide 492 by the sum of these corrected readings for the constant of the air-thermometer. Call this constant K.

Second. To Measure any Temperature t'.—Note the corresponding reading of the mercury column h', and that of a barometer b' in the same room. The reading of the mercury column plus that of the barometer will correspond to b' + h' in the formula

$$t' = \frac{49^2}{b+h}(b'+h') - 460 = K(b'+h') - 460.$$

Third. To Compare a Mercurial Thermometer.—Make simultaneous readings of the thermometer when hanging in the chamber with the air-bulb, and the height of the mercury column. Perform reduction, and plot a calibration curve for each 10° of graduation.

Fourth. For general use of the air-thermometer, arrange

the bulb so that it can be inserted into the medium whose temperature is to be measured, with the U-shaped tubes in an accessible position for reading. Obtain the temperature as explained above (see Second).

294. Form for Reducing Air-thermometer Determinations.

TEMPERATURE DETERMINATIONS WITH AIR-THERMOMETER.

By  Determination of Constant.													
	Symbol.	I.	II.	111.	IV.								
Temperature of air-bulb	b												
Thermometer. Reduced to 32°.  Constant = $492 + (b + h)$	h K		••••••										

# DETERMINATION OF TEMPERATURE.

t' = K(b' + h') - 460.

No.	Barometer.										Air-thermometer.							b'+ h'				t' Tem-					Mercury Thermometer.																							
				ıd Ç.	-	1	7	נז	ıe	۲,		d	r	6' e- ce					e:		I-		т	h	er				k re				S	ur	D.		1	pera- ture.			Read- ing.		-	Erro						
1	1.																					1.										١.																		
2	١.					1											١.					١.																			.									
3	1.					1											١.			٠.		١.										١.				١.					ا.									
4	١.					1					١.						١.					١.					١.					١.				١.					.					۱.				
5	:	•	•						•	•	٠	•		•	•	•		•	•	•	•		•	•	• •	•	٠	•	•	٠.	•		•	• •	•		• •	•	•			٠.	•	•	•	$\cdot  $		•	•	
· 7	-								•	•	$\cdot$												:					:					•		•				•			• •		•						
	1.	٠	•	•	•	ï	• •	•	•	•	٠١	•	•	•	•	•		•	• •	•	٠	ŀ	•	• •	• •	•	٠	٠	•	•	•	•	•	• •	•	٠	• •	•	٠	• •	ŀ	• •	•	•	•	١.	٠.	•	•	
9	1.	٠	•	• •	• •	ŀ		•	•	•	٠	•	• •	•	٠	٠	٠	٠	•	•	•	ŀ	•	• •	• •	٠	٠	•	•	•	•		•	• •	•	٠	• •	•	•	• •	٠1	٠.	٠	•	•	٠	٠.	٠	•	
10		•	•	•		ŀ		•	•	•	٠١		٠.	•	٠	٠	٠	•	•	٠.	•	ŀ	•	٠.			٠	•	•	•					•	١.	٠.	•	٠		٠ŀ		•	•	•	٠l			•	
11	•	•	•			1	٠.		•	•	٠١			•	•	•					•	١.	•													.				٠.		٠.		٠		٠.				
12	.					1					١.											١.			٠.											.!	٠.				.1.					١.				

### 295. Determination of Boiling and Freezing Points.




FIG. 140.—APPARATUS TO TEST BOILING-POINT.

First. To test for Boiling-point.—Suspend the thermometer so that it will be entirely surrounded in the vapor of boiling water at atmospheric pressure but will not be in contact with the water. Note the reading. From the barometer-reading calculate the boiling-point for the same time. The difference will be the error in position of the boiling-point.

The engraving (Fig. 140) shows an instrument for determining the boiling-point. The bulb of the thermometer is exposed to steam at atmospheric pressure, which passes up to the top of the instrument around the tube, and down on the outside, discharging into the air, or it may be returned directly to the cup, thus obviating the need of supplying water. In the form shown, the parts telescope into each other for convenience in carrying, which is entirely unnecessary for laboratory uses.

Secondly. To test for Freezing-point.— Surround the bulb of the thermometer by a mixture of water and ice, or water and snow; drain off most of the water. The difference between the reading obtained

and the zero as marked on the thermometer (32° for Fahr. scale) is the error in location of freezing-point.

296. Metallic Pyrometers are instruments used for measuring high temperatures. The ordinary instruments sold under this name are made of two metals which have different rates of expansion, copper and iron generally being used. The difference in the rate of expansion is employed by means of levers and gears to rotate a needle over a dial graduated to degrees.

In using the metallic pyrometer no reading should be taken until it has had sufficient time to arrive at the temperature of the medium in which it is enclosed; when one tube alone is heated, the needle may be stationary on the dial, or even have a retrograde motion.

The metallic pyrometer is usually calibrated by immersing in a pipe filled with steam under pressure and comparing the temperature with that given by a calibrated mercurial thermometer. The scale so obtained is assumed to be uniform throughout the range of the pyrometer and beyond the limits of the calibration. Comparison might be made with an airthermometer. The extreme range of such pyrometers is about 1200° Fahr., but they are probably of little value for temperatures exceeding 1000° Fahr.

Wedgewood's Pyrometer is based on the permanent contraction of clay cylinders due to heating. This contraction is determined by measurement in a metal groove with plane sides inclined towards each other. This pyrometer does not give uniform results.

297. Air-pyrometer.—The air-thermometer with a bulb of porcelain, or platinum or other refractory material, affords an accurate method of measuring high temperatures.

Mr. Hoadley\* states that the ordinary air-thermometer made of hard glass can be used to determine temperatures of 800° Fahr. With porcelain bulb it has been used to measure temperatures of 1900° Fahr.

298. Calorimetric Pyrometers.—Pyrometers of this class determine the temperature by heating a metal or other refractory substance to the heat of the medium whose temperature is to be measured. Suddenly dropping the heated body into a large mass of water, the heat given off by the body is equal to that gained by the water; from this operation and the known specific heat of the substance the temperature is computed. Thus, let K equal the specific heat of the body, M its weight; let W equal the weight of water, t its temperature before, and t' after, the body has been immersed; let T equal the temperature of the heated body, t' its final temperature. Then

$$KM(T-t') = W(t'-t).$$

<sup>\*</sup> See Vol. VI., Transactions American Society Mechanical Engineers.

From which

$$T = \frac{W}{MK}(t'-t) + t'.$$

In connection with pyrometrical work, the specific heat of the substance used often has to be determined.

299. Determination of Specific Heat.—The specific heat of a body is determined by heating it to a known temperature; for instance, after heating it in steam of atmospheric pressure until it has attained a known temperature T, its weight M having been accurately determined, it is dropped suddenly without loss of heat into a vessel containing W pounds of water at a temperature of  $60^{\circ}$  Fahr. Let K be the specific heat of the body, and t' the resulting temperature. The vessel must be so made that there is no loss of heat, and that the water can be thoroughly agitated so that an accurate measure of the temperature t' can be taken; also the effect of the vessel in cooling the body must be determined and considered a part of the weight W. Then will the loss of heat of the body be equal to that gained by the water.

 $K(T-t')M = W(t'-60^{\circ}).$ 

From which

$$K = \frac{W(t'-60^{\circ})}{M(T-t')}.$$

The specific heat of most bodies is not quite constant but is found to increase with higher temperatures.

300. Values of Specific Heat and Melting-point.— The metals required for pyrometrical purposes are those with a high melting-point and a uniform and known specific heat. The obvious losses of heat in (1) conveying the heated body to the calorimeter, and (2) radiation of heat from the calorimeter, may be considerable, and should be ascertained by radiation tests and the proper correction made. Nearly all metals are oxydized, or acted on by the furnace-gases, long before the melting-point is reached; so that, in general, whatever metal is used, it must be protected by a fire-clay or graphite crucible. Platinum, copper and iron are usually employed. The following table gives determinations of melting-points and specific heats:

TABLE OF MELTING-POINTS AND SPECIFIC HEATS OF METALS.

	Meltin	g-point.	
Metal.	Degrees Fahr.	Degrees Centigrade,	Specific Heat. Low Temperatures.
Platinum		2000	0.034
Steel			0.118
Wrought-iron	4700		0.110
Cast-iron	3400		0.14
Copper	2550		0.94
Porcelain		••••	0.170
Brass	1870	1	0.094
Zinc	700	415	0.093
Lead	630	325	0.030
Bismuth	493	264	0.030
Tin	426	228	0.047
Mercury	— 38		0.030
Sulphur	228		0.200
Antimony		425	,

The mean specific heat of *Platinum\** has been the subject of careful investigation. It was found to vary from 0.03350 at 100° C. to 0.0377 at 1100° C. by Poullet, the experiment being made with a platinum reservoir air-thermometer.

The following were the determinations:

Platinum	•	Copper.							
Range of Temperature. Degree Centigrade.	Mean Specific Heat.	Range of Temperature, Degree Centigrade.	Mean Specific Heat,						
0 to 100 0 " 200 0 " 300 0 " 400 0 " 500 0 " 600 0 " 700 0 " 800 0 " 900 0 " 1000	0.03350 .03392 .03434 .03476 .03518 .03560 .03602 .03644 .03686 .03770	15 to 100 16 '' 172 17 '' 247	0.09331 0.09483 0.09680						

<sup>\*</sup> See Encyclopædia Britannica, art. Pyrometer.

For wrought-iron the true specific heat at a temperature t on the Centigrade scale is given as follows by Weinbold:

$$C_t = 0.105907 + 0.00006538t + 0.000000066477t^2$$
.

Porcelain or Fire-clay having a specific heat from 0.17 to 0.2, although not a metal, is well adapted for pyrometrical purposes.

301. Hoadley Calorimetric Pyrometer.—The Hoadley pyrometer is described in Vol. VI., p. 712, Transactions of the American Society of Mechanical Engineers. It consisted of a vessel, Fig. 141, made of several concentric vessels of copper, with water in the inner one, eider-down in the intermediate spaces, and a cover of the same nature. Also a sub-




FIG. 141.-HOADLEY PYROMETER.

stance to be heated consisting of balls of platinum, or wroughtiron and copper covered with platinum. These balls were heated in a crucible, conveyed to the calorimeter and suddenly dropped in. The calorimeter was provided with an agitator made of hard rubber, with a hole in the centre for a thermometer. The balls used as heat-carriers weighed about three quarters of a pound each; the vessel held about twelve pounds of water. This apparatus is now at Cornell University. The balls were heated in crucibles and conveyed to the calorimeter in a fire-clay jar as shown in Fig. 142. The cover




FIG. 142.—PLATINUM BALLS AND CRUCIBLE.

of this jar was quickly removed and the balls dropped into the water in the calorimeter.

302. Electric Pyrometers.—The fact that electric currents are excited by differences of temperature in different parts of a metallic circuit is made use of for measuring large as well as small differences of temperature.

The electromotive force of a circuit at different temperatures is given by Professor Tait\* as

$$E = A(t_1 - t_2)[T - \frac{1}{2}(t_1 + t_2)],$$

in which E = electromotive force; T, a constant temperature, such that no current is produced if temperatures on either side are equal, and which depends on the metal: for copper and iron it is about 284° C. A is a constant depending on the metals;  $t_1 =$  the higher temperature,  $t_2$  the lower.

303. Siemens's Pyrometer.—This instrument is based on the well-known principle of increase of resistance with rise of temperature.

The formula given by Siemens for the resistance of metals is

$$R = \alpha \sqrt{T} + \beta T + \gamma;$$

<sup>\*</sup> See article Pyrometer, Encyc. Britannica.

in which R equals the resistance to be measured,  $\alpha$ ,  $\beta$ , and  $\gamma$  are coefficients, and T equals the absolute temperature.

The resistance is ascertained by a volt-meter, and the coefficients  $\alpha$ ,  $\beta$ , and  $\gamma$  are determined by special calibration. The heated substance is a platinum wire wound around a clay cylinder and protected by a covering of fine clay; this is inserted into the furnace or medium whose temperature is required. The current is passed alternately in different directions, and the resistance is measured by the gas accumulating in a volt-meter at either pole.

The instrument is very sensitive to slight changes of temperature, and is well suited for accurate measurements of moderate temperatures. In the measurement of high temperatures considerable difficulty was experienced because of change in the coefficients due to the extreme heat.

304. General Remarks regarding Pyrometers.—An extended series of experiments with the different pyrometers described has led the author to believe that the calorimetric forms, as described in Articles 298 and 301, despite their inconvenience and the losses from radiation which attend their use, give, if we except the air-pyrometer, more uniform and reliable results than the others. The electrical pyrometers are subject to the same inaccuracy as the calorimetric pyrometers, due to complex changes in the electrical resistances of the thermometric substance, so that the results are quite uncertain for high temperatures.

The electrical pyrometers also need for their successful use a command of electrical energy and the possession of a set of electrical measuring instruments. While these pyrometers may give reliable results with skilled electricians, they are of little practical use to the engineer. The calorimetric pyrometers are cheap, portable, and easy to use, and with careful handling give uniform and fairly reliable results. The best substance for use in these instruments as a heat-conveyer is, in the opinion of the author, a porcelain or fire-clay ball about 2 inches in diameter. The metals, not even excepting platinum, are readily attacked by the furnace-gases, and when

employed need to be protected in a crucible of refractory material. If used by heating directly in the furnace, wroughtiron is perhaps as good as any of the metals. It may be oxidized and fall in pieces, but since the oxide has about the same specific heat as the original metal, determinations may be made with the residue without any great error. The porcelain or fire-clay balls seem to be unaffected by the furnace-gases, and do not radiate heat as rapidly as the metals, so that were the specific heat as accurately determined they would be superior in every way to the metallic balls. The determination of the specific heat of burned fire-clay as made by Mr. D. J. Jenkins at Sibley College was 0.1702 at temperature of boiling water. By comparison with results obtained with a metal whose specific heat was known, the specific heat at 1000° C. (1832° F.) is cal-The latter quantity is subject to corculated as about 0.20. rection.

The air-pyrometer with a porcelain or platinum bulb can be used conveniently, and the corresponding temperatures so readily and easily deduced from the determinations that it is worthy a much more extended use. The bulb may be made in any desired form, and a long capillary stem can be led from the bulb to the measuring tubes a long distance without sensible error, so that it may be adapted to a variety of uses.

### CHAPTER XIII.

METHODS OF DETERMINING THE AMOUNT OF MOISTURE IN STEAM.

may be dry and saturated, wet or superheated, as described in Article 265, page 312. The term quality is used to express the relative condition of the steam as compared with dry and saturated steam of the same pressure. It is in any case the total heat in a pound of the sample steam, less the heat of the liquid, divided by the total latent heat of evaporation of one pound of dry steam at the same pressure, see page 314.

For moist or wet steam, which is to be considered as made up of a mixture of water and dry steam, the quality would equal the percentage by weight of dry steam in the mixture.

For superheated steam the quality would exceed unity, and is to be considered as that weight of dry and saturated steam, the heat in which is equivalent to that in one pound of the superheated steam, neglecting in both cases the heat of the liquid.

In case of superheated steam, its temperature is higher than that of dry and saturated steam at the same pressure; this excess of temperature is termed degree of superheat.

306. Importance of Quality Determinations.—The importance of correctly determining the quality of steam is great, because the percentage of water carried over in the steam in the form of vapor or drops of water may be large, and this water is an inert quantity so far as its power of doing work is concerned, even if not a positive detriment to the engine. Any tests for the efficiency of engine or boiler not accompanied with determinations of the amount of water carried over in the

steam would be defective in essential particulars, and might lead to erroneous or even absurd results.

307. Methods of Determining the Quality.—The methods of measuring the amount of moisture contained in steam may be considered under three heads: first, Calorimetry proper, in which the method is based on some process of comparing the heat actually existing in a pound of the sample with that known to exist in a pound of dry and saturated steam at the same pressure. Secondly, Mechanical Separation of the water from the steam, involving the processes of separation and of weighing. Thirdly, a Chemical Method, in which case a soluble salt is introduced into the water of the boiler. This salt is not absorbed by dry steam, and if it is found in the steam it indicates the presence of water. The quality is equal to the ratio of salt in the steam to that in an equal weight of water drawn from the boiler.

All methods for determining the quality of steam are included under the head of *calorimetry*, and instruments for determining the quality are termed *calorimeters*.

308. Classification of Calorimeters.—The following classification of different forms of calorimeter is convenient and comprehensive:

	1	Jet	Barrel or Tank. Continuous.
:	Condensing	Surface {	Barrel or Tank. Continuous.  Barrus—Continuous. Hoadley Calorimeter. Kent—Tank Calorimeter.
Calorimeters	Superheating	{ Exter	nal—Barrus Superheating. nal—Peabody Throttling.
	Directly determini	ng moisture.	Separator. Chemical.

In nearly every calorimetric process the heat of the sample is determined by condensing the steam at atmospheric pressure, or at least measuring the heat when its conditions of pressure and temperature are different from its original state. This process involves no error. The following is a statement of an investigation concerning it made by Sir William Thomson:\*

"If steam have to rush through a long fine tube or through a fine aperture within a calorimetric apparatus, its pressure will be diminished before it is condensed; and there will, therefore, in two parts of the calorimeter be saturated steam at different temperatures; yet on account of the heat developed by the fluid friction, which would be precisely the equivalent of the mechanical effect of the expansion wasted in the rushing, the heat measured by the calorimeter would be precisely the same as if the condensation took place at a pressure not appreciably lower than that of the entering steam."

310. Use of Steam-tables.—In reducing calorimetric experiments steam-tables will be required. The explanation of the terms used will be found in Article 265, page 312, and tables will be found in the Appendix of the book.

Students will please notice, that the pressures referred to in the steam-tables are absolute, not gauge pressures, and that gauge pressures are to be reduced to absolute pressures, by adding the barometer-reading reduced to pounds per square inch, before using the tables.

The following symbols will be employed to represent the different properties of steam:

Properties of Steam.	Symbol.	Properties of Steam.	Symbol.
Pressure, pounds per sq. in. Pressure, pounds per sq. foot Temperature, degrees Fahr. Temperature absolute Heat of the liquid Internal latent heat External latent heat Total latent heat	ρ or I ΑΡωστΕ	Total heat B. T. U.  Weight of cu. ft. of steam lbs. Vol. of 1 lb. steam, cubic ft. Vol. of 1 lb water, cubic ft. Change in volume $v - \sigma$ Quality of steam Per cent of moisture Degree of superheat	v or C o u x

TABLE OF SYMBOLS.

<sup>\*</sup> Mathematical Papers, XLVIII., p. 194.

The quantities q,  $\rho$ , APu, r, and  $\lambda$  are given in B. T. U. per pound of saturated steam reckoned from  $32^{\circ}$  Fahr.

311. General Formula for the Heat in One Pound of Steam.—The heat existing in one pound of steam with any quality x can be expressed by the formula

$$x\rho+q=h$$
. . . . . . (1)

The heat, however, which is required to raise water from 32° F. and convert it into steam at a given temperature will include the external latent heat, and will be expressed by the formula

$$xr+q=h'.$$
 . . . . . . (2)

The heat that may be given out by condensation or change of pressure is expressed in equation (2); that which exists in the steam without change of pressure or external work, by equation (1).

Since in all calorimetric processes the steam is condensed, or at least the pressure changed, equation (2) is to be employed to represent the available heat.

If the pressure of the steam is known, r and q can be found from the steam-tables: If the heat h in B. T. U. above  $32^{\circ}$  can be found for the sample steam, all the quantities in the above equation with the exception of x are known, and we shall find

$$x = \frac{h' - q}{r} \dots \dots (3)$$

In case x is greater than unity, the steam is superheated, and the degree of superheat

$$D = \frac{(x-1)r}{0.48}; \dots \dots (4)$$

when 0.48 equals the specific heat of steam,  $c_s$ .

312. Methods of Determining the Heat in a given Sample of Steam.—There are two methods of determining the heat k in a given sample of steam.

1. Condensing the Steam at Atmospheric Pressure.—In this case the weight of the steam is obtained by weighing the condensing water before and after condensation has taken place and determining the corresponding temperatures. Thus let the weight of condensing water be represented by W, that of the condensed steam by w; the temperature of the condensing water cold by  $t_1$ , the condensing water warm by  $t_2$ ; the original temperature of the steam by  $t_3$ , that of the condensed steam by  $t_4$ . Suppose that the calorimeter absorb heat to the same extent as k pounds of water; then the heat added by condensing one pound of steam is equal to

$$\frac{W+k}{w}(t_1-t_1)\ldots \ldots (5)$$

The original heat above 32° from equation (2), page 363, is xr+q. Since in equation (5) the temperature is reckoned above zero, it will be more convenient to use, instead of xr+q+32, xr+t, which is very nearly identical.

Since the heat lost in condensing one pound of steam is equal to that gained by the water, we shall evidently have

$$xr+t-t_1=\frac{W+k}{w}(t_1-t_1);$$

from which

$$x = \frac{W+k}{w} \frac{(t_{s}-t_{s})}{r} - \frac{(t-t_{s})}{r} \dots \dots (6)$$

If the temperature of condensed steam equal that of the warm condensing water,  $t_1 = t_2$ , which is the usual condition of condensation.

2. Superheating the Steam.—If the pressure and temperature of superheated steam is known, the degree of superheat D can be found by deducting the normal temperature, as given in the steam-table for that pressure, from the observed temperature. The total heat in a pound of the superheated steam

is equal to that in a pound of saturated steam, as given by the steam-tables, plus the product of the degree of superheat into the specific heat  $c_i$  of the steam; that is,

$$H = \lambda + c_{\bullet}D$$
.

The superheating may be done by extraneous means, as in the Barrus superheating calorimeter, or by throttling, as in the throttling calorimeter. In the latter the heat required for superheating is obtained by reducing the pressure, which, being accompanied by a corresponding reduction of boiling point, liberates heat sufficient to evaporate a small percentage of moisture only.

In the case of the superheating calorimeter, the heat required to evaporate the moisture and superheat the steam is measured by the loss of temperature n in an equal weight of superheated steam, so that

$$c_{\rho}n = r(1-x) + c_{\rho}D;$$
  

$$1 - x = c_{\rho}\frac{(n-D)}{r}. \qquad (7)$$

In the case of the throttling calorimeter there is no change in the total amount of heat, but there is a change of pressure, so that the quantities in the first member of (8) correspond to the original pressures of steam before throttling, and those in the second member to the calorimeter pressures after throttling, and

$$xr+q=\overline{\lambda_c}+c_\rho D, \qquad x=\frac{\lambda_c-q+c_\rho D}{r}.$$
 (8)

313. Condensing Calorimeters.—Condensing calorimeters are of two general classes: I. The jet of steam is received by the condensing water, and the condensed steam intermingles directly with the condensing water. 2. The jet of steam is condensed in a coil or pipe arranged as in a surface condenser,

and the condensed steam is maintained separate from the condensing water.

The principle of action of both classes of condensing calorimeter is essentially the same, and is expressed by equation (6):

$$x = \frac{W + k (t_1 - t_1)}{r} - \frac{(t - t_1)}{r}.$$

In the first class  $t_1 = t_2$ , and

$$x = \frac{W + k(t_2 - t_1)}{r} - \frac{(t - t_2)}{r} \cdot \dots \cdot (9)$$

Both forms of condensing calorimeter can be made to act continuously or at intervals, and there are several distinct types of each.

The most common type of condensing calorimeter is one in which the condensing water is received in a barrel or tank, and hence is termed a barrel calorimeter. The special forms will be described later.

# 314. Effect of Errors in Calorimeter Determinations.

First. Condensing Calorimeters.—To determine the effect of error, suppose in each case the quantity under discussion to be a variable and differentiate the equation

$$x = \frac{\frac{W}{w}(t_{1} - t_{1}) - (t - t_{2})}{x}$$

We have

$$\Delta x \div \Delta W = (t_{s} - t_{1}) \div wr;$$

$$\Delta x \div \Delta w = -(W \div w^{s})(t_{s} - t_{1}) \div r;$$

$$\Delta x \div \Delta t_{1} = [(W \div w) + 1] \div r;$$

$$\Delta x \div \Delta t_{s} = W \div wr.$$

Since  $\Delta r = -\Delta t$ , nearly, for ordinary pressures of steam, and further is a function of the pressure, we have approximately

$$\Delta p = \Delta \rho = -\Delta r;$$

$$\Delta x \div \Delta p = \left[ \frac{W}{v} (t_2 - t_1) - t - r + t_2 \right] \div r^2.$$

The weight of condensing water usually held by the barrel-calorimeters is from 300 to 400 lbs., while the weight of the steam condensed varies from 16 to 20 lbs., and the corresponding temperatures have a range of 50° to 70° F. For these cases it will be found that the percentage of error in quality, supposing other data correct, is approximately the same as the percentage of error in the weights. The error in thermometer-determination has nearly the same effect, whether made before or after the steam has been condensed. For the amounts usually employed the error of one fifth of one degree in tempera ture has about the same effect as one half of one per cent error in weight; that is, it makes an error of about the same amount in the quality of steam.

The following shows in tabular form the effect of errors with condensing calorimeters in which the ordinary weights of water and of steam are used:

Brro Condensin	or in ng Water.		or in ed Steam.	Tempe	ror n rature, Water.	Temp	rror in erature, Water.	Er i Ste pres	ing Error in	
Lbs.	Per ct.	Lbs.	Per ct.	Degs.	Per ct.	Degs.	Per ct.	Lbs.	Per c.	Resulting Quality.
Total wt.	= 360 lbs.	Total wt.	= 20 lbs.	Temp.	=50° F.	Temp.	=110° F.	Pr. =	88 lbs.	
3.6 1.8 1.5 0.3	1.0 0.5 0.40 0.08	0.2 0.1 0.08 0.016	1.0 0.5 0.4 0.08	0.53 0.27 0.18 0.045	1.2 0.6 0.5 0.1	0.65 0.30 0.25 0.05	0.60 0.30 2.5 0.50	7.0 3.5 3.0 0.6	8.0 4.0 3.5 0.7	1.2 0.6 0.5 0.1
Total wt.	= 300 lbs.	Total wt.	= 20 lbs.			0.25				

0.t 0.5 0.2

TABULATION OF ERRORS.

In the table, the errors in the various observations expressed in the same horizontal line have the same effect on the result.

From the table it is seen, for the given weights, that an error of 3.6 pounds in condensing water, of 0.2 pound in condensed steam, of 0.53° F. in temperature of cold water, of 0.65° F. in warm water, or of 7 pounds in steam-pressure will severally make an error in the result of 1.2 per cent. Expressed in percentages, an error of 1 per cent in weight or 1.2 and 0.6 per cent in thermometer-readings makes an error in the quality of 1.2 per cent.

The conditions for determination of moisture within one half of one per cent require—

- 1. Scales that weigh accurately to half of one per cent of the quantity to be weighed.
- 2. Thermometers that give accurate determinations to about one fifth of one degree F.
  - 3. An accurate pressure-gauge.
  - 4. Correct observations of the resulting quantities.
  - 5. Determination of loss caused by calorimeter.

Secondly. Superheating Calorimeters.—The Barrus Superheating Calorimeter.—In this, if  $t_1 - t$  is the gain of temperature of the sample steam, and  $t_2 - t_1$  is the loss of temperature in the superheated steam, we have, neglecting radiation,

$$1 - x = 0.48[t_s - t_1 - (t_s - t)] \div r.$$

In the *Throttling Calorimeter*, where the steam is superheated by expanding, we have by equation (7), making  $c_i = 0.48$ ,


$$x = \frac{\lambda + 0.48D - q}{r}.$$

In either form of superheating calorimeter the effect of an error of one degree in temperature is to make an error in x of 0.06 of one per cent, while an error of  $9^{\circ}$  in temperature will affect the value of x but 0.5 per cent. The boiling point

should be correctly determined, however, especially if the amount of superheating is small.

An error in gauge-reading has about one half the effect on the quality of the steam as in the other class of calorimeters.

315. Method of Obtaining a Sample of Steam.—It is usually arranged so as to pass only a very small percentage of the total steam through the calorimeter, and it is important that this sample shall fairly represent the entire quantity of steam. From experiments made by the author, it is quite certain that the quality varies greatly in different portions of the same pipe, and that it differs more in horizontal than in vertical pipes. Steam drawn from the surface of the pipe is likely to contain more than the average amount of moisture; that from the centre of the pipe to contain less. The better method for obtaining a sample of steam is to cut a long threaded nipple into which a series of holes may be drilled, and screw this well into the pipe. Half-inch pipe is generally used for calorimeter connections, and it may be screwed into the main pipe one half or three quarters of the distance to the centre, with the end left open and without side-perforations, as shown in Fig. 143, or screwed three fourths the



distance across the pipe, a series of holes drilled through the sides, and the end left open or stopped, as shown in Fig. 144. A lock-nut on the nipple, which can be screwed against the pipe when the nipple is in place, will serve to make a tight joint. Since it is very easy to separate a portion of the water from the steam mechanically, the holes drilled in the nipples should be large, otherwise the sample of steam is likely to be too dry. It has been the recent practice of the author to use

a nipple of sufficient length to reach three quarters across the main steam-pipe, and provided with several holes, each onefourth inch in diameter.

The collecting-nipple is placed preferably in a vertical pipe a short distance below a bend from the horizontal, and the calorimeter is located as close as possible to the main steam-pipe.

316. Method of Inserting Thermometers.—In the use of calorimeters it is frequently necessary to insert thermometers




FIG. 145 .- STEAM-THERMOMETER.

FIG. 146.-THERMOMETER-CUP.

into the steam in order to correctly measure the temperature. For this purpose thermometers can be had mounted in a brass case, as shown in Fig. 145, which will screw into a threaded opening in the main pipe.

The author prefers to use instead a thermometer-cup of the form shown in Fig. 146, which is screwed into a tapped open-

ing in the pipe. Cylinder-oil or mercury is then poured into the cup, and a thermometer with graduations cut on the glass inserted. The thermometer-cups are usually made of a solid brass casting, the outside being turned down to the proper dimensions and threaded to fit a  $\frac{3}{4}$ -inch pipe-fitting. The inside hole is drilled  $\frac{1}{4}$  inch in diameter, and the walls are left  $\frac{1}{16}$  inch thick. The total length varies from  $4\frac{1}{4}$  to 6 inches—depending on the place where it must be used. In either case it is essential that the thermometer be inserted deep into the current of steam or water, and that no air-pocket forms around the bulb of the thermometer. The thermometer should be nearly vertical, and as much of the stem as possible should be protected from radiating influence.

If the thermometer is to be inserted into steam of very little pressure, the stem of the thermometer can be crowded into a hole cut in a rubber cork which fits the opening in the pipe. In case the thermometer cannot be inserted in the pipe it is sometimes bound on the outside, being well protected from radiation by hair-felting; but this practice cannot be recommended, as the reading is often much less than is shown by a thermometer inserted in the current of flowing steam. In the use of thermometers, breakages will be lessened by carefully observing the directions as given in Article 286, p. 342.

- 317. Determination of the Water-equivalent of the Calorimeter.—The calorimeters exert some effect on the heating of the liquid contained in them, since the inner substance of the calorimeter must also be heated. This effect is best expressed by considering the calorimeter as equivalent to a certain number of pounds of water producing the same result. This number is termed the water-equivalent of the calorimeter. The water-equivalent, k, can be found in three ways:
- 1. By computing from the known weight and specific heat of the materials composing the calorimeter. Thus let c be the specific heat,  $W_c$  the weight; then

2. By drawing into the calorimeter, when it is cooled down to a low temperature, a weighed quantity of water of higher temperature and observing the resulting temperature. Thus let W equal the weight of water,  $t_1$  the first and  $t_2$  the final temperatures, and k the water-equivalent sought. Since the heat before and after this operation is the same,

$$(W+k)t_1=Wt_1.$$

From which

$$k = \frac{W(t_1 - t_2)}{t_2}.$$

3. By condensing steam drawn from a quiescent boiler, and thus known to be dry and saturated, with a weighed quantity of water of known temperature in the calorimeter; the temperature, pressure, and weight of the steam being known. The conditions are the same as for equation (6), page 364, all the quantities being known excepting k.

By solving equation (6),

$$k = \frac{w(rx + t - t_{\bullet})}{t_{\bullet} - t_{\bullet}} - W. \quad . \quad . \quad . \quad (10)$$

For the barrel and jet condensing calorimeters generally,  $t_1 = t_1$ , and we have

$$k=\frac{w(rx+t-t_1)}{t_1-t_1}-W.$$

The cooling effect of superheating calorimeters is generally expressed in degrees of temperature in the reading of one of the thermometers.

#### SPECIAL FORMS OF CALORIMETERS.

318. Barrel or Tank Calorimeter.—The barrel calorimeter belongs to that class of condensing calorimeters in which a jet of steam intermingles directly with the water of condensation. It is made in various ways; in some instances the

walls are made double and packed with a non-condensing substance, as down or hair-felting, to prevent radiation, and the instrument is provided with an agitator consisting of paddles fastened to a vertical axis that can be revolved and the water thoroughly mixed; but it usually consists of an ordinary wooden tank or barrel resting on a pair of scales, as shown in Fig. 147.




FIG. 147 -THE BARREL CALORIMETER.

A sample of steam is drawn from the main steam-pipe by connections, as explained in Article 315, page 369, and conveyed by hose, or partly by iron pipe and partly by hose, to the calorimeter. In the use of the instrument, water is first admitted to the barrel and the weight accurately determined. The pipe is then heated by permitting steam to blow through it into the air; steam is then shut off, the end of the pipe is submerged in the water of the calorimeter, and steam turned on until the temperature of the condensing water is about 110° F. The pipe is then removed, the water vigorously stirred, the temperature and the final weight taken. If the effect of the calorimeter, k, expressed as additional weight of water, is known, the quality can be computed as in equation (6), page 364.

$$x = \frac{(W + k)(t_1 - t_1)}{wr} - \frac{(t - t_1)}{r}. \qquad (6)$$

A tee screwed crosswise of the pipe, as shown in Fig. 147, forms an efficient agitator, provided the temperature be taken immediately after the steam is turned off.

The pipe may remain in the calorimeter during the final weighing if supported externally, and if air be admitted so that it will not keep full of water; in such a case, however, it should also be in the barrel during the first weighing, or else the final weight must be corrected for displacement of water by the pipe. The effect of displacement is readily determined by weighing with and without the pipe in the water of the calorimeter.

The determination of the water-equivalent of the barrel calorimeter will be found very difficult in practice, and it is usually customary to heat the barrel previous to using it, and then neglect any effect of the calorimeter. This nearly eliminates the effect of the calorimeter. The accuracy of this instrument, as shown in Article 314, page 367, depends principally on the accuracy with which the temperature and the weight of the condensed steam are obtained. The conditions for obtaining the temperature of the water accurately are seldom favorable, as it is nearly impossible to secure a uniform mixture of the hot and cold water; the result is that determinations made with this instrument on the same quality of steam often vary 3 to 6 per cent. From an extended use in comparison with more accurate calorimeters, the author would place the average error resulting from the use of the barrel calorimeter at from 2 to 4 per cent.

Example.—Temperature of condensing water, cold,  $t_1$ , is 52°.8 F.; warm,  $t_2$ , 109°.6 F. Steam-pressure by gauge, 79.7; absolute, 94.4. Entering steam, normal temperature, from steam-table,  $t_1$ , 323°.5 F. Latent heat,  $t_2$ , 888.2 B. T. U. Weight of condensing water cold,  $t_2$ , 360 pounds; warm,  $t_2$ ,  $t_3$ ,  $t_4$ , 379.1 pounds, wet steam,  $t_4$ , 19.1 pounds. Calorimeter-equivalent eliminated by heating. The quality

$$x = \frac{360}{19.1} \frac{(109.6 - 52.8)}{888.2} - \frac{323.5 - 109.6}{888.2} = 95.4$$

- 319. Directions for Use of the Barrel Calorimeter.—Apparatus.—Thermometer reading to  $\frac{1}{8}$  degree F., range 32° to 212°; scales reading to  $\frac{1}{80}$  of a pound; barrel provided with means of filling with water and emptying; proper steam connections; steam-gauge or thermometer in main steam-pipe.
  - 1. Calibrate all apparatus.
- 2. Fill barrel with 360 pounds of water, and heat to 130 degrees by steam; waste this and make no determinations for moisture. This is to warm up the barrel.
- 3. Empty the barrel, take its weight, add quickly 360 pounds of water, and take its temperature.
- 4. Remove steam-pipe from barrel; blow steam through it to warm and dry it; hang on bracket so as not to be in contact with barrel; turn on steam, and leave it on until temperature of resulting water rises to 110° F. Turn off steam; open aircock at steam-pipe as explained.
- 5. Take the final weights with pipe in barrel, in same position as in previous weighings; also take weights with the pipe removed: calculate from this the displacement due to pipe, and correct for same.

Alternative for fourth and fifth operations.—Supply steam through a hose, which is removed as soon as water rises to a temperature of 110° F. Weigh with the hose removed from the barrel. Stir the water while taking temperatures.

- 6. Take five determinations, and compute results as explained. Fill out and file blank containing data and results.
- 7. Compute the value of the water-equivalent, k, in pounds by comparing the different sets of observations.
- 320. The Continuous-jet Condensing Calorimeter.— A calorimeter may be made by condensing the jet of steam in a stream of water passing through a small injector or an equivalent instrument. The method is well shown in Fig. 148. A tank of cold water, B, placed upon the scales R, is connected to the small injector by the pipe C; the injector is supplied with steam by the pipe S, the pressure of which is taken by the gauge P; the temperature of the cold water is taken at e, that of the warm water at g. Water is discharged into the

weighing-tank A. The amount taken from the tank B is the weight of cold water W; the difference in the respective weights of the water in tanks A and B is the weight of the steam w.

The quality is computed exactly as for the barrel calorimeter.

In case an injector is used, as shown in Fig. 148, the tank B is not needed: water can be raised by suction from the tank A through the pipe d. The original weight of A will be that




FIG. 148.—THE INJECTOR CALORIMETER.

of the cold water; the final weight will be that of steam added to the cold water.

In case an injector is not convenient, and the water is supplied under a small head, a very satisfactory substitute can be made of pipe-fittings, as shown in Fig. 149. In this case, steam of known pressure and temperature is supplied by the pipe A cold water is received at S', and the warm water is discharged at S. The temperature of the entering water is taken by a thermometer in the thermometer-cup T', that of the discharge by a thermometer at T. The steam is condensed in front of the nozzle C.

This class of instruments present much better opportunities of measuring the temperatures accurately than the barrel calorimeter, and the results are somewhat more reliable.

In the use of continuous calorimeters of any class, the instrument should be put in operation before the thermometers are put in place or any observations taken. The poise on the weighing-scale can be set somewhat in advance of its balancing position, and when sufficient water has been pumped out the scale-beam will rise; this may be taken as the signal




FIG. 149.-JET CONTINUOUS CALORIMETER.

for saving the water which has been previously wasted, and of commencing the run.

The water equivalent of the calorimeter, k, will be small, and due principally to radiation. It can be found by passing hot water through the calorimeter and noting the loss in temperature.

321. The Hoadley Calorimeter.—This instrument belongs to the class of non-continuous surface calorimeters. The

instrument is described in Transactions of the American Society of Mechanical Engineers, Vol. VI., page 716, and consisted of a condensing coil for the steam, situated in the bottom of a tank-calorimeter, very carefully made to prevent radiationlosses. The dimensions were 17 inches diameter by 32 inches deep, with a capacity of about 200 pounds of water. The




FIG. 150.—HOADLEY'S CALORIMETER.

calorimeter was made of three concentric vessels of galvanized iron, the spaces being filled with hair-felt and eider-down. The condenser consisted of a drum through which passed a large number of half-inch copper tubes, the steam being on the outside, the water on the inside, of these tubes; the agitator consisting of a propeller-wheel attached to an axis that could be rotated by turning the external crank K, effectually stirring the water. The thermometer for measuring the temperature was inserted in the axis of the agitator at T.

In the hands of Mr. Hoadley the instrument gave accurate determinations.

In practice the instrument was arranged as in Fig. 151; the calorimeter E was placed on the scales F, and supplied by cold water from the elevated barrel A. The temperature of the entering water was taken at C. Steam was admitted to the condensing-coil until the temperature of the condensing water reached, say, 110° F. The weights before and after




Fig. 151.—Hoadley's Calorimeter Arranged for Use.

adding steam were taken by the scales F; the temperature of the warm condensing water was taken by a thermometer, G, inserted in the axis of the agitator. The water-equivalent was determined as explained in Article 317, page 371, and the quality computed by equation (6), page 364. The rate of cooling was determined, and an equivalent amount added as a correction for any loss of heat by radiation.

322. The Kent Calorimeter.—This instrument differs from the Hoadley instrument principally in the arrangement of the condensing coil. This when filled with steam could be removed from the calorimeter, so as to enable the weight of

steam to be taken on a smaller and more delicate pair of scales than those required for the condensing water, thus giving more accurate determinations of the weight of the steam condensed.

323. The Barrus Continuous Calorimeter.—This calorimeter is shown in Fig. 152 in section and in Fig. 153 in perspective. It consists of a steam-pipe, af, surrounded by a




FIG. 152.—BARRUS CONTINUOUS CALORIMETER.

tub or bucket, O, into which cold water flows; the condensing water is received as it enters the bucket in a small brass tube, k, surrounding the pipe a, and is conveyed over and under baffle-plates, m, so as to be thoroughly mixed with the water in the vessel, and is finally discharged at c. Thermometers are placed at f and at g to take the temperature of the water as it

enters and leaves, and finally the condensing water is caught from the overflow and weighed. The condensed steam falls below the calorimeter; by means of the water gauge glass at e




FIG. 153.-THE BARRUS CONTINUOUS AND SUPERHEATING CALORIMETERS.

it may be seen and kept at a constant height. The temperature of the condensed steam while it is still under pressure is shown by a thermometer at h. In order to use the calorimeter it is necessary to weigh the condensed steam; this cannot be done without further cooling, as it would be converted into steam were the pressure removed. For this purpose it is passed through a coil of pipe immersed in a bucket filled with water,

shown at S in Fig. 153. The water used in the cooling bucket S has no effect on the quality of the steam and is not considered in the results; it is allowed to waste, but the condensed steam is caught at W, Fig. 153, and weighed.

The quality of steam is computed by omitting k in formula (6), page 364. Hence

$$x = \frac{W}{w} \frac{(t_{i} - t_{i})}{r} - \frac{(t - t_{i})}{r}.$$

w is the weight of condensed steam after correction for radiation-loss as explained in Article 324; w being equal to w'-u.

324. Directions for Using the Barrus Continuous Calorimeter.—Apparatus needed.—Thermometers; pail for receiving condensed steam; tank and scales for the condensing water.

Directions.—1. Fill the thermometer-cups with cylinderoil. (Do not put thermometers in place until apparatus is working.)

- 2. Turn on condensing water and steam; regulate the flow of condensing water so as to keep the bucket O nearly full, and the temperature of the discharge-water as much above temperature of the room as injection is below: this should be about 110° F. Regulate the flow of condensed steam so as to keep the water in the glass e at a constant level. Turn water on to the cooling coil in the bucket S, and reduce the condensed steam to a temperature of about 120°.
- 3. After the apparatus is working under uniform conditions, put the thermometers in the cups for temperature of injection and discharge water, and having previously weighed the vessels, at a given signal, note time and commence to catch the condensed steam and the condensing water. Continue the run until about 360 or 400 pounds of condensing water has run into the receiving tank. Without disturbing the condition of the apparatus, commence simultaneously to waste the discharge from both pipes. Find the weights of

condensed steam (w') and condensing water (W); note time of ending run.

- 4. Make three more runs similar to the first.
- 5. To find the radiation-correction of the instrument: Empty the bucket O of condensing water, and surround the condensing tube a with hair-felting; make a run of the same length, and with steam of same pressure as in the previous runs. The weight of steam condensed will be the radiation-loss, which we call u, and is to be deducted from the weight of condensed steam obtained in the previous runs of the same length. Find the condensation per hour.
  - 6. Work up quality of steam by the formula

$$x = \left[\frac{W}{w' - u}(t_s - t_1) - (t - t_2)\right] \div r.$$

Make report as described for other calorimeters.

Example.—The following is the result of a trial with the Barrus continuous calorimeter: Temperature of injection-water,  $t_1 = 37^{\circ}.5$  Fahr.; temperature of discharge-water,  $t_2 = 83^{\circ}.8$  Fahr.; temperature of condensed steam,  $t_3 = 304.9$  Fahr.; steam-pressure by gauge, 72.4 lbs.; temperature of entering steam,  $t = 317^{\circ}.9$ ; length of test, 40 minutes; weight of cooling water, W = 573.5 lbs.; weight of condensed steam, w' = 29.89 lbs.; radiation-loss u = 0.13 lb. Neglecting value of u,

$$x = \frac{573.5}{29.89} \frac{(83.8 - 37.5)}{891} - \frac{(317.9 - 304.9)}{891}$$
$$= \frac{19.21 \times 46.3 - 13.0}{891} = \frac{876.4}{891} = 98.4.$$

x = 98.4 if not corrected for radiation-loss. If corrected,

$$x = \left(\frac{573.5}{29.76}46.3 - 130\right) \div 891 = 98.9.$$

# 325. Forms for Use with Condensing Calorimeters.

# MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY.

PRIMING TEST WIT	H CONDE	nsing (	CALORII	METER.		
Made by			• • • •	· · · • • •		189
Test of	• • • • • • • •		Ste	eam		<i>.</i> .
at						
Kind of calorimeter		-		• • • • • •	••••	• • • • • •
Number of run	ļ	I.	II.	III.	ıv.	v.
Duration of run, minutes Gauge-pressure, lbs Absolute pressure, lbs. Scale-readings, tare, lbs. Tare and cold water, lbs. Final weight, lbs. Quantities: Condensing water, lbs. Condensed steam, lbs. Temperatures, deg. Fahr.: Condensing water, cold Condensing water, warm Condensed steam Steam at pressure P. Ratio water to steam Quality, per cent. Per cent moisture. Degree of super-heat.	## P   W + V   W   W   ##   ##   ##   ##   ##   ##					
Correction due to displacement of Calorimeter-equivalent						
Temp. roomdeg. Fah	ır. Ba					
Quality $x = \left[\frac{W}{w}(t_2 - t_1) - (t - t_2)\right]$	(s) $+ r$ .			III. IV. V.		


Degree of super-heat D = (x - 1)r + 0.48.

## CALORIMETER TEST.

Di	ate.		1	• • • • •	••			ature of				1
No. of		- i	Conden Wate	sing r.	Conder Wate		Cond	ensing ter.	rature ensed r. /s	rature off.	bress-	Ę.
Signal.	Time	Difference.	Weight.	Diff.	Weight.	Diff.	Hot.	Cold.	Condensed Water. 19	Temperature of Room.	Gauge-press- ure.	Barometer.
Total . Aver		 			••••••							
Duration	on o	f te	st	••••						••••		min.
Weight	of	stea	m conde	nsed.	• • • • • • •	• • • • •	. <b></b>	• • • • • •				lbs.
Weigh	of	con	densing v	vater.		••••		• • • • • •				"
Averag	e te	mpe	rature of	hot c	ondensir	ng wa	ter(	C.;	.Fahi	r.; .	В.	T.U.
"				cold	**	61	<b></b>	"	. "	•		"
"				cond	ensed ste	am		"	. "			
"				roon	1		•••••		. "	•	deį	g. C.
"	р	ress	ure of ai	r					• • • · · ·	. lbs.	per so	}. in,
"	a	bsol	ute press	ure of	the stea	m				. "	"	••
Therm			in water								B.'	T.U.
			by conde									
	•		by cond	•								
			n same.									"
			er conden									16.
_		-	by each	_				•				
			one pour				•	•		· · · ·	• • •	••
Per cer	nt o	ſ	••••••	••••	· · · · · · · ·	••••	• • • • • •	• • • • • •	••••	• • • • •	• • • • •	• • • •
						9	ianed					

326. Barrus Superheating Calorimeters.—In the Barrus Superheating Calorimeter, Fig. 154, the steam-pipe leading from

the main is bifurcated, one branch, E, passing over the flames of a large Bunsen burner, the other passing upward, and finally downward, when it is jacketed by the enlargement of the



first branch. The branches discharge separately, each through equal orifices, about one-eighth inch in diameter.

This instrument is shown in Fig. 154 in elevation, and on the left-hand side of Fig. 153 in perspective. The steam in one branch is superheated at G; that in its normal condition is received at H, and is discharged at N. The superheated steam forms a jacket from I to K outside the sample to be tested, and is discharged at the orifice M. The temperature of the jacket steam is taken at A and at B; that of the normal steam is measured at C, as

B B O AIFFORD

FIG. 154.—BARRUS SUPER-HEATING CALORIMETER.

it is discharged; it is found as it enters from its pressure taken at H, by reference to the steam-table.

The theory of this calorimeter is as follows:

- 1. An equal weight of steam flows through each branch of the pipe.
- 2. The steam, superheated by the gas-flame, is used as a jacket for the other branch, and parts with as much heat, except for radiation, as the other gains.
- 3. This amount may be measured provided the steam discharged from the central tube is superheated.

To measure this gain or loss of heat, thermometers are placed to take the temperature of steam as it enters and leaves the jacket, and on the central pipe near the same places.

Formula.—Let (1-x) be the amount of water to be evaporated; in so doing it will take up from the jacket-steam r(1-x) heat-units. Let t be the normal temperature of the steam at the gauge pressure; let  $T_1$  be the temperature of the superheated jacket-steam at entering, and  $T_2$  as it leaves; let  $T_3$  be the temperature of the superheated steam discharged from the sample pipe, and let radiation-loss in degrees  $F_2$ . If the specific heat of steam be 0.48, since gain and loss of heat are equal, we have

$$0.48(T_1 - T_2 - I) = r(1 - x) + 0.48(T_2 - I).$$

$$\therefore$$
 1 - x = 0.48[ $T_1 - T_2 - l - (T_2 - t)$ ]  $\div r$ ;

from which x may be found.

To find l, the radiation-loss in degrees, shut off steam in the branch leading to the centre steam-pipe, and find reading of thermometers  $T_1$  and  $T_2$ . After a run of same length as in test, take  $l = T_1 - T_2$ .

Directions for using Barrus Superheating Calorimeter.—Apparatus needed.—Three thermometers reading 400° F. each, and pressure-gauge, superheating lamps, etc.

First. Calibrate instruments, and ascertain by a run of twenty minutes that equal amounts of steam are discharged from each orifice. This may be done by condensing the steam.

Second. Put cylinder-oil in oil-cups; attach gauge.



Third. Put in working order; after thermometer at end of sample-steam-pipe shows superheat, commence the run.

Fourth. Take readings once in two minutes for twenty minutes.

Fifth. Obtain radiation-loss l as explained.

Sixth. Work up results as explained, and make report as in previous cases.

327. Form for Determination with Barrus Superheating Calorimeter.

#### BARRUS SUPERHEATING CALORIMETER.

DATE.....

Time.	Temp. Jacket steam Lentering. Temp. Sample Steam at Exit.		Steam- pressure by Gauge.	Barometer.	
Average					
			in.;		
Sample stea	am, gauge pre	essure	• • • • • • • • • • • • •	• · · · · · · · · · · · · · · · · · · ·	bs. per sq. in
Sample stea			• • • • • • • • • • • • • • • • • • • •		-
-	absolute			1	bs. per sq. in
44 4	absolute temperatu	re at absolute	•••••		bs. per sq. in
44 41	absolute temperatu	"	pressure		bs. per sq. in F
44 41	absolute temperatu	"	pressure	C.; C.; C.;	bs. per sq. in 
Superheated	absolute temperatu t d steam, temp	"	e pressure	C.;C.;C.;	bs. per sq. in F F F
Superheated	d steam, temperature.  d steam, temperature.  of steam at a	" outlet perature at inl " octoor	e pressure	C.;C.;C.;	bs. per sq. in 
Superheated	d steam, temperature.  d steam, temperature.  of steam at a	ore at absolute or outlet  perature at inl or or  absolute pressi	e pressure	C.;C.;C.;	bs. per sq. in

328. The Throttling Calorimeter.—This instrument was designed in 1888 by Prof. C. H. Peabody of Boston, and rep-

resents a greater advance than any previously made in practical calorimetry. The equations for its use and limitations of the same were given by Prof. Peabody in Vol. IX., Transactions Am. Society Mechanical Engineers. As designed originally, it consisted of a small vessel four inches in diameter by six to

eight inches long, and connected to the steam-supply with a pipe containing a valve, b, used to throttle the steam supplied the calorimeter. Fig. 155 shows the original form of the calorimeter. which is arranged so that any desired pressure less than that in the main steam-pipe can be maintained in the calorimeter A. The pressure in the calorimeter is shown by a steam-gauge at g, and the temperature by a thermometer at D: the main steam-pipe is provided with a drip at f, to drain the pipe before making calorimetric tests.




FIG. 155.—PEABODY'S THROTTLING CALORIMETER.

In using the calorimeter, any desired pressure can be maintained in the vessel A by regulating the opening of the admission and exhaust valves.

The effect of this operation will be to admit the heat due to high-pressure steam into a vessel filled with steam of lower pressure. The excess of heat is utilized firstly in evaporating moisture in the original steam; secondly, if there is sufficient heat remaining, in raising the temperature in the vessel A above that due to its pressure, thus superheating the steam. Unless the steam in the chamber A is superheated, no determinations can be made with the instrument. The equation for its use is obtained as follows: the heat in one pound of high-pressure steam before reaching the calorimeter is expressed as in formula (2), Article 311, page 363, by xr + q. After reaching the calorimeter the heat is that due to the press-

ure in the calorimeter added to that due to the superheat, or  $\lambda_c + 0.48(T_1 - T_c)$ . Since these quantities are equal,

$$xr + q = \lambda_c + 0.48(T_1 - T_c);$$

from which

$$x = [\lambda_c - q + 0.48(T_1 - T_c)] \div r;$$
 . . (11)

in which r equals latent heat, and q heat of liquid due to pressure in main pipe as given in the steam-table.

 $\lambda_c$  = total heat in one pound of dry steam at calorimeter pressure;  $T_1$  = reading of thermometer in calorimeter, and  $T_c$  = normal temperature of steam in calorimeter due to calorimeter pressure. Care must be taken that both  $\lambda_c$  and q are given in the same units.

Example.—Suppose that the gauge pressure on the main steam-pipe is 80 pounds, that on the calorimeter 8 pounds atmospheric pressure 14 pounds, as reduced from the barometer-reading, and that the thermometer in the calorimeter reads 274°.2 F. Required the quality of the steam.

In this case we obtain the following quantities from the steam-table:

	P Absolute Pressure,	T Temperature Deg. F.	Heat of Liquid, B. T. U.	λ Total Heat, B. T. U.	Latent Heat. B. T. U.
Entering steam In calorimeter	94 22	323.I 233.I	293.2 202.0	1153.0	887·3 951.0

From which

$$x = [1153 - 293.2 + 0.48(274.2 - 233.1)] \div 887.3;$$
  
 $x = 99.1.$ 

Per cent of moisture, 100 - x = 0.9.

329. Heisler's Throttling Calorimeter.—This instrument differs from Peabody's principally in size and form. It is shown complete and ready for use in Fig. 156, and full size in the sectional view, Fig. 157.



FIG 156.—HEISLER'S THROTTLING CALORIMETER.

The chief difference between this and Peabody's calorimeter is in the use of a standard orifice placed between two non-conducting washers. The steam is throttled in passing through this orifice, and reduced to a low pressure in the calorimeter. The form, as shown in Fig. 157, it is claimed, is such as to bring the steam intimately in contact with the thermometer-tube in its passage through the calorimeter.

The instrument, as shown in Fig. 156, is connected to an attached mercury-manometer which is used for measuring the pressure in the calorimeter.




FIG. 157.—HEISLER'S CALURIMETER. (SECTION; FULL SIZE.)

330. Throttling Calorimeter of Pipe-fittings.—A very satisfactory calorimeter can be made of pipe-fittings, as shown




FIG. 158 .-- THROTTLING CALORIMETER OF PIPE-FITTINGS.

in Fig. 158. Connection is made to the main steam pipe, as explained in Article 315, page 369. The calorimeter is made

of  $\frac{3}{4}$ -inch fittings arranged as shown; the steam-pipe W is of  $\frac{1}{4}$ -inch pipe, and the throttling orifice is made by screwing on a cap, in which is drilled a hole  $\frac{1}{8}$  or  $\frac{1}{16}$  inch in diameter.

A thermometer-cup, Fig. 146, page 370, is screwed into the top, and an air-cock inserted opposite the supply of steam. A manometer, B, for measuring the pressure is attached by a piece of rubber tubing as shown. The exhaust steam is discharged at E. The back-pressure on the calorimeter can be increased any desired amount by a valve on the exhaust-pipe; when no valve is used the pressure is so nearly atmospheric that a manometer is seldom required.

331. Method of finding Normal Temperature in the Calorimeter.—It is essential to know the normal temperature within the calorimeter; this will vary with the pressure on the calorimeter, which pressure is equal to the barometer-reading plus the manometer-reading.

The following table gives the normal temperature corre-TABLE OF BOILING-POINTS,

Normal	Total Pressure	Normal	Total Pressure
Temperature.	on Calorimeter.	Temperature,	on Calorimeter.
Degrees F.	Inches Hg.	Degrees F.	Inches Hg.
209.5 .6 .7 .8 .9 210.0 .1 .2 .3 .4 .5 .6 .7 .8 .9 211.0	28.466 .523 .580 .637 .695 .752 .810 .867 .925 .983 29.041 .099 .157 .215 .274 .332 .391 .449 .508	.7 .8 .9 212.0 .1 .2 .3 .4 .5 .6 .7 .8 .9 213.0 .8 214.0 215.0 216.0 217.0 218.0	.744 .803 .863 .922 .982 30.041 .101 .161 .221 .281 .341 .403 .402 .522 31.004 .107 .692 32.277 .862
.5	.626	219.0	34.032
.6	.685	220.0	.617

Difference 1° F = 0.585 inch. Difference 1 inch = 1°.709.

sponding to various absolute pressures nearly atmospheric, expressed in inches of mercury:


In the use of the instrument the total pressure in the calorimeter is to be taken as the sum of the barometer-reading and the attached manometer. The degree of superheat of the steam in the calorimeter is the difference between the temperature as shown by the pressure and that shown by the inserted thermometer.

332. Graphical Solution for Throttling-Calorimeter Determinations.—In the practical use of this instrument it is customary to exhaust at atmospheric pressure, so that the normal temperature in the calorimeter is the boiling-point at atmospheric pressure, and  $\lambda_c$  is 1146.6; in which case formula (11) becomes

$$x = \frac{1146.6 + 0.48(T_1 - 212) - q}{r}$$
$$= \frac{1146.6 - q}{r} + \frac{0.48(T_1 - 212)}{r}.$$

If in this form we suppose the steam-pressure constant, and the degree of superheat and quality of steam alone to vary, r and q will both be constant, and we shall have the equation of a right line, in which  $\frac{1146.6-q}{r}$  is the distance above the origin that the line cuts the axis of ordinates, and  $0.48 \div r$  is the tangent of the angle that the line makes with the axis of abscissæ. Drawing lines corresponding to the different gauge or absolute pressures, a chart may be formed from which the values of x may be obtained without calculation.

Using degrees of superheat in the calorimeter as abscissæ and absolute steam-pressure as ordinates, and drawing lines corresponding to various percentages of moisture, we have a diagram shown in Fig. 159, from which the results of observations made with the throttling calorimeter may be taken at once without further calculation.








Fig. 159.—Diagram giving Results from Throttling Calorimeter without Computation.

Use of the Diagram.—To find the percentage of moisture in the steam from the diagram, pass in a horizontal direction along the base-line until you arrive at the number corresponding to the degree of superheat in the calorimeter; then pass in a vertical direction until you reach the required absolute pressure of steam. The position with reference to the curved lines shows at once the percentage of moisture, and can be read easily to one tenth of one per cent. Thus, for example, suppose that we have the following readings: Barometer, 20.8 inches; attached manometer, 1.5 inches-making a total pressure in the calorimeter of 31.3 inches, corresponding to a temperature of 214°.27 Fahr. Steam-gauge, 80 pounds; absolute pressure, 94.7 pounds; thermometer-reading in calorimeter, 254° Fahr. From which the degree of superheat is found to be  $254^{\circ} - 214^{\circ}.27 = 39^{\circ}.73$ .

Following the directions as given, the percentage of moisture is seen from the diagram to be 1.66 per cent. The quality would be 1.00 - 1.66 = 98.34 per cent. While the diagram is especially computed for determinations when the pressure in the calorimeter is atmospheric or but slightly above, it will be found to give quite accurate results when the calorimeter is under pressure, by considering that the ordinates represent the difference of pressures on the steam and in the calorimeter. Thus, in the example, Article 328, page 300, the steam-pressure was 80 pounds, calorimeter-pressure 8 pounds; degree of superheat 274.2-233.1 = 41.1; resulting quality by calculation 99.1, indicating 0.9 per cent of moisture. Using difference of pressure 80 - 8 = 72 as ordinate, and 41.1 as abscissa, we find from the chart that the percentage of moisture is 0.92; from which

$$x = 99.08.$$

333. Limits of the Throttling Calorimeter.—To determine the amount of moisture that can be evaporated by throttling, make  $T_1 = T_c$  in formula (11); then  $x = (\lambda_c - q) \quad (7. . . . . . . .$ 

$$x = (\lambda_c - q)$$
  $r$ . . . . . (12)

The amount of moisture that can be determined by the

**o**6.8

throttling calorimeter in expanding from the given pressure to atmospheric, as computed by substituting in formula (12), is as follows:

ressure, pound	s per square in.	Maximum per cent of prim-	Quality of the
Absolute.	Gauge.	ing.	steam, per cent.
300	285.3	07.7	92.3
250	235.3	7.0	93.0
200	185.3	6.1	93.9
175	160.3	5.8	94.2
150	135.3	5.2	94.8
125	110.3	4.6	95.4
100	85. <b>3</b>	4.0	96.0

LIMITS OF THE THROTTLING CALORIMETER.

By reducing the pressure below the atmosphere, the limits of the instrument may be somewhat increased.

60.3

75

- 334. Directions for Use of Throttling Calorimeter.—
  Apparatus.—Steam-thermometer; pressure-gauge; manometer for measuring pressure in calorimeter in inches of mercury.
- 1. Attach the calorimeter to a perforated pipe extending well into the main steam-pipe to secure a fair sample of steam. Calibrate all the apparatus.
- 2. Fill thermometer-cup with cylinder-oil, having first carefully removed any moisture from the cup. Place thermometer in the cup, and after it has reached its maximum commence to take observations.
- 3. Read steam-pressure, attached manometer, and temperature at frequent intervals.
  - 4. Compute the quality of the steam for each observation.

335.	Forms f	or Thr	ottling-C	alorimet	er Determi	inations.

Priming tests of	• • • • • • • • •	· · · · · · · · ·	• • • • • • • • • •	• • • • • • • • • • •
Made by			· · · · · · · · · · · · ·	
at,	N. Y.,		<b></b> .	189
with	. Throttling	g Calorim	eter.	
Barometer-readinginch	s. Stea	m used d	uring run.	lbs.

	Number	I	2	3	4	5	6	7	8	9
hality of steam $x = \frac{\lambda - g + o}{o + g}$ begrees superheat $D = \left(\frac{x - 1}{o + g}\right)$	Time  Steam-pressure, main pipe  Manometer reading calorimeter  Golorimeter  Heat at steam-pressure P. Normal temperature in calorimeter  Total heat, pressure in main  Total heat for pressure P. Calorimeter  Total heat, pressure m  Latent heat for pressure P. Calorimeter  Ouality of eteam  Degrees of superheat									

#### AVERAGE RESULTS OF CALORIMETER TEST.

	L	)ate	• • • • • •		٠.
Duration of tes	it	• • • • • • • • • • • • • • • • • • • •	• • • • • • •	mi	a.
Barometer		in.;	lbs.	, per sq. i	n.
Boiler-pressure	by gauge	• • • • • • • • • • • • • • • • • • • •		• 11	
"	absolute		٠ '		
Calorimeter-pr	essure by gauge				
44	" absolute	• • • • • • • • • • • • • • • • • • • •			
Calorimeter-ter	mperature	C.;	F.		
Per cent of mo	isture in steam			. <b>.</b> . <b></b>	
	9	ioned			

336. The Separator Calorimeter.—The separator calorimeter, as designed by the author, consists of a chamber A into which leads the steam-pipe SB, Fig. 160, perforated in its lower portion with a large number of holes, each  $\frac{1}{8}$  inch in diameter. From the top of the chamber an exhaust-pipe S' is connected, across which extends a diaphram with a centre orifice O,  $\frac{1}{18}$  inch in diameter.

In the use of the instrument steam is supplied at S, the water is deposited in the chamber A, and dry steam escapes through the orifice at O. A steam-gauge can be attached at G if desired, but neither gauge-readings nor temperatures are required.

The later forms of the instrument consist of two chambers, each made as shown in Fig. 160, the instrument being so constructed that the exhaust S' from the first chamber is made to




FIG. 160.-THE SEPARATOR CALORIMETER.

supply the steam for the second chamber; but one orifice is used, and that is placed in the discharge from the second chamber. In this case perfectly dry steam will be received in the second chamber, and any moisture deposited there will be

due to radiation-loss. Since the chambers are of the same size, this quantity is to be used as a correction to the amount deposited in the first chamber.

The later forms of the instrument are provided with a graduated scale for determining the weight of water deposited in each chamber, an arrangement not shown in Fig. 160.

The accuracy of this instrument depends on the completeness of the separation of the water from the steam, and on the condition that the exhaust steam is in each case dry and saturated.

To determine this a series of tests were conducted for the author by Messrs. Brill and Meeker with steam of varying degrees of quality. The range in moisture was from 33 to 1 per cent, yet in every case the throttling calorimeter attached to the exhaust gave dry steam within limits of error of observation. The following were the results of this examination:

SEPARATING CALORIMETER.

	Obse	ervations o		Steam fro	ation of Ex om Calorime ing Calorin	ter by		
	T	P	w	w	x	t	x	No. of
Calori- meter.	Duration Run, minutes.	Gauge Pressure, pounds.	Pounds Separated Water in Run.	Pounds Condensed Steam in Run.	Quality Steam, per cent.	, Calori-	Steam in Exhaust.	Obser
AS	25	81.5	1.15	4.45	79.46	281	99.95	6
B	25	78.2	0.15	5.20	97.2	281.3	100.00	6
AS	25	80.8	0.525	4.25	89.005	286.5	100.00	6
A \ B \ A \ B \	25	79.5	0.150	4 · 75	96.94	281.8	99.95	6
$A \hat{S}$	25	78.5	0.300	5.000	94 - 34	282.8	100.00	6
	25	77.6	. 150	5.45	97.32	282.3	100.00	6
A	24	79.5	1.8	4 - 55	71.65	280.1	99.94	1 6
B(	24	78.5	1.4	4.90	77 - 77	279.5	99.9	6
A } B {	20	83.5	1.15	4.1	77.67	286.5	100.00	
B	20	81.6	1.70	4 - 75	73.64	282.7	99.98	1 5
	20	74.8	0.65	3.95	85.87	283.7	100.05	5
	20	82.0	0.85	3.95	82.29	286.8	100.05	5
	20	82.6	0.35	4.15	92.22	285.6	100.0	5
	20	81.5	0.20	3.95	95.15	285.2	100.05	5
A S	20	81.4	2.20	4.325	66.28	283.1	100.0	5
$B \left\{ A \right\}$	20	80.3	o.30	4 - 55	93.81	282.8	100.0	5 5
AS	20	82.0	0.20	4.65	95.8	282.8	99.98	5
B (	20	81.1	0.20	4.40	95 · 7	284.0	100.0	١,

337. Formula for Use of the Separating Calorimeter.— Let w equal the weight of dry steam discharged at the exhaustorifice, W the water drawn from the separator, R the water thrown down during the run by radiation. Then the quality of the steam is

$$x=\frac{w+R}{W+w};$$

the amount of moisture,

$$1-x=\frac{W-R}{W+w}.$$

The radiation loss can be determined by using steam of known quality as determined by the throttling calorimeter, or better still by arranging two separating calorimeters of exactly the same size in series, so that the steam exhausted from the first is used as supply in the second. As the second receives perfectly dry steam, the water deposited is due to radiationloss, and the weight of water obtained from this calorimeter is the value of R to be substituted in the above formula.

The Limits of the Instrument.—The instrument will give correct determinations for any amount of moisture, and for any degree of superheat, less than the radiation-loss. For small amounts of moisture a very exact determination of R is necessary. The limit of accuracy with careful handling is less than one-fourth of one per cent.

338. General Method of Using.—In the use of the instrument it has been the usual practice of the author to lead a hose from the exhaust to a condensing vessel, and condense the exhaust-steam for a run of one-half or one hour in length. This is readily done, since with 80 lbs. steam-pressure the weight of dry steam discharged will not be much in excess of 12 lbs., and will require a condensing vessel containing only about 200 lbs. of cold water. The water in the calorimeter may be drawn off during the run so as to keep it at about the same level, by setting the cock so as to drip slightly; this water may be discharged directly into a glass flask through the cock W, and will in general be sufficiently cool to prevent any loss

by vaporization. When the instruments are provided with graduated scales the weight of the water deposited can be read directly, and may be drawn off at the end of the run.

In case it is not convenient to condense the steam, a pressure-gauge may be attached to the calorimeter, the area of the orifice of discharge accurately measured, and the discharge may be computed by Napier's rule as follows: (see Article 231, page 274.)

Flow in pounds per second 
$$=\frac{\text{absolute pressure} \times \text{area in square inches}}{70}$$
.

The error by the use of this rule was shown by Prof. Peabody not to exceed one or two per cent. A table calculated by Napier's rule is given in the Appendix.

Example.—The following is an actual case of simultaneous determinations of the quality of samples of steam from the same pipe with a separating and a throttling calorimeter.

			Separa	iting Calor	imeter.		Throte Calorin	ding neter.	
Duration of Run.	Steam Pressure- gauge.	Weight of Steam during Run, lbs.	Weight of Entrained Water.	Total Weight of Steam.	Radiation- loss by Condensa- tion, lbs.	$\frac{W-R}{W+w}$	Tempera- ture in Calori- meter.	Per cent of Moist- ure.	
min.	P	าบ	IV	W + w	R	1 - x		1-x	
20 20 20	77 81.5 83.0	4.65 4.85 4.70	0.1406 0.14859 0.15062		.053 .053 .048	1.8 1.9 2.1	247.4 248.0 246.0	1.8 1.9 2.1	
	Per hou	r			.051				

- 339. Special Directions.—1. Apparatus.—Calorimeter; steam-gauge.
- 2. Attach to steam-pipe so as to secure a fair sample of steam. Attach hose to exhaust-opening so that it can be led to a vessel of water and condensed. Attach rubber tube to bottom of separator so that water can be drawn off and weighed.

- 3. Start steam flowing through the calorimeter, and after it has attained uniform conditions arrange valve to discharge water so that it will maintain constant level in the water-gauge. At the same instant commence to condense steam from the exhaust, and to save water discharged from the calorimeter. At end of run have water in gauge-glass same height as at beginning. In case it is not convenient to condense and weigh the steam, attach a steam-gauge and calculate the flow by Napier's rule, but carefully measure the area of discharge-orifice before each experiment.
- 4. Measure the steam condensed by radiation, by arranging two separating calorimeters in series, and find its weight R.
  - 5. Calculate the quality as explained.

## 340. Form for Separator-Calorimeter Experiment.

# MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY. PRIMING TEST WITH SEPARATOR CALORIMETER.

Made by									
No. of Run.	Dura- tion of Run.	Gauge Pressure.	Absolute Pressure.	Weight of Exhaust.	Weight of Water.	Total Weight of Steam.	Radia- tion- loss.	Mois- ture.	Quality.
	min.	lbs.	P lbs.	tw lbs.	W lbs.	W+w	R lbs.	ı – X per ct.	X per ct.
1 2 3 4 5 6 7 8 9 10 11 12 13 14									

Diameter of orifice in. Area of orificesq. in.	Symbol A.
Barometer-readingin.	
Formula of instrument, $I - x = (W - R) + (W + w)$ .	
Napier's Rule, Flow of Steam, pounds per second = $\frac{1}{\sqrt{6}} PA$ .	
Method of determining $R$	
Results	
	• • • • • • • • • • • • • • • • • • • •
Method of determining $W$	

341. The Chemical Calorimeter.—This instrument depends on the fact that certain soluble salts will not be absorbed by dry steam, but will be carried over by water, so that if the salt appears in the steam its presence indicates water.

Various salts have been used, but common salt, chloride of sodium, gives as good results as any.

The proportion that the salt in a given weight of condensed steam bears to that in a given weight of water drawn from the boiler, is the percentage of moisture in the steam. The method of analysis is a volumetric one, and is as follows:

Add three or four ounces of common salt to the water in the boiler; after it is dissolved, draw from the boiler a small amount of water and condense an equal weight of steam, which are to be kept in separate vessels. Add to each of them a few drops of neutral chromate of potash, but in each case an equal quantity, which amount may be measured by a pipette; the same amount should also be added to a vessel containing an equal weight of distilled water, in order to obtain a standard or zero-point for the scale used in the analysis.

By means of a graduated pipette a triturated solution of nitrate of silver is permitted to flow, a single drop at a time, into each of the three solutions. The effect is to cause the formation of the chloride of silver, and until that formation completely takes place the resulting liquid will be whitish or milky; but because of the presence of the bichromate, the instant the chloride has all been precipitated the liquid turns red. The amount of nitrate of silver required is measured by the graduated pipette, and gives the information regarding the salt present.

The detailed directions for the test are as follows:

Take in each case 100 cubic centimeters of liquid containing a few drops of neutral chromate of potassium, and drop from a triturated solution holding 10.8 grams of silver to the liter; the following data were obtained in a test:

AMOUNT OF NITRATE OF SILVER REQUIRED TO TURN 100 C. C. RED.

100 C, C, Of	First Trial.	Second Trial.	Third Trial.	
Condensed steam	0.1 c. c.	0.05 c. c.	0.1 c. c.	а
	13.6 c. c.	14.0 c. c.	13.35 c. c.	в
	0.05 c. c.	0.05 c. c.	0.05 c. c.	с

Letting the results with these three samples be denoted by a, b, and c respectively, and the amount of moisture by 1 - x, we have

$$1 - x = \frac{a - c}{b - c}.$$

This gives the following results:

	First Trial.	Second Trial.	. Third Trial.
Amount moisture	$\frac{0.1 - 0.05}{13.605} = .0037$	$\frac{0.05 - 0.05}{14.0 - 0.05} = 0$	$\frac{0.1 - 0.05}{13.35 - 0.05} = .00375$

Average = 0.0025.

This method is evidently applicable only in determining the amount of moisture in the steam as it leaves the boiler, and will give no information regarding the additional moisture that may be added to the steam by condensation.

Instead of common salt, sulphate of soda is sometimes used, and the percentage of moisture determined by the percentage of sulphuric acid present in the steam as compared with that in water from the boiler.

342. Comparative Value of Calorimeters.—These instruments, arranged in order of accuracy, are no doubt as follows:

throttling; separating; Barrus superheating; Hoadley; continuous condensing; chemical; and lastly the barrel.

The ease with which the throttling and separating instruments can be used, their small bulk, and great accuracy, render them of chief practical importance.

The throttling calorimeter can be used only for steam with a small amount of moisture, as explained in Article 333: but the separating instrument is not limited by the amount of moisture entrained in the steam. It is not, however, as well adapted for superheated steam, nor can the results be determined as quickly as with the throttling instrument; when carefully handled the accuracy is, however, substantially the same.

## CHAPTER XIV.

## DETERMINATION OF THE HEATING VALUE OF FUELS— FLUE-GAS ANALYSIS.

343. Combustion.—Combustion or burning is a rapid chemical combination. The only kind of combustion which is used to produce heat for engineering purposes is the combination of fuel of different kinds with oxygen. In the ordinary sense the word combustible implies a capacity of combining rapidly with oxygen so as to produce heat. The chief elementary constituents of ordinary fuel are carbon and hydrogen. Sulphur is another combustible constituent of ordinary fuel, but its quantity and its heat-producing power are so small that it is of no appreciable value.

The chemical elements are those which have not been decomposed; these unite with each other in various definite proportions, which may be represented by certain numbers termed chemical equivalents or atomic weights. These for gaseous bodies are very nearly proportional to their densities at the same pressure and temperature.

The atomic weight of a chemical compound equals the sum of the atomic weights of all the elements entering into the combination. Air is not a chemical compound, but a mechanical mixture of nitrogen and oxygen.

The following table gives the properties of the principal elementary and compound substances that enter into the composition of ordinary fuels:

Substance.	Symbol.	Chemical Equivalent by Weight.	Chemical Equivalent by Volume.	Properties of Elements by Volume.
Oxygen	N	16 14	I I	
Hydrogen	C P	12 31	?	
SulphurSiliconAir	Si 77N + 23O	32 14 100	100	79N + 210
WaterAmmoniaCarbonic oxide	NH. CO	18 17 28	2 2 2	H + 0 H + N C + 0
Carbonic acid	CH,	4 <del>1</del> :4 :6	2 2 2	C + 0; C + H; C + H;
Sulphurous acid	SO <sub>3</sub> SH <sub>3</sub> S <sub>2</sub> C	64 34 76	2 2 2	S + O <sub>3</sub> S + H <sub>2</sub> C + S <sub>1</sub>

344. Calorific Power or Heat of Combustion.—The calorific value of a fuel is expressed in *British thermal units* or in *calories*, according as Fahrenheit or Centigrade thermometric scales are used. The calorific value may be determined by direct experiment, or it may be computed from a chemical analysis as follows:

The carbon is credited with its full heating power, due to its complete oxidation as determined by a calorimeter experiment. The hydrogen is credited with its full heating power, after deducting sufficient to form water with the oxygen present in the compound; since when hydrogen and oxygen exist in a compound in the proper proportion to form water, the combination of these constituents has no effect on the total heat of combustion.

The calorimetric value, determined experimentally, of one pound of hydrogen is 62,032 B. T. U.; that of one pound of carbon, 14,500 B. T. U. Hence the combustion of one pound of hydrogen is equivalent to that of 4.28 pounds of carbon.

A formula for the total heat, h, of combustion in B. T. U.

for each pound of the compound containing hydrogen and carbon would be

$$h = 14.500 \left[ C + 4.28 \left( H - \frac{O}{8} \right) \right] .$$
 (1)

For theoretical evaporative power, in pounds of water from and at 212 F.,

$$E = \frac{h}{966} = 14.6 \left[ C + 4.28 \left( H - \frac{O}{8} \right) \right].$$
 (2)

The number of pounds of air required to supply the oxygen necessary for the combustion of one pound of fuel to CO<sub>s</sub> can be computed from the formula

$$A = 12 \left[ C + 3 \left( H - \frac{O}{8} \right) \right]; \dots (3)$$

and the corresponding volume in cubic feet can be found by multiplying by the specific volume of one pound at 70 degrees Fr. In which case the volume in cubic feet is

$$a = 149 \left[ C + 3 \left( H - \frac{O}{8} \right) \right].$$
 (4)

In the above formulæ, C, H, and O represent the number of pounds respectively of carbon, hydrogen, and oxygen in the product of combustion.

When in the combustion of hydro-carbon fuels in an ordinary furnace hydrogen is consumed, the water formed passes off in the state of vapor, hence the latent heat of evaporation is not available. One pound of hydrogen burns to 9 pounds of water, the latent heat of which at 212° is 966 units; hence we must deduct  $966 \times 9 = 8694$  units from the tabular value

of the heat due to the combustion of hydrogen. This leaves 53,338 units available. Therefore the actual value in terms of carbon is H=3.67C, instead of 4.28C as stated in (1), and the heat of combustion actually available is

$$h = 14.5\infty \left[ C + 3.67 \left( H - \frac{O}{8} \right) \right].$$
 (5)

The following table gives the heat of combustion of the principal combustible substances:

TOTAL HEAT OF COMBUSTION WITH OXYGEN.

Substance.	Pounds of Oxygen required per Pound of Combustible.	Pounds of Air required per Pound of Combustible (nearly).	Total Heat, B. T. U. per Pound.	Pounds of Water evaporated per Pound of Combustible from 212°.	Product of Combustion.
Hydrogen gas	8	36	62,032	62.6	H,O
Carbon burned to CO	1.33	6	4,400	4.50	CO
Carbon burned to CO <sub>2</sub>		12	14,450	14.67	CO,
Olefiant gas	3.43	15.43	21,344	22.1	CO, and H <sub>2</sub> O
Liquid hydro-carbon		l	19,000	20	
• •			(21,700	22.5 5	60
Sulphur to SO <sub>2</sub>	I	4.5	3.740	4.09	SO <sub>3</sub>
Silicon to SiO <sub>2</sub>	2.29	10.2	14,000	14.24	SiO,
Phosphorus to P <sub>2</sub> O <sub>4</sub>		6.5	10,250	10.45	P <sub>2</sub> O <sub>6</sub>
Marsh gas, C <sub>1</sub> H <sub>4</sub>	3.55	16.2	26,400		CO <sub>2</sub> and H <sub>2</sub> O
Crude petroleum		15.0	18,600	τ8.53	44 44
	•••••		19,200	19.73	
	• • • • •		18,800	19.04	
Ether			16,100	16.41	4 4 4
Tallow	• • • • • •	<i>•</i> • • • •	16,000	.16.37	
Alcohol	• • • • •		12,700	13.06	
Methyl alcohol (wood-spirit)			9,200	9.65	
		5.7	5,750	6.18	CO, and SO,
Carbonic oxide	1.33	6	10,100	10.4	CO <sub>2</sub>

345. Determination of the Heating Value by the Oxygen required.—It was observed by Welter\* that those

<sup>\*</sup> Chemical Technology, Vol. I., p. 336: Graves and Thorp.

constituents of a compound which require an equal amount of oxygen for combustion evolve also equal quantities of heat; from which he concluded that since the oxygen required for the combustion of a body is in the same relation as the quantity of heat evolved, it might fairly be made the measure of the heating power. When, therefore, oxygen is consumed by the burning of carbon, wood, hydrogen, etc., the heat which is evolved must increase with the quantity that is consumed; or the same amount of heat is generated by a certain given weight of oxygen, whether that quantity be employed in converting carbon into carbonic acid, or hydrogen into water.

The oxygen required is 2\frac{2}{3} for one part of carbon; 8 for one part of hydrogen.

One part by weight of carbon will raise the temperature of 80.5 parts of water from freezing to boiling.

One part by weight of hydrogen will raise 234 parts of water from freezing to boiling.

One part by weight of oxygen in burning carbon will heat  $\frac{80.5}{2\frac{3}{8}} = 29.1$  parts of water.

One part by weight of oxygen in burning hydrogen will heat  $\frac{284}{8} = 29.3$  parts of water from the freezing to the boiling point.

In round numbers, therefore, the heating effect of oxygen may be assumed as sufficient to raise 29.2 parts of water from the freezing to the boiling point. This is equivalent to 2920 Centigrade heat-units, or to 5230 B. T. U.

Calorific Value.—The calorific value of the fuel would therefore be the product of this number by the number of parts of oxygen required. Thus let  $\alpha$  equal the number of parts of oxygen required for each combustible; then the heat produced by the combustion is

 $h = 2920\alpha$  in Centigrade units;  $h = 5230\alpha$  in B. T. U.

Thus, for example, in the combustion of carbon to CO,,

2 parts by weight of oxygen are required for each one of carbon; hence for this case  $\alpha = 2\frac{2}{3}$ , and

$$h = 5230 \times 2$$
 = 14,100.

In the combustion of hydrogen to water 8 parts by weight of oxygen are required, and in this case  $\alpha = 8$ ; hence

$$h = 5230 \times 8 = 41,840.$$

This is about two thirds of the actual value of the calorific power of hydrogen, but does not differ much from the heat available in ordinary combustion.

In case of a compound body, let a fuel contain a, b, c, and d parts by weight of different combustible ingredients; and let  $\alpha$ ,  $\alpha_1$ ,  $\alpha_2$ ,  $\alpha_3$  be the parts by weight of oxygen required by each. Then

$$h = 2920(a\alpha + b\alpha_1 + c\alpha_2 + d\alpha_3)$$
 in Centigrade units;  
=  $5230(a\alpha + b\alpha_1 + c\alpha_2 + d\alpha_3)$  in Fahrenheit units.

346. Temperature produced by Combustion.—In the determination of the calorific value of a fuel two principal factors are involved, namely, the calorific power, or the total amount of heat to be obtained from the perfect combustion of its constituents, and the calorific intensity, or the temperature attained by the gaseous products of combustion. The calorific power will be the same regardless of the method of combustion; that is, a unit of carbon or of hydrogen will give the same heat whether burned with the oxygen of the air or of a metallic oxide. The calorific intensity or temperature, however, will be greater as the volume of gases heated is less. Thus carbon burned to CO, will produce a much higher temperature when burned in oxygen gas than when in the air, since in the latter case it must heat an additional quantity of nitrogen equal to rather more than three times the weight of the oxygen.

The maximum temperature cannot be either computed or determined experimentally with complete accuracy, partly because the total combustion of a quantity of fuel in a given time at one operation is practically impossible, but more particularly from the fact that dissociation of gaseous compounds produced in burning takes place at temperatures far below those indicated as possible by calculation.

The maximum temperature is calculated as follows:

The value of one pound of carbon is 8080 Centigrade heatunits, or 14,500 B. T. U. The heat absorbed by any body is equal to the product of its weight, w, specific heat, s, and rise of temperature, t. Hence

wst = 8080, or  $t = 8080 \div ws$ , in Centigrade degrees, and

 $t = 14,550 \div ws$ , in Fahrenheit degrees.

In the case of combustion of carbon to CO, in oxygen gas, the oxygen required for each part of carbon is 2\frac{3}{2} parts; the specific heat of CO, is 0.216. Hence the maximum temperature

$$\frac{8080}{3.67 \times 0.216} = 10,187^{\circ} \text{ C.},$$

or

$$\frac{14,550}{3.67 \times 0.216} = 18,367^{\circ} \text{ F}.$$

In case it is burned in air an additional weight of 8.88 pounds of nitrogen, with a specific heat of 0.24, must be raised to the temperature of combustion. Hence the maximum temperature will be

$$\frac{8080}{3.67 \times 0.216 + 8.888 \times 0.24} = 2731^{\circ} \text{ C.}$$
 or 4860° F.

The maximum temperature to be attained by combustion of the following substances, as calculated by R. Bunsen, is:

Combustible.	In Ox	ygen.	Ín Air.		
Carbon	9873° C.	17,803° F.	2458° C.	4456° F.	
	7067	12,752	3042	5507	
	9187	16,568	5413	9775	
	7851	14,103	5329	9624	
	8061	14,542	3259	5898	

If the air supplied to the fuel be in excess of that required for perfect combustion, the temperature will be less.

When the excess of air is 50 per cent, the maximum temperature from combustion of carbon is 3515° F.; when the excess is 100 per cent, the maximum temperature is 2710° F.

The specific heats under constant pressure of the gases usually occurring in connection with combustion are

Carbonic-acid gas	0.217
Steam	
Nitrogen	0.245
Air	0.238
Ashes (probably)	0.200
Oxygen	
Carbonic oxide	
Hydrogen	0.235

347. Composition of Fuels.—The fuels in ordinary use contain, in addition to the combustible compounds, more or less mineral or earthy matter that remains as ash after the combustion has taken place; there is also frequently water in the hygroscopic state. The presence of these incombustible substances and the fact that perfect combustion can rarely be secured tend to make the actual heating effect less than that indicated by the theory. The percentage of ash as given in various boiler trials shows a wide variation, as follows:

American coals	5	to	22	per cent
English coals	2.9	to	27.7	"
Prussian coals	1.5	to	11.6	46 -
Saxon coals	7.4	to	63.4	

The following table gives the composition of the principal fuels and the weight of air required to produce perfect combustion:

AVEDA	GF	COMP	OSITION	OF	FIIFIS
AVERA	JL	CUMP	U.S.I.I.U.N	()r	ruri.

Fuel.	Carbon.	Hydrogen. H	Oxygen.	Ash.	Pounds of Air required for one of Fuel.	
Charcoal from wood	0.93	}	i		11.16	
nom peat	0.80	1			9.6	
Coke, good	0.94				11.3	
Coal, anthracite	0.915	0.035	•	0.03 to 0.05	1 4	
" dry bituminous	0.87	0.05	0.04	0.04 100.22	12.06	
" coking.:	0.85	0.05	0.06	" " "	11.73	
" "	0.75	0.05	0.05	11 11 11	10.58	
" cannel	0.84	0.06	0.08		11.88	
" dry, long-flaming	0.77	0.05	0.15	l	10.32	
" lignite	0.70	0.05	0.20	1	9.30	
Peat, dry	0.58	0.00	0.31	5 to 15	7.68	
Wood, dry	0.51	0.057	42.0	0.01	6.00	
" air-dried, 20% H2O.		4.8	34.8	0.01	6.00	
Mineral oil	0.85	0.15	1		15.7	

348. Principle of Fuel-calorimeters.—The caloric value of a fuel is determined by its perfect combustion under such conditions that the heat evolved can be absorbed and measured. It is essential in such cases that (1) the combustion be perfect, and that (2) the heat evolved be absorbed and measured.

The combustion may take place in atmospheric air, in oxygen gas, or in combination with a chemical that supplies the oxygen required. It is essential in all cases that the supply of oxygen be adequate for perfect combustion.

The heat evolved by combustion is determined by the rise in temperature of a given weight of water in a calorimeter of which the cooling effect, K, has been carefully determined, and in which the escaping gases are reduced to the temperature of the room. Let w equal the weight of fuel, E the heat evolved in heat-units by the combustion of one part, W the number of parts by weight of water heated from a temperature t' to t. Then if the escaping gases be reduced in temperature to that of the room,

$$wE = (K + W)(t - t'),$$

from which

$$E = \frac{(K+W)(t-t')}{w}.$$

- 349. Method of Obtaining Sample of the Fuel.—The calorimetric determination is made only on a very small portion of the fuel, and care should be exercised to have the selected sample fairly represent the fuel to be tested. To select a sample of coal for calorimetric examination several lots of ten pounds each should be chosen from different portions of the coal to be tested. These should be put in one pile. thoroughly mixed, and from the mixture several lots of one pound each taken. These latter quantities are to be pulverized, thoroughly mixed into one pile, and from this the required sample selected. It is recommended that the sample be subjected to a considerable pressure by placing it in a cylinder and compressing it by means of a piston moved by hydraulic pressure or by a screw: this is of especial importance if the fuel is to be burned in oxygen gas, since small particles are likely to form an explosive mixture; and further, soot and tarry masses, which under the most favorable circumstances might be burned, will be found in the residue.
- 350. Heat-equivalent of the Calorimeter.—The effect of the calorimeter is most conveniently expressed as equivalent to a given weight of water; this is obtained, as for calorimeters used in determining the quality of steam (see Article 317, page 371), either by finding the sum of the products of the weights and specific heats of the various constituents of the calorimeter, or by comparing the results obtained with those which should have been found by the combustion of some fuel whose calorific power is known—as for instance pure carbon in oxygen gas—or again by its cooling effect on steam of known pressure and weight, or on warm water as explained on page 372.
- 351. Method of Determining Perfect Combustion.—The quality of the combustion is only to be determined by an analysis of the resulting gases and of the products of combustion. In case of perfect combustion all carbon is reduced to

CO,, all available hydrogen to water, sulphur to sulphuric acid; and further, the sum of the weights of all the products of combustion should, after deducting the air and oxygen obtained from the atmosphere, equal the original weight of the coal.

The method adopted by Favre and Silbermann \* of ascer taining the weight of the substances consumed by calculation from the weight of the products of combustion was as follows: Carbonic acid was absorbed by caustic potash, carbonic oxide was first oxidized to carbonic acid by heated oxide of copper and then absorbed by caustic potash; water vapor was absorbed by sulphuric acid. This system showed that it was necessary to analyze the products of combustion in order to detect imperfect action. Thus in the case of substances containing carbon, CO was always present to a variable extent with CO,, and corrections were necessary in order to determine the total heat due to the complete combination with oxygen. The conclusion arrived at by these experimenters was that in general there was an equality in the heat disengaged or absorbed in the respective acts of chemical combination or of decomposition of the same elements; that is, the heat evolved during the combination of two simple elements is equal to the heat absorbed at the time of the chemical separation, and the quantity of heat evolved is the measure of the sum of the chemical and mechanical work accomplished in the reaction.

352. Favre and Silbermann's Fuel-calorimeter.—This apparatus, as shown in Fig. 161, consisted of a combustion-chamber, A, formed of thin copper, gilt internally, and fitted with a cover through which solid combustibles could be introduced into the cage C. The cover was traversed by a tube, E, connected by means of a suitable pipe to a reservoir of the gas to be used in combustion, and by a second tube, D, the lower end of which was closed with alum and glass, transparent but adiathermic substances which permitted a view of the process of combustion without any loss of heat.

For convenience of observation a small inclined mirror was placed above the peep tube D.

<sup>\*</sup>See Conversion of Heat into Work: Anderson.

The products of combustion were carried off by a pipe, F, the lower portion of which constituted a thin copper coil, and the upper part was connected to the apparatus in which the non-condensible products were collected and examined. The whole of this portion of the calorimeter was plunged into a thin copper vessel, G, silvered internally and filled with water, which




FIG. 161.—FAVRE AND SILBERMANN'S FUEL-CALORIMETER.

was kept thoroughly mixed by means of agitators, H. The second vessel stood on wooden blocks inside a third one, I, the sides and bottoms of which were covered with swan-skins with the down on, and the whole was immersed in a fourth vessel, J, filled with water kept at the average temperature of the laboratory. Thermometers, K, K, of great delicacy were

used to measure the increase of temperature in the water surrounding the combustion-chamber. The quantity of heat developed by the combustion of a known weight of fuel was determined by the increase of temperature of the water contained in the vessel G. For finding the calorific value of gases only, the cage C was removed and a compound jet, NO, substituted for the single gas-pipe, ignition being produced by an electric spark or by some spongy platinum fixed at the end of the jet.

353. Thompson's Calorimeter.—Thompson's Calorimeter\* is often employed for determination of the heating values of fuels. It consists of a glass jar graduated to contain 1034 grams of water; in this are inserted (1) a thermometer to indicate elevation of temperature, and (2) a cylindrical combustionchamber with a capacity of about 200 grams of water. chamber is capped at the top, and a small tube furnished with a valve is screwed into it, to hold the fuel. The combustible to be examined, 2 grams, is mixed as intimately as possible with 22 grams of a very dry mixture of 3 parts of potassic chlorate and I part of potassic nitrate, and introduced into the combustion-tube; a nitrate of-lead fuse is added and lighted. This tube is introduced into the combustion-chamber, the cap screwed on, and the whole placed without delay in the water of the calorimeter. The combustion takes place directly in the water, and the gases disengaged rise to the surface. The water is proportioned to the fuel as 966 is to 1, so that the rise in temperature in degrees F. is proportional to the evaporative power. The oxygen required for the combustion is supplied by the chemicals added. The water equivalent of the calorimeter as above described is about ten per cent. When combustion has ceased, the rise in temperature of the water is observed: to this one tenth is added for the water value of the calorimeter.

The corrected number gives the number of grams of water which a gram of the combustible can evaporate.

<sup>\*</sup>See Chemical Technology, Vol. I.

354. The Berthier Calorimeter.\*—This calorimeter is based on the reduction of oxide of lead by the carbon and hydrogen of the coal, the amount of lead reduced affording a measure of the oxygen expended, whence the heating power may be calculated by Welter's law, Article 345. One part of pure carbon being capable of reducing 34½ times its weight in lead.

The operation is performed by mixing intimately the weighed sample (10 grams) with a large excess of pure litharge (400 grams). The mixture, placed in a crucible sufficiently capacious to contain three times its bulk, and rendered impervious to the gases of the furnace by a coating of fire-clay or by a glaze, is covered with an equal quantity of pure litharge (protoxide of lead). The crucible, being closed with a lid and placed on a support in the furnace, is slowly heated to redness, and when the gases which cause the mixture to swell considerably have escaped, it is covered with fuel and strongly heated for about ten minutes, in order to collect the globules of lead in a single button. The oxygen from the litharge combines with and burns the combustible ingredients of the fuel, leaving for every equivalent of oxygen consumed an equivalent of reduced metallic lead.

The heating power is calculated as follows: I part of pure carbon requires 2.666 parts of oxygen by weight, which taken from litharge leaves 34.5 parts of metallic lead. The same weight of carbon is sufficient to heat 80 parts of water from 32° to  $^{212}$ °. Hence every unit of lead reduced by any kind of fuel corresponds by Welter's law with  $\frac{80}{34.5} = 2.23$  parts of water raised

from the freezing to the boiling point.

355. The Berthelot Calorimeter.—This calorimeter, as modified by Hempel, consists of a very strong vessel with a capacity of about 250 c.c., into which the fuel is placed after being compressed into a solid form; the combustion is per-

<sup>\*</sup>Chemical Technology, Vol. I., page 337.

formed in an atmosphere of oxygen gas under a pressure of 10 to 12 atmospheres.\*

The fuel is ignited by an electric spark, and the heat generated is known by measuring the rise in temperature in the surrounding water, as in the Favre and Silbermann calorimeter.

The oxygen gas is generated in a tube about one inch in diameter connected to the calorimeter by an intervening tube about 1 inch in diameter. To this latter tube is attached a pressure-gauge to indicate the pressure, and a safety-gauge to prevent damage from explosion or excessive pressure. A stop-cock is also inserted close to the calorimeter. For generating the oxygen the tube is filled with 40 grams of a mixture of equal parts of manganese dioxide and potassium chlorate. It is then heated by the full flame of a Bunsen burner applied first at the end nearest the calorimeter and gradually moved to the farther end.

To use the instrument, the fuel, connected to platinum wires for electrical ignition, is introduced and suspended in the calorimeter, the top of which is firmly screwed on and the valve closed. Oxygen gas is then generated until the pressure reaches 90 pounds, and exhausted into the air to remove other gases from the calorimeter. The escape-valve from the calorimeter is closed and oxygen gas generated until the pressure-gauge shows 150 to 175 pounds pressure per square inch; then the connecting stop-valve is closed and the electric current applied. After the heat of combustion has been absorbed the determination is made as with the Favre and Silbermann calorimeter.

356. Continuous Coal-calorimeter.—A continuous coal-calorimeter, designed chiefly by Wm. Kent of New York, was employed in the recent investigations of Hoyt and Mc-Gregor at Sibley College in determining the heating values of various American coals. This calorimeter differs from that used by Favre and Silbermann principally in size and form. The fuel is introduced, by means of a piston working in a tube, to a chamber surrounded with fire-clay, and the combustion

<sup>\*</sup> See Hempel's Gas Analysis, translated by Dennis.

arranged to take place either in an atmosphere of oxygen gas, or in air at any pressure. The coal is ignited by an electric spark or by a jet of illuminating-gas; the products of combustion are carried through a coiled pipe immersed in a vessel of water. Cold water is continuously supplied at one point and the heated water removed at another, the product of the weight of water by the gain in temperature, corrected by the calorimeter equivalent, being the calorific power of the coal. The products of combustion and the ash in each case being analyzed, to determine the character of the combustion.

In using the instrument, the same precautions are to be observed as in using the continuous calorimeters for steam, Article 324, page 382. No observations are to be taken until the instrument is in full operation and the working conditions are uniform.

357. Value of Coal determined by a Boiler-trial.—The calorific value of a coal is sometimes determined by the amount of water evaporated into dry steam under the conditions of use in a steam-boiler. This method is fully explained in the latter part of the present work in the chapter on the methods of testing steam-boilers. The calorific values obtained in actual boiler-trials are much less than those obtained in the calorimeters, because of loss of heat by radiation into the air and by discharge of hot gases into the chimney. The results obtained by such a trial by Prof. W. R. Johnson at the Navy Yard, Washington, in 1843, with a small cylindrical boiler, were as follows:

Area of	Coal pe	r Hour.	Water ev per I	Water evaporated	
grate, Sq. Ft.	Total.	Per Sq. Ft. of Grate.	Total.	Per Sq. Ft. of Grate,	from 212° F. per lb. of Cual.
14.30	94.91	6.64	12.37	0.87	9.63
14.14	99.16	7.01	13.73	0.97	9.68
14.15	105.02	7.42	12.16	0.86	8.48
14.20	99.71	7.02	12.75	0.90	9.26
	Fire-grate, Sq. Ft.  14.30  14.14	Area of Fire, grate, Sq. Ft. Total.  14.30 94.94  14.14 99.16  14.15 105.02	Fire, Sq. Ft. Total. Per Sq. Ft. of Grate.  14.30 94.94 6.64  14.14 99.16 7.01  14.15 105.02 7.42	Area of Fire-grate, Sq. Ft.  Total.  Per Sq. Ft. of Grate.  14.30 94.94 6.64 12.37  14.14 99.16 7.01 13.73  14.15 105.02 7.42 12.16	Area of Firegrate, Sq. Ft.         Total.         Per Sq. Ft. of Grate.         Total.         Per Sq. Ft. of Grate.           14.30         94.94         6.64         12.37         0.87           14.14         99.16         7.01         13.73         0.97           14.15         105.02         7.42         12.16         0.86

358. Object of Analysis of the Products of Combustion.—The products resulting from the combustion of ordinary fuel contain principally a mixture of air, CO<sub>1</sub>, and some combustible gases, as CO and H. To determine whether or not the combustion is perfect, it is necessary to know the percentage that the combustible gases escaping bear to the total products of combustion. It is also important to know whether the air supplied is sufficient for the purposes of combustion, and also whether it is in excess of the amount actually required. As shown in Article 346, page 412, the presence of an excess of air over that required has the effect of lowering the tempera-

From a careful examination of the products of combustion we should be able to ascertain its character and make the necessary corrections for such losses as may be due to imperfect combustion.

ture of the furnace; steam would have the same effect even in a greater degree, as can readily be shown by calculation.

The methods to be employed must be such as any engineer can fully comprehend, and the apparatus portable and convenient. The degree of accuracy sought need not be such as would be required in a chemical laboratory where every convenience for accurate work is to be found. Indeed, considering the approximations to be made in its application, it is very doubtful if determinations nearer than one per cent in volume are required, or even of any value. determinations are obtained readily with simple instruments, and serve to show the approximate condition of the gaseous products of combustion. The student is referred to "Handbook of Technical Gas Analysis," by Clemens Winkler (London, John Van Voorst), and to "Methods of Gas Analysis," by Dr. W. Hempel, translated by L. M. Dennis (Macmillan & Co.); also to a paper on tests of a hot-blast apparatus by J. C. Hoadley, Vol. VI. Transactions of the American Society of Mechanical Engineers.

In a thorough examination of the value of fuel, the ashes should also be analyzed, since if they contain any combustible, or partly burned combustible, the heating value must be determined, and proper allowance made for the same.

350. General Methods of Flue-gas Analysis.—The gases to be sought for are CO,, CO, O, and H. Unless the temperature is very high, CO is found only in very small quantities, and rarely exceeds one per cent. Prof. L. M. Dennis, of Cornell University, makes the statement that Dr. W. Hempel, of Dresden, whose principal work has been the analysis of gases, states that rarely ever is more than a trace of carbonic oxide (CO) to be found in the products resulting from ordinary combustion. Considering the difficulty of absorbing CO, and the consequent errors that are likely to arise, it may be in general better to neglect it. The hydrogen, H; present is also a very small quantity, unless the temperature is abnormally low, and can be neglected without sensible error. The analysis may be of two kinds, gravimetrical and volumetric. The former is seldom used, but will be found described in an article by J. C. Hoadley, Transactions of the American Society of Mechanical Engineers, Vol. VI., page 786. In this case the various gases are passed through solid absorbents, and the several constituents successively absorbed and weighed. The method of analysis usually adopted is a volumetric one, and consists of the following steps, which will be described in detail later on.

A. The sample is first collected and then introduced into a measuring-tube; 100 c.c. of the gas is retained, the remainder wasted.

B. The constituents of the gas are then absorbed by successive operations, in the following order: carbonic acid (CO<sub>3</sub>), free oxygen (O), carbonic oxide (CO), and hydrogen (H). The absorption is accomplished by causing the gas to flow over the reagent in the liquid or solid form, which is introduced into the gas or remains permanently in a separate treating-tube. It is then made to flow back to the measuring-tube and the loss of volume measured. The loss is due to absorption, the various absorbents used being as follows:

For carbonic acid, CO,, either potassium hydroxide (caustic potash KOH), or barium hydroxide.

For oxygen, O, either (1) a strong alkaline solution of pyrogallic acid, (2) chromous chloride, (3) phosphorus, (4) metallic copper.

For carbon monoxide, CO, either an ammoniacal or a hydrochloric-acid solution of cuprous chloride.

For hydrogen, H, an explosion or rapid combustion in the presence of oxygen, or absorption by metallic potassium, sodium, or palladium. The reagent usually employed as an absorbent is the one first mentioned in each case.

- 360. Preparation of the Reagents.—Absorbents of Oxygen.—1. Potassium pyrogallate. This is prepared by mixing together, either directly in the absorption pipette or in the apparatus, 5 grams of pyrogallic acid dissolved in 15 c.c. of water, and 120 grams of caustic potash (KOH) dissolved in 80 c.c. of water. Caustic potash purified with alcohol should not be used for analysis. The absorption of the gas should not be carried on at a temperature under 15° C. (55° Fahr.); it may be completed with certainty in three minutes by shaking the gas in contact with the solution.
- 2. Chromous chloride will absorb oxygen alone in a mixture of oxygen and hydrogen sulphide; it is prepared with difficulty, and not much used.
- 3. Phosphorus is one of the most convenient absorbents: it is to be kept in the solid form under water and in the dark; the gas is to be passed over the reagent, displacing the water, and kept in contact with it for about three minutes. The end of the absorption is shown by a disappearance of a light glow, which characterizes the process of absorption. The phosphorus will remain in serviceable condition for a long time.
- 4. Copper, at a red heat or in the form of little rolls of wire-gauze immersed in a solution of ammonia and ammonium carbonate, is a very active absorbent for oxygen.

Absorbents of Carbonic Acid (CO<sub>3</sub>).—I. Caustic potash. This solution may be used in varying strengths, depending on the method of gas analysis. With the Elliot apparatus, a solu-

tion of 3 to 5 per cent of KOH in distilled water is sufficiently strong, the gas being kept in contact with it for several minutes. When a separate treating-tube is used for each reagent, a solution of one part of commercial caustic potash to two parts of water is employed. The absorption is accomplished very quickly in the latter case, and often by passing the gas but once through the treating-tube. The process is more quickly and thoroughly performed by introducing into the treating-tubes as many rolls of fine iron-wire gauze as it will hold.

2. Barium hydroxide in solution is the best absorbent in case the quantity of CO<sub>3</sub> is very small; in this case titration with oxalic acid will be required.

Absorbents of Carbon Monoxide (CO).—I. (a) Hydrochloric-acid solution of cuprous chloride is prepared by dissolving 10.3 grams of copper oxide in 100 to 200 c.c. of concentrated hydrochloric acid, and then allowing the solution to stand in a flask of suitable size, filled as full as possible with copper wire, until the cupric chloride is reduced to cuprous chloride, and the solution is completely colorless.

(b) Winkler directs that 86 grams of copper scale be mixed with 17 grams of copper powder, prepared by reducing copper oxide with hydrogen, and that this mixture be brought slowly and with shaking into 1086 grams of hydrochloric acid of 1.124 specific gravity. A spiral of copper wire is then placed in the solution, and the bottle closed with a soft rubber stopper. It is dark at first, then becomes colorless, but in contact with the air becomes brown. The absorbing power is 4 c.c. of CO.

The ammoniacial solution is to be used in case hydrogen is to be absorbed by palladium. This is prepared from the colorless solution (a) as follows: Pour the clear hydrochloric acid solution into a large beaker-glass containing 1½ to 2 litres of water, to precipitate the cuprous chloride. After the precipitate has settled, pour off the dilute acid as completely as of possible, then wash the cuprous chloride with 100 to 150 c.c. distilled water, and add ammonia to the solution until the liquid takes a pale-blue color. The solutions of cupric chloride decompose readily, and in general should be used when fresh, or

preserved under a layer of petroleum. The treating-tube containing the reagent is frequently supplied with spirals of small copper wire which tend to preserve and increase the absorbing capacity of this reagent.

361. Method of obtaining a Sample of the Gas.—In order to take a sample of the gas for analysis from any place, such as a furnace, flue, or chimney, an aspirating-tube is introduced into the flue: this consists of a tube open at both ends, the outside end being provided with a stop-cock and connected with the collecting apparatus by an india-rubber tube. There




FIG. 162.—HOADLEY'S FLUE-GAS SAMPLER.

is probably a great diversity in the composition of gases from various parts of the flue.

For obtaining an average sample, J. C. Hoadley employed a mixing-box B,\* provided with a large number of  $\frac{1}{4}$ -inch pipes, ending in various parts of the cross-section of the flue A. An elevation of the mixing-box is shown at B'. From the mixing-box four tubes CC lead downward from various parts to a mixing-chamber D, from which a pipe E leads to the collecting apparatus. Two of these mixing-boxes were used, one placed in the flue a short distance above the other, and an agreement of the samples obtained from each was regarded as proof of the substantial accuracy of the sample.

<sup>\*</sup> Trans. Am. Soc. M. E., Vol. VI.

It is hardly probable that a tube furnished with various branches or a long slit will give a fair sample, since the velocity of gases in the aspirating-tube is such that most of the gas will be collected at the openings nearest the collecting apparatus; the author has often employed a branch-tube with holes opening in different portions of the chimney. The material for the aspirating-tube is preferably porcelain or glass, but iron has no especial absorptive action on the gases usually to be found in the flue, and may be used with satisfaction. A long length of rubber tubing may, however, sensibly affect the results.

The gas should be collected as closely as possible to the furnace, since it is liable to be diluted to a considerable extent by infiltration of air through the brick-work-beyond the furnace.

In order to induce the gas to flow outward and into the collecting apparatus, pressure in the collecting vessel, termed an aspirator, must be reduced below that in the flue. accomplished by using for an aspirator two large bottles connected together by rubber tubing near the bottom, or better still, two galvanized iron tanks, about 6 inches diameter and 2 feet high, connected near the bottom by a rubber tube, in which is a stop-cock; one of the bottles or tanks has a closed top and a connection for rubber tubing provided with stopcock at the top; the other bottle or tank is open to the atmosphere. To use the aspirator, the vessel with the closed top is filled with water by elevating the other vessel; it is then connected to the aspirating-tube, the open vessel being held so high that it will remain nearly empty. After the connection is made, and the stop-cocks opened, the empty vessel is brought below the level of the full one, and the water passing from the one connected to the aspirating-tube lessens the pressure to such an extent that it will be filled with gas. process should be repeated several times in order to insure the thorough removal of all air from the aspiratingtubes. The liquid used for this purpose is generally water, which is an absorbent to a considerable extent of the gases

contained in the flues. To lessen its absorbent power, the water used should be shaken intimately with the gas in order to saturate it before the sample for analysis is taken. When mercury is used as the liquid this precaution is not necessary.

A small instrument, on the principle of an injector, in which a small stream of water or mercury is constantly delivered, is an efficient aspirator, and is extremely convenient for continuous analysis.

362. General Forms of Apparatus employed for Volumetric Gas Analysis.—The apparatus employed for volumetric gas analysis consists of a measuring-tube, in which the volume of gas can be drawn and accurately measured at a given pressure, and a treating tube into which the gases are introduced and then brought in contact with the various reagents already described. The apparatus employed may be divided into two classes: (1) those in which there is but one treating-tube, the different reagents being successively introduced into the same tube; (2) those in which there are as many treating-tubes as there are reagents to be employed, the reagents being used in a concentrated form, and the gases brought into contact with the required reagent by passing them into the special treating tube.

In either case the steps are, as explained in Article 358: (a) Obtain 100 c.c. by measurement; (b) to absorb the CO<sub>2</sub>, bring the gas in contact with KOH, and measure the reduction of volume so caused; this is equivalent to the percentage of CO<sub>2</sub>; (c) bring the gas in contact with pyrogallic acid and KOH, and absorb the free oxygen. Measure the reduction of volume so caused; this is equivalent to the percentage of free oxygen; (d) determine the other constituents in a similar manner.

In performing these various operations it is essential that the tubes be kept clean and that the reagents be kept entirely separate from each other. This is accomplished by washing or causing some water to pass up and down the tubes or pipettes several times after each operation.

363. Elliot's Apparatus.—This is one of the most simple outfits for gas analysis, and consists of a treating-tube AB and

a measuring-tube A'B', Fig. 163, connected by a capillary tube at the top, in which is a stop-cock, G. The tubes shown in Fig. 163 are set in a frame-work having an upper and a lower shelf, on which the bottles L and K can be placed. In using the




FIG. 163.—ELLIOT'
APPARATUS.

apparatus, it is first washed, which is done by filling the bottles with water, opening the stop-cocks F and G, and alternately raising and lowering the bottles K and L. The bottles are then filled with clean distilled water, raised to the positions shown, and the stop-cocks G and F closed. The gas is then introduced by connecting the discharge from the aspirator to the stem of the three-way-cock F, and turning it so that its hollow stem is in connection with the interior of the tube

AB; lowering the bottle L, the water will flow out from the tube AB and the gas will flow in. When the tube AB is full of gas the cock F is closed, the aspirator is disconnected, and the gas is measured. The gas must be measured at atmospheric pressure. That may be done by holding the bottle in such a position that the surface of the water in the bottle shall be of the same height as that in the tube. A distinct meniscus will be formed by the surface of the water in the tube; the reading must in each case be made to the bottom of the To measure the gas, which will be considerably in excess of that needed, the cock G is opened, the bottle K depressed, the bottle L elevated; the gas will then pass over into the measuring-tube A'B'; the bottle K is then held so that the surface of the water shall be at the same level as in the measuringtube, and the bottle L manipulated until exactly 100 c. c. are in the measuring-tube; then the cock G is closed, the  $\operatorname{cock} F$ opened, the bottle L raised, and the remaining gas wasted, causing a little water to flow out each time to clean the connecting tubes. The measuring-tube A'B' is surrounded with a jacket of water to maintain the gas at the uniform temperature of the room. After measuring the sample it is then run over into the treating-tube AB, and the reagent introduced through

the funnel above F by letting it drip very slowly into the tube AB. After there is no farther absorption in the tube AB, the cock F is closed and the gas again passed over to the measuring-tube A'B', and its loss of volume measured. This operation is repeated until all the reagents have been used; in each case, when the gas is run back from the measuring-tube, pass over a little water to wash out the connections; exercise great care that in manipulating the cocks K or G no gas be allowed to escape or air to enter.

364. Wilson's Apparatus.\*—This apparatus is illustrated in Fig. 164. It is used in essentially the same manner as the Elliot apparatus, mercury being used as the displacing liquid

in place of water. It consists of a treating-tube d, a measuring-tube a, connected at the top by a capillary tube f. The measuring-tube ends in a vessel filled with mercury, and in this case the pressure on the tubes can be regulated by lowering and raising the single bottle filled with mercury, and the gas can be manipulated as in the Elliot apparatus, using one bottle instead of two. Reagents are introduced into the funnel e, and come in contact with the gas in the treating-tube d.

The collecting-tube used with this apparatus is shown at B, and consists of a vessel filled with mercury. One side is connected to the aspirator-tube; some of the mercury is allowed to run out through a cock, and the space is fi



Fig. 164.—Apparatus for Gas Analysis.

through a cock, and the space is filled by the gas. Sufficient mercury is retained to form a seal.

365. Fisher's Modification of Orsat's Apparatus.—This

<sup>\*</sup> Thurston's Engine and Boiler Trials, p. 107.

apparatus, shown in Fig. 165, belongs to the class in which each reagent is introduced in a concentrated form into a special treating-tube. The apparatus consists of a measuring-tube surrounded by a water-jacket, into which the gas can be introduced substantially as explained for the Elliot apparatus. Each




FIG. 165.-FISHER'S GAS-ANALYSIS APPARATUS.

reagent is introduced in a concentrated form into a pair of burettes connected at the bottom by a U-shaped tube.

In making an analysis the gas is first drawn into the measuring-tube and 100 c.c. retained; the cock in the tube leading to one of the treating-tubes is then opened, the bottle raised, and the gas driven over into the treating-tube. This

operation is facilitated by connecting a soft rubber bag to the opposite side of the treating-tube, by means of which alternate pressure and suction can be applied, and the reagent protected from the atmosphere. After the absorption is complete, which will take from one to three minutes in each tube, the gas is returned to the measuring-tube by lowering the bottle and exerting pressure on the attached rubber bag. The rubber bag is not shown in Fig. 165, and is not required, provided the treating-tube is completely filled with the reagent on the side toward the measuring-tube.

The treating-tubes are filled in order from the measuring-tube with the following reagents: (1) with 50 per cent solution of KOH; (2) with a solution of pyrogallic acid and KOH, or with sticks of phosphorus (see Article 359); (3) with a hydrochloric-acid or an ammoniacal solution of cuprous chloride in contact with copper wire (see Article 359).

In the first treating-tube is absorbed CO<sub>2</sub>, in the second O, and in the third CO.

A modification of the Fisher apparatus has a fourth tube in which hydrogen can be exploded; the reduction in volume, due to the explosion, gives the amount of hydrogen present.


Fisher's apparatus can be used with water or mercury for obtaining the required pressure to move the gases. It is extremely portable, accurate, and convenient for use.

For engineering uses, when an apparatus must be carried from place to place for determinations, it is the most valuable form which has been devised.


366. Hempel's Apparatus for Gas Analysis.\*—This apparatus, shown in Figs. 166 to 170, is especially designed for the accurate analysis of the constituents of various gases; for laboratory use it presents many advantages over the other apparatus described. The apparatus consists of the following parts: 1. The measuring burette, shown in Fig. 166a, which is constructed and used as follows: It is furnished with an iron

<sup>\*</sup>See Hempel's Gas Analysis, by L. M. Dennis. Catalogue of Eimer & Amend, New York.

base, which is connected by a rubber tube to an open tube a (see Fig. 166) with a similar base. The stop-cock d is opened, the tube a elevated, and water or mercury, whichever may be



used, flows from a over to b. Gas is introduced as follows: The measuring-tube b is filled with liquid, the cocks d and c closed, and connection made at c to the vessel containing the gas to be measured; the cocks d and c are then opened, the tube a lowered; the liquid will then flow from the measuringtube b to a, and the gas will fill the measuring-tube. To measure the volume of gas, hold the tube a as shown in Fig. 165, so that the water-level shall be the same in both tubes, thus bringing the gas under atmospheric pressure. Read the vol-



FIGS. 169-170.—HEMPEL'S ABSORPTION BURETTES.

ume directly by the graduation corresponding to the lower edge of the meniscus.

The absorption-pipcttes are different in form from those used in the Fisher apparatus, and are connected only as required to the measuring-burette, but are used in essentially the same way. Several forms of these are employed as shown in Figs. 167 to 170. The forms shown in Fig. 168 and Fig. 170 are

ordinarily used for reagents in solution. In such a case the measuring-tube is connected at e, Fig. 168, the reagent occupying the bulbs a and b. The top of the measuring-burette e, Fig. 165, is connected to the absorption-pipette, and the gas moved alternately forward and backward as required by raising or lowering the tube a. In case reagents in the solid form are to be used, the absorption-pipette is made of the form shown in Fig. 169, in case regents which decompose very easily are used a pipette of the form shown in Fig. 167 is employed. The general methods employed are the same as those previously described.

367. Deductions and Computations from Flue-gas Analysis.—The determinations give the percentage of volume of  $CO_1$ ,  $O_2$ , and  $CO_3$  existing in the products of combustion. Of these constituents the carbon is derived entirely from the fuel and the oxygen in great part from the atmosphere. Every part of oxygen drawn in from the atmosphere brings with it nitrogen, which passes through the furnace unchanged. The nitrogen is calculated as follows: The proportion of nitrogen to oxygen existing in the atmosphere is 79 to 21 by volume; call this ratio  $S_3$ ; denote the percentage of volume of the gases existing in the sample as follows:  $CO_4$  by  $K'_1$ , oxygen by  $O'_2$ , CO by  $U'_2$ , nitrogen by  $O'_2$ . Then we shall have

$$K' + O' + U' + N' = 100$$
 per cent, . . . (1)

from which

$$N' = 100 - (K' + O' + U')$$
. . . . (2)

If the oxygen were all derived from the atmosphere, both the amount of nitrogen N' and of carbonic oxide U' could be computed, since in such a case the volume occupied by the free oxygen before combining would equal

$$2K' + O' + U'$$
.

Hence the nitrogen

$$N'' = S(2K' + O' + U')$$
. . . . . (3)

Substituting this latter value in equation (1),

$$K' + O' + U' + S(2K' + O' + U') = 100$$

from which

$$U' = \{100 - [K'(1+2S) + O'(1+S)]\} \div (1+S).$$
 (4)

Since there is to be found from 2 to 5 per cent of oxygen in the fuel, equation (4) will generally give negative values for the CO, and should not be used.

In practice, if the CO cannot be determined it can be considered zero without sensible error, since it seldom exceeds one half of one per cent.

The amount of oxygen found in the coal can be computed as follows:

The value of the nitrogen in the sample is given in equation (2).

The oxygen O'' drawn from the air with the nitrogen is

Hence that obtained from the fuel must be

$$2K' + O' - O''$$
.

In equation (2) the nitrogen is calculated on the assumption that the flue-gas contains only oxygen and carbon; in case hydrogen, H', is present, then the value of the nitrogen would be

$$N' = 100 - (K' + O' + U' + H')$$
. (6)

The principal object of the flue-gas analysis may be considered as accomplished when the percentage of uncombined

oxygen and of CO<sub>s</sub> is determined, since in every case the amount of the other gases present will be very small. From these we can find the ratio of the total oxygen supplied to that used. This ratio, which is called the *dilution coefficient X*, shows the volume of air supplied to that required to furnish the oxygen for the combustion.

It may be computed by comparing the total volume of nitrogen with that required to unite with the combined oxygen, from which

$$X = \frac{N'}{N' - SO'} \cdot \dots \cdot (7)$$

The analysis and the computations considered relate to volumes of the various gases. They may be reduced to proportional weights by multiplying the volume of each gas by its atomic weight and dividing by the total weights. Knowing the proportional weights for each gas and the total carbon consumed, the total air passing through the furnace can be computed. Thus for the perfect combustion of a pound of carbon will be required 2.67 pounds of oxygen, for which will be required 11.7 pounds of air. If the ratio of air used to that required be X, then the weight of air per pound of fuel equal 11.7X. One pound of air at 32° Fahr. occupies 12.5 cubic feet. Knowing which, the volume of air per pound of coal can be computed as equal

$$12.5 \times 11.7X = 146.2X$$
.

The maximum temperature  $T_m$ , that can possibly be attained in the furnace, is to be calculated as in Article 346, page 413.

Having the maximum temperature of the furnace and the temperature of the escaping gases, the *efficiency*, E, of the furnace may be calculated by an application of Carnot's law as

$$E=\frac{T_{m'}-T'}{T_{m'}}, \quad . \quad . \quad . \quad . \quad (9)$$

in which  $T_{m'}$  is the absolute temperature of the furnace and T' the absolute temperature of the escaping gases. The absolute temperature in degrees Fahr. is found by adding 460 to the thermometer-reading. That is,

$$T_{m}' = T_{m} + 460.$$

Rankine, in his work on the steam-engine, pages 287 and 288, gives formulæ for computing velocity of flow in flues, the head required to produce a given reading of the draught-gauge, and the required height of chimney.

These formulæ are developed from the experimental work of Peclét, and while they do not agree well with modern practice, still give interesting results for comparison. The practical application is shown in the following example of an analysis made at Cornell University, the coal burned being that obtained after deducting ashes and clinkers.

## 368. Form for Data and Computations in Flue-gas Analysis.—Test made Nov. 3, 1890.

440

	Sym	D ment	Ğ	Determination.	
	j g		н		18.
Reading draught gauge, water-inches			0.4	0.4	0.
Temperature flue,	7		300	300°	320
Temperature boiler-room	~		-94	.92	.94
Temperature outside air	~		, 2	,24	43°
Weight of coal burned per second	æ		.5 lbs.	.s lbs.	.5 lbs.
CO2, per cent of volume	K,		6.9	8.9	9.6
O + CO2, per cent of volume			16.5	16.9	16.9
O, free oxygen, per cent of volume	Ó		9.6	10.1	9.3
CO, per cent of volume	'n		90.0	0.07	0.0
Nitrogen, per cent of volume	, ×	100 - (K' + O' + U')	86.4	82.4	82.2
Dilution coefficient	×	$\frac{N'}{N'-SO}$	1.72	1.89	1.75
Proportional weight	M	14N' + 16O' + 28U' + 44K'	1827.	1756.9	1773.1
Per cent free O. by Weight		160' M	9 per cent	per cent per cent per cent	8.4 per cent
Per cent total O. by weight		$\frac{16}{M}(aK'+U'+O')$	5.7	22.7	26.2
Per cent total carbon by weight		$\frac{12}{M}(U'+K')$	 8.5	80 0.	8.4

21.5	8263.	77.2	8.6	2850.	<b>2</b> 69.	18.6	8.69	39.	73.	100.
20.3   22.3   21.5	1090. 1222. 8263.	86.0	9.5	2650.	277.	8.61	1.64	38.3	75.	25.
20.3	1090.	81.5	4.8	2910.	255.	17.8	64.	38.6	78.	100.
11.7X	0.238(T-t)W	T <sub>B</sub>	B 14500	5000 + X	12.5 W	$\frac{wV_{\bullet}(\downarrow\!$	$\frac{u^3}{2g}(13 + \frac{0.012h}{m})$	$\frac{(461+T)r}{\left(\frac{1}{V}\right)(.0807+\frac{1}{V})}$	$\frac{h}{100000000000000000000000000000000000$	H'-H
ž	B	E	•	7,	7.	*	*	i <del>e</del>	H	14,
Weight of air per pound carbon	Heat units lost per pound carbon in flue	Efficiency per cent	Per cent heat lost in flue	' Maximum temperature possible in furnace, degrees Fahr $\mid T_{\mathbf{m}} \mid$	Volume air per pound coal at 32° Fahr., cu. ft	Velocity in feet per second*	*Head to produce draught, from calculated velocity	*Head to produce draught, from draught gauge-reading	*Required height chimney $H$	Actual heightThrottling effect damper

Nore. -In formulæ S = ratio of N to O, which in the example was taken as equal to 3.77. Symbol for temperature, T with prime, denotes absolute temperature. \* See Rankine's Steam-engine, pages 287 and 288.

#### CHAPTER XV.

#### METHODS OF TESTING STEAM-BOILERS.

369. Object of Testing Steam-boilers.—The object of the test must be clearly perceived in the outset; it may be to determine the efficiency of a given boiler under given conditions; the comparative value of various fuels, or of different boilers working under the same conditions; or the quantity of coal consumed and water used in providing steam for a given engine. The results of the test are usually expressed in pounds of water evaporated for one pound of the fuel used.

The conditions of temperature and pressure between which boilers work vary within wide limits, the amount of heat absorbed per pound of steam produced is not constant, and a standard of reference is necessary. Thus to convert a pound of steam from feed-water at a temperature of 70 degrees Fahr. into steam at 80 pounds absolute pressure per square inch will require, per pound of steam, (1174.3 - 70 + 32) = 1036.3 B. T. U.; but to convert a pound of water at a temperature of 212° into steam at atmospheric pressure will require only 967 B. T. U. To compare the work done with a standard condition it is customary to express the results of the test as equivalent to the evaporation per pound of fuel from water at 212° Fahr. to steam at atmospheric pressure, or, in other words, "from and at 212°."

The fuel also varies greatly in its evaporative power, as shown in the preceding chapter, and, moreover, a certain proportion is likely to drop through the grates unconsumed, so that

it is customary to reduce the results still further, and to find the evaporation per pound of the combustible part.

370. Definitions.—The following terms are frequently used:

Actual evaporation. This is the evaporation per pound of fuel or of combustible under the actual conditions of the test, uncorrected for temperature of feed-water and for moisture.

Equivalent evaporation from and at  $212^{\circ}$  is the amount of water that would have been evaporated had the temperature of feed-water been  $212^{\circ}$ , the steam dry and at atmospheric pressure. If x represent the quality of steam, e the factor of evaporation, the equivalent evaporation is equal to the actual multiplied by xe.

Factor of evaporation is the ratio that the heat,  $\lambda$ , existing in one pound of steam at the given pressure and reckoned from the temperature, t, of feed-water, bears to the total heat of evaporation at 212°, r. That is,

$$e=\frac{\lambda-t+32}{r}.$$

A table of the factors of evaporation is given in the Appendix.

The ash is the actual incombustible part of the coal; it is the residue which falls through the grates, less any combustible particles.

The combustible is the fuel less the residue which falls through the grates; it is the weight of that portion actually burned. In the absence of any determinations whatever, the combustible is frequently assumed as § of that of the coal.

The quality of the steam is the percentage by weight of dry saturated steam in a mixture of steam and water. It is to be found by a throttling or separating calorimeter attached very near the boiler (see Articles 334 to 338).

371. The Efficiency of a Boiler.—The efficiency is the ratio of the heat supplied to that utilized. The heat supplied is measured by the coal consumed, less the heat discharged into the chimney; it is assumed that it is all converted into

CO and CO,, and that each pound of carbon converted into CO, gives off 14,500 B. T. U., and each pound converted into CO generates 4400 B. T. U. The amount of coal consumed is obtained by carefully measuring and deducting all ash and unconsumed portions. The relative proportions of CO, and CO are obtained by a flue-gas analysis (see Articles 363 to 367).

The heat utilized is obtained by weighing the water evaporated into dry steam and multiplying by the heat required, as given in a steam-table, to convert one pound from the temperature of feed-water into steam of the given pressure, reducing this result if necessary for any moisture in the steam. The moisture is to be found as explained in Article 334 or 337.

372. Efficiency of the Furnace.—This is not usually considered separately from the boiler. It can be obtained (see Article 367) by finding the temperature of the furnace with a pyrometer as explained in Article 304, page 358, or by computation as explained in Article 346, page 412, and by measurement of the temperature of the entering and discharged gases. Thus let  $T_f$  be the temperature of the furnace,  $t_d$  that of the discharged gas,  $t_r$  that of the boiler-room. Then the efficiency is, by application of Carnot's cycle (see Article 368),

$$E=\frac{T_f-(t_d-t_r)}{T_f+460}.$$

The heat discharged from the furnace is in part utilized in converting water into steam, in part dissipated in radiation, and in part discharged into the flue. These losses should, if possible, be separately determined.

It is recommended that the temperature of the furnace and of the flue be measured in each boiler test.

373. Horse-power of a Boiler.—The horse-power of a boiler is a conventional definition of capacity, since the boiler of itself does no work. As the weight of steam required for different engines varies within wide limits, an arbitrary rating was adopted by the judges of the Centennial Exhibition in

1876 as a standard nominal horse-power for boilers. This standard, which is now generally used, fixed one horse-power as equivalent to 30 pounds of water evaporated into dry steam per hour from feed-water at  $100^{\circ}$  Fahr., and under a pressure of seventy pounds per square inch above the atmosphere. This is equal to an evaporation of 34.488 pounds from and at 212° F. The "unit of evaporation" being 966.7 B. T. U., the commercial horse-power is  $34.488 \times 966.7 = 33,600$  B. T. U.

374. Graphical Log.—The results of a boiler-test can be represented graphically by considering intervals of time as proportional to the abscissæ, and ordinates as proportional to the various pressures and temperatures measured. The graph-




FIG. 171.

ical representation is valuable as showing variations in any of these quantities. The boiler-test is usually made in connection with that of an engine, and the complete log is represented on one sheet, as shown in Fig. 171 (from Thurston's Engine and Boiler Trials).

375. Method of Making a Boiler-test.—A standard method of making a boiler-test was adopted by the American Society of Mechanical Engineers, and is published in Vol. VI.

of the Transactions. This method is complete and should be followed in every case. The method is as follows.

#### PRELIMINARIES OF A TEST.

- I. In preparing for and conducting trials of steam-boilers, the specific object of the proposed trial should be clearly defined and steadily kept in view.
- II. Measure and record the dimensions, position, etc., of grate and heating surfaces, flues and chimneys, proportion of air-space in the grate-surface, kind of draught, natural or forced.
- III. Put the Boiler in good condition.—Have heating surface clean inside and out, grate-bars and sides of furnace free from clinkers, dust and ashes removed from back connections, leaks in masonry stopped, and all obstructions to draught removed. See that the damper will open to full extent, and that it may be closed when desired. Test for leaks in masonry by firing a little smoky fuel and immediately closing damper. The smoke will then escape through the leaks.
- IV. Have an understanding with the parties in whose interest the test is to be made as to the character of the coal to be used. The coal must be dry, or, if wet, a sample must be dried carefully and a determination of the amount of moisture in the coal made, and the calculation of the results of the test corrected accordingly.

Wherever possible, the test should be made with standard coal of a known quality. For that portion of the country east of the Alleghany Mountains good anthracite egg coal or Cumberland semi-bituminous coal may be taken as the standard for making tests. West of the Alleghany Mountains and east of the Missouri River, Pittsburg lump coal may be used.\*

V. In all important tests a sample of coal should be selected for chemical analysis.

<sup>\*</sup>These coals are selected because they are almost the only coals which contain the essentials of excellence of quality, adaptability to various kinds of furnaces, grates, boilers, and methods of firing, and wide distribution and general accessibility in the markets.

- VI. Establish the correctness of all apparatus used in the test for weighing and measuring. These are:
  - 1. Scales for weighing coal, ashes, and water.
- 2. Tanks, or water-meters for measuring water. Water-meters, as a rule, should only be used as a check on other measurements. For accurate work, the water should be weighed or measured in a tank.
- 3. Thermometers and pyrometers for taking temperatures of air, steam, feed-water, waste gases, etc.
  - 4. Pressure-gauges, draught-gauges, etc,

VII. Before beginning a test, the boiler and chimney should be thoroughly heated to their usual working temperature. If the boiler is new, it should be in continuous use at least a week before testing, so as to dry the mortar thoroughly and heat the walls.

VIII. Before beginning a test, the boiler and connections should be free from leaks, and all water-connections, including blow and extra-feed pipes, should be disconnected or stopped with blank flanges, except the particular pipe through which water is to be fed to the boiler during the trial. In locations where the reliability of the power is so important that an extra feed-pipe must be kept in position, and in general when for any other reason water-pipes other than the feed-pipes cannot be disconnected, such pipes may be drilled so as to leave openings in their lower sides, which should be kept open throughout the test as a means of detecting leaks, or accidental or unauthorized opening of valves. During the test the blow-off pipe should remain exposed.

If an injector is used, it must receive steam directly from the boiler being tested, and not from a steam-pipe, or from any other boiler.

See that the steam-pipe is so arranged that water of condensation cannot run back into the boiler. If the steam-pipe has such an inclination that the water of condensation from any portion of the steam-pipe system may run back into the boiler, it must be trapped so as to prevent this water getting into the boiler without being measured.

#### STARTING AND STOPPING A TEST.

A test should last at least ten hours of continuous running, and twenty-four hours whenever practicable. The conditions of the boiler and furnace in all respects should be, as nearly as possible, the same at the end as at the beginning of the test. The steam-pressure should be the same, the water-level the same, the fire upon the grates should be the same in quantity and condition, and the walls, flues, etc., should be of the same temperature. To secure as near an approximation to exact uniformity as possible in conditions of the fire and in temperatures of the walls and flues, the following method of starting and stopping a test should be adopted:

X. Standard Method.—Steam being raised to the working pressure, remove rapidly all the fire from the grate, close the damper, clean the ash-pit, and as quickly as possible start a new fire with weighed wood and coal, noting the time of starting the test and the height of the water-level while the water is in a quiescent state, just before lighting the fire.

At the end of the test, remove the whole fire, clean the grates and ash-pit, and note the water-level when the water is in a quiescent state; record the time of hauling the fire as the end of the test. The water-level should be as nearly as possible the same as at the beginning of the test. If it is not the same, a correction should be made by computation, and not by operating pump after test is completed. It will generally be necessary to regulate the discharge of steam from the boiler tested by means of the stop-valve for a time while fires are being hauled at the beginning and at the end of the test, in order to keep the steam-pressure in the boiler at those times up to the average during the test.

XI. Alternate Method.—Instead of the Standard Method above described, the following may be employed where local conditions render it necessary:

At the regular time for slicing and cleaning fires have them burned rather low, as is usual before cleaning, and then thoroughly cleaned; note the amount of coal left on the grate as nearly as it can be estimated; note the pressure of steam and the height of the water-level—which should be at the medium height to be carried throughout the test—at the same time; and note this time as the time of starting the test. Fresh coal, which has been weighed, should now be fired. The ash-pits should be thoroughly cleaned at once after starting. Before the end of the test the fires should be burned low, just as before the start, and the fires cleaned in such a manner as to leave the same amount of fire, and in the same condition, on the grates as at the start. The water-level and steam-pressure should be brought to the same point as at the start, and the time of the ending of the test should be noted just before fresh coal is fired.

#### DURING THE TEST.

XII. Keep the Conditions Uniform.—The boiler should be run continuously, without stopping for meal-times or for rise or fall of pressure of steam due to change of demand for steam. The draught being adjusted to the rate of evaporation or combustion desired before the test is begun, it should be retained constant during the test by means of the damper.

If the boiler is not connected to the same steam-pipe with other boilers, an extra outlet for steam with valve in same should be provided, so that in case the pressure should rise to that at which the safety-valve is set, it may be reduced to the desired point by opening the extra outlet, without checking the fires.

If the boiler is connected to a main steam-pipe with other boilers, the safety-valve on the boiler being tested should be set a few pounds higher than those of the other boilers, so that in case of a rise in pressure the other boilers may blow off, and the pressure be reduced by closing their dampers, allowing the damper of the boiler being tested to remain open, and firing as usual.

All the conditions should be kept as nearly uniform as possible, such as force of draught, pressure of steam, and height of water. The time of cleaning the fires will depend upon the character of the fuel, the rapidity of combustion, and the kind of grates. When very good coal is used, and the combustion not too rapid, a ten-hour test may be run without any cleaning

of the grates, other than just before the beginning and just before the end of the test. But in case the grates have to be cleaned during the test, the intervals between one cleaning and another should be uniform.

XIII. Keeping the Records.—The coal should be weighed and delivered to the firemen in equal portions, each sufficient for about one hour's run, and a fresh portion should not be delivered until the previous one has all been fired. The time required to consume each portion should be noted, the time being recorded at the instant of firing the first of each new portion. It is desirable that at the same time the amount of water fed into the boiler should be accurately noted and recorded, including the height of the water in the boiler, and the average pressure of steam and temperature of feed during the time. By thus recording the amount of water evaporated by successive portions of coal, the record of the test may be divided into several divisions, if desired, at the end of the test, to discover the degree of uniformity of combustion, evaporation, and economy at different stages of the test.

XIV. Priming Tests.—In all tests in which accuracy of results is important, calorimeter tests should be made of the percentage of moisture in the steam, or of the degree of superheating. At least ten such tests should be made during the trial of the boiler, or so many as to reduce the probable average error to less than one per cent, and the final records of the boiler test corrected according to the average results of the calorimeter tests.

On account of the difficulty of securing accuracy in these tests the greatest care should be taken in the measurements of weights and temperatures. The thermometers should be accurate to within a tenth of a degree, and the scales on which the water is weighed to within one hundredth of a pound.

### ANALYSES OF GASES.-MEASUREMENT OF AIR-SUPPLY, ETC.

XV. In tests for purposes of scientific research, in which the determination of all the variables entering into the test is desired, certain observations should be made which are in general not necessary in tests for commercial purposes. These are the measurement of the air-supply, the determination of its corr

§ 375·1

tained moisture, the measurement and analysis of the fluegases, the determination of the amount of heat lost by radiation, of the amount of infiltration of air through the setting, the direct determination by calorimeter experiments of the absolute heating value of the fuel, and (by condensation of all the steam made by the boiler) of the total heat imparted to the water.

The analysis of the flue-gases is an especially valuable method of determining the relative value of different methods of firing, or of different kinds of furnaces. In making these analyses great care should be taken to procure average samples, since the composition is apt to vary at different points of the flue, and the analyses should be intrusted only to a thoroughly competent chemist, who is provided with complete and accurate apparatus.

As the determination of the other variables mentioned above are not likely to be undertaken except by engineers of high scientific attainments, and as apparatus for making them is likely to be improved in the course of scientific research, it is not deemed advisable to include in this code any specific directions for making them.

#### RECORD OF THE TEST.

XVI. A "log" of the test should be kept on properly prepared blanks, containing headings as follows:

	Pa	ESSURI	ts.		Твм	PERATU	ires.		Fu	BL.	FEE	
Тімв.	Barometer.	Steam-gauge.	Draught- gauge.	External Air.	Boiler-room.	Flue.	Feed-water.	Steam,	Time.	Pounds.	Time.	Pounds or c. ft.

#### REPORTING THE TRIAL.

XVII. The final results should be recorded upon a properly prepared blank, and should include as many of the following items as are adapted for the specific object for which the trial is made. The items marked with a \* may be omitted for ordinary trials, but are desirable for comparison with similar data from other sources.

Results of the trials of a.....

	Boiler at	• • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	•
	To determine			,
				1
	Date of trial			j
2.	Duration of trial	hours.		
	DIMENSIONS AND PROPORTIONS.		1	}
			1	
Leav	re space for complete description. See Ap			
_	pendix XXIII.	sq. ft.	1	1
	Grate surface widelongArea	sq. it.		
	Water-heating surface	sq. ft.	!	
	Ratio of water heating surface to grate-sur-	5q. 1t.	1	
U.	face			
	AVERAGE PRESSURES.			
7.	Steam-pressure in boiler, by gauge	lbs.		
#ģ.	Absolute steam pressure	lbs.	1	ĺ
	Atmospheric pressure, per barometer	in.		
	Force of draught in inches of water	in.		
	AVERAGE TEMPERATURES.			
	Of external air	deg.		
	Of fire-room	deg.		
	Of steam	deg.		
	Of escaping gases	deg.	1	l
15.	Of feed-water	deg.		l
	FUEL.			i
76	Total amount of coal consumed †	lbs.		i
	Moisture in coal			l
	Dry coal consumed	lbs.		1
	Total refuse, drvpounds =	per cent.		ł
	Total combustible (dry weight of coal, Item			l
	18, less refuse, Item 19)	lbs.		Ì
<b>#</b> 21.	Dry coal consumed per hour	lbs.		İ
<b>*22.</b>	Combustible consumed per hour	lbs.	l	l

<sup>\*</sup> See reference in paragraph preceding table.

<sup>†</sup> Including equivalent of wood used in lighting fire. I pound of wood equals 0.4 pound coal. Not including unburnt coal withdrawn from fire at end of test.

	RESULTS OF CALORIMETRIC TESTS.			
_	Quality of steam, dry steam being taken as unity	per cent.		
	Number of degrees superheated	deg.		
	WATER.			
	Total weight of water pumped into boiler and apparently evaporated *	lbs.		
•	Water actually evaporated, corrected for quality of steam †	lbs.		
	Equivalent water evaporated into dry steam from and at 212° F.	lbs.		
•	Equivalent total heat derived from fuel in British thermal units †	B. T. U.		
30.	Equivalent water evaporated into dry steam from and at 212° F. per hour	lbs.		
	ECONOMIC EVAPORATION.			ŀ
31.	Water actually evaporated per pound of dry coal, from actual pressure and tempera-			
32.	ture†	lbs.		
	dry coal from and at 212° F. f Equivalent water evaporated per pound of	lbs.		
	combustible from and at 212° F.†		1	<u> </u>

<sup>\*</sup> Corrected for inequality of water-level and of steam-pressure at beginning and end of test.

Item 27 = Item 26  $\times$  Item 23.

Item 28 = Item 27 × Factor of evaporation.

Factor of evaporation =  $\frac{H-h}{965.7}$ , H and h being respectively the total heatunits in steam of the average observed pressure and in water of the average observed temperature of feed, as obtained from tables of the properties of steam and water.

```
Item 29 = Item 27 \times (H-h).
```

Item 31 = Item 27 + Item 18.

Item 32 = Item 28 ÷ Item 18 or = Item 31 × Factor of evaporation.

Item 33 = Item 28 + Item 20 or = Item 32 + (per cent 100 - Item 19).

Items 36 to 38. First term = Item 20  $\times \frac{0}{5}$ 

Items 40 to 42. First term = Item 39  $\times$  0.8698.

Item 43 = Item 29 × 0.00003 or =  $\frac{\text{Item } 30}{34\frac{1}{2}}$ . Item 45 =  $\frac{\text{Difference of Items } 43 \text{ and } 44}{\text{Item } 44}$ .

<sup>†</sup> The following shows how some of the items in the above table are derived from others:

COMMERCIAL EVAPORATION.  34. Equivalent water evaporated per pound of dry coal with one sixth refuse, at 70 pounds	
34. Equivalent water evaporated per pound of dry coal with one sixth refuse, at 70 pounds	
dry coal with one sixth refuse, at 70 pounds	
gauge-pressure, from temperature of 100° F. = Item 33 multiplied by 0.7249 lbs.	
RATE OF COMBUSTION.	
35. Dry coal actually burned per square foot of grate-surface per hour	
*36. Consumption of surface lbs.	
*37. Coal assumed with heating surface lbs.  One sixth refuse. Per sq. ft. of least	
area for draught lbs.	
RATE OF EVAPORATION.	
39. Water evaporated from and at 212° F. per square foot of heating-surface per hour lbs.  ( Water evaporated ) Per sq. ft. of grate-	
per hour from tem surface lbs.	
per ature of 100° F. Per sq. ft. of water- lbs.  perature of 100° F. Per sq. ft. of water- lbs.  per hour from tem- per hour from tem- per ature of 100° F. Per sq. ft. of least	
(sure.† ) area for draught. lbs.	
COMMERCIAL HORSE POWER.	
43. On basis of thirty pounds of water per hour evaporated from temperature of 100° F. into steam of 70 pounds gauge pressure,	
(= 34½ lbs. from and at 212°)} H. P.	
44. Horse-power, builders' rating, atsquare feet per horse-power	
45. Per cent developed above, or below, rating the Per cent.	

Precautions are to be taken in every possible way to prevent and avoid irregularities in the conduct of the trial and errors of observation.\*

In preparing for and conducting trials of steam-boilers the specific object of the proposed trial should be clearly defined and steadily kept in view, and as suggested by Mr. Hoadley—

(1) If it be to determine the efficiency of a given style of boiler or of boiler-setting under normal conditions, the boiler brickwork, grates, dampers, flues, pipes, in short, the whole apparatus, should be carefully examined and accurately described,

<sup>\*</sup> The appendix to the report above quoted should be read in this connection.

and any variation from a normal condition should be remedied, if possible, and if irremediable, clearly described and pointed out.

- (2) If it be to ascertain the condition of a given boiler or set of boilers with a view to the improvement of whatever may be faulty, the conditions actually existing should be accurately observed and clearly described.
- (3) If the object be to determine the relative value of two or more kinds of coal, or the actual value of any kind, exact equality of conditions should be maintained if possible, or, where that is not practicable, all variations should be duly allowed for.
- (4) Only one variable should be allowed to enter into the problem; or, since the entire exclusion of disturbing variations cannot usually be effected, they should be kept as closely as possible within narrow limits, and allowed for with all possible accuracy.

Blanks should be provided in advance, in which to enter all data observed during the test. The preceding instructions contain the form used in presenting the general results. Records should be, as far as possible, made in a standard form, in order that all may be comparable.

The observations must be made by the engineer conducting the trial, or by his assistants, with this object distinctly in mind; and each should have a well-defined part of the work assigned him, and should assume responsibility for that part, having a distinct understanding in regard to the extent of his responsibility, and a good idea of the extent and nature of the work done by his colleagues, and the relations of each part to his own. No observations should be permitted to be made by unauthorized persons for entrance upon the log; and no duties should be permitted to be delegated by one assistant to another, without consultation and distinct understanding with the engineer in charge. The trial should, wherever possible, be so conducted that any error that may occur in the record may be detected, checked, or, if advisable, removed, by some process of mutual verification of related observations. It is in this direction that the use of graphical methods of record and automatic instruments have greatest value.

Several methods of weighing fuel have been found very satisfactory, but it should be an essential feature that the weights shall be made by one observer and checked by another, at as distant a point as is convenient. The weighing of the fuel by one observer at the point of storage, and the record at that point of times of delivery, as well as of weights of each lot, and the tallying of the number and record of the time of receipt at the furnace-door, will be usually found a safe system. The failure to record any one weight leads to similar error, and can only be certainly prevented by an effective method of double observation and check.

The same remarks apply, to a considerable extent, to the weighing of the water fed to the boiler. A careful arrangement of weighing apparatus, a double set of observations, where possible, and thus safe checks on the figures obtained, are essential to certainty of results. With good observers at the tank, and with small demand for water, a single tank can be used; but two are preferable in all cases, and three should be used if the work demands very large amounts of feed-water, as at trials of very large boilers, or of "batteries." The more uniform the water supply, as well as the more steady the firing, the less the liability to mistake in making the record.

The two blanks which follow were prepared by the Author for use in laboratory as well as professional work.

Such blanks are always desirable, and are sometimes even more elaborate than those here illustrated.\* For ordinary purposes, a less complete tabulation may be sufficient; while, for special purposes and for scientific investigations and the work of research, considerable more elaboration may be found desirable, or even necessary.

Graphical methods of representation of the data and conditions and of the progress of the trial, as elsewhere illustrated, are also often found exceedingly useful and convenient.

376. Additional Forms for Log and Report.—The following forms are somewhat more complete than those given in Article 375:

<sup>\*</sup>Vide "Stevens Indicator," Nov. '89.

## MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY.

	Log of E	OILE	R-TRIAL.
	e at	Ву	<b>\( \cdot \c</b>
	2	D,	· · · · · · · · · · · · · · · · · · ·
Fire	man	• • • •	
	Made by REPORT OF		
	************		
Kind	d of Boiler	Ma	anufactured by
	Duration of Trial Hours.  Grate-surf., lengthft.,	F.	Amount usedPounds. Evaporated, dry steam"
	width ft Sq. ft.	≥ 8	Evap. from and at 212° "
ایا	Water-heating surface "	11-	1 1
. 6	Superheating surface "	11	Per Pound of Fuel.
Dimensions.	Area for draught (calorimeter). "	H	Actual Pounds.
Ë	Area, chimney "		Equiv. from and at 212° "
ā	Height, chimney Ft.		Per Pound of Combustible.
;	Ratio heating to grate surface	11	ActualPounds.
_	Ratio air-space to grate-surface BarometerInches mercury.	ے ا	Equiv. from and at 212°
. ģ	Steam-gauge Pounds	₩.8	1
ي ي	Draught-gaugeInches water.	Evaporation.	Per Sq. Ft. Heating-surface per Hr.
<u> </u>	Absolute steam-pressurePounds.	P P	Actual Pounds.
_	External air Degrees F.	E E	Equiv. from and at 212°
ָ בַּ	Boiler-room "	11	1 -
įį	Flue "		From 100° F. to 70 Pounds by Gauge.
Temperature.	Furnace "	11	Per Pound of FuelPounds,
9	Feed-water "		Per Pound of Combustible "
1-	Steam	.	Per §-pound of Fuel "
1	Total coal consumedPounds.		Pen Sanana Fast of C
-	Moisture in coalPer cent.		Per Square Foot of Grate.
Š	Dry coal consumed Pounds. Total refuse, dry "		Actual, from feed-water tem-
1 12	Total refuse, dry Per cent.	1	peraturePounds.
1	Total combustible Pounds.	9	Equiv. from and at 212° "
,	Dry coal per hour "	1 2	Per Sq. Ft. of Water-heating Surface.
1	Combustible per hour "	D.	)
, <u>j</u>	Dry coal per square foot of	2	ActualPounds. Equiv. from and at 212°
Hour	grate "	1 2	i i
ž	Combustible per square foot	d	Per Sq. Ft. of Least Draught-area.
	of grate "	Evaporation per Hour.	ActualPounds.
5	Dry coal per square foot of	-	Equiv. from and at 212°
. —	grate		On basis 341 lbs. equiv. evap.
i	Combustible per square foot of grate Heating-surface.	-	per hourH. P.
_	Quality of steamPer cent.	7.	Builders' rating "
.	Superheat Degrees.	12	Ratio of commercial to builders' rat-
	Total weight water used Pounds.		ing
Water.	(by meter) Cu. ft.		Heat generated per hour B. T. U.
. ₩	Total evap., dry steam Pounds.		Heat absorbed per hour "
	Factor of evaporation	11	Efficiency of boilerPer cent.
Total	Total from and at 2120 Pounds.	1.	Efficiency of furnace "
-	1	Hi .	

Note.—Actual evaporation signifies the evaporation from feed-water temperature to dry steam at gauge-pressure. It is apparent evaporation corrected for calorimeter-determination.

\* Standard Commercial H. P.

377. Abbreviated Directions for Boiler-testing.—Apparatus.—As in standard tests: tanks and scales for weighing water; meter for measuring water; apparatus for flue as analysis; barometer and pyrometer.

Directions.—Calibrate all apparatus, meters, scales, thermometers, and gauges; arrange throttling or separator calorimeter to obtain quality of steam delivered. Note condition of Boiler and Furnace Rules, VII-IX. Start and close the test either by standard or alternative method, Rules X and XI. During test proceed as in Rules XIII and XIV. Continue the test as long as time will permit, at least four hours, taking simultaneous observations each 15 minutes at a signal given by a whistle; keep record so that coal and water consumption can be computed for each hour.

Put 100 pounds of coal in a box and dry in a hot place for 24 hours; if ashes are damp from use of a steam-blower, dry a sample of 100 pounds in same manner. In general, ashes may be removed at once and weighed.

Report and Computation.—Make report on standard forms submitted and compute the required quantities. Submit with report a graphical log, in which time is taken as abscissa, and the various observed quantities as ordinates.

#### CHAPTER XVI.

#### THE STEAM-ENGINE INDICATOR.

378. Uses of the Steam-engine Indicator.—The steam-engine indicator is an instrument for drawing a diagram on paper which shall accurately represent the various changes of pressure on one side of the piston of the steam-engine during both the forward and return stroke.




FIG. 172.—THE INDICATOR-DIAGRAM.

The general form of the indicator-diagram is shown in Fig. 172; the ordinates of the diagram, measured from the line GG, are proportional to the pressure per square inch above the atmosphere; measured from the line HH, are proportional to the absolute pressure per square inch acting on the piston. The abscissa corresponding to any ordinate is proportional to the distance moved by the piston. ABCDE is the line drawn during the forward stroke of the engine, EFA that drawn during the return stroke. The ordinates to the line ABCDE represent the pressures acting to move the piston forward; those to the line EFA represent the pressures acting to retard or

stop the motion of the piston on its back stroke. The ordinates intercepted between the lines represent the effective pressure acting to urge the piston forward. Since the abscissæ of the diagram are proportional to the space passed through by the piston, and the intercepted ordinate to the effective pressure acting on the piston, the area of the diagram must be proportional to the work done by the steam on one side of the piston, acting on a unit of area and during both forward and return stroke. (See Article 21, page 17.)

From this diagram can be obtained, by processes to be explained later: 1. The quantity of power developed in the cylinder, and the quantity lost in various ways,—by wire-drawing, by back pressure, by premature release, by mal-adjustment of valves, leakage, etc.

- 2. The redistribution of horizontal pressures at the crankpin, through the momentum and inertia of the reciprocating parts, and the angular distribution of the tangential component of the horizontal pressure; in other words, the rotative effect around the path of the crank.
- 3. Taken in combination with measurements of feed-water or of the exhaust steam, with the amount and temperatures of condensing water, the indicator furnishes opportunities for measuring the heat losses which occur at different points during the stroke.
- 4. The indicator-diagram also shows the position of the piston at times when the valve-motion opens or closes the steam and exhaust ports of the engine. It also furnishes information regarding the general condition of the engine, and the arrangement of the valves, adequacy of the ports and passages, and of the steam or the exhaust pipes.
- 379. Indicated and Dynamometric Power.—The steam-engine indicator is used in all steam-engine tests to measure the force of the steam acting on a unit of area of the piston. A dynamometer of the absorbing or transmission type (see pages 216 to 228) is used to measure the work delivered by the steam-engine. The work of the engine is usually expressed in horse-power; one horse-power being equivalent to 33,000 foot-pounds

per minute. The work shown by the steam-engine indicatordiagram is termed the *Indicated horse-power* (I.H.P.); that shown by the dynamometer, *Dynamometric horse-power* (D.H.P.).

The mean effective pressure per unit of area acting on the piston is obtained from the indicator-diagram; this quantity, multiplied by the area of the piston and the distance travelled by the piston in feet per minute, will give the work in footpounds. Thus let p equal the mean effective pressure, l the length of stroke of the engine in feet, n the number of revolutions, a the area of the piston in square inches. Then the work done per minute by the steam acting on one side of the piston, in horse-power, is

 $plan \div 33,000.$ 

380. Early Forms of the Steam-engine Indicator.—Watt and McNaught.—The steam-engine indicator was in-

vented by James Watt, and was extensively used by him in perfecting his engine. The indicator of Watt,\* as used in 1814, consisted of a small steam-cylinder AA, as shown in Fig. 173, in which a piston was moved by the steam-pressure, against the resistance of a spring FC. The end of the piston-rod carried a pencil, which was made to press against a sheet of paper DD, moved backward and forward in conformity to the motion of the piston. By this method a diagram was produced similar to that shown in Fig. 172.

McNaught's indicator, which succeeded that of Watt and was in general use until about 1860, differed from the form used by Watt principally in the use of a vertical cylinder instead of the sliding panel, which was turned backward and forward




FIG. 173.—THE WATT INDICATOR.

on a vertical axis, in conformity to the motion of the piston.

<sup>\*</sup> See Thurston's Engine and Boiler Trials, page 130.

381. The Richards Indicator. \*—The Richards indicator was invented by Professor C. B. Richards about 1860; it contains every essential constructive feature found in recent indicators, and may be considered the prototype from which all other indicators differ simply in details of workmanship, form, and size of parts.

The construction of this indicator is well shown in Fig. 174,




FIG. 174.-THE RICHARDS INDICATOR.

from which it is seen to consist of a steam-cylinder AA, in which is a piston B, connected by a rigid rod with the cap F. The movement of the piston is resisted by the spring CD in such a manner that its motion in either direction is proportional to the pressure. The motion of the piston-rod is transferred to a pencil at K, by links which are so arranged that the pencil

<sup>\*</sup> See the Richards Indicator, by C. B. Porter; New York, D. Van Nostrand.

THE STEAM-ENGINE INDICATOR.

§ 382.]

463

moves parallel to the piston B, but through a considerably greater range. The indicator-spring can be taken out by unscrewing the cap E, removing the top of the instrument and unscrewing the piston B, and another spring with a different tension can be substituted. The drum OR is made of light metal, mounted on a vertical axis, and provided with a spring arranged to resist rotation. The drum is connected to the cross-head or reducing motion by a cord, and is given a motion in one direction by the tension transmitted through the cord and in a reverse direction by the indicator drum-spring. The paper on which the diagram is to be drawn is wrapped smoothly around the drum OQ, being held in place by the clips PQ. The indicator is connected to the steam-cylinder by a pipe leading to the clearance-space of the engine; a cock, T, being screwed into this pipe, and the indicator connected to the cock by the coupling U.

382. The Thompson Indicator.—This indicator is shown in Figs. 175 and 176. It differs from the Richards indicator



FIG. 175.-THE THOMPSON INDICATOR.




Fig. 176.—Section of Thompson Indicator.

principally in the form of the parallel motion, form of indicatorspring, and details of workmanship. The parts of the instrument are much lighter, and it is better adapted for use on highspeed engines.

The use is essentially the same as the Richards; the method of changing springs should be thoroughly understood, and is as follows: Unscrew the milled-edged cap at the top of steam-cylinder; then take out piston, with arm and connections; disconnect pencil-lever and piston by unscrewing the small milled-headed screw which connects them; remove the spring from the piston, substitute the one desired, and put together in same manner, being careful, of course, to screw the spring up firmly against cap and well down to the piston-head. The method of changing springs is simple, easy, and convenient, and does not require the use of any wrench or pin of any kind.

383. The Tabor Indicator.—The Tabor indicator, shown in Figs. 177 and 178, in the form now manufactured differs from other indicators principally in producing the parallel



FIG. 177.-THE TABOR INDICATOR.

motion of the pencil by a pin moving in a peculiarly-shaped slot. It also differs in details of construction and in form of the indicator-spring; the pencil-point being arranged to move not only parallel to the piston, but uniformly five times as fast as the piston at every part of the range.

The method of changing springs in the Tabor indicator is as

follows: Remove the cover of the cylinder, remove the screw beneath the piston, unscrew the piston from the spring and the spring from the cover, and replace the spring When the lower end desired. of the piston-rod is introduced into the square hole in the centre of the piston, care must be taken that it sets fairly in the hole before the screw is applied. Unless such care is observed, the corners may catch and cause derangement. The tension on the drum-spring may be varied by removing the




FIG. 178.—SECTION OF TABOR INDICATOR.

paper drum, loosening the thumb-screw which encircles the central shaft, lifting the drum-carriage so as to clear the stop, and then winding the carriage in the direction desired.

384. The Crosby Indicator.—The Crosby indicator as at present constructed is shown in Figs. 179 and 180. It differs from those already described in the form of piston- and drumsprings and in the arrangement for producing accurate parallel motion.

The special directions for this instrument are given by the manufacturers as follows:

To remove the piston, spring, etc., unscrew the cap, then, by the sleeve, lift all the connected parts free. This gives full access to the parts to clean and oil them.

To detach the spring, unscrew the cap from spring-head, then unscrew piston-rod from swivel-head, then, with the hollow slotted wrench, unscrew the piston-rod from the piston. To attach a spring, simply reverse this process. Before setting the foot of the spring unscrew G slightly, then, after the piston-rod has been firmly screwed down to its shoulder, set G up firmly against the bead, and thereby take up all lost motion.

It is often desirable to change the position of the atmospheric

*line* on the paper. This can easily be done by unscrewing the cap from the cylinder and raising the sleeve BB which carries the pencil-movement. Then turn the cap to the right or left,




FIG. 179.—THE CROSBY INDICATOR.

and the piston-rod will be screwed off or on the swivel E, and the position of the atmospheric line will be raised or lowered.

Never remove the pins or screws from the joints K, I, L, M, but keep them well oiled with refined porpoise-jaw oil, which is furnished with each instrument.

The tension on the drum-spring should be increased or diminished according to the speed at which the instrument is used, by means of the thumb-nut on top of the drum-spindle.

Use a spring of such a number that the diagram will not be

over one and three-quarter inches high; as, for instance, a No. 40 spring should not be used for pressures above 70 lbs.




FIG. 180.—SECTION OF THE CROSBY INDICATOR.

385. The Calkins Indicator.—The Calkins indicator is one of the recent forms, worthy of notice. It possesses, as shown in Fig. 181, the usual features of steam-engine indicators, modified by details of construction in its moving parts and form of indicator-spring. The parallel motion is produced partly by cams, partly by links, and gives a good diagram 2½ inches in height. The spring is inserted by screwing it first into the cap and afterward screwing on the piston to the squared shank.

The drum-spring is adjusted by simply turning a ratchetwheel placed beneath the paper-drum.

# 386. The Straight Lyne and the Perfection Indicators. —The straight Lyne indicator, as shown in Fig. 182, was de-




FIG. 181.—SECTIONAL VIEW, ONE-HALF SIZE, CALKINS STEAM-ENGINE INDICATOR.

signed by Mr. L. F. Lyne. Its principal peculiarity is the guide near the paper drum for securing the parallel motion.

The Perfection indicator, shown in Fig. 183, differs from those described in the form of the spring and in the arrangement of the levers for the parallel motion. This instrument is made with jewelled bearings and with aluminium drum.

387. The Bachelder, Straight Line, and Arc Indicators.

—The Bachelder indicator, as shown in Fig. 184, differs radi-





FIG. 182.-THE STRAIGHT LYNE INDICATOR.

FIG. 183.-THE PERFECTION INDICATOR.

cally from the indicators described in the form of springs employed; the indicator-spring is flat and arranged with a



'Fig. 184.-THE BACHELDER INDICATOR.

movable fulcrum, so that the scale of the spring can be easily and quickly changed, and the drum-spring is conical in form.

The straight-line indicator, as shown in Fig. 185, differs

from the ones described principally in the form of its parallel motion. The instrument shown in the figure has a reducing motion attached as a part of the indicator, which the author regards as a desirable improvement.




FIG. 185 -THE STRAIGHT-I INE INDICATOR.

The arc indicator is similar to the straight-line indicator as shown above, but the pencil part is pivoted to a fixed point, and the pencil rises in an arc of a circle instead of a straight line.

- 388. Parts of the Steam-engine Indicator.—The parts of the steam-engine indicator must be constructed essentially as follows:
- 1. The Steam-cylinder.—This contains the piston, the indicator-spring, and attachments for the pencil mechanism. In the upper portions of the walls relief-holes are bored to insure atmospheric pressure above the piston.
- 2. The Piston.—This is usually solid, with grooves or holes in its outer edge; it is made to fit loosely in the cylinder to reduce friction, and is not steam-tight. When in use it must be lubricated with cylinder-oil of best quality; it is connected to the pencil mechanism by a piston-rod.
- 3. The Pencil Mechanism.—This receives the motion from the piston-rod, increases its amplitude, and transfers it to a pencil by means of guides or parallel-motion links, so that the

pencil moves in a right line and usually four to six times the distance of the piston. The height of the atmospheric line, or line of no pressure, on the drum, can often be adjusted by means of a threaded sleeve fitting on the piston-rod. In the arc indicator the pencil swings in an arc of a circle.

4. The Indicator-spring.—This is usually a helical spring; when in use it has one end screwed to the upper head of the cylinder, and the other screwed to the piston. To insure accurate results the spring must be accurate, and there must be no play or lost motion between the piston and the cylinder-head, and the spring must receive and deliver the force axially. The number of pounds pressure on the square inch required to move the pencil one inch is stamped on the spring, and the springs are designated by that number. It is essential to know the error, if any, in this number. A spring can be readily removed and another substituted when desired; the maximum compression probably should not exceed one third of an inch.

The spring is in many respects the most important part of the indicator, as the form of the diagram is directly affected by any error. The following cuts show some of the principal







FIG. 187.-TABOR SPRING.

forms adopted by a few of the makers, and it may perhaps be sufficient to state that within the range of action of the indicator any of these forms can be made practically perfect.

DIMENSIONS OF PRINCIPAL INDICATORS.

Name of Indicator	CROSBY.	TABOR, O. S.	TABOR, N. S.	THOMPSON, N. S.	ARC.	McInnes.	MCINNES. BACHELDER, RICHARDS, CALKINS.	RICHARDS.	CALKINS.
Maker	Crosby St'm Gauge Co.	Ashcroft Steam Gauge Co.	t Steam c Co.	Am. Steam Gauge Co.	*	++	Thompson & Am. Steam Bushnell. Gauge Co.	Am. Steam Gauge Co.	eøs:
Address	Boston.	New York.	York.	Boston.	Boston.	:	New York.	Boston.	Boston. New York.
Price	\$100.00	\$100.00   \$100.00	\$100.00	\$100.00	\$25.00		\$75.00	\$85.00	\$35.00
Weight, pounds	1.65	2.63	2.25	2.92	<b>†</b> 1.55	2.05	2.49	3.51	4.16
Diam. piston, inches	0.796	0.796	0.797	0.798	0.562	0.796	0.80	0.796	0.796
Area piston, sq. inches	0.4976	0.4976	0.4989	0.5001	0.248	0 4089	0.5026	o. 1976	- 0 4976
Diam. of drum, inches	1.5	2.625	2.312	81	1.5	1.825	1.75	2.00	2.03
Weight of drum, lbs	0.28	0.40	0.38	0.60	0.32	0.38	0.43	0.94	0.26
Form of drum-spring	Spiral.	Flat helix.	Flat helix.	Flat helix. Flat helix. Flat helix.	Spiral.	Spiral.	Spiral.	Flat helix.	Flat helix. Flat helix.
Ratio of pencil to piston-movement	9	۱'n	4	4	· – •	9	ø	4	w
Weight of pencil-move-	0.43	0.34		0.69					

‡ Made in Glasgow, Scotland. ical Specialties Co. † Weight with cock. 
\$\\$ Engineers Instrument Co., Broadway, N. Y. \* Arc indicator made by Mechanical Specialties Co.

The Bachelder indicator (see Fig. 184) is made with a flat spring, and to a certain extent the tension is regulated by changing its fulcrum.

- 5. The Paper-drum, to which the card is attached, consists of a brass cylinder attached to a spindle which is connected to the drum-spring, the action of which has been described. The drum can be removed readily, and the tension on the spring changed at pleasure. Two clips or fingers serve to hold the paper in position.
- 6. The Cord used, although not a part of the indicator, must be selected with great care; it must be of a character not to be stretched by the forces acting on the indicator. Steel wire is sometimes used for this purpose. Any variation in length of the connecting cord affects the abscissa in the diagram.
- 7. The Reducing-motions, also not a part of the indicator, must give an exact reproduction, on a smaller scale, of the motion of the piston; otherwise the length of the indicator-diagram will either not be accurately reduced, or the events will not be properly timed.
- 389. The table opposite gives the actual dimensions of the principal indicators described, as obtained by careful measurement of those owned by Sibley College.
- 390. Reducing-motions for Indicators.—The maximum motion of the indicator-drum is usually less than four inches; consequently it can seldom be connected directly to the cross-head of the engine, but must be connected to some apparatus which has a motion less in amplitude but corresponding exactly in all its phases to that of the cross-head. This apparatus is termed a reducing-motion. Since the horizontal components of the indicator-diagram and consequently its area and form depend upon the motion of the piston, it is evident that the accuracy of the diagram depends upon the accuracy of the reducing-motion. Various combinations of levers and pulleys have been used \* for reducing-motions, a few of which will be

<sup>\*</sup> See Thurston's Engine and Boiler Trials.

described. Several simple forms of reducing-motion are given here as suggestions, but it is expected that the student will devise other motions if required, and ascertain the amount of error, if any, in the motion used.




FIG. 188.—THE SIMPLE PENDULUM REDUCING-MOTION.

The cheaper and more easily arranged reducing-motions consist usually of some form of swinging lever or pendulum (see Fig. 188) pivoted at one point, and connected at its lower end to the cross-head by a lever. The indicator-cord is attached to the swinging lever at some point having the proper motion. These motions never give an exact reproduc-

tion of the motion of the piston; but if the pendulum and cross-head are simultaneously at the centre of the stroke, the error is very small.




FIG. 189 .- THE BRUMBO PULLEY.

A form of the pendulum-motion, called the Brumbo pulley, is frequently used as shown in Fig. 189. The pendulum is sometimes modified, so that its lower end is pivoted directly to a




FIG. 100.-THE PANTOGRAPH.

point in the cross-head, its upper half moving vertically in a swinging tube. The cord is attached to an arc on this tube as in Fig. 188.

The pantograph, or lazy-tongs, as shown in Fig. 190, with plan of method of attachment shown in Fig. 191, is a perfect reducing motion, but because of its numerous joints it is not adapted to high-speed engines.




FIG. 191.-METHOD OF ATTACHING THE PANTOGRAPH.

A form of pantograph with four joints only, shown in Fig. 192, is much better adapted to high-speed engines than the one with more numerous joints shown above.




FIG. 192.-METHOD OF USING THE PANTOGRAPH.

Reducing-wheels.—Reducing wheels, which consist of a large and a small pulley (see Fig. 193) attached to the same axis, are extensively used by engineers. The method of attaching this reducing-motion to an engine is shown in Fig. 194.

391. The Indicator-cord.—The indicator-cord should be as nearly as possible inextensible, since any stretch of the cord causes a corresponding error in the motion of the indicator-drum. As it is nearly impossible to secure a cord that will not

stretch, it should be made as short as possible, and a fine wire of steel or iron or of hard-drawn brass should be used if practicable.




FIG. 193.-SCHARFFER AND BUDENBERG REDUCING-MOTION.




FIG. 194.-WEBSTER AND PERKS REDUCING MOTION.

The indicator-cord supplied by makers of indicators is a braided hard cotton cord, stretching but little under the required stress.

If a "rig" is to be permanently erected, it is recommended that the motion be taken from a sliding bar attached to the cross-head and extending to or beyond the indicators. The angle of the cord with the path of motion of the cross-head should be as nearly constant as possible, since any variation in this angle will cause a distortion in the motion of the drum.

In Figs. 189, 192, and 194 will be seen devices to overcome the effect of angularity of the indicator-cord.

The indicator-cord is usually hooked and unhooked into a loop in a cord fastened to the reducing-motion. A very convenient form for such a loop, and one that can readily be adjusted, is shown in Fig. 195. The indicator-cord is usually



provided with a hook fastened as shown in Fig. 182, which is hooked when diagrams are needed into the loop attached to the reducing-motion.

The author would strongly urge that the indicator-cord be arranged so as to avoid the necessity of frequent hooking and unhooking, thus throwing severe and unnecessary strains on the indicator-drum and cord: this can be done by connecting a point on the cord near the indicator with a spiral spring fastened to a fixed point in the line of the cord produced. This spring should be strong enough to keep the slack out of the cord. When it is desired to stop the motion, the drum-cord is pulled toward the reducing-motion to the extent of its travel, and held or tied until another diagram is needed. Some of the indicator-drums are provided with ratchets or detents that serve the same purpose. When several indicators are in use and simultaneous diagrams are required, a detent-motion worked by an electric current will prove very satisfactory. In case of compound engines when numerous indicators are required these suggestions become of even greater importance.

302. Standardization of the Indicator.—The accuracy of

the indicator-diagram depends upon the following features, all of which should be the subject of careful examination:

- (1) Uniformity of the indicator-spring.
- (2) Accuracy of the drum-motion.
- (3) Parallelism of the piston-movement to the cylinder.
- (4) Parallelism of the pencil-movement to the axis of the drum.
  - (5) Friction of the piston and pencil-movements.
  - (6) Lost motion.

The calibration of these parts should be made as nearly as possible under the conditions of actual use and as described in the following articles.

393. Calibration of the Indicator-spring.—The accuracy of the indicator-spring is only to be determined by comparison with standardized apparatus. This may be done as follows:

Firstly: with the open mercury column. This can be done with steam only, as the leakage of water past the loosely-fitting piston would render it impossible to maintain the pressure. Insert the spring; see that the indicator is oiled and in good Attach the indicator as previously explained for condition. the calibration of steam-gauges, page 338; put paper on the drum; turn on steam-pressure until the instrument is warm; turn off the steam, and pressing the pencil lightly against the paper, turn the drum by hand, thus drawing the atmospheric line. Apply pressure by increments equal to one fifth that marked on the spring, keeping the motion continually upward, stopping only long enough to draw the line for the required pressure. Take ten increments first up then down; the average position of any line will give the ordinate corresponding to that pressure; the difference between any two lines (see Fig. 196) will be twice the friction of indicator-piston at that point.

Second: with the standard scales. This method was devised by Professor M. E. Cooley, of Ann Arbor. In this case the indicator, is supported on a bracket above the platform of the scales. Force is applied to the indicator-piston by means of a rod which can be raised or lowered by turning a hand-wheel; this rod terminates above in a cap nicely fitted to the under

side of the piston, and below it rests on a pedestal standing on the platform of the scales. Any force applied to compress the spring is registered on the scale beam. The reading of the scale-beam is that force acting on one-half square inch. as the piston is usually one-half square inch in area; this is to be multiplied by 2 to correspond with the reading given by the indicator-spring. The indicator can be heated by wrapping rubber tubing around the cylinder and passing steam through the tube.




FIG. 196.—INDICATOR-SPRING CALIBRATION.

FOR CALIBRATION OF INDICATOR SPRING

Mark a	nparison of indica and No.	with. tor of spri	ng.	• • • • • •	• • • • • • •				
No.	Gauge.			Ordinates.					
	Inches	Lbs.	Actual Pressure.	Inches.			Pounds.	Actual Pressure.	Error. Per cent.
				Up.	Down.	Mean.	Founds.		
	1		1		1	ı	1	١	<u>'                                     </u>

394. Test for Parallelism of the Pencil-movement to the Axis of the Drum.—This is tested by removing the spring from the indicator, rotating the drum, and drawing an atmospheric line; then hold the drum stationary in various positions and press the piston of the indicator upward throughout its full stroke, while the pencil is in contact with the paper. The lines thus drawn should be parallel to each other and perpendicular to the atmospheric line.

Parallelism of the piston-movement to the cylinder axis is shown when the increments for equal pressure are the same in all positions of the diagram. It is important that the piston is not cramped or pushed over by the spring, in any part of its stroke.

Friction of the piston and pencil-movement can be determined in the calibration of the indicator-spring as explained. When the spring is removed from the indicator, the parts should work easily and freely but without lost motion.

395. Accuracy of the Drum-motion.—The accuracy of the drum-motion depends on the form of the drum-spring, the mass moved, the length of the diagram, and the elasticity of the connecting cord.

Indicator-drums would revolve in a harmonic motion if the inertia of the mass could be neglected. The speed of rotation is greatest near the half-stroke of the piston; therefore, if the drum-spring tension can be adjusted so as to exactly counterbalance the effect of the inertia of the moving parts, the theoretical harmonic motion will be nearly realized.

In most indicator drum-springs the tension increases directly in proportion to the extension. Since the speed of the drum is greatest at half stroke, at this point the drum will run ahead of its theoretic motion if the spring tension is not sufficient to counteract the effect of the inertia of the moving parts. Therefore if the tension of the drum-spring is adjusted to exactly balance the effect of inertia at half-stroke, the card should be as nearly as possible theoretically correct. To obtain the value of this tension, use is made of the formulæ for the harmonic motion of a body as follows. Let

 $t = \text{time of } \frac{1}{2} \text{ length of card } = \frac{1}{2} \text{ of a revolution };$   $s = \frac{1}{2} \text{ length of card };$ 

$$t = \frac{\pi}{2\sqrt{a}}$$
; (see Church's Mechanics.)

P = pM = T, where T is the tension in the spring at  $\frac{1}{2}$  the length of the card.

$$p = -sa$$
;  $a = -\frac{p}{s}$ ;  
 $M = \frac{W}{g} = \text{mass of rotating parts}$ ;  $a = -\frac{T}{Ms}$ .  
 $\therefore t = -\frac{\pi}{2\sqrt{\frac{T}{Ms}}}$ ;  $t^{2} = \frac{\pi^{2}}{4(\frac{T}{Ms})}$ ;  $T = \frac{\pi^{2}Ms}{4t^{2}}$ .

The foot, pound, second system is used in the formulæ. The results are shown in the following table.

TABLE FOR TENSION ON INDICATOR DRUM OF 1.0 LB. WEIGHT.

Revolutions per Minute.	Pounds of Force to pull Drum 1.75 ID.	Revolutions per Minute.	Pounds of Force to pull Drum 1.75 in.
50	0 10	225	2.5
75	0.25	250	3.15
100	0.50	275	3.8
125	0.8	300	4-55
150	1.15	350	6.15
175	1.55	375	7.0
200	2.0	400	8.0

The total error introduced by inertia can be determined as follows: Attaching the indicator to an engine, permit it to run sufficiently long to harden the cord and the knots, then stop the engine, turn it over by hand and find the length of the diagram with the speed so small as to eliminate the inertia; leaving the cords connected, run the engine at full speed: any

inertia effect will be shown by an increase in the length of the diagram. This increase in length may be partly due to stretch in the indicator-cord caused by inertia of the rotating parts, as even with the best tension on the springs, determined as explained, it may be sensibly lessened by the use of wire. A simple arrangement, consisting of a pin and connecting-rod leading to the face-plate of a lathe, the tool-rest being utilized as a guide, may be used instead of an engine for obtaining complete determination of this error. The amount of error caused by over-travel of the drum has been found by experiment to be from 0.5 to 1.5 per cent at 250 revolutions, with the best tension on the drum spring.

Uniform Tension on the Indicator-cord.—It is often important to determine whether the drum-spring maintains a uniform tension on the cord, or whether it alternately exerts a greater



FIG. 197.—Brown Drum-spring Testing-device.

or less stress; this may be determined by the instrument shown in Fig. 197. The testing instrument consists of a wooden plate, A, on one end of which is fastened the brass frame, BB, carrying the slide, C, with its cross-head, D. The head of the spring, F, is screwed to the cross-head, while the other end is connected with the bent lever, G, carrying the pencil The connecting-rod, E, which moves the slide, C, receives its motion from a crank not shown in the figure. The swinging leaf holds the paper on which the diagram is to be taken. The indicator to be tested is clamped to the plate as shown, and the drum-cord connected with the free end of the spring. The crank is made to move at the speed at which it is desired to test the drum-spring. The paper is then pressed up to the pencil and the diagram taken. If the tension

on the cord is constant, the lines which represent the forward and return strokes will be parallel to the motion of the slide; but, if the stress is not constant, the pencil will rise and fall as the stress is greater or less. The line drawn when the cord has been detached from the indicator (Fig. 198) is the line of no stress. In the diagram, horizontal distance represents the position of the drum, and vertical distance represents strain on the cord. The perfect diagram would be two lines near together and parallel to the line of no stress, and would represent a constant stress, and consequently a constant stretch of the cord, from which no error would result.

When the length of the cord and the amount it will stretch under varying stresses is known, the errors in the diagram due to stretch of cord caused by irregular stresses applied by the drum-spring can be calculated.




FIG. 198.—DIAGRAMS SHOWING VARIATION IN DRUM-SPRING STRESS.

# 396. To Adjust and Calibrate a Drum-spring.

- 1. Find the weight of the moving parts, and compute the theoretic stress on the indicator-cord. (See Article 395.)
- 2. Attach to the face-plate of a lathe in such a manner that the speed can be varied within wide limits.
- 3. Draw diagrams at various rates of speed, various lengths of stroke, and various tensions on the drum-spring.
- 4. Find the error in the diagram for each condition. Plot the results, and deduce from the curve shown the best length of diagram and best tension for each speed.

5. Repeat the came operations with the Brown spring testing-device, and compare the results.

307. Method of Attaching the Indicator to the Cylinder.

—Holes for the indicator are drilled in the clearance-spaces at the ends of the cylinders, in such a position that they are not even partially choked by any motion of the piston. These holes are fitted for connection to half-inch pipe: they are located preferably in horizontal cylinders at the top of the cylinder; but if the clearance-spaces are not sufficiently great they may be drilled in the heads of the cylinder, and connections to the indicators made by elbows. The holes for the in-




FIG. 199.—SECTION OF CROSBY THREE-WAY COCK.

Fig. 200.—Elevation of Crosby Three-way Cock.

dicator-cocks are usually put in the cylinders by the makers of the engine, but in case they have to be drilled great care must be exercised that no drill-chips get into the cylinder. This may be entirely prevented by blocking the piston and admitting twenty or thirty pounds of steam-pressure to the cylinder.

The connections for the indicator are to be made as short and direct as possible. Usually the indicator-cock can be screwed directly into the holes in the cylinder, and an indicator attached at each end. In case a single indicator is used to take diagrams from both ends of the cylinder, half-inch piping with as easy bends as possible is carried to a three-way cock, as in Fig.

194, to which the indicator is attached. The cock is located as nearly as possible equidistant from the two ends of the cylinder.

The form of the three-way cock is shown in Figs. 199 and 200, and the method of connecting in Fig. 194.

In connecting an indicator-cock, use a wrench very carefully; but on no account use lead in the connections, as it is likely to get in the indicator and prevent the free motion of the piston.

## 398. Directions for Taking Indicator-diagrams.

Firstly, provide a perfect reducing-motion, and make arrangements so that the indicator-drum can be stopped or started at full speed of the engine. (See Article 301.)

Secondly, clean and oil the indicator, and attach it to the engine as previously explained. Insert proper spring; oil piston with cylinder-oil.

Thirdly, put proper tension on the drum-spring (see Article 395); see that the pencil-point is sharp and will draw a fine line.

Fourthly, connect the indicator-cord to the reducing-motion; turn the engine over and adjust the cord so that the indicator-drum has the proper movement and does not hit the stops.

Fifthly, put the paper on the drum; turn on steam, allow it to blow through the relief-hole in the side of the cock; then admit steam to the indicator-cylinder, close the indicator-cock, start the drum in motion, and draw the atmospheric line with engine and drum in motion; open the cock, press the pencil lightly and take the diagram; close the cock and draw a second atmospheric line. Do not try to obtain a heavy diagram, as all pressure on the card increases the indicator friction and causes more or less error. Take as light a card as can be seen; brass point and metallic paper are to be used when especially fine diagrams are required.

When the load is varying, and the average horse-power is required, it is better to allow the pencil to remain during a number of revolutions, and to take the mean effective pressure from the several diagrams drawn.

Remove card after diagram has been taken, and on the back of card make note of the following particulars, as far as conveniently obtainable:

No	Time	Date
Diagram from M		Engine
Diameter of cylinder		Built by
Length of stroke		
Revolutions per minute		Barometer reads
Pressure of steam, in lbs., in bo	oiler	Throttle
Position of throttle-valve		Regulator
Vacuum per gauge, in inches		Remarks
Temperature of hot-well		
Scale of spring		
Inside diameter of feed-pipe	• • • • • •	
" " exhaust-pipe		
Valves		

Sixthly, after a sufficient number of diagrams has been taken, remove the piston, spring, etc., from the indicator while it is still upon the cylinder; allow the steam to blow for a moment through the indicator-cylinder, and then turn attention to the piston, spring, and all movable parts, which must be thoroughly wiped, oiled, and cleaned. Particular attention should be paid to the springs, as their accuracy will be impaired if they are allowed to rust; and great care should be exercised that no gritty substance be introduced to cut the cylinder or scratch the piston. Be careful never to bend the steel bars or rods.

399. Care of the Indicator.—The steam-engine indicator is a delicate instrument, and its accuracy is liable to be impaired by rough usage. It must be handled with care, kept clean and bright; its journals must be kept oiled with suitable oil. It must be kept in adjustment. In general, all screws can be turned by hand sufficiently tight, and no wrench should be used to connect or disconnect it. Never use lead on the connections. Before using it, take it apart, clean and oil it. Try each part separately. See if it works smoothly; if so, put it together without the spring. Lift the pencil-lever, and let it

fall; if perfectly free, insert the spring as explained, and see that there is no lost motion; oil the piston with cylinder-oil, and all the bearings with nut or best sperm-oil. Give it steam, but do not attempt to take a card until it blows dry steam through the relief. If the oil from the engine gums the indicator, always take it off and clean it. After using it remove the spring, dry it and all parts of the indicator, then wipe off with oily waste. Fasten the indicator in its box, in which it will go, as a rule, only one way, but it requires no pounding to get it properly in place; carefully close the box to protect it from dust.

## CHAPTER XVII.

## THE INDICATOR-DIAGRAM.

400. Definitions.—The indicator-diagram is the diagram taken by the indicator, as explained in Article 378, page 459.

In the diagram the ordinates correspond to the pressures per square inch acting on the piston, the abscissæ to the travel




Fig. 201.—Diagram from an Improved Greene Engine. Cylinder, 16 Inches in Diameter, 36 Inches Stroke. Boiler-pressure, 100 lbs. 80 Revolutions per minute. Scale, 50.

of the piston. During a complete revolution of an engine occur four phases of valve-motion which are shown on the indicator-diagram, viz.: admission, CDE, when the valve is open and the steam is passing into the cylinder; expansion, EF, when steam is neither admitted nor released and acts by its

expansive force to move the piston; exhaust, FGH, when the admission-port is closed and the exhaust opened so that steam is escaping from the cylinder; and compression, HC, when all the ports are closed and the steam remaining in the cylinder acts to bring the piston to rest.

The Atmospheric Line, AB, is a line drawn by the pencil of the indicator when the connections with the engine are closed and both sides of the piston are open to the atmosphere. This line represents on the diagram the pressure of the atmosphere, or zero gauge-pressure.

The Vacuum Line, OK, is a reference-line drawn a distance corresponding to the barometer-pressure (usually about 14.7 pounds) by scale below the atmospheric line. It represents a perfect vacuum, or absence of all pressure.

The Clearance Line, OY, is a reference-line drawn at a distance from the end of the diagram equal to the same per cent of its length as the clearance or volume not swept through by the piston is of the piston-displacement. The distance between the clearance line and the end of the diagram represents the volume of the clearance of the ports and passages at the end of the cylinder.

The Line of Boiler-pressure, JK, is drawn parallel to the atmospheric line, and at a distance from it by scale equal to the boiler-pressure shown by the gauge. The difference in pounds between it and DE shows the loss of pressure due to the steam-pipe and the ports and passages in the engine.

The Admission Line, CD, shows the rise of pressure due to the admission of steam to the cylinder by opening the steamvalve. If the steam is admitted quickly when the engine is about on the dead-centre, this line will be nearly vertical.

The Point of Admission, C, indicates the pressure when the admission of steam begins at the opening of the valve.

The Steam Line, DE, is drawn when the steam-valve is open and steam is being admitted to the cylinder.

The Point of Cut-off, E, is the point where the admission of steam is stopped by the closing of the valve. It is difficult to determine the exact point at which the cut-off takes place.

It is usually located where the outline of the diagram changes 'its curvature from convex to concave. It is most accurately determined by extending the expansion line and steam line so that they meet at a point.

The Expansion Curve, EF, shows the fall in pressure as the steam in the cylinder expands doing work.

The Point of Release, F, shows when the exhaust-valve opens.

The Exhaust Line, FG, represents the change in pressure that takes place when the exhaust-valve opens.

The Back pressure Line, GH, shows the pressure against which the piston acts during its return stroke. On diagrams taken from non-condensing engines it is either coincident with or above the atmospheric line, as in Fig. 201. On cards taken from condensing engines it is found below the atmospheric line, and at a distance greater or less according to the vacuum obtained in the cylinder.

The Point of Exhaust Closure, H, is the point where the exhaust-valve closes. It cannot be located very definitely, as the first slight change in pressure is due to the gradual closing of the valve.

The Point of Compression, H, is where the exhaust-valve closes and the compression begins.

The Compression Curve, HC, shows the rise in pressure due to the compression of the steam remaining in the cylinder after the exhaust-valve has closed.

The Initial Pressure is the pressure acting on the piston at the beginning of the stroke.

The Terminal Pressure is the pressure above the line of perfect vacuum that would exist at the end of the stroke if the steam had not been already released. It is found by continuing the expansion curve to the end of the diagram, as in Fig. 201. This pressure is always measured from the line of perfect vacuum, hence it is the absolute terminal pressure.

Admission Pressure is the pressure acting on the piston at end of compression, and is usually less than initial pressure.

Compression Pressure is the pressure acting on the piston at beginning of compression; this is also the least back pressure.

Cut-off Pressure is the pressure acting on the piston at beginning of expansion.

Release Pressure is the pressure acting on the piston at end of expansion.

Mean Forward Pressure is the average height of that part of the diagram traced on the forward stroke.

Mean Back Pressure is the average height of that part traced on the return stroke.

Mean Effective Pressure (M. E. P.) is the difference between mean forward and mean back pressure during a forward and return stroke. It is the length of the mean ordinate intercepted between the top and bottom lines of the diagram multiplied by the scale of the diagram. It is obtained without regard to atmospheric or vacuum lines.

Ratio of Expansion is the ratio of the volume of steam in the cylinder at end of the stroke, compared with that at cutoff. In computations for this quantity the volume of clearance must be taken into account. Ratio of expansion is denoted by r. For hyperbolic expansion, p being pressure in pounds per square foot at cut-off, and v the corresponding total volume, the work done per stroke and per square inch of area  $= pv(1^p + Hy \log r)$ .


The volume may be expressed as proportional to linear feet, with an additional length equal to the per cent of clearance, since the area of the cylinder is constant. The product of pressure per square foot into total volume is a constant quantity for hyperbolic expansion. The ratio of expansion is the reciprocal of the cut-off measured from the clearance line. This cut-off is distinguished from that shown directly on the card by designating it as the absolute cut-off.

Initial Expansion is the fall of pressure during admission, due to an imperfect supply of steam.

Wire-drawing is the fall of pressure between the boiler and cylinder; it is usually indicated by initial expansion.

401. Measurement of Diagrams.—The diagrams taken are on a small scale, they are often irregular, and the boundary lines are frequently obscure, so that the measurement must be made with great care.

The diagrams may be taken from each end of the cylinder on a separate card, as shown in Fig. 201; or by the use of the three-way cock (see Article 398), in which case the two diagrams will be drawn on the same card as shown in Fig. 202. In the latter case each diagram is to be considered separately; that is, the area of each diagram, as CDEBFC and GHIJKG, is to



be determined as though on a separate card. The object of diagram-measurements is principally to obtain the mean effective pressure (M. E. P.).

Two methods are practised.


First, the *method of ordinates*. In this case the atmospheric line AB is divided into ten equal spaces, and ordinates are erected from the centre of each space. The sum of the length of these various ordinates divided by the number gives the mean ordinate. This multiplied by the scale of the diagram gives the mean effective pressure. The sum of the ordinates is expeditiously obtained by successively transferring the length of each ordinate to a strip of paper and measuring its length.

Secondly, with the planimeter. The planimeter gives the mean ordinate much more accurately and quickly than the

method of ordinates. The various planimeters are fully described, pages 26 to 49.

With any planimeter the area of the diagram can be obtained, in which case the mean ordinate is to be found by dividing by the length of the diagram. Several of the planimeters give the value of the mean ordinate, or M. E. P., directly.

In some instances the indicator-diagram has a loop, as in Fig. 203, caused by expanding below the back-pressure line; in this case the ordinates to the loop are negative and should be



subtracted from the lengths of the ordinates above. In case of measurement by the planimeter, if the tracing-point be made to follow the expansion-line in the order it was drawn by the indicator-pencil, the part within the loop will be circumscribed by a reverse motion, and will be deducted automatically by the instrument, so that the reading of the planimeter will be the result sought.

402. Indicated Horse-power.—Indicated horse-power is the horse-power computed from the indicator-diagram, being obtained by the product of M. E. P. (p), length of stroke in feet (l), area of piston in square inches (a), and number of revolutions (n), as represented in the formula  $plan \div 33,000$ . In this computation the area on the crank side of the piston is to be corrected for area of piston-rod, and the two ends of the cylinders computed as separate engines. Further, in this computation, it will not in general answer to multiply the average M.E.P. of a number of cards by the length of stroke and by the

average of the number of revolutions, but each card must be subjected to a separate computation and the results averaged. This can be readily done for each engine by computing a table made up of the products of the average value of n by length of stroke and area of piston, and for different values of M. E. P. from 1 to 10. Take from this table the values corresponding to the given M. E. P., increase or diminish this as required by the per cent of change of speed from the average. A very convenient table for this purpose, entitled "Horse-power per Pound, Mean Pressure," is given in the Appendix to this work, arranged with reference to diameter of cylinder in inches and piston-speed in feet per minute.

403. Form of the Indicator-diagram.—The form of the indicator-diagram has been carefully worked out for the ideal case by Rankine and Cotterell.\* In the ideal case the steam works in a non-conducting cylinder, and all loss of heat is due to transformation into work, the expansion in such a case being adiabatic. In the actual case the problem is much more complicated, since a large portion of the heat is utilized in heating the cylinder, and is returned to the steam at or near the time of exhaust, doing little work. It is found, however, in the best engines working with quick-acting valve-gear, that the steam and back-pressure lines are straight and parallel to the atmospheric line, and that the expansion and compression lines are very nearly hyperbolæ, asymptotic to the clearance line and to the vacuum line.

If we denote by p the pressure measured from the vacuum line, and by v the volume corresponding to a distance measured from the clearance line, so that pv shall be the co-ordinates of any point, we shall have as characteristic of the hyperbola

pv = constant.

This is the same as Mariotte's law for the expansion of noncondensible gases, since, according to that law, the pressure varies inversely as the volume.

<sup>\*</sup> Steam-engine, by James H. Cotterell.

Rankine found by examination of a great many actual cases that the expression  $pv^{\dagger}$  = constant agrees very nearly with the ideal case of adiabatic expansion. The variation from the ideal expansion line in any given case may be considerable, and the hyperbola drawn from the same origin is considered as good a reference-line as any that can be used, and the student should become familiar with the best methods of constructing it.

404. Methods of Drawing an Hyperbola.—The methods of drawing an hyperbola, the clearance and vacuum lines being given, are as follows:

First Method. (See Fig. 204.)—CB, the clearance line, and CD, the vacuum line, being given, draw a line parallel to the




FIG. 204.-METHOD OF DRAWING AN HYPERBOLA.

atmospheric line through B; find by producing the steam and expansion lines the point of cut-off, c. Draw a series of radiating lines from the point C to the points E, F, G, H, and A, taken at random, and a line cb intersecting these lines, drawn from c parallel to BC. From the points of the intersection of cb with these radiating lines draw horizontal lines to meet vertical lines drawn from the points E, F, G, H, and

A; the intersections of these lines at e, f, g, h, and a are points in the hyperbola passing through the point c. If it is desired to produce the hyperbola from a upward, the same method is used, but the line AB is drawn through the point a, and the vertical lines are extended above AB instead of below.

Second Method. (See Fig. 205.)—The hyperbola may be drawn by a method founded on the principle that the intercepts made by a straight line intersecting an hyperbola and its asymptotes are equal. Thus if abcd represent an hyperbola, BC and CD its asymptotes, then the intercepts aa' and bb' made by the straight line a'b' are equal.

To draw the hyperbola: Beginning at any point, as a, draw




Fig. 205.-Method of Drawing an Hyperbola.

the straight line a'b', and lay off from the line CD b'b, equal to a'a; then will b be one point in the hyperbola. Draw a similar line c'a' through b, making d'c equal c'b; then will c be another point in the hyperbola. This process can be repeated until a suitable number of points is found; the hyperbola is to be drawn through these points. A similar method can be used to draw the hyperbola EF.

405. Construction of Saturation and Adiabatic Curves.

—The saturation curve of steam is represented almost exactly by the equation  $pv^{ij} = a$  constant. This is the curve whose

volumes and pressures correspond to those given in the steamtables; no doubt the easiest way to construct such a curve is to take the volumes from the steam-tables corresponding to given pressures and set them off along the volume axis; lay off the corresponding pressures as ordinates; then a curve drawn through the extremities of the ordinates will be the expansion curve, which, as the form of the equation shows, does not differ greatly from an hyperbola.

The adiabatic curve, or that corresponding to neither gain nor loss of heat, is expressed approximately by proveconstant,\* and differs somewhat more from the hyperbola than the saturation curve.

Any of the exponential curves which are represented by the equation  $pv^* = p_1v_1^* = p_2v_2^*$  can be drawn as follows:

From the above expression

$$n \log v + \log p = n \log v_1 + \log p_1,$$

from which

$$\log p = n \log v_1 + \log p_1 - n \log v;$$

from which, if u,  $v_1$ , and v are known, p may be determined. The values of n are as follows:


```
Equilateral hyperbola, n = 1;
Saturation curve—steam, n = \frac{17}{16} = 1.0646;
Adiabatic curve—steam, n = 1.035 + 0.14;
"gas, n = 1.408;
Isothermal "n = 1.0.
```

These three expansion curves are represented in Fig. 206; the pressures from 0 to 90 pounds per square inch are represented by the ordinates, and the volumes in cubic feet corresponding to one pound in weight are represented by abscissæ

<sup>\*</sup> Rankine's Steam-engine, page 385.

<sup>+</sup> See Thurston's Engine and Boiler Trials, page 251.

In the figure the curve A to G is the hyperbola, A to I the saturation curve, and A to L the adiabatic curve. ON is the axis of the hyperbola, of which OB and OH are asymptotes. It is to be noticed that the saturation curve corresponds to a uniform quality of steam, the adiabatic curve to a condition in which the moisture is increasing, and the hyperbolic curve



FIO. 206,-THE THREE EXPANSION CURVES.

to a condition in which the moisture is decreasing, the latter agreeing more closely with the actual condition.

406. Weight of Steam from the Indicator-diagram.—
The diagram shows by direct measurement the pressure and volume at any point in the stroke of the piston; the weight per cubic foot for any given pressure may be taken directly from a steam-table. The method, then, of finding the weight of steam for any point in the stroke is to find the volume in cubic feet, including the clearance and piston displacement to the given point, which must be taken at cut-off or later, and multiply this by the weight per cubic foot corresponding to the pressure at the given point as measured on the diagram. This will give the weight of steam in the cylinder accounted for by the indicator-diagram, per stroke. In an engine working with compression, the weight of steam at terminal pressure

filling the clearance-space is not exhausted; this weight, computed for a volume equal to clearance and with weight per cubic foot corresponding to admission pressure, should be subtracted from the above. This may be reduced to pounds of steam per I. H. P. per hour, by multiplying by the number of strokes required to develop one horse-power per hour of time.

The method of computing would then be: Find the weight per cubic foot, from a steam-table corresponding to the absolute pressure, at the given point, multiply this by the corresponding volume in cubic feet, including clearance, and this by the number of strokes per hour. The result will be the weight of steam per hour. Divide this by the horse-power developed, and we shall have the consumption in pounds of dry steam per I. H. P. Thus let

```
A = area of piston in square feet;

a = """"" inches;

N = number of strokes per hour;

n = """ minute;

w = weight of cubic foot of steam at the given pressure;

l = total length of stroke in feet;

l = length of stroke in feet to point under consideration;

l = per cent of clearance; l' = l_a + cl.
```

Then the consumption of dry steam in pounds per hour per horse-power,

$$S = \frac{NAl'w}{\text{H. P.}} = \frac{60n\frac{a}{144}(l_a + cl)w}{\frac{plan}{33,000}} = 13,750\frac{w(l_a + cl)}{p}. \quad (1)$$

Some of the steam may be restored by compression, reducing the results given in equation (1).

As an example: Compute the steam consumption as shown in Fig. 201 at point of cut-off E and at terminal pressure.

The absolute pressure shown by the diagram is \$7\$ pounds at cut-off and 37 at end of the stroke.

The length of stroke total is 3 feet, at cut-off is  $\frac{3}{4}$  foot. Clearance is 3.2 per cent. M. E. P. (p) is 50 pounds. Steam consumption at Cut-off.—From steam-table  $\frac{3}{4}$  =0.2208.

$$S = 13,750 \frac{(0.2208)(0.75+0.09)}{50} = 17.15$$
 lbs. per I.H.P. per hour.

Steam-consumption at End of Stroke.—From steam-table w = 0.0896.

$$S = 13,750 \frac{(0.2208)(3 + 0.09)}{50} = 20.5$$
 lbs. per I. H. P. per hour.

This, it should be noticed, is not the actual weight of steam used per horse-power by the engine, but is that part which is shown from the amount of dry steam remaining in the cylinder at the points under consideration. The amount is usually less when computed at cut-off than at the end of the stroke, since some of the steam which was condensed when the steam first entered the cylinder is restored by evaporation during the latter portion of the period of expansion. The correction factor for the steam restored by compression can be calculated graphically by drawing a line parallel to the atmospheric line. through the point for which the steam-consumption was calculated, to an ordinate through the point of admission. The ratio of the part between expansion and compression curves to the whole line is the factor which is to be multiplied by the previous results to give the consumption of steam per I. H. P. per hour. In the examples considered above this factor is unity.

If we consider the steam-consumption only for the end of the stroke,  $l_a$  of equation (1) becomes equal to  $l_a$ , and the equation reduces to the following form:

Neglecting the clearance,

$$S_t = 13,750 \frac{w}{p}; \quad . \quad . \quad . \quad . \quad . \quad . \quad (3)$$

in which p = the M. E. P. of the diagram, and w the weight per cubic foot corresponding to the terminal pressure. Formula (3) has been tabulated as follows:

Thompson's tables, given in the Appendix, give values of 13,750w, and the tabular values must be divided by the M. E. P. to give the steam-consumption per I. H. P. per hour.

Tabor's tables give values of  $\frac{13,750}{p}$ , and the tabular values must be multiplied by the weight of a pound of steam corresponding to the terminal pressure, to give the steam-consumption.


Williams's tables, published in the Crosby catalogue, give values of  $\frac{p}{425.43}$ , and the results in each case have to be multiplied by 32.32w to give the steam-consumption.

A graphical correction is made in all cases for compression by drawing a horizontal line through the terminal pressure to compression line of diagram, and multiplying the result given in the table by the ratio of the portion of this line intercepted between terminal point and compression, to the whole stroke.

407. Clearance Determined by the Diagram.—The clearance is usually to be determined by actual measurement of the volume of the spaces not swept through by the piston, and comparing this result with the volume of piston-displacement, the ratio being the clearance. Since the expansion and compression lines of the diagram are nearly hyperbolæ, the clearance line can be drawn by a method nearly the reverse of that used in constructing an hyperbola (Article 404).

In this case proceed as follows: Lay off the vacuum line CD (Fig. 207) parallel to the atmospheric line FT, and at a distance corresponding to the atmospheric pressure. The position of the clearance line can be determined by two methods, corresponding to those used in drawing the hyperbola. First

method: Take two points, a and b in the expansion curve and c and d in the compression line, and draw horizontal and vertical lines through these points, forming rectangles aa'bb' and cc'dd'. Draw the diagonal of either rectangle, as a'b', to meet the vacuum line CD: the point of intersection C will be



a point in the clearance line CB, and the clearance will equal  $CN \div FT$ . Second method: Draw a straight line through either curve, as mn through the compression curve or ef through the expansion curve, and extend it in both directions. On the line m'n' lay off nn' equal to mm', or on the line e'f' lay off ee' equal to ff'; then will either of the points e' or n' be in the clearance line and the line drawn perpendicular to the vacuum line through either of these points is the clearance line. In an engine working with much compression the clearance will be given more accurately from the compression curve than from the expansion curve, since it is more nearly an hyperbola.

408. Re-evaporation and Cylinder Condensation.—By considering the hyperbolic curve as a standard, an idea can be obtained of the restoration by re-evaporation and the loss by

cylinder condensation. Thus in Fig. 208, suppose that a is the point of cut-off at boiler-pressure, construct an hyperbola as explained; in the example considered it is seen to lie above the expansion line for a short distance after cut-off, then to cross the line at b, and remain below it nearly to the end of the stroke. The amount by which the expansion line rises above the hyperbola may be considered as due to re-evaporation. The area of the diagram lying above would represent the work added by heat returned to the steam from the cylinder.

The methods for determining the cylinder condensation are




FIG. 208.—WORK RESTORED BY RE-EVAPORATION.


similar to this process, except that the hyperbola is usually drawn upward from the point corresponding to the terminal pressure, to meet a horizontal line drawn to represent the boiler-pressure, as follows:

This construction is shown by the dotted lines in the diagrams in Fig. 209. The area of the figure enclosed by the dotted lines, compared with that of the diagram, is the ratio that the ideal diagram bears to the real; the difference is the loss by cylinder condensation.

The student should understand that both these methods are approximations which may vary much from the truth.

409. Discussion of Diagrams.—Diagrams are often taken

where some portion of the engine is out of adjustment, or the indicator or reducing motion is not in perfect order. It is often



PIO. 209.-LOSS BY CYLINDER-CONDENSATION.

possible in such cases to determine the defect from the diagram, and to suggest the proper remedy. A few examples are submitted. Such examples could be multiplied indefinitely, and skill and experience will, in general, be required to prop-





FIG. 210.—UNSYMMETRICAL VALVE-SETTING.

erly interpret them. Thus Fig. 210 is an illustration of a diagram taken when the valves were set unsymmetrically. Curves or waves in the expansion or compression lines indicate inertia-

effects in the drum-motion, which is sometimes sufficient to make the compression line concave when it should be convex, as shown in the lower diagram of Fig. 211. Vertical curves are due in large measure to vibrations in the pencil-lever and indicator-spring; they are usually excessive with a light spring and high speed. In the case of an automatic engine running under variable loads, each revolution will show a different diagram, as shown in Fig. 211.



Different Forms of Admission-lines.—The form of the admission-line is changed \* according to the relative time of valve-opening and position of piston in its stroke.

The normal form is shown at A. In BCD and E the valve opens late, and after the piston has started on its return stroke. In F and G the exhaust-valve closes late, so that live steam escapes. H and I are familiar examples of extreme compression, produced on high-speed automatic engines working with a light load. J shows a sharp corner above the compression

<sup>\*</sup> Power, September 1891.

line, and in general indicates too much lead. In case the valve opens too early, the admission-line leans as at K.

410. Diagrams from Compound and Triple-expansion Engines.—The diagram from any cylinder of a compound or triple-expansion engine is not likely to differ in any noticeable





FIG. 212.—TYPICAL ADMISSION-LINES.

particular from those taken from a simple engine as already described. They are usually taken with different springs for the different cylinders, but may have very nearly or exactly the same lengths.

The diagrams from a compound engine may be reduced to an equivalent diagram, taken from a single cylinder by the following method: Lay off a vertical line OB, and a horizontal line PQ. Let PQ be the vacuum line, and BC the line of

highest steam-pressure acting in the small cylinder. Lay off ON proportional to the volume of the small cylinder, and OP proportional to the volume of the large cylinder. Let FA be the line of back pressure of the large cylinder, AD that of the small cylinder: then BCDA is the diagram from the small cylinder, EKFA that from the large cylinder.

To combine them into one diagram, draw a line KGH parallel to POQ, intersecting both diagrams, and lay off upon it HL = KG; and GL = GH + KG represents the total volume



in both cylinders when the pressure is OG, and L is a point in the expansion line the same as though the action took place in the large cylinder only. In the same way other points may be found, and the line CDLM drawn. This diagram may be discussed as if it represented the steam acting in the large cylinder only.

Fig. 214 is a combined diagram from a triple-expansion engine,\* in which the cylinders have the ratio of 1:2.25:2.42, and the total ratio of expansion is 8. The length of each diagram is made proportional to the total volume of the cylinder from which it was taken; the diagrams are all drawn to the same scale of pressures, and each is located at a distance from a vertical line proportional to the volume of its clearance. From the point of cut-off corresponding to boiler-pressure an hyperbola is drawn as has been explained, and the area surrounding the diagrams is shaded. The work done in the three cylinders can be computed from the diagram as though done in one only.

<sup>\*</sup> See Thurston's Engine and Boiler Trials, page 202.

411. Crank-shaft and Steam-chest Diagrams.—Diagrams may be taken with the motion of the indicator-drum proportional to any moving part of the engine, as for instance the crank-shaft.






FIG. 214.—COMBINED DIAGRAM FROM TRIPLE-EXPANSION ENGINE.

In such a case, shown by Fig. 215, the ordinates will be as before proportional to the pressures per square inch acting on the piston, but the abscissæ will correspond to distances moved



through by the crank-pin. In Fig. 215 A to B is the exhaust, from B to C compression, D to E steam line, E to A expansion. Diagrams may also be taken with the indicator mounted on the valve-chest; in this case the indicator would show variation in pressure in the steam-chest.



## CHAPTER XVIII.

#### METHODS OF TESTING THE STEAM-ENGINE.

- 412. Various Efficiencies of the Steam-engine.\*—The efficiency of the steam-engine is frequently expressed in various manners, as follows:
- I. Thermodynamic efficiency. This is the ratio of work done by the working substance to the mechanical equivalent of the heat expended on it to do that work. In the perfect engine-cycle this efficiency is measured by the quantity  $\frac{T_1 T_2}{T_1}$ , the range of temperature worked through divided by the maximum initial absolute temperature of the fluid entering the cylinder of the engine.
- 2. Actual efficiency of working substance. This is here considered to be the ratio of the heat transformed into work to the total available heat entering the system. If there were no losses of heat except those due to work, the efficiency of the working substance would be 1.00, but radiation, the cooling effect of the cylinder, etc., cause losses which vary with different working substances and in different cylinders.
- 3. Mechanical efficiency. This is the ratio of the work done on the piston to that delivered, or that of I.H.P. to D.H.P.
- 4. Efficiency of the engine. This is the ratio of the work actually done to the mechanical equivalent of the heat expended; it should equal the product of the efficiencies of the various parts.
  - 5. Plant efficiency. This is the product of the several

<sup>\*</sup> See "Manual of the Steam-engine," by R. H. Thurston, Vol. I., page 706.

efficiencies of the various parts or machines which compose the plant.

Fuel and Water Consumption of Ideal and Real Engines.—
The ordinary standard of comparison of the work done by different engines is the fuel and water consumed for each horse-power per hour. The horse-power is equal to 33,000 foot-pounds per minute, or 1,980,000 per hour, which is equivalent to 42.4 B. T. U. per minute, or 2544 units per hour. Since in steam of ordinary pressure there are about 1150 B. T. U. per pound above 32° Fahr. in a perfect engine, with efficiency equal to 1, the water-consumption would be 2.2 to 2.25 pounds per horse-power per hour. The weight of coal under the best conditions would be about one tenth the water-consumption, or from 0.2 to 0.22 pound per horse-power per hour.

The several efficiencies of the *real engine* are much less than unity in each case. Thus in the best engine the thermodynamic efficiency is about 0.2, the efficiency of the working substance from 0.9 to 0.75, and of the machine about 0.95. So that the total efficiency of the best real engine would be

$$E = 0.20 \times 0.90 \times 0.95 = 0.17.$$

This would mean a consumption per I.H.P. per hour of

$$\frac{2,544}{0.17}$$
 = 14,940 B. T. U.;  
 $\frac{2.2}{0.17}$  = 12.94 pounds of water;  
 $\frac{0.22}{0.17}$  = 1.29 pounds of fuel.

413. Objects of the Engine-test.—The test may be made: 1. To adjust the valves or working parts of the engine.
2. To determine the indicated or dynamometric horse-power.
3. To ascertain the friction for different speeds or conditions.
4. To determine the consumption of fuel or steam per horse-power per hour.
5. To investigate the heat-changes which

characterize the passage of the steam through the engine. The general method of the test will depend largely on the object for which the test is made; in any event the apparatus to be used should be carefully calibrated, the dimensions of the engine obtained, and the test conducted with care.

414. Measurements of Speed.—The various instruments employed for measurement of speed are speed-indicators, tachometers, continuous counters, and chronographs.

Where the number of revolutions only is required, it is usually obtained either by counting or by the hand speed-indicator. Counting can be done quite accurately without an




FIG. 217 .- DOUBLE-ENDED SPEED-INDICATOR.

instrument, by holding a stick in the hand in such a position that it is struck by some moving part, as the cross-head of an engine, once in each revolution. The hand speed-indicator, of which one form is shown in Fig. 217, consists of a counter operated by holding the pointed end of the instrument in the end of the rotating shaft. In using the instrument, the time is noted by a watch at the instant the counting gears are put in operation or are stopped. A stop-watch is very convenient for obtaining the time. The errors to be corrected are principally those due to slipping of the point on the shaft, and to the slip of the gears in the counting device in putting in and out of operation. The best counters have a stop device to prevent this latter error, and the gears are engaged or disengaged with



the point in contact with the shaft. To prevent slipping of the point, the end of the instrument is sometimes threaded and screwed into a hole in the end of the shaft.

The continuous counter consists of a series of gears arranged to work a set of dials which show the number of revolutions. The arrangement of gearing in such an instrument is shown in Fig. 218. The instrument can usually be made to register by either rotary or reciprocating motion, and can be had in a




FIG. 218.

square or round case. The reading of the counter is taken at stated intervals and the rate of rotation calculated.

Tachometers (see Fig. 219) are instruments which utilize the centrifugal force in throwing outward either heavy balls or a liquid. The motion so caused moves a needle a distance proportional to the speed, so that the number of revolutions is read directly from the position of the needle on the graduated dial. The tachometer is arranged with a pointed end to hold against the shaft whose speed is to be determined, or with a pulley so that it may be driven by a belt.

Brown's Speed-indicator consists of a U-shaped tube joined to a straight tube in the centre. The revolution of the U-tube around the centre tube induces a centrifugal force which ele-



FIG. 219 .- SCHAEFFER AND BUDENBERG HAND TACHOMETER.

vates mercury in the revolving arms and depresses it in the centre tube. A calibrated scale gives the number of revolutions corresponding to a given depression.

415. The Chronograph.—The chronograph,\* Fig. 220, consists of a drum revolved by clock-work so as to make a




FIG. 220.

definite number of revolutions per minute. A carriage having one or two pens, h, g, as may be required is moved parallel

<sup>\*</sup> See Thurston's Engine and Boiler Trials, page 226.

to the axis of the cylinder by a screw which is connected with the chronograph-drum A by gearing.

The pen in its normal condition is in contact with the paper, and it is so connected to an electro-magnet that it is moved axially on the paper whenever the circuit is broken. The circuit may be broken automatically by the motion of a clock, or by hand with a special key, or by any moving mechanism. Two pens are usually employed, one of which registers automatically the beats of a standard clock; the other may be arranged to note each revolution or fraction of a revolution of a revolving shaft. The distance between the marks made by the clock gives the distance corresponding to one second of time; the distance between the marks made by breaking the circuit at other intervals represents the required time which is to be measured on the same scale.

This instrument has been in use by astronomers for a long time for minute measurements of time, and by its use intervals as short as one one-hundredth (.01) part of a second can be measured accurately.

Tuning-fork Chronograph.—A tuning-fork emitting a musical note makes a constant and known number of vibrations. The number of vibrations of the fork corresponding to the musical tones are as follows:

If now a small point or stylus be attached to one of the arms of a tuning-fork, as shown in Fig. 221,\*—in which F is one of the arms of the tuning-fork, and CAED a piece of elastic metal to which the stylus, AP, is attached,—and if the fork be put in vibration and the stylus permitted to come in contact with any surface that can be marked, as a smoked and varnished cylinder moved at a uniform rate, the vibrations of the tuning-fork will be recorded on the cylinder by a series of wavy lines, as shown in Fig. 223; the distance between the

<sup>\*</sup> See Thurston's Engine and Boiler Trials, page 233.

waves corresponding to known increments of time. If each revolution or portion of a revolution of the shaft whose speed

is required be marked on the cylinder, the distance between such marks, measured to the same scale as the wavy lines made by the tuning-fork, would represent the time of revolution.

Fig. 222 (from Thurston's Engine and Boiler Trials) represents the Ranson chronograph; in this case the tuning-fork is moved axially by a carriage operated by gears, and is kept in




FIG. 221.—STYLUS FOR TUNING—FORK.

vibration by an electro-magnet. The operation of the instrument is the same as already described. The form of the record being shown in Fig. 223; the wavy marks being those




FIG. 222.-TUNING-FORK CHRONOGRAPH.

made by the tuning forks, those at right angles being made at the end of a revolution of the shaft whose speed is required.

The tuning fork with stylus attached,\* as in Fig. 222, can be made to draw a diagram on a revolving cylinder connected

<sup>\*</sup> See Engine and Boiler Trials, page 234.

directly to the main shaft of the engine, or the shaft itself may be smoked and afterward varnished. If the fork be moved axially at a perfectly uniform rate, the development of the lines drawn will be for uniform motion, straight and of uniform pitch; but for variations in speed these lines will be




FIG. 223.-SPEED-RECORD FROM CHRONOGRAPH.

curved and at a varying distance apart. From such a diagram the variation in speed during a single revolution can be determined.

- 416. Autographic Speed-recorder.—Variations in speed are shown autographically in several instruments by recording on a strip of paper moved by clock-work the variation in centrifugal force of revolving weights. In the Moscrop speed-recorder, shown in Fig. 224, the shaft B is connected with the shaft whose speed is to be measured. The variation in the height of the balls near B, caused by variation in speed, gives the arm C a reciprocating motion, so that an attached pencil makes a diagram, FED, on the strip of paper moved by clockwork. The ordinates of this diagram are proportional to the speed.
- 417. The Surface Condenser.—In the measurement of the steam used by the engine the surface condenser is frequently employed. The surface condenser usually consists of a vessel in which are a great many brass tubes. It is usually arranged so that the exhaust steam comes in contact with the outer surface of these tubes, and the condensing water flows through the tubes. The condensed steam falls to the bottom of the condenser and is removed by an air-pump; the heat of the steam being taken up by the condensing water. If the condenser is free from leaks, the air-pump of ample size and with little clearance, and if the proper temperatures are main-

tained, nearly all the atmospheric pressure can be removed from the condenser and the back-pressure on the engine correspondingly reduced.

The surface condenser affords more accurate means of




FIG. 224.-THE MOSCROP SPEED-RECORDER.

obtaining the water-consumption of a steam-engine than the measurement of feed-water during a boiler-test, since the effect of steam-leaks are to a great extent eliminated.

The condenser should be tested for leaks by noting how

long a given reading of the vacuum-gauge can be maintained when all the connecting valves are closed, or by turning on steam when the water-pipes are empty, or *vice versa*, and noting whether there is any leakage.

#### FORM FOR TEST ON CONDENSER.

Date	
Duration of test	min.
Barometerlbs. per	r sq. ia.
Temperature, entering steam	F.
Temperature, condensed steam	F.
Temperature, cold condensing waterC.	F.
Temperature, hot condensing water	F.
Hook-gauge reading (corrected)	. inches.
(Hook-gauge reading)	· · · · · ·
Temperature at weir	F.
Weight of condensed steam	lbs.
Breadth of weir	.inches.
End area oftubes	sq. ft.
Area steam surface	sq. ft,
Area water surface	sq. ft.
Weight steam condensed per hour	lbs.
Weight condensing water used per hour	lbs.
Weight steam condensed per pound of water	lbs.
Weight steam condensed per sq. ft. steam surface per hour	lbs.
Weight steam condensed per sq. ft. water surface per hour	lbs.
Velocity of water through tubesft.	per sec.
Heat acquired by condensing water used per hourB	. T. U.
Heat given up by steam condensed per hour	. T. U.
Signed	••

418. Calibration of Apparatus for Engine-testing.— Before commencing any important test, all instruments and apparatus to be used should be adjusted and carefully compared with standards, under the same conditions as in actual practice. The errors or constants of all instruments should be noted in the report of the test, and corresponding corrections made to the data obtained.

The instruments to be calibrated are:

- 1. Steam-gauge.—Compare with mercury column, or with standard square-inch gauge, for each five pounds of pressure, reading both up and down throughout the range of pressures likely to be used in the test. (See Article 282, page 338.)
- 2. Steam-engine Indicator-springs.—Put the indicator under actual steam-pressure (see Art. 393, p. 479) and compare the length of ordinate of the card with the reading of the mercury column or a standard gauge for the same pressure. Take ten readings, both up and down, through an extreme range equal to two and one-half times the number on the spring. The steam-pressure may be varied by throttling the supply and exhaust. The ordinate may also be compared by a special method with readings of a standard scale; the indicator being heated by the flow of steam through a rubber tube wound around it.
- 3. Speed-indicators.—The accuracy can be checked by hand counting. For the best work chronographs should be used. Continuous counters are necessary for accuracy in a long run. (See Articles 414 and 415.)
- 4. Indicator Reducing-motion.—This may be tested by dividing the stroke of the engine on the guides into twelve equal parts and noting whether the card is similarly divided. It should be tested for both return and forward stroke. When the form of the card is considered, this is an important matter, as many reducing-motions distort its shape. (See Article 390, page 472.)
- 5. Indicator-cords and Connections.—See that the connecting cords do not stretch at high speeds, and that the drum-spring of the indicator has a proper tension and gives a correct motion of the drum. This is important. (See Article 395.)
- 6. Weighing-scales.—Compare the readings with standard weights.
- 7. Water-meters.—Calibrate by actually weighing the discharge under conditions of use as regards pressure and flow.

In case meters are used, temperatures of the water must be taken in order to obtain the weight. (See Article 213, page 255.)

- 8. Thermometers.—Test the thermometer for freezing-point by comparison with water containing ice or snow; test for boiling-point by comparison with steam at atmospheric pressure in the special apparatus described on page 352, the correct boiling-point being determined by readings of the standard barometer. The other tests of the thermometer can in general be left to the makers of the instrument. In cases where great accuracy is required the readings should be compared throughout the whole scale with a standard air-thermometer, as described on page 350.
- 9. Pyrometer.—Compare with a standard thermometer while immersed in steam for the lower ranges of temperature, and with known melting-points of metals for higher. The correction may also be determined by cooling heated masses of metals in large bodies of water and calculating the temperature from the known relations of specific heats. (See Articles 298 to 304).
- 10. The Planimeter, which is used for measuring the indicator-diagram, should be calibrated by making a comparison with a standard area, as explained in Article 38, page 44. The following form is useful to record the results of calibrations:

#### BLANK FORM FOR CALIBRATION OF INSTRUMENTS.

### STEAM-ENGINE INDICATOR-SPRINGS.

Used on	Head.	Crank.
Maker's name		
Maker's number		
Scale of spring		
Number of spring		
When tested		
How tested		
Per cent error		

#### STEAM-GAUGES.

Maker.	Position.	Number.	Error, lbs.	When Tested.	How Tested.

#### THERMOMETERS.

		Bolling-point.		Fre				
Position.	Registered Number.	Read- ing.	Per Ba- rometer.	Error.	Read- ing.	Error.	Barometer.	

- 419. Preparations for Testing.—The preparations required will depend largely on the object of the test. They should always be carefully made, and in general are to include the following operations:
- I. Weighing of Steam.—Prepare to weigh all the steam supplied the engine. This may be done by weighing or measuring all the feed-water supplied the boiler (see Article 375), provided there is no waste nor other use of steam; or it may be done by condensing (see Article 417) and weighing all the exhaust from the engine. In the first case especial precaution must be taken to prevent leaks, and in the latter to reduce the temperature of the condensed steam to 110° F. before weighing. The weights may in some cases be determined from a meter-reading (see Article 214).
- 2. Quality of Steam.—Attach a calorimeter (see Articles 330 to 336), which may be of the throttling or separator kind, to the main steam-pipe, near the engine. This attachment may be made by a half-inch pipe, cut with a long thread and extending three fourths across the main steam-pipe. This pipe

should be provided with large holes so that steam will be drawn from all parts of the main steam-pipe (see page 370).

- 3. Leaks.—The engine should be tested for piston-leaks by turning on steam with the piston blocked and cylinder-cocks opened on the end opposite that at which steam is supplied. If leaks are found, they should be stopped before beginning the test.
- 4. Indicator Attachments.—Arrange a perfect reducing-motion. The kind to be used will depend entirely upon circumstances. The lazy-tongs or pantograph is reliable for speeds less than 125, and can be easily applied. The pendulum pivoted above and furnished with an arc, although not perfectly accurate, is much used. Make yourself familiar with the various devices in use. (See Article 390).
- 5. An Absorption Dynamometer may be required; if so, arrange a Prony brake to absorb the power of the engine, and make provision for lubricating it and removing the heat generated (see Article 178, page 472). In many commercial tests the power is absorbed by machinery or in useful work, and the efficiency is wholly determined by measurements of the amount and quality of steam and from the indicator-diagram.
- 6. Weight of Coal.—This is generally taken during an enginetest, but will be treated here as pertaining to boiler-testing; the methods of weighing are fully described under that head (see Article 375).

An engine fitted completely for a test is shown in Fig. 216, from Thurston's Engine and Boiler Trials. In this case two indicators are employed, the drum-motion being derived from a pendulum reducing-motion; a Prony brake is attached to absorb and measure the power delivered, water for keeping the brake cool being delivered near the bottom and on the inside of the flanged brake-wheel by a curved pipe, and drawn out by another pipe the end of which is funnel-shaped and bent so as to meet the current of water in the wheel. The speed is taken by a Brown speed-indicator mounted on top of the brake, and also by a hand speed-indicator. The steam-pressure is measured

near the engine; the quality of steam is determined by a sample drawn from the vertical pipe near the engine.

420. Measurement of Dimensions of Engine.—Make careful measurements of the dimensions of engine; the diameter of piston, length of stroke, and diameter of piston-rod, as may be required.

Piston-displacement.—This is the space swept through by the piston; it is obtained by multiplying the area of the piston by the length of stroke. For the crank end of the cylinder the area of the piston-rod is to be deducted from the area of the piston.

Clearance is the space at the end of cylinder and between valve and piston, filled with steam, but not swept through by the piston. To measure the clearance, put the piston at end of its stroke and fill the space with a known weight of water, ascertaining that no leaks occur by watching with valve-chest cover and cylinder head removed. Make this determination for both ends of the cylinder, and from the known weight of water compute the volume required.

This is usually reduced to percentage, by dividing by the volume of piston-displacement.

This last reduction may be obviated, as suggested by Prof. Sweet, by finding, after the clearance-spaces are full of water, how far the piston will have to move in order to make room for an equal amount of water; this distance divided by the full stroke is the percentage required. Another approximate way sometimes necessary is to fill the whole cylinder and clearance-spaces with water; from this volume deduct the piston-displacement and divide by 2.

Preliminary Run.—It will be found advisable to make a preliminary run of several hours before beginning the regular test, to ascertain if all the arrangements are perfect.

421. Quantities to be observed.—The observations to be taken on a complete engine-test are given in the following list.

Fill out the following blank spaces.

# DESCRIPTION OF ENGINE. Kind of engine...... | Lap of valve.............inches.

Maker's name	Scale indicator-spring
Brake-armfeet.	Piston areasq. in
Diameter cylinder inches.	Steam-port area "
Length strokefeet.	Exhaust-port area "
Diameter piston-rodinches.	Diameter fly-wheelinches
Diameter crank-pin "	Clearance, headlbs. water
Length crank-pin "	" crank " "
Diameter wrist-pin	" per cent P.D. head
Travel valve "	" " " crank
LOG O	F TEST.
Number	Temperatures:
Time	Engine-room
Revolutions:	Condensed steam
Continuous counter	Feed-water
Speed-indicator	Injection-water
Gauge-readings:	Discharge-water
Boilerlbs.	Calorimeter:
Steam-pipe"	Steam-pipe
Steam-chest "	Steam-chest
Exhaustinches hg.	Weights:
Condenser " "	Condensed steam
Barometer " "	Feed-water
Temperatures:	.Injection-water
External air	Calorimeter

422. Special Engine-tests.—Preliminary Indicator Practice.—A simple test with the indicator will be found a useful exercise in rendering the student familiar with the methods of handling the indicator and of reducing and computing the data to be obtained from the indicator-diagrams. The directions are as follows:

Apparatus.—Throttling calorimeter; steam-gauge; two indicators; reducing-motion, and indicator-cord.

1. Obtain dimensions of engines. Measure the clearance; see that indicators are oiled and in good condition, and that

the reducing-motion gives a perfect diagram. Adjust the length of cord so that the indicator will not hit the stops. Prepare to take cards as explained in Article 398, page 486.

- 2. Take diagrams once in each five minutes, simultaneously from head and crank end of cylinder; take reading of boiler-gauge, barometer, gauge on steam-pipe or on steam-chest, vacuum-gauge if condenser is used, temperature or pressure of entering steam, temperature of room, and number of revolutions.
  - 3. Measure or weigh the condensed steam during run.
- 4. From the cards taken compute the M. E. P. and I. H. P. for each card as required by the log.
- 5. Take a sample pair of diagrams, one from head and one from crank end. (a) Find clearance from diagrams (see Article 407, page 503); (b) draw hyperbolæ respectively from cut-off and release and find re-evaporation and cylinder condensation (see Article 408); (c) produce hyperbola from release to meet horizontal line representing boiler-pressure; complete the diagram with hyperbola from point of admission. Compute the work (I. H. P.) from this new diagram. Draw conclusions from the form of card (see Article 409).
- 6. Compute the steam-consumption per stroke and per I. H. P. at cut-off and at end of stroke from the diagram (see Article 406). Compare this with the actual amount as determined by the test.
- 7. From the weight of dry steam as shown by the indicatordiagram, and the actual weight as determined by the amount of condensed steam, determine the quality at cut-off and release.
  - 8. Make report of test on the following form:

REPORT OF TEST O	ONENGINE.
	Date
Duration of test	
Revolutions per min	•••••••••••••
Steam used per min	
Rarometerin.	

	Crar	k End.	Head	Bod.
Piston-displacement		cu. í	.	cu. ft.
Clearance (per cent of P. D.)		. <b></b>		•••
Engine constant		• • • •		• • •
Cut-off (per cent of stroke)		• • • •		• • •
Release (per cent of stroke)				
Compression (per cent of stroke)		• • • •		
Pressure at cut-off		lbs.		lbs.
Pressure at release		"		"
Pressure at compression		"	• • • • • • • • • • • • • • • • • • • •	"
Mean effective pressure		"	1	"
Revolutions per minute				
Horse-power		H. E.		Total.
1	Per St		Per Revo-	Per I.H.P.
Weight of steam at cut-off	C. B.			
Weight of steam at release				
Weight of steam during compression				
Re-evaporation per H. P. per hour				
Weight of water per revolution, actual				
Weight of mixture in cylinder per revolution				
Per cent of mixture accounted for as steam a				
Per cent of mixture accounted for as steam at				•
Weight of water per H. P. per hour, actual.				
Weight of water per H. P. per hour, by indic				
Signed				

423. Valve-setting.—This exercise will consist, first, in obtaining dimensions of ports and valves, and in drawing the valve-diagram corresponding to a given lead and angular advance, and setting the valve by measurement with a lead corresponding to that shown on the diagram. The valve-diagram may be drawn by Zeuner's \* or Bilgram's method, as may be convenient; † from the valve-diagram draw the probable indicator-diagram and compute its area, and from that figure the indicated horse-power.‡

<sup>\*</sup> See Valve-gears, by Halsey. D. Van Nostrand Co., N. Y.

<sup>†</sup> Valve-gears, by Peabody. J. Wiley & Sons, N. Y.

t Valve-gears, by Spangler. J. Wiley & Sons, N. Y.

The method of drawing the indicator-diagram by projection from the valve-diagram is well shown in Fig. 225, from Thurston's Manual of the Steam-engine. The steam-pressure and back-pressure lines being assumed, the various events as shown on the valve-diagram are projected upon these lines, and the indicator-diagram completed as shown.

Secondly, in attaching the indicators and taking diagrams




Fig. 225.—Indicator-diagram constructed from Valve-diagram.

from which the error in the position of the valve is determined. Its position is corrected as required, to equalize the indicator-diagrams taken from each end of the cylinder.

The special directions are as follows:

Apparatus.—Scale, dividers, and trammel-point, the latter consisting of a rod the pointed end of which can be set on a mark on the floor and which carries a marking point at the other end.

1. Measure dimensions of valves and ports, throw of eccentric, and other dimensions called for by engine-log.

- 2. From these data, with a definite lead assumed, draw valve-diagram, and note position of piston for cut-off, release, compression, and admission.
- 3. Set the valve to the assumed lead, and with angular advance as indicated by the valve-diagram. Turn the engine over and see that the lead is the same at both ends of the piston.

This requires the engine to be set on its centre; this is done by bringing the piston to the extreme end of the stroke at either cylinder-end, so that the piston- and connecting-rods form one straight line. As the motion of the piston is very slow near the end of the stroke, this position is determined most accurately as follows: Mark a coincident line on crosshead and guides corresponding to the position of the crank when at an angle of about 20° measured from its horizontal position; then, from a fixed point on the floor, swing the trammel-point as a radius, and mark a line on the circumference of the fly-wheel; turn the engine over until the marks again coincide with the piston on the other side of the centre and make a second mark on the fly-wheel with the trammel-point; bisect the distance on the wheel between these marks and obtain a third line; turn the wheel until this line is shown by the trammel to be at the same distance from the reference-point, on the floor, as the other marks: the engine will then be on its centre. Move the valve the proper amount to make its position correspond with that shown on the diagram. In setting the valve remember that to change angular advance, the eccentric must be rotated on the shaft; and to equalize events for both ends of cylinder, the valve must be moved on the stem. These adjustments must be made together, as they are to some extent mutually dependent.

4. From the valve-diagram draw an ideal indicator-diagram as explained, assuming initial steam-pressure to be 100 pounds per square inch, absolute back pressure 5 pounds absolute, and that expansion and compression curves are true hyperbolæ.

Calculate its area by formula.

Area = 
$$PV(\mathbf{1} + \log_e r) - P_o V_o(\mathbf{1} + \log_e r')$$
,

in which V = volume at cut-off, and P = corresponding pressure;  $V_{\bullet} =$  clearance volume, and  $P_{\bullet} =$  clearance pressure; r = number of expansions, and r' = number of compressions.

- 5. Compute the horse-power of the diagram so drawn, and compare with that shown by the diagram taken.
- 424. Friction-test.—For this test the engine should be fitted with a Prony brake (see Article 178, page 216), to absorb and measure the power developed. Indicator-diagrams are to be taken and the indicated horse-power computed (see Article 402, page 404). The indicated horse-power being the work done by the steam on the piston of the engine, the dynamometer horse-power, that delivered by the engine, the difference will be the power absorbed by the engine in friction, or the friction horse-power. It is customary to reduce this amount to equivalent mean pressure acting on the piston by dividing by product of area of piston in square inches and speed in feet per minute. In making the test for friction of the engine the loads on the brake-arm should be varied, with the speed uniform, or the load on the brake-arm should be constant with varied speed, noting in each case the effect on the frictional work. It has been shown by an extended series of experiments \* that the friction of engines is practically constant regardless of the work performed, and that the work shown by the indicator-diagram, when the engine is running light or not attached to machinery, is practically equal to the engine-friction in case the speed is maintained uniform. the case of variation in speed the friction work increases nearly in proportion to increase of speed.

Detailed directions for this test are not considered necessary.

425. Simple Efficiency-test.—Engines are frequently sold on a guarantee as to coal or water consumption per indicated horse-power (I. H. P.), or in some instances per dynamometer horse-power (D. H. P.); in such a case a test is to be made showing the I. H. P. or the D. H. P. as may be required, and the water and coal consumed.

<sup>\*</sup> See Transactions Am. Soc. Mech. Engineers, Vol. VIII., page 86.

The I. H. P. is to be obtained as already explained in Article 402; the D. H. P. by readings from a Prony brake, Article 178. The coal-consumption is to be obtained by a boiler-test, Article 375; the total water consumed, by the feed water used in the boiler-test, corrected for leaks and quality: or by condensing the steam in a surface condenser, Article 417. The quality of the steam should be taken near the engine, as explained in Article 336, page 400. The principal quantities to be observed are quantities required for a boiler-test, quality of steam near engine, number of revolutions of engine per minute, and weight of feed-water or weight of condensed steam. These observations should be taken regularly and simultaneously once in ten or fifteen minutes, and at the same instant an indicator-diagram should be taken. From these data are computed the quantities required.

426. The Calorimetric Method of Engine-testing.—
Hirn's Analysis.—The calorimetric method of testing engines
as developed from Hirn's theory by Professor V. DwelshauversDery of Liège enables the experimenter to determine the
amount of heat lost and restored and that transformed into
work in the passage of the steam through the cylinder.\*

The principle on which the method is founded is as follows: The amount of heat supplied the engine is determined by measuring the pressure, quality, and weight of the steam; that removed from the engine is obtained by measuring the heat in the condensed steam and that given to the condensing water. The amount of heat remaining in the cylinder per pound of steam at any point after cut-off can be calculated from the data obtained from the indicator-diagram; this multiplied by the known weight gives the total heat.

The heat supplied to the engine added to that already existing in the clearance-spaces gives the total amount of heat available; if from this sum there be taken the heat existing at cut-off and the heat equivalent of the work done during admission, the difference will be the loss during admission, due

<sup>\*</sup>See Table Properties of Steam, V. Dwelshauvers-Dery, Trans. Am. Soc. M. E., Vol. XI.

principally to cylinder-condensation. The difference between the heat in the cylinder at cut-off and that at release after deducting the work equivalent is that lost or restored during expansion. This method applied to all the events of the stroke, and at as many places as required, gives full information of the transfer of heat to and from the metal.

In the fundamental equations of this analysis which follow, the following symbols are used:

Quantity.	Symbol.	Quantity.	Symbol.
Heat admitted per stroke Weight of steam per stroke Absolute pressure of entering steam, per sq. inch Temperature, degrees Fahr. Heat of the liquid Internal latent heat  Total latent heat Quality of the steam Degree of superheat Per cent of moisture Specific heat of steam of constant pressure	M  p t q p r x D 1-x	Heat equivalent of energy of steam in the cylinder at any instant	A S v V V C W G

The value of the quantity at any point under discussion is denoted by the following subscripts: clearance, c; beginning of admission, o; cut-off, i; release, i; beginning of compression, i.

The equations are as follows:

Heat in the Entering Steam.—If the steam is moist,

if the steam is superheated D degrees,

$$Q = M(q + r + c_{\bullet}D). \quad . \quad . \quad . \quad (2)$$

Heat in the Cylinder.—Since the steam in this case is invariably moist, we have the following equations:

In the clearance spaces,	$h_c = M_o(q_c + x_c \rho_c);$		(3)
At admission,	$h_{\bullet} = M_{\circ}(q_{\bullet} + x_{\bullet}\rho_{\bullet});$		(4)
At cut-off,	$h_1 = (M + M_0)(q_1 + x_1\rho_1);$	•	(5)
At release,	$h_{s} = (M + M_{o})(q_{s} + x_{s}\rho_{s});$		(6)

 $h - M(a \perp ra)$ 

At compression,  $h_a = (M + M_a)(q_a + x_a \rho_a)$ . (7)

The external work is to be determined from the indicatordiagram. Let the heat equivalent of this work be represented as follows:

During admission,	$AW_a$ ;	•	•	•	•	•	•	•	(8)
During expansion,	$AW_b$ ;		•	•	•				<b>(</b> 9)
During exhaust,	$AW_{c}$ ;.		•	•					(10)
During compression,	$AW_d$								(11)

The volume in cubic feet, V, of a given weight of steam, M. can always be expressed by the formula

$$V = M(xu + \sigma); \quad . \quad . \quad . \quad . \quad (12)$$

in which u equal the excess of volume of one pound of steam over that of one pound of water;  $u = v - \sigma$ .

Substituting the value of u in the above equation,

As  $\sigma$  is a very small quantity,  $(1-x)\sigma$  can be safely dropped as less than the errors of observation, and in all practical applications the formula used is

$$V = Mxv$$
. . . . . . . . (14)

In the exact equation (13) or the approximate equation (14), if the pressure, weight, and volume of steam are known, its specific volume, v, can be found, and x may be computed.

At any point in the stroke after the steam-valve is closed, the volume and pressure of steam in the cylinder can be determined from the indicator-diagram if the dimensions of the engine and its clearance are known. If the weight of steam used is known from an engine-test, there can be determined from the indicator-diagram both the quality and amount of heat in the cylinder at any point, with the single exception of the steam remaining in the clearance spaces. Thus let  $V_c$  equal volume of clearance;  $V_o + V_c$ , volume at admission, usually equal to  $V_c$ ;  $V_1 + V_c$ , volume at cut-off;  $V_2 + V_c$ , at release;  $V_a + V_c$ , at compression; M, the weight of steam used;  $M_o$ , the weight of steam caught and retained in the clearance spaces. Then, by method used in equation (12),

$$V_{\epsilon} = M_{\bullet}(x_{\epsilon}u_{\epsilon} + \sigma_{\epsilon}); \qquad (15)$$

$$V_{o} + V_{c} = M_{o}(x_{o}u_{o} + \sigma_{o});$$
 . . . (16)

$$V_1 + V_c = (M_0 + M)(x_1u_1 + \sigma_1); . . . (17)$$

$$V_2 + V_c = (M_0 + M)(x_2u_2 + \sigma_2);$$
 . . (18)

$$V_1 + V_2 = (M_0 + M)(x_1 u_1 + \sigma_2).$$
 (19)

In the above equations we know the volumes and pressures for each point, and the weight of steam, M, passing through the engine. So that in the five equations there are six unknown quantities:  $M_0$ ,  $x_c$ ,  $x_0$ ,  $x_1$ ,  $x_2$ , and  $x_3$ , of which  $x_0$  may be assumed as 1.00 without sensible error. In the above equations, (15) and (16) are usually identical; they differ from each other only when there is a sensible lead which shows on the diagram.

The weight of steam in the clearance space is computed from equation (15):

$$M_0 = (V_c) \div (x_c u_c + \sigma_c) = V_c \div x_c v_c$$
, nearly.

Assume x = 1.00:

In computing the heat at any point, it is customary to compute the sensible and internal heat in two operations. Thus in equation (4) make h, the total heat, equal to H, the sensible heat, plus H', the internal heat; then

$$h_{\circ} = H_{\circ} + H_{\circ}' = (x_{\circ}\rho_{\circ} + q_{\circ})M_{\circ};$$
or
$$H_{\circ} = M_{\circ}q_{\circ}, \qquad (21)$$

$$H_{\circ}' = x_{\circ}\rho_{\circ}M_{\circ}; \qquad (22)$$

and in equation (5),

$$H_1 = q_1(M_0 + M), \ldots (23)$$

$$H_1' = (x_1 \rho_1)(M_0 + M).$$
 . . . . . (24)

From equation (17),

$$M_{\circ} + M = \frac{V_{1} + V_{c}}{x_{1}u_{1} + \sigma_{1}} = \frac{V_{1} + V_{c}}{x_{1}v_{1} + \sigma(1 - x)} = \frac{V_{1} + V_{c}}{x_{1}v_{1}}, \text{ nearly.}$$
 (25)

By substituting in (24),

$$H_1' = \rho_1(V_1 + V_c) + v_1;$$


which form is used in the computations that follow.

The analysis determines the loss of heat during a given period, by finding the difference between the heat in the cylinder at the beginning of the period and the sum of that utilized in work during the period and that remaining at the end of the period.

The following directions and example should make the method clearly understood.

427. Directions for Engine-testing by Hirn's Analysis.

Directions.—1. Make a complete engine-test with a constant load, weigh the condensing water, and measure its temperature



before and after condensing the steam. Obtain the quality of the entering steam either in the steam-pipe or steam-chest; if convenient, make calorimetric determinations of the quality of the steam in the exhaust, which may be used as a check on the results, but which is necessary in case the exhaust steam is not condensed.

- 2. Calibrate all the instruments used, and correct all observations where required.
- 3. From the average quantities on the log, corrected as shown by the calibration, fill out form I, of data and results. The steam and condensing water used per revolution to be divided between the forward and backward strokes of the piston in proportion to the M. E. P. of these respective strokes, as shown on the log.
- 4. Draw on each diagram as explained lines corresponding to zero volume and to zero pressure, and divide the diagrams as shown in Fig. 226 into sections, by drawing lines to points of admission W, cut-off cn, release Oe, and compression od.

Measure for each diagram the percentages of cut-off, release, and compression, calling the original length of the diagram without clearance 100 per cent.

5. Measure the absolute pressure from each card and enter the averages in blank form No II, using subscripts as follows: 0, admission; 1, cut-off; 2, release; 3, compression; c, clearance.

Take from a steam-table the heat of liquid, internal latent heat, total latent heat, total heat, and specific volume, corresponding to each of the above pressures.

- 6. Compute the volumes in cubic feet for clearance, total volumes, including clearance, at admission, cut-off, release, and compression, and place the average results in the proper columns.
- 7. Compute the area corresponding to each period into which the diagram is divided and find the mean pressure for that period. Also find the work done in each period, expressed in foot-pounds and also in B. T. U. (It is to be noted that the work done during the return stroke is negative.) Enter the average of these results in the proper place, noting the use of the subscripts a, b, c, and d.
- 8. Calculate the heat-losses as indicated on Form III, which is an account of the heat used during 100 strokes of the engine.

The weight of steam, M, in pounds is 100 times the amount used for one stroke as given on Form I. The weight of steam in clearance is to be calculated for admission, pressure, and volume, and with x equal 1.00. M, to be calculated in the same manner. Calculate from known weights and temperatures the heat exhausted from the engine in the condensed steam K' and in the condensing water K.

Calculate by the formulæ, as explained, the heat supplied the engine, and the sensible and internal heat, at each event in the stroke of the engine.

- 9. Calculate the cylinder-loss at admission as the difference between that supplied added to that already in the clearance, and that remaining at cut-off added to that used in work. If the heat is flowing from the metal, the sign will be negative, otherwise positive.
- 10. Perform the same operation for each period of the engine; the difference between the heat at the beginning of each period and that at the end, taking into account the work done, is the loss.
- II. Take the algebraic sum of these losses and of the heat equivalent of the external work, and if no error has been made in the calculations, this sum, which is the total transformation, will equal the difference between the heat supplied and that exhausted. That is, using the symbols of the analysis, D = D.' It is also evident that this quantity is the loss by radiation.

The importance of this check on the accuracy of the computations should not be overlooked. If no errors of computation are made, in each case the value of D will equal that of D'.

12. Make the remaining calculations as on Form IV; these give the quality which the steam must have at various portions of the stroke to correspond with the foregoing calculations. The quality is calculated from the volume remaining in the cylinder. Compute the various efficiencies.

Note that the heat lost during admission is in some respects a measure of the initial cylinder-condensation.

The following forms are given partially filled out with the results of a test made by application of Hirn's analysis.

MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY.

			Scale of Spring.		
	ا نه		D. H. P.	<u> </u>   <b>&gt;</b> >	Test made by
	Brake.		Load.	-	
	<u>'</u>		I. H. P. Total.		Test ma
	j.		I. H. P.	İ	_
	Crank.		М. В. Р.		:::
.	Head.		л. н. г.		
	H		м. в. р.		. : ge
	gi.		. 1228W-Water		Kind of engine
	Weights.		Feed-water. Injection-water.	1	Sq. i
	3	·.	Condensed Steam	1	engii
			Exhaust.		1 of on all
	rs.	Calorimeter.	Cylinder.		Kinc Piste
			Steam-chest.		
LOG OF 1ESI.		చ	Steam pipe.	3.	
٥	ratur		Discharge-water.		-
3	Temperatures.	Feed-water.		>	Diam. piston-rod, inches Diam. crank-pin, inches Length crank-pin Diam. wrist-pin, inches
	ř			1	od, ii
ł			Condensed Steam	)	On-r nk-p ank-l
			Engine-room.	1	Diam. piston-rod, inches
			Barometer. External Air,	1	iam.
	بو	Inches Ilg.	Condenser.	1	_
	ding	Inch	Exhaust,	   Q	-  : : :
	Gauge-readings.		Steam-cheat.	<b>-</b>	ater.
	Gaug	Pounds.	Steam-pipe.	Ϊ.	-
		g.	Boiler.		, ig
	Revolu- tions.		Speed-indicator.		head, lbs.
	Rev tio	iter.	Continuous Cour	<b>\</b>	Clearance, head, lbs. water  " crank, " ''  Brake-arm
			.əmiT		ran ce-a

#### FORM NO. I.

## APPLICATION OF HIRN'S ANALYSIS TO SIMPLE CONDENSING ENGINE.

# DATA AND RESULTS. Test of steam-engine made by ..... at Cornell University.

Kind of engine, slide-valve throttling. Diameter cylinder.... 6.06 inches. Length stroke..... 8 inches. Diameter piston-rod... 111 Volume cylinder......crank end, 0.12921 cu. ft.; head end, 0.13354 cu. ft. Volume clearance, cubic foot, head...... 0.01744 Clearance in per cent of stroke...... 13.06 Volume clearance, cubic foot, crank..... Clearance in per cent of stroke...... 12.51 Boiler-pressure by gauge ..... 69.4. Barometer ..... 29.276 Boiler pressure absolute, pounds..... 83.7 Boiling temperature, atmospheric pressure, deg. F...... 210.7 Steam used during run, pounds...... 716.424 Quality of steam in steam-pipe...... 0.99 Quality of steam in steam-chest ........... 0.9941 Quality of steam in compression...... 1.001 Weight of condensed steam per hour..... 259,92 Pounds of wet steam\* per stroke.....head, 0.0100707; crank, 0.0100383 Temperatures condensed steam...... 103.47 deg. F.

Symbols.

To denote different portions of the stroke, the following subscripts are used: Admission, a; expansion, b; exhaust, c; compression, d.

To denote different events of the stroke, the following sub-numbers are used: Cut-off. 1; release, 2; compression, beginning of, 3; admission, beginning of, 0; in exhaust, 5. Quality of steam denoted by X.
Cut-off, crank end, per cent of stroke... 20.544. Release, crank end... 93.958
Cut-off, head end, per cent of stroke... 18.963. Release, head end... 94.971

Cut-off, crank end, per cent of stroke... 20.544. Release, crank end. 93.958
Cut-off, head end, per cent of stroke... 18.963. Release, head end. 94.971
Compression, crank end, per cent of stroke... 52.341
Compression, head end, per cent of stroke... 39.770
Pounds of steam per I. H. P. 39.351
Pounds of steam per brake H. P. 55.314
I. H. P. Head... 3.3152. Crank... 3.3054. Total. 6.6206
Brake horse-power... 4.71

<sup>\*</sup> Wet steam is the steam uncorrected for calorimetric determinations.

# FORM NO. II. ABSOLUTE PRESSURES FROM INDICATOR-DIAGRAMS AND CORRESPONDING PROPERTIES OF SATURATED STEAM.

				Begin	ining	Sym	bols.
		Cut-off. Release. Compression. Df Appression.				Ran- kine.	Clau- sius.
Subscripts used			2	3	0		
Absolute pressure	Crank					P	p
Heat of liquid				(		s	q
Internal latent heat.						I	ρ
Latent-heat evapo- ration	Crank	1				L	,
Total heat	Head Crank					H	, λ
Vol. 1 lb. cu. ft Volumes symbols	Head Crank					С	ข
Volumes symbols Volumes head, cu. ft		$V_0 + V_1$	$V_0 + V_2$	$V_0 + V_3$	$V_0 + V_0$	$V_{\bullet}$	<b></b>
Volumes crank, cu. f							

# MEAN PRESSURES AND HEAT EQUIVALENTS OF EXTERNAL WORK.

	Subscripts.	Head End.			Crank End.			
		scripts	Mean Pressures.	External Work.		Mean Pressures.	External Work.	
		riessures.	Foot-lbs.	B. T. U.	Foot-lbs.		B, T. U	
SymbolsAdmission	а	MP			MP			
Expansion Exhaust Compression Total	ď							

<sup>\*</sup>  $A = \frac{1}{778}$  .  $V_0 =$  volume in clearance-spaces.

FORM NO. III. HIRN'S ANALYSIS—HEAT-TRANSFER PER 100 STROKES.

$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Quantities.	Symbols.	Formulæ.	Head.	Crank.
$M_{\bullet}$ $100(V_{\bullet} + V_{\bullet}) + v_{\bullet}$ $0.164$ $K'$ $Mg$ $1.26i$ $K'$ $Mg$ $1.26i$ $K'$ $G(g_{h} - g_{h})$ $1.26i$ $K'$ $G(g_{h} - g_{h})$ $1.26i$ $H_{\bullet}$ $100 - \frac{V_{\bullet} + V_{\bullet}}{V_{\bullet}} \rho_{\bullet}$ $1.26i$ $H_{\bullet}$ $100 - \frac{V_{\bullet} + V_{\bullet}}{V_{\bullet}} \rho_{\bullet}$ $1.36i$ $H_{\bullet}$ $100 - \frac{V_{\bullet} + V_{\bullet}}{V_{\bullet}} \rho_{\bullet}$ $1.30i$ $H_{\bullet}$ $100 - \frac{V_{\bullet} + V_{\bullet}}{V_{\bullet}} - H_{\bullet}^{\prime} - H_{\bullet}^{\prime} - H_{\bullet}^{\prime}$ $1.30i$ $H_{\bullet}$ $H_{\bullet}$ $H_{\bullet}$ $H_{\bullet}$ $H_{\bullet}$ $H_{\bullet}$ $H_{\bullet}$ $100 - \frac{V_{\bullet}}{V_{\bullet}} + H_{\bullet}^{\prime} - H_{\bullet}^{\prime} - H_{\bullet}^{\prime} - H_$	Steam from boiler. Iba	M		1.097	1.093
$K'$ $Mq_t$ $16t$ $K'$ $Mq_t$ $16t$ $K'$ $G(q_k - q)$ $16t$ $K'$ $G(q_k - q)$ $16t$ $K'$ $M(xr + q)$ $16t$ $K_0$ $M(xr + q)$ $16t$ $K_0$ $M_0$ $16t$ $K_1$ $(M + M_0)q_1$ $318.348$ $K_1$ $(M + M_0)q_1$ $318.348$ $K_1$ $(M + M_0)q_1$ $318.348$ $K_1$ $(M + M_0)q_2$ $318.348$ $K_2$ $K_1$ $K_2$ $K_3$ $K_2$ $K_3$ $K_2$ $K_3$ $K_4$ $K_3$ $K_4$	Steam at admission, lbs.		$100(V_0 + V_0) + v_0$	90.10	0.144
$ K' \qquad Mq_{6} $ $ C(q_{1}-q_{1}) $ $ C(q_{1}-q_{1}) $ $ C(q_{1}-q_{1}) $ $ M_{6} $ $ M_{6} $ $ M_{6} $ $ M_{6} $ $ M_{6} $ $ M_{6} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{2} $ $ M_{1} $ $ (M+M_{6})q_{1} $ $ M_{2} $ $ M_{1} $ $ (M+M_{6})q_{2} $ $ M_{2} $ $ M_{2} $ $ M_{3} $ $ M_{4} $ $ M_{2} $ $ M_{4} $ $ M_{5} $ $ M_{5} $ $ M_{7} $ $ M_{8} $ $ M_{7} $ $ M_{8} $	Stearm, total, lbs	$M+M_{\bullet}$		1.261	1.237
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Heat of condensed steam		Mgg	78.062	78.181
$K = G(n_{L} - \eta)$ $Q = M(xr + \eta)$ $H_{0}$ $M_{0}q_{0}$ $H_{1}$ $100^{L} + V_{0}$ $H_{1}$ $100^{L} + V_{1}$ $H_{1}$ $100^{L} + V_{1}$ $H_{2}$ $100^{L} + V_{1}$ $H_{3}$ $100^{L} + V_{1}$ $H_{4}$ $100^{L} + V_{1}$ $H_{5}$ $100^{L} + V_{1}$ $H_{5}$ $100^{L} + V_{1}$ $H_{5}$ $H_{7}$ $H_{8}$ $H_{7}$ $H_{7}$ $H_{7}$ $H_{7}$ $H_{7}$ $H_{7}$ $H_{7}$ $H_{8}$ $H_{7}$	Condensing water, 1bs			21.201	21.227
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Heat given to condensing water	¥	G(pt - g)	1048.652	1049.928
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Heat supplied to engine	0	M(xr+q)	1285.274	1281.478
$H_{0}'  100 \frac{V_{o} + V_{o}}{v_{o}} \\ H_{1}  (M + M_{o})v_{1} \\ H_{2}  (M + M_{o})v_{1} \\ H_{3}  100 \frac{V_{o} + V_{o}}{v_{1}} \\ H_{3}  (M + M_{o})v_{2} \\ H_{3}  100 \frac{v_{1} + V_{o}}{v_{2} + V_{o}} \\ H_{4}  100 \frac{v_{2} + V_{o}}{v_{3} + V_{o}} \\ H_{5}  100 \frac{V_{o}}{v_{3} + V_{o}} \\ H_{5}  100 $	Sensible heat at admission	Н.	M.90	37.998	33.457
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Internal heat at admission	Н,	$\frac{V_0 + V_0}{v_0} \rho_0$	r43.550	125.579
$H_1'  \text{too} \frac{V_+ + V_1}{v_1} \\ H_2  (M + M_0)_{v_2} \\ H_3  (M + M_0)_{v_3} \\ H_4  \text{too} \frac{v_1}{v_2} + \frac{V_2}{v_3} \\ H_5  \text{too} \frac{v_3}{v_3} + \frac{V_2 + V_2}{v_3} \\ H_5  \text{too} \frac{v_3}{v_3} + \frac{V_2 + V_2}{v_3} \\ H_5  \text{too} \frac{V_2 + V_3}{v_3} \\ H_6  \text{too} \frac{V_2 + V_3}{v_3} \\ H_7  \text{too} \frac{V_2 + V_3}{v_3} + \frac{V_1 - M_1 - M_2}{v_3} \\ G_0  H_1 + H_1' - H_2' - H_1' - M_2' \\ G_0  H_3 + H_3' - H_3' - H_3' - M_2' \\ G_0  H_3 + H_3' - H_3' - H_3' - M_2' \\ G_0  H_3 + H_3' - H_3' - H_3' - M_3' \\ G_0  H_3 + H_3' - H_3' - H_3' - M_3' \\ G_0  H_2  H_3' - H_3' - H_3' - H_3' \\ G_0  H_3 + H_3' - H_3' - H_3' - H_3' \\ G_0  H_3 + H_3' - H_3' - H_3' - H_3' \\ G_0  H_3 + H_3' - H_3' - H_3' - H_3' \\ G_0  H_3 + H_3' - H_3' - H_3' - H_3' \\ G_0  H_3 + H_3' - H_3' - H_3' \\ G_1  H_2  H_3' - H_3' - H_3' \\ G_2  H_3 + H_3' - H_3' - H_3' \\ G_3  H_3 + H_3' - H_3' - H_3' \\ G_4  H_3 + H_3' - H_3' - H_3' \\ G_5  H_3 + H_3' - H_3' - H_3' \\ G_7  H_7  $	Sensible heat at cut-off		$(M+M_{\bullet})q_1$	338.348	328.216
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Internal heat at cut-off		$100\frac{V_0 + V_1}{T_0}\rho_1$	545.500	528.169
$H_{3}' \qquad 100 \frac{V_{+} + V_{3}}{v_{3}}$ $H_{3} \qquad M_{60s}$ $H_{5} \qquad M_{60s}$ $H_{5} \qquad 100 \frac{v_{+} + V_{3}}{v_{+} + V_{3}}$ $H_{5} \qquad 100 \frac{v_{+} + V_{3}}{v_{+} + V_{3}}$ $U_{6} \qquad V_{6} + H_{6}' - H_{1} - H_{1}' - AW_{6}$ $U_{6} \qquad H_{1} + H_{1}' - H_{3} - H_{6}' - AW_{6}$ $U_{6} \qquad H_{3} + H_{3}' - H_{6} - H_{6}' - AW_{6}$ $U_{6} \qquad H_{3} + H_{3}' - H_{6} - H_{6}' - AW_{6}$ $U_{7} \qquad 1003 \cdot 033$ $U_{7} \qquad U_{7} + U_{7$	Sensible heat at release		$(M+M_0)q_3$	254.408	254.030
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Internal heat at release		10 V + V 10 10 10 10 10 10 10 10 10 10 10 10 10	701.118	706.586
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Sensible heat, beginning of compression		Mogs	21.392	19.082
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Internal heat, beginning of compression		100 V + V 3 P 3	113.914	103.631
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Cylinder-loss during admission	ೆ	$Q + H_0 + H_0' - H_1 - H_1' - AW_0$	551.135	549.824
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	:	ර	$H_1 + H_1' - H_2 - H_3' - AW_5$	- 135.861	- 163.178
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	:	å	$H_9 + H_8' - H_8 - H_8' - (K + K') - AW_8$	- 303.364	- 285.382
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	:	3	$H_3 + H_3' - H_0 - H_0' - AW_A$	- 29.727	- 18.603
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	Heat discharged, and work	В	K+K'+4W	1203.003	1198.818
D'. Q.+Q.+Q.+Q.	Loss	a	Q - B	82.181	82.659
	Loss.	Ď.	0°+0+0+0°	82.181	82.659

Special symbols, V<sub>a</sub> = volume clearance, t = measured temperature. Subscript 5 applies to exhaust, t to injection, k to discharge, g to air-pump discharge.

FORM NO. IV.

# HIRN'S ANALYSIS—SUMMARY AND RESULTS.

Quantities	Symbols.	Formulæ.		Head.	Crank.
Quality of steam entering.	h	Per calorimeter,	per cent.	17.66	14-96
Quality of steam at cut-off	<i>x</i> 1	$100 \frac{V_0 + V_1}{(M + M_0)C_1}$	:	52.34	51.50
Quality of steam at release.	r <sub>3</sub>	$\frac{\Gamma_0 + V_2}{(M + M_0)C_2}$	:	65.34	98.26
Quality of steam at compression	î,	$\frac{V_0 + V_3}{4/\sqrt{C_3}}$	;	71.75	91.72
Quality of steam at admission	¥,	Per calorimeter,	:	102.05	102,05
Quality of steam in exhaust	4	$\left(\frac{x+y}{y}-a_{1}\right)+r_{3}$	3	90.214	90.195
Heat lost, admission	4	0+0	:	42.881	42.905
Heat restored, expansion	9	0°+0	:	10.571	12.733
Heat rejected, exhaust	v	0+0	:	23.603	22.270
Heat lost, compression	ø	04+0	;	- 2.313	- 1.452
Heat utilized, work.	8	D + 822	:	5.518	5 518
Heat lost, radiation	¥	0+0	:	6.394	6.450
Ratio, radiation to work		R+w		1.1588	1.1689
Ratio, cylinder-condensation to work		2+2		7.7711	7.7757
Thermodynamic efficiency	¥	$(t-t_3)+(46t+t)$	per cent.	126 61	16.031
Actual efficiency	$E_{1}'$	0+ %; + 0	3	8.518	5.518
Efficiency compared with ideal	¥	E1+ F	:	27.67	28.49

In the above test, a calorimeter was arranged on the engine to obtain quality of the steam in compression. A slight correction for the steam used, 0.0040 lb., is made.

- 429. Hirn's Analysis applied to Non-condensing Engines.—In this case: I. Determine the weight of water used by weighing that supplied the boiler, taking precautions to prevent loss of steam between the engine and the boiler by leaks. Apply the calorimeter and ascertain the quality near the engine. The heat in one pound of steam above  $32^{\circ}$  Fahr. will be represented by the formula xr + q, as previously explained. This quantity multiplied by the weight, M, is the heat supplied. M may be taken for I or for 100 strokes, as convenient.
- 2. Determine the quality of the exhaust-steam by attaching a calorimeter in the exhaust-pipe, close to the engine. The heat discharged by one pound will be, as explained in Article 311,  $x_*r_* + q_*$ ; in which the symbols denote quantities taken at exhaust-steam pressure. This quantity multiplied by the weight, M, is the heat discharged, and is equal to K + K' in the Form III, page 543.
- 3. With these exceptions, the method is exactly as explained for the condensing engine, and the same forms are to be used.

In obtaining the quality of the exhaust-steam, a separating calorimeter (see page 399) with two chambers arranged in series can be used with success.

430. Application of Hirn's Analysis to Compound Engines.—Compound engines are usually run condensing, and the special directions are for that case; but in case the engine is run non-condensing the method of Article 429 can be applied.

Directions. - With calorimeter between the cylinders:

1. Attach a calorimeter in the exhaust of the high-pressure cylinder, and determine the heat exhausted from the high-pressure cylinder as explained for non-condensing engines.

Treat the high pressure cylinder as a simple non-condensing engine, as explained in Article 429.

2. Determine by the calorimeter between the cylinders the heat supplied to the low-pressure engine. This quantity will be the same as that exhausted from the high-pressure, corrected for steam used by the calorimeter and for radiation from the connecting pipes.

3. Fill out the forms for each cylinder as a separate engine. By using two calorimeters between cylinders the same method can be applied to a triple-expansion engine.

In case the pressure of the steam between the cylinders is less than atmospheric a calorimeter can be used by attaching a special air-pump and condenser, so as to secure a flow of steam through the calorimeter.

Without calorimeter between the cylinders:

- 1. Determine the weight of steam, M, for both cylinders from the condensed steam of the low-pressure cylinder. This will give the quantity M.
- 2. For the high-pressure cylinder compute the quantities as in Form III, omitting those terms containing K and K', the heat exhausted.
- 3. Determine K and K' as follows: K+K' is evidently equal to the heat supplied the high-pressure engine, less the heat transformed into work, expressed in B. T. U., less the loss by radiation. The total loss by radiation in the whole engine is equal to the heat supplied the first cylinder, less the work done by all the cylinders, less the heat discharged from the last one. As an approximation, divide this total radiation-loss equally between the cylinders, assuming that the lower temperature of the low-pressure cylinder will offset its increased size. This will give us in Form III the value of D=Q-B. Compute B, substitute this value in the equation B=K+K'+AW. Compute K+K' and complete the analysis for the high-pressure cylinder.
- 4. For the low-pressure cylinder, determine the entering heat as that discharged from the high-pressure cylinder, K+K', plus the assumed radiation as given above.

Make a complete analysis for each cylinder as explained for a simple engine.

431. Hirn's Analysis applied to a Triple-expansion Engine.—When the quality of the steam between the cylinders can be determined, treat the engine as three separate engines as explained.

When the quality cannot be determined, treat the case as explained for a compound engine, as follows:

- 1. Find the entire loss as equal to the difference between that supplied to the first cylinder and that discharged from the last, increased by the work done in the whole system reduced to thermal units. Divide this by the number of cylinders to find the assumed radiation-loss from each.
- 2. Take the cylinders in series, and assume the discharged heat to equal the heat supplied, diminished by that transformed into external work, and make a separate analysis for each cylinder as explained for a simple engine.

The following is an application of Hirn's analysis to a triple-expansion engine by Prof. C. H. Peabody at the Massachusetts Institute of Technology.

The main dimensions of the engine are as follows:

The following table gives the data and results of a test with Hirn's analysis, made by the graduating class:

Duration of test, minutes	60
Total number of revolutions	5299
Revolutions per minute	88.3
Steam-consumption during test, pounds:	
Passing through cylinders	1193
Condensation in high-pressure jacket	57
" in first receiver jacket	61
" in intermediate jacket	85
" in second receiver jacket	53
" in low-pressure jacket	89
Total	1538

- 8.36

§ 431.]	METHODS	0F	TESTING	THE	STEAM-ENGINE	. 549
,	During compre	ssion	l		Qd	0.45
					$Q_j$	4.56
						1.50
	intermediate r					3-
						4.92
					Q <sub>R</sub>	0.58
	mediate cylind		• • • • • • • • • • • • • • • • • • • •	•••••	······································	0.50
			_		q	131.89
					Qa'	131.69
						-
						- 18.65
	•				Q <sub>c</sub> '	0.22
					Qı'	0.44
	••				······································	6.82
	•			• • • • • •	Qd	2.45
	nd intermediate					
						4.20
	Lost by radiation	on	• • • • • • • • • • • • • • • • • • •	•••••		1.20
Low	-pressure cyline	der—	•			
	Brought in by	stean	a	,	Q" ·	132.14
	During admissi	on .			Q <sub>s</sub> "	5.85
	During expans	ion .	• • • • • • • • • • • •			<b>-</b> 9.51
	During exhaust	i	• . • • • • • . • • •	• • • • • •		2.53
					$Q_{d''}$	0.00
	Supplied by jac	ket.				7.08
	Lost by radiati	on				4.34
	l loss by radiat				-	
					ΣQ.	10.07
						11.68
	pressures in the					
	a-pressure cylin	-				
						145.9
						143.2
					••••••	41.3
•	•				••••••	41.5
,						43.7
					••••••	48.7
	•					64.5
7				• • • • • • •	• • • • • • • • • • • • • • • • • • • •	75-3
	rmediate cylind					
					•••••	37.2
					••••••	35.0
	•				••••••	13.6
					•••••••	13.4
1					•••••	16.3
	"	head	end			17.9

550	EXPERIMENTAL ENGINEERING.	[§ 431
	Admission, crank end	20.4
	" head end	21.1
L	ow-pressure cylinder—	
_	Cut-off, crank end	12.1
	" head end	12.0
	Release, crank end	5.6
	" head end	5.4
	Compression and admission, crank end	3.7
	" " head end	4.3
Heat	equivalents of external work, B. T. U., from areas on indicator-	4.5
	diagram to line of absolute vacuum:	
н	ligh-pressure cylinder—	
	During admission, A Wa, crank end	5.71
	" head end	16.6
	During expansion, A Wb, crank end	to.65
	" head end	18.01
	During exhaust, A Wc, crank end	7.73
	" head end	8.08
	During compression, A Wd, crank end	0.48
	" head end	0.62
Īr	ntermediate cylinder—	0.02
	During admission, A Wa, crank end	7.58
	" " head end	7.30 7.43
	During expansion, A Wb, crank end	9.54
	" " head end	9.34
	During exhaust, A Wc, crank end	9.22
	" " head end	9.27
	During compression, A Wa, crank end	0.39
	" head end	0.39
т.	ow-pressure cylinder—	0.00
	During admission, $AW_a$ , crank end	
	" head end	7.75
	During expansion, A Wb, crank end	7.99
	" head end	6.83 6.87
	During exhaust, $AW_c$ , crank end	
	" " head end	5.08
	During compression, A Wa, crank end	5.08
	" head end	0.00
D		0.00
	r and economy : leat equivalents of work per stroke—	
п	High-pressure cylinder	
	Intermediate cylinder	8.44
		7.12
	Low-pressure cylinder	9.64
	Total	25.20
т	otal heat furnished by jackets	27 58

§ 431.] ME	THODS OF	TESTING	THE	STEAM-ENG	<i>SINE</i> . 551
Distribution	n of work :				
High-p	ressure cylind	ler			1.00
Interm	ediate cylinde	er	· • • • • •		0.84
Low-pi	ressure cylind	er	. <b></b> .		1.14
Horse-power	er				104.9
Steam per l	orse-power p	er hour			14.65
B. T. U. po	er horse-powe	r per minute.		•••••	258.3

,

·

.

•

. .

## CHAPTER XIX.

# METHODS OF TESTING ENGINES OF SPECIAL CONSTRUCTION.

- 432. Special Methods of Engine-testing.—Engines employed for certain specific purposes, as for pumping water or for locomotive service, are constructed with peculiar features rendered necessary by the work to be accomplished. In such cases it is frequently difficult to arrange to make all the measurements in the manner prescribed for the tests of the general type of the steam-engine; further, it is often of importance that the amount and character of the work accomplished be taken into consideration. To secure results that can safely be compared, it is essential that certain methods of testing be adopted and that the results be expressed in the same form and referred to the same standards.
- 433. Method of Testing Steam Pumping-engines.—A standard method of testing steam pumping-engines has been adopted by the American Society of Mechanical Engineers (see Vol. XI. of the Transactions). The method is as follows:

# (I) TEST OF FEED-WATER TEMPERATURES.

The plant is subjected to a preliminary run, under the conditions determined upon for the test, for a period of three hours, or such a time as is necessary to find the temperature of the feed-water (or the several temperatures, if there is more than one supply) for use in the calculation of the duty. During this test observations of the temperature are made every fifteen minutes. Frequent observations are also made of the speed, length of stroke, indication of water-pressure gauges, and other

instruments, so as to have a record of the general conditions under which this test is made.

Directions for obtaining Feed-water Temperatures.—When the feed-water is all supplied by one feeding instrument, the temperature to be found is that of the water in the feed-pipe near the point where it enters the boiler. If the water is fed by an injector this temperature is to be corrected for the heat added to the water by the injector, and for this purpose the temperature of the water entering and of that leaving the injector are both observed. If the water does not pass through a heater on its way to the boiler (that is, that form of heater which depends upon the rejected heat of the engine, such as that contained in the exhaust-steam either of the main cylinders or of the auxiliary pumps), it is sufficient, for practical purposes, to take the temperature of the water at the source of supply, whether the feeding instrument is a pump or an injector.

When there are two independent sources of feed-water supply, one the main supply from the hot-well, or from some other source, and the other an auxiliary supply derived from the water condensed in the jackets of the main engine and in the live-steam reheater, if one be used, they are to be treated independently. The remarks already made apply to the first, or main, supply. The temperature of the auxiliary supply, if carried by an independent pipe either direct to the boiler or to the main feed-pipe near the boiler, is to be taken at convenient points in the independent pipe.

When a separator is used in the main steam-pipe, arranged so as to discharge the entrained water back into the boiler by gravity, no account need be made of the temperature of the water thus returned. Should it discharge either into the atmosphere to waste, to the hot-well, or to the jacket-tank, its temperature is to be determined at the point where the water leaves the separator before its pressure is reduced.

When a separator is used, and it drains by gravity into the jacket-tank, this tank being subjected to boiler-pressure, the

temperature of the separator-water and jacket-water are each to be taken before their entrance to the tank.

Should there be any other independent supply of water, the temperature of that is also to be taken on this preliminary test.

Directions for Measurement of Feed-water.—As soon as the feed-water temperatures have been obtained the engine is stopped, and the necessary apparatus arranged for determining the weight of the feed-water consumed, or of the various supplies of feed-water if there is more than one.

In order that the main supply of feed-water may be measured, it will generally be found desirable to draw it from the cold-water service-main. The best form of apparatus for weighing the water consists of two tanks, one of which rests upon a platform-scale supported by staging, while the other is placed underneath. The water is drawn from the service-main into the upper tank, where it is weighed, and it is then emptied into the lower tank. The lower tank serves as a reservoir, and to this the suction-pipe of the feeding apparatus is connected.

The jacket-water may be measured by using a pair of small barrels, one being filled while the other is being weighed and emptied. This water, after being measured, may be thrown away, the loss being made up by the main feed-pump. To prevent evaporation from the water, and consequent loss on account of its highly heated condition, each barrel should be partially filled with cold water previous to using it for collecting the jacket-water, and the weight of this water treated as tare.

When the jacket-water drains back by gravity to the boiler, waste of live steam during the weighing should be prevented by providing a small vertical chamber, and conducting the water into this receptacle before its escape. A glass watergauge is attached, so as to show the height of water inside the chamber, and this serves as a guide in regulating the discharge-valve.

When the jacket-water is returned to the boiler by means of a pump, the discharge-valve should be throttled during the test, so that the pump may work against its usual pressure,

that is, the boiler-pressure as nearly as may be, a gauge being attached to the discharge-pipe for this purpose.

When a separator is used and the entrained water discharges either to waste, to the hot well, or to the jacket-tank, the weight of this water is to be determined, the water being drawn into barrels in the manner pointed out for measuring the jacket-water. Except in the case where the separator discharges into the jacket-tank, the entrained water thus found is treated, in the calculations, in the same manner as moisture shown by the calorimeter-test. When it discharges into the jacket-tank, its weight is simply subtracted from the total weight of water fed, and allowance made for heat of this water lost by radiation between separator and tank.

When the jackets are drained by a trap, and the condensed water goes either to waste or to the hot-well, the determination of the quantity used is not necessary to the main object of the duty trial, because the main feed-pump in such cases supplies all the feed-water. For the sake of having complete data, however, it is desirable that this water be measured, whatever the use to which it is applied.

Should live steam be used for reheating the steam in the intermediate receiver, it is desirable to separate this from the jacket-steam, if it drain into the same tank, and measure it independently. This, likewise, is not essential to the main object of the duty trial, though useful for purposes of information.

The remarks as to the manner of preventing losses of live steam and of evaporation, in the measurement of jacket-water, apply to the measurement of any other hot water under pressure, which may be used for feed-water.

Should there be any other independent supply of water to the boiler, besides those named, its quantity is to be determined independently, apparatus for all these measurements being set up during the interval between the preliminary run and the main trial, when the plant is idle.

# (2) THE MAIN DUTY-TRIAL.

The duty-trial is here assumed to apply to a complete plant, embracing a test of the performance of the boiler as well as that of the engine. The test of the two will go on simultaneously after both are started, but the boiler-test will begin a short time in advance of the commencement of the engine-test, and continue a short time after the engine-test is finished. The mode of procedure is as follows:

The plant having been worked for a suitable time under normal conditions, the fire is burned down to a low point and the engine brought to rest. The fire remaining on the grate is then quickly hauled, the furnace cleaned, and the refuse withdrawn from the ash-pit. The boiler-test is now started, and this test is made in accordance with the rules for a standard method recommended by the Committee on Boiler Tests of the American Society of Mechanical Engineers. This method. briefly described, consists in starting the test with a new fire lighted with wood, the boiler having previously been heated to its normal working degree; operating the boiler in accordance with the conditions determined upon; weighing coal, ashes, and feed-water; observing the draught, temperatures of feedwater and escaping gases, and such other data as may be incidentally desired; determining the quantity of moisture in the coal and in the steam; and at the close of the test hauling the fire, and deducting from the weight of coal fired whatever unburned coal is contained in the refuse withdrawn from the furnace, the quantity of water in the boiler and the steam-pressure being the same as at the time of lighting the fire at the beginning of the test.

Previous to the close of the test it is desirable that the fire should be burned down to a low point, so that the unburned coal withdrawn may be in a nearly consumed state. The temperature of the feed-water is observed at the point where the water leaves the engine heater, if this be used, or at the point where it enters the flue-heater, if that apparatus be employed. Where an injector is used for supplying the water, a deduction

is to be made in either case for the increased temperature of the water derived from the steam which it consumes.

As soon after the beginning of the boiler-test as practicable the engine is started and preparations are made for the beginning of the engine-test. The formal commencement of this test is delayed till the plant is again in normal working condition, which should not be over one hour after the time of lighting the fire. When the time for commencement arrives the feed-water is momentarily shut off, and the water in the lower tank is brought to a mark. Observations are then made of the number of tanks of water thus far supplied, the height of water in the gauge-glass of the boiler, the indication of the counter on the engine, and the time of day; after which the supply of feed-water is renewed, and the regular observations of the test, including the measurement of the auxiliary supplies of feed-water, are commenced. The engine-test is to continue at least ten hours. At its expiration the feed-pump is again momentarily stopped, care having been taken to have the water slightly higher than at the start, and the water in the lower tank is brought to the mark. When the water in the gauge-glass has settled to the point which it occupied at the beginning, the time of day and the indication of the counter are observed, together with the number of tanks of water thus far supplied, and the engine-test is held to be finished. The engine continues to run after this time till the fire reaches a condition for hauling, and completing the boiler-test. then stopped, and the final observations relating to the boilertest are taken.

The observations to be made and data obtained for the purposes of the engine-test, or duty-trial proper, embrace the weight of feed-water supplied by the main feeding apparatus, that of the water drained from the jackets, and any other water which is ordinarily supplied to the boiler, determined in the manner pointed out. They also embrace the number of hours' duration, and number of single strokes of the pump during the test; and, in direct-acting engines, the length of the stroke, together with the indications of the gauges attached to the

force and suction mains, and indicator-diagrams from the steamcylinders. It is desirable that pump-diagrams also be obtained.

Observations of the length of stroke, in the case of directacting engines, should be made every five minutes; observations of the water-pressure gauges every fifteen minutes; observations of the remaining instruments—such as steamgauge, vacuum-gauge, thermometer in pump-well, thermometer in feed-pipe; thermometer showing temperature of engineroom, boiler-room, and outside air; thermometer in flue, thermometer in steam-pipe, if the boiler has steam-heating surface, barometer, and other instruments which may be used—every half-hour. Indicator-diagrams should be taken every half-hour.

When the duty-trial embraces simply a test of the engine, apart from the boiler, the course of procedure will be the same as that described, excepting that the fires will not be hauled, and the special observations relating to the performance of the boiler will not be taken.

Directions regarding Arrangement and Use of Instruments, and other Provisions for the Test.—The gauge attached to the force-main is liable to a considerable amount of fluctuation unless the gauge-cock is nearly closed. The practice of choking the cock is objectionable. The difficulty may be satisfactorily overcome, and a nearly steady indication secured, with cock wide open, if a small reservoir having an air chamber is interposed between the gauge and the force-main. By means of a gauge-glass on the side of the chamber and an air-valve, the average water-level may be adjusted to the height of the centre of the gauge, and correction for this element of variation is avoided. If not thus adjusted, the reading is to be referred to the level shown, whatever this may be.

To determine the length of stroke in the case of direct acting engines, a scale should be securely fastened to the frame which connects the steam and water cylinders, in a position parallel to the piston-rod, and a pointer attached to the rod so as to move back and forth over the graduations on the scale. The marks on the scale, which the pointer reaches at the two

ends of the stroke, are thus readily observed, and the distance moved over computed. If the length of the stroke can be determined by the use of some form of registering apparatus, such a method of measurement is preferred. The personal errors in observing the exact scale-marks, which are liable to creep in, may thereby be avoided.

The form of calorimeter to be used for testing the quality of the steam is left to the decision of the person who conducts the trial. It is preferred that some form of continuous calorimeter be used, which acts directly on the moisture tested. either the superheating calorimeter \* or the wire-drawing † instrument be employed, the steam which it discharges is to be measured either by numerous short trials, made by condensing it in a barrel of water previously weighed, thereby obtaining the rate by which it is discharged, or by passing it through a surface-condenser of some simple construction, and measuring the whole quantity consumed. When neither of these instruments is at hand, and dependence must be placed upon the barrel calorimeter, scales should be used which are sensitive to a change in weight of a small fraction of a pound, and thermometers which may be read to tenths of a degree. The pipe which supplies the calorimeter should be thoroughly warmed and drained just previous to each test. In making the calculations the specific heat of the material of the barrel or tank should be taken into account, whether this be of metal or of wood.

If the steam is superheated, or if the boiler is provided with steam-heating surface, the temperature of the steam is to be taken by means of a high-grade thermometer resting in a cup holding oil or mercury, which is screwed into the steampipe so as to be surrounded by the current of steam. The temperature of the feed-water is preferably taken by means of a cup screwed into the feed-pipe in the same manner.

Indicator-pipes and connections used for the water-cylin-

<sup>\*</sup> Vol. VII, p. 178, 1886, Transactions A. S. M. E. See page 386 of this volume.

<sup>†</sup> Vol. XI, 1890, p. 193, Transactions A. S. M. E. See page 388 of this volume.

ders should be of ample size, and, so far as possible, free from bends. Three-quarter-inch pipes are preferred, and the indicators should be attached one at each end of the cylinder. It should be remembered that indicator-springs which are correct under steam heat are erroneous when used for cold water. When such springs are used, the actual scale should be determined, if calculations are made of the indicated work done in the water-cylinders. The scale of steam-springs should be determined by a comparison, under steam-pressure, with an accurate steam-gauge at the time of the trial, and that of water-springs by cold dead-weight test.

The accuracy of all the gauges should be carefully verified by comparison with a reliable mercury-column. Similar verification should be made of the thermometers, and if no standard is at hand, they should be tested in boiling water and melting ice.

To avoid errors in conducting the test, due to leakage of stop-valves either on the steam-pipes, feed-water pipes, or blow-off pipes, all these pipes not concerned in the operation of the plant under test should be disconnected.

# (3) LEAKAGE-TEST OF PUMP.

As soon as practicable after the completion of the main trial (or at some time immediately preceding the trial) the engine is brought to rest, and the rate determined at which leakage takes place through the plunger and valves of the pump, when these are subjected to the full pressure of the forcemain.

The leakage of the plunger is most satisfactorily determined by making the test with the cylinder-head removed. A wide board or plank may be temporarily bolted to the lower part of the end of the cylinder, so as to hold back the water in the manner of a dam, and an opening made in the temporary head thus provided for the reception of an overflow pipe. The plunger is blocked at some intermediate point in the stroke (or, if this position is not practicable, at the end of the stroke), and

the water from the force-main is admitted at full pressure be hind it. The leakage escapes through the overflow pipe, and it is collected in barrels and measured.

Should the escape of the water into the engine-room be objectionable, a spout may be constructed to carry it out of the building. Where the leakage is too great to be readily measured in barrels, or where other objections arise, resort may be had to weir or orifice measurement, the weir or orifice taking the place of the overflow-pipe in the wooden head. The apparatus may be constructed, if desired, in a somewhat rude manner, and yet be sufficiently accurate for practical requirements. The test should be made, if possible, with the plunger in various positions.

In the case of a pump so planned that it is difficult to remove the cylinder-head, it may be desirable to take the leakage from one of the openings which are provided for the inspection of the suction-valves, the head being allowed to remain in place.

It is here assumed that there is a practical absence of valveleakage, a condition of things which ought to be attained in all well-constructed pumps. Examination for such leakage should be made first of all, and if it occurs and it is found to be due to disordered valves, it should be remedied before making the plunger-test. Leakage of the discharge-valves will be shown by water passing down into the empty cylinder at either end when they are under pressure. Leakage of the suction-valves will be shown by the disappearance of water which covers them.

If valve-leakage is found which cannot be remedied, the quantity of water thus lost should also be tested. The determination of the quantity which leaks through the suction-valves, where there is no gate in the suction-pipe, must be made by indirect means. One method is to measure the amount of water required to maintain a certain pressure in the pump-cylinder when this is introduced through a pipe temporarily erected, no water being allowed to enter through the discharge-valves of the pump.

The exact methods to be followed in any particular case, in determining leakage, must be left to the judgment and ingenuity of the person conducting the test.

# (4) TABLE OF DATA AND RESULTS.

In order that uniformity may be secured, it is suggested that the data and results, worked out in accordance with the standard method, be tabulated in the manner indicated in the following scheme:

#### DUTY-TRIAL OF ENGINE.

#### Dimensions,

I. Number of steam-cylinders	
2. Diameter of steam-cylinders	ios.
3. Diameter of piston-rods of steam-cylinders	ins.
4. Nominal stroke of steam-pistons	ft.
5. Number of water-plungers	
6. Diameter of plungers	ins.
7. Diameter of piston-rods of water-cylinders	ins.
8. Nominal stroke of plungers	ft.
q. Net area of plungers	sq. ins
IO. Net area of steam-pistons	sq. ins
11. Average length of stroke of steam-pistons during trial	
12. Average length of stroke of plungers during trial	ft.
(Give also complete description of plant.)	
_	
Temperatures.	
13. Temperature of water in pump-well	degs.
14. Temperature of water supplied to boiler by main feed-pump.	degs.
15. Temperature of water supplied to boiler from various other	
sources	degs.
To do do	
Feed-water.	
16. Weight of water supplied to boiler by main feed-pump	
17. Weight of water supplied to boiler from various other sources.	
18. Total weight of feed-water supplied from all sources	lbs.
Pressures.	
19. Boiler-pressure indicated by gauge	
20. Pressure indicated by gauge on force-main	
21. Vacuum indicated by gauge on suction-main	
22. Pressure corresponding to vacuum given in preceding line	
23. Vertical distance between the centres of the two gauges	
24. Pressure equivalent to distance between the two gauges	lbs.

## Miscellaneous Data.

	miscenaneous Data.
26.	Duration of trial
	Total leakage of pump during trial, determined from results of leakage-test
29.	Mean effective pressure, measured from diagrams taken from steam-cylinders
	Principal Results.
31. 32.	Duty
	Additional Results.*
	Number of double strokes of steam-piston per minute
	Indicated horse-power developed by the various steam-cylinders I. H. P.
37.	Feed-water consumed by the plant per hour lbs.  Feed-water consumed by the plant per indicated horse-power  per hour, corrected for moisture in steam lbs.
38.	Number of heat-units consumed per indicated horse-power per hour B. T.U.
39.	Number of heat-units consumed per indicated horse-power per minute B. T.U.
40.	Steam accounted for by indicator at cut-off and release in the various steam-cylinders
41.	Proportion which steam accounted for by indicator bears to the feed-water consumption
	Sample Diagrams taken from Steam-cylinders.
at the is	o, if possible, full measurements of the diagrams, embracing pressures initial point, cut-off, release, and compression; also back-pressure, and portions of the stroke completed at the various points noted.]
43.	Number of double strokes of pump per minute

<sup>\*</sup> These are not necessary to the main object, but it is desirable to give them,

Sample Diagrams taken from Pump-cylinders.				
•••••				
•••••				
•••••				
DATA AND RESULTS OF BOILER-TEST.				
[IN ACCORDANCE WITH THE SCHEME RECOMMENDED BY THE BOILE COMMITTEE OF THE SOCIETY.]	R-TEST			
1. Date of trial				
2. Duration of trial h	rs.			
Dimensions and Proportions.	•			
3. Grate-surface wide long Areas	q. ft.			
4. Water-heating surface s	q. ft.			
5. Superheating-surface s	q. ft.			
6. Ratio of water-heating surface to grate-surface				
(Give also complete description of boilers.)				
Average Pressures.				
7. Steam-pressure in boiler by gauge	bs.			
8. Atmospheric pressure by barometer li				
9. Force of draught in inches of water in				
Average Temperatures.				
10. Of steam	degs.			
II. Of escaping gases	legs.			
12. Of feed-water				
Fuel.				
13. Total amount of coal consumed # l	bs.			
14. Moisture in coal %	<b>S</b>			
15, Dry coal consumed ll	bs.			
16. Total refuse (dry)ll	bs.			
17. Total combustible (dry weight of coal, item 15, less refuse,				
item 16) lt				
18. Dry coal consumed per hour lt	bs.			
Results of Calorimetric Test.				
19. Quality of steam, dry steam being taken as unity				
20. Percentage of moisture in steam \$				
21. Number of degrees superheated	iegs.			

<sup>\*</sup>Including equivalent of wood used in lighting fire. One pound of wood equals 0.4 of a pound of coal, not including unburned coal withdrawn from fire at end of test.

# Water.

22. Total weight of water pumped into boiler and apparently evaporated *	lhe.
23. Water actually evaporated corrected for quality of steam	
• • • • • • • • • • • • • • • • • • • •	105.
24. Equivalent water evaporated into dry steam from and at	ú . ·
212° F.†	ibs.
25. Equivalent total heat derived from fuel, in British thermal	
units	B. T.U.
26. Equivalent water evaporated into dry steam from and at	•
212° F. per hour	lbs.
Economic Evaporation.	
·	
27. Water actually evaporated per pound of dry coal from actual	
pressure and temperature	lbs.
28. Equivalent water evaporated per pound of dry coal from	
and at 212° F	lbs.
29. Equivalent water evaporated per pound of combustible from	
and at 213° F	lbs.
30. Number of pounds of coal required to supply one million	
British thermal units	lbs.
Rate of Combustion.	
31. Dry coal actually burned per square foot of grate-surface per	
hour	lbs.
Rate of Evaporation.	
32. Water evaporated from and at 212° F. per square foot of	
heating-surface per hour	lhs.
• • • • • • • • • • • • • • • • • • • •	

To determine the percentage of surface moisture in the coal a sample of the coal should be dried for a period of twenty-four hours, being subjected to a temperature of not more than 212°. The quantity of unconsumed coal contained in the refuse withdrawn from the furnace and ash-pit at the end of the test may be found by sifting either the whole of the refuse, or

<sup>\*</sup> Corrected for inequality of water-level and of steam-pressure at beginning and end of test.

<sup>†</sup> Factor of evaporation =  $\frac{H-h}{965.7}$ , H and h being, respectively, the total heat-units in steam of the average observed pressure, and in water of the average observed temperature of feed.

a sample of the same, in a screen having \$\frac{4}{8}\$-inch meshes. This, deducted from the weight of dry coal fired, gives the weight of dry coal consumed, for line 15.

Results of actual trial, as illustrated by the committee, would be computed by the use of the following formulæ:

1. Duty = 
$$\frac{\text{Foot-pounds of work done}}{\text{Total number of heat-units consumed}} \times 1,000,000$$
$$= \frac{A(P \pm p + s) \times L \times N}{H} \times 1,000,000 \text{ (foot-pounds)}.$$

- 2. Percentage of leakage =  $\frac{C \times 144}{A \times L \times N} \times 100$  (per cent).
- 3. Capacity = number of gallons of water discharged in 24 hours

$$= \frac{A \times L \times N \times 7.4805 \times 24}{D \times 144}$$
$$= \frac{A \times L \times N \times 1.24675}{D} \text{ (gallons)}.$$

4. Percentage of total friction

$$= \left(\frac{I.H.P. - \frac{A(P \pm p + s) \times L \times N}{D \times 60 \times 33,000}}{I.H.P.}\right) \times 100$$

$$= \left[1 - \frac{A(P \pm p \times s) \times L \times N}{A. \times M.E.P. \times L. \times N.}\right] \times 100 \text{ (per cent)};$$

or, in the usual case, where the length of the stroke and number of strokes of the plunger are the same as that of the steampiston, this last formula becomes—

Percentage of total frictions = 
$$\left[1 - \frac{A(P \pm p + s)}{A_s \times M.E.P.}\right] \times 100 (p.c.)$$

In these formulæ the letters refer to the following quantities:

- A = Area, in square inches, of pump-plunger or piston, corrected for area of piston-rod. (When one rod is used at one end only, the correction is one half the area of the rod. If there is more than one rod, the correction is multiplied accordingly.)
- P = Pressure, in pounds per square inch, indicated by the gauge on the force-main.
- Pressure, in pounds per square inch, corresponding to indication of the vacuum-gauge on suctionmain (or pressure-gauge, if the suction-pipe is under a head). The indication of the vacuumgauge, in inches of mercury, may be converted into pounds by dividing it by 2.035.
- s = Pressure, in pounds per square inch, corresponding to distance between the centres of the two gauges. The computation for this pressure is made by multiplying the distance, expressed in feet, by the weight of one cubic foot of water at the temperature of the pump-well, and dividing the product by 144; or by multiplying the distance in feet by the weights of one cubic foot of water at the various temperatures.
- L = Average length of stroke of pump-plunger, in feet.
- N = Total number of single strokes of pump-plunger made during the trial.
- A = Area of steam-cylinder, in square inches, corrected for area of piston-rod. The quantity  $A_i \times M.E.P.$ , in an engine having more than one cylinder, is the sum of the various quantities relating to the respective cylinders.
- $L_i$  = Average length of stroke of steam-piston, in feet.
- **N**<sub>s</sub> = Total number of single strokes of steam-piston during trial.
- M.E.P. = Average mean effective pressure, in pounds per

square inch, measured from the indicator-diagrams taken from the steam cylinder.

I.H.P. = Indicated horse-power developed by the steamcylinder.

C = Total number of cubic feet of water which leaked by the pump-plunger during the trial, estimated from the results of the leakage-test.

D = Duration of trial, in hours.

H = Total number of heat-units [B. T. U.] consumed byengine = weight of water supplied to boiler by main feed-pump x total heat of steam of boilerpressure reckoned from temperature of main feedwater + weight of water supplied by jacket-pump x total heat of steam of boiler-pressure reckoned from temperature of jacket-water + weight of any other water supplied x total heat of steam reckoned from its temperature of supply. The total heat of the steam is corrected for the moisture or superheat which the steam may contain. moisture, the correction is subtracted, and is found by multiplying the latent heat of the steam by the percentage of moisture, and dividing the product by 100. For superheat, the correction is added. and is found by multiplying the number of degrees of superheating (i.e., the excess of the temperature of the steam above the normal temperature of saturated steam) by 0.48. No allowance is made for heat added to the feed-water. which is derived from any source, except the engine or some accessory of the engine. Heat added to the water by the use of a flue-heater at the boiler is not to be deducted. Should heat be abstracted from the flue by means of a steamreheater connected with the intermediate receiver of the engine, this heat must be included in the total quantity supplied by the boiler.

The following example is one of those given by the com-

mittee to illustrate the method of computation. The figures are not obtained from tests actually made, but they correspond in round numbers with those which were so obtained:

EXAMPLE.—Compound Fly-wheel Engine.—High-pressure cylinder jacketed with live steam from the boiler. Low-pressure cylinder jacketed with steam from the intermediate receiver, the condensed water from which is returned to the boiler by means of a pump operated by the engine. steam-pipe fitted with a separator. The intermediate receiver provided with a reheater supplied with boiler-steam. Water drained from high-pressure jacket, separator, and reheater collected in a closed tank under boiler-pressure, and from this point fed to the boiler direct by an independent steam-pump. Jet-condenser used operated by an independent air-pump. Main supply of feed-water drawn from hot-well and fed to the boiler by donkey steam-pump, which discharges through a feed-water heater. All the steam-pumps, together with the independent air-pump, exhaust through the heater to the atmosphere.

#### DIMENSIONS.

Diameter of high-pressure steam-cylinder (one).       20 ir         Diameter of low-pressure steam-cylinder (one).       40 for the control of plunger (one).         Diameter of plunger (one).       20 for the control of plunger (one).         Diameter of each piston-rod       4 for the control of plunger (one).		
Stroke of steam-pistons and pump-plunger	• • • • • •	3 ft.
GENERAL DATA.		
<ol> <li>Duration of trial (D)</li> <li>Boiler-pressure indicated by gauge (barometric press-</li> </ol>	10	hrs.
ure, 14.7 lbs.)	120	lbs.
3. Temperature of water in pump-well	60	degs.
pump, leaving heater	215	
pump	225	
<ol> <li>Temperature of water supplied by high-pressure jacket, separator, and reheater-pump, that derived from separator being 340°, and that from jackets</li> </ol>		

300

7.	Weight of water supplied to boiler by main feed-pump	18,863	lbs.
	Weight of water supplied by low-pressure jacket-pump	615	41
	Weight of water supplied by pump for high-pressure		
•	jacket, separator, and reheater-tank, of which 210		
	lbs. is derived from separator	1,025	**
IO.	Total weight of feed-water supplied from all sources	20,503	**
II.	Percentage of moisture in steam after leaving sepa-	- •	
	rator	1.5	×
	DATA RELATING TO WORK OF PUMP.		
12.	Area of plunger minus $\frac{1}{4}$ area of piston-rod $(A)$	307.8	8 sq. in.
	Average length of stroke ( $L$ and $L_s$ )	3	ft.
14.	Total number of single strokes during trial (N and $N_z$ )	24,000	
15.	Pressure by gauge on force-main (P)	95	lbs.
	Vacuum by gauge on suction-main	7-5	in.
17.	Pressure corresponding to vacuum given in preceding		
	line (p)	3.6	g lbs.
	Vertical distance between centres of two gauges	10	ft.
	Pressure equivalent to distance between two gauges (s)	4-3	3 lbs.
20.	Total leakage of pump during trial, determined from	_	
	results of leakage-test (C)	3,078	cu. ft.
	Number of double strokes of pump per minute  Mean effective pressure measured from pump-dia-	20	
32.	grams	705	lbs.
92	Indicated horse-power exerted in pump-cylinders	105	5 I.H.P.
	indicated notice-power excited in pump cylinders,	**/-5	3 1.11.1 .
	. DATA RELATING TO WORK OF STEAM-CYLINI	DERS.	
•	Area of high-pressure piston minus $\frac{1}{4}$ area of rod $(A_{E})$		8 sq. in.
	Area of low-pressure piston minus \( \frac{1}{4} \) area of rod (A <sub>12</sub> )	1,250.3	
	Average length of stroke, each	3	ft.
27.	Mean effective pressure measured from high-pressure		. ••
- 0	diagrams (M.E.P. <sub>1</sub> )	59.2	5 lbs.
28.	Mean effective pressure measured from low-pressure diagrams (M.E.P. <sub>2</sub> )	13.6	. "
-	Number of double strokes per minute (line 21)	20	,
•	Indicated horse-power developed by HP. cylinder		I.H.P.
•	Indicated horse-power developed by LP. cylinder	61.82	-
	Indicated horse-power developed by both cylinders	128.15	
	Feed-water consumed by plant per indicated horse-		,
<i>J</i> <b>J</b> ·	power per hour, corrected for separator-water and		
	for moisture in steam	15.60	lbs.
34.	Number of heat-units consumed per indicated horse-		
•	power per hour	15,652.1	B.T.U
35.	Number of heat-units consumed per indicated horse-	-	
	power per minute	260.9	"

TOTAL HEAT OF STEAM RECKONED FROM THE VARIOUS TEMPERATURES OF FEED-WATER, AND COMPUTATIONS BASED THEREON.

36.	Total heat of 1 lb. of steam at 120 lbs. gauge-pressure, containing 1.5% of moisture, reckoned from 0° F.=		
	1220.6—(1.5% of 866.7)	207.6	B.T.U.
37.	Ditto, reckoned from 215° temperature of main feed-		
	water = $1207.6 - 215.9$	991.7	**
38.	Ditto, reckoned from 225° temperature of low-pressure		
	jacket-water = 1207.6 - 226.1	981.5	**
39.	Ditto, reckoned from 290° temperature of high-pres-		
	sure jacket and reheater water = $1207.6 - 292.3 =$	915.3	**
40.	Heat of separator-water reckoned from 340°=353.9-		
	343.8	10.1	**
41.	Heat consumed by engine $(H) = (18.863 \times 991.7) +$		
	$(615 \times 081.5) + (815 \times 015.2) + (210 \times 10.1) = \dots 20.058$	. 160	66

#### RESULTS.

Substituting these quantities in the formulæ, we have:

I. Duty = 
$$\frac{{307.88 \times (95 + 3.69 + 4.33) \times 3 \times 24,000}}{{H}} \times 1,000,000$$
$$= 113,853,044 \text{ foot-pounds.}$$

2. Percentage of leakage = 
$$\frac{\frac{C}{3078 \times 144}}{\frac{A}{307.88 \times 3 \times 24,000}} \times 100 = 2.0\%.$$

3. Capacity = 
$$\frac{{307.88 \times 3 \times 24,000 \times 1.24675}}{D}$$
10
= 2,763,716 gallons.

4. Percentage of total frictions

$$= \left(1 - \frac{\frac{A}{307.88 \times (95 + 3.69 + 4.33)}}{\frac{A_{11}}{(307.88 \times 59.25) + (1250.36 \times 13.6)}}\right) \times 100$$

$$= 9.0\%$$

In the use of a system like the preceding, every precaution should be observed in the adoption of methods, as well as in taking observations. The water discharged by a pumping-engine, for example, should never be obtained by computation from the measured dimensions of the pump and the observed number of strokes, but should be measured directly. A weir is commonly arranged for this purpose. Where the delivery of the pump has been actually measured, and the pump thus standardized, its use as a meter is less liable to error, but it is best avoided whenever possible.

434. Standard Method of Testing Locomotives.— The following is a reprint of a report of a committee on standard methods of testing locomotives appointed by the American Society of Mechanical Engineers, and submitted at the San Francisco meeting in 1892:

Locomotive-testing is conducted under such unfavorable circumstances and surroundings that many of the exact methods employed in testing stationary engines or boilers cannot be used. It is desirable, therefore, that locomotive-tests be always made with a special train when possible, so that the same cars shall be used for the different trips, and the weight of train be uniform. The speed of the train can also be under control, and the tests not hampered by the rules governing a regularly scheduled train. Special and peculiar apparatus is employed by nearly every different experimenter as having some extra merit of convenience or accuracy, and we have endeavored to ascertain the best practical instruments and methods for the various measurements, and to illustrate or explain them.

When a dynamometer-car is not used:

As a final basis of comparison of locomotives, we recommend as a unit the number of thermal units used per indicated horse-power per hour. The object in view in testing a locomotive will determine the methods employed and the extent and kind of data necessary to obtain. Some tests are made to ascertain the economy of a particular kind of boiler or fire-

box; others, the value of employing compound cylinders; others, to ascertain the relative merits of certain coals for locomotive use.

As a practical and commercial unit the amount of coal consumed per ton-mile may be used.

For a coal-test we give a separate method and test blanks, Form D, for tabulating results.

For a unit of comparison of boiler-test we recommend the number of thermal units F. taken up every hour by the water and steam in the boiler.

For a measurement of the resistance overcome in hauling a train, a dynamometer-car is essential, and we give a method of operating a dynamometer-car and of recording results.

For a uniform method of recording results of indicatortests, we recommend the blank Form A.

For tabulating general results, Form B is presented.

The waste from the injector should be ascertained by catching it in a vessel conveniently attached, or by starting the injector several times in the engine-house and catching the over-flow in a tub.

The total weight of the water caught divided by the number of applications of the injector gives the average waste. The observer in the cab should keep a record of the number of times the injector is applied during the trips, and thus obtain data for estimating the total waste.

## FUEL MEASUREMENTS.

The measurement of fuel in locomotive-tests is not difficult so far as a determination of the total amount shovelled into the fire is concerned. A weighed amount may be shovelled into the tank, and the amount remaining, after a given run, be weighed to determine the amount used, provided no water is used to wet down the coal. But it is next to impossible to determine the amount of coal used at any particular portion of a run when the coal is put in the tender in bulk. If coal is put in sacks containing 125 pounds each, with a small amount of weighed coal on the foot-plate, even with heavy firing it is

found quite possible for the fireman to cut open the bags, and dump the coal on the foot-plate as needed. In this way the rate of consumption on difficult portions of the run could readily be estimated. The use of water-meters and of coal in sacks obviates any need of weighing the tender, and thus removes one of the largest inaccuracies incident to the ordinary locomotive-tests. To determine the amount of coal used during the trip, it is only necessary to count the number of bags which have been emptied. However, the determination of the amount of fuel used during a run is not all that is necessarv for a test. The measurement of the fire-line before and after a test is very essential and extremely difficult. If the run is a long one, then the errors in the determination of the fire-line may not be great; but for short runs there seems to be no way of measuring the difference between the heat-value of coal in the fire before the test and after with sufficient accuracy to give reliable data. In tests made on a heavy grade, one trip closely succeeding another, it is of course impracticable to drop the fire and measure the amount of fuel in the ashes remaining. Such measurements are unsatisfactory and inaccurate in any case, because it is not practicable to draw the fire without wetting it, as the ashes rise into the machinery, and they are too hot to handle. When one run succeeds another within a short space of time, some other method is necessary for measuring fuel used than by dumping the coal.

The test is commenced with a good fire in the furnace, and the height of coal estimated by two or more assistants engaged in the trial. At the end of the run the fire should be in the same condition as near as possible. No raw coal should be in the box and steam-pressure and pyrometer-pressure falling.

#### APPLICATION OF THE INDICATOR.

If the power of the engine is to be determined, the action of the valve-gear examined, or the coal and water used per unit of power in a unit of time, the indicator must be used. This instrument should be attached to a three-way cock just at the outer edge of the steam-chest, in order that the connecting pipes (which should be \( \frac{1}{4} \) inch in diameter) can go directly in a diagonal direction to holes tapped into the sides of the cylinder rather than into the heads (Fig. 227). By this arrangement the pipes are shorter than when they pass over




FIG. 227-REDUCING-MOTION FOR LOCOMOTIVES.


the steam-chest into the heads, and have but short horizontal portions, thus facilitating the rapid draining of the pipes. Moreover, if a cylinder-head is knocked out the pipes are not dragged off, and the operator and indicator escape injury. The indicator should not be placed on horizontal pipes on a level with the axis of the cylinder-heads.

The indicator-pipes and three-way cock should be covered with a non-conductor, wrapped with canvas and painted. The indicator itself should be wrapped as high as the vent-holes in its steam-cylinder.

The indicator-gear may be a rigid, true pantograph motion, either fixed or adjustable in height (Fig. 228); or it may be a simple pendulum connected by link to the cross-head with a wooden quadrant 2 inches thick, and having a radius such as will make the indicator-card 3 inches long.

The cord of the indicator should be 8 or 10 inches long, and connected with a rod reaching forward from the pantograph.

In order to determine the steam-chest pressure, the indicator should be so piped that a steam-chest diagram can be



drawn by it. A steam-gauge on the chest is inaccurate and difficult to use.

Indicator-diagrams should be taken at equal distances instead of at equal time-intervals, in order to properly average the power. They should therefore be taken at mile-posts. The signal for taking diagrams should be given by the observer in the cab, who can pull a cord and ring a bell at the front of the engine, or blow the whistle.

For the safety of the operator at the indicator, it is recommended that the seat be on a piece of boiler-plate above the cylinder, and so arranged that a piston or cylinder-head can pass out without injuring him.

The person who takes the indicator-diagrams should be thoroughly sheltered by a temporary box containing a seat placed on the front end of the engine. Besides the usual indicator, there should be located near the observer a revolution-counter, which should be so arranged that after starting out the instrument will continue to record the revolutions for a period of exactly one minute, starting every time from zero, and when the minute has elapsed the counter will stop. Such an instrument is already in existence for taking the continuous revolutions of dynamos and high-speed engines, and little or no difficulty would be experienced in obtaining an instrument capable of taking the revolutions from some reciprocating part of the machinery.

It is desirable also to have an electric connection between the indicator and the recording apparatus in the dynamometercar, so that at the instant an indicator-diagram is taken, the fact may be registered on the dynamometer-diagram, see Article 181, page 218; and the cards should be numbered consecutively, and the record likewise.

Besides the person taking the indicator-diagrams, another person should be located in the cab of the engine, whose duty it should be to observe the point of cut-off given by the position of the reverse-lever, the position of the throttle-lever, and the boiler-pressure, all of which conditions should be recorded in a log-book for this purpose.

Besides recording on the dynamometer-diagram the fact that an indicator-card is being taken, a bell should be rung at the same time, so as to call the attention of the observers in the dynamometer-car to this fact.

## LOCOMOTIVE-BOILER TESTS .- GENERAL DIRECTIONS.

First. The drawing of the boiler to accompany the report of tests should be particular in specifying the construction in detail, with reference to coal-burning and generating steam, such as heating surface, grate area and the distribution of openings through the grate, volume of fire-box, size and thickness of

flues, size of smoke-box, and the arrangement for draught, together with the thickness of walls between the heated gases and the water in the boiler; the weight of the boiler itself should be given, and the number of cubic feet of water-space and of steam-space in the boiler, the division between the two to be taken at the middle of the range of the gauges.

Second. Boilers for tests should be thoroughly cleaned on both sides of the heating surface, by a removal of the flues, before any test is commenced, and these surfaces should be kept clean by frequent washing during the test.

Exception.—When it is desired to make a comparison of boilers for the purpose of determining a difference between them as to incrustation, they should first be tested as above when clean, and then tested again without cleaning further than the ordinary washing out of the boilers after the lapse of some months' service. The results are to be reduced to evaporation per square foot of heating surface; both boilers using the same water during the period of testing.

Third. In case the measure of the capacity of the locomotive boiler for generating steam be desired, without reference to the engines forming the locomotive, this capacity should be measured by the number of British thermal units, taken up per hour by the water and steam in the boiler, which may be readily determined from the observed data of temperature of water fed to the boiler, pounds of water evaporated per hour, and steam-pressure under which this evaporation occurs. Use any good set of steam-tables, such as Peabody's or Porter's, found in Appendix, or in Richard's Steam-engine Indica-In such cases it will be necessary to specify all the pertinent conditions under which such measure of the capacity of the boiler is made, so that in comparing with the capacity of another boiler all such conditions may be made as nearly alike as possible. It is, however, believed that a measure of the capacity of a locomotive boiler, without any reference to the capacity or efficiency and method of working of the engines on the locomotive which such boiler feeds, will not be of particular value in comparison of boilers, unless the conditions

under which the enrines are worked with different boilers are identical, or nearly so.

Fourth. On account of the important influence which the temperature, and especially the moisture of the atmosphere, has upon the results obtained in a boiler-test, it is necessary to compare two or more boilers at the same place and at the same time, to get results which may be strictly comparable. The temperature of the air should then be noted for record.

Fifth. To properly determine the amount of water fed to a locomotive boiler in service on a locomotive during any test, it is necessary to use a good water-meter, which should have its maximum error determined by previous tests and given with the report.


Sixth. The coal used should be dry when weighed, and placed in sacks, each containing 100 or 125 lbs., care being taken to insure that all scales used are accurate. When an unusually large amount of coal is needed, a weighed quantity of coal may be placed in the front of the tender and used first, and the test finished with coal from the sacks. An analysis of the coal used should accompany the report, which should show the volatile matter, the fixed carbons, etc., the moisture, and the ash contained in the coal. The ashes should be dried if they contain any moisture, and carefully weighed and recorded after each test-run.

Seventh. The temperature of the smoke-box gases should be measured by a good pyrometer, located near enough to the flues in the smoke-box to get the average temperature of the gases after they have passed the heating surface, and before they are mixed with the exhaust steam. It is suggested that pyrometers, such as that offered by Schaeffer & Budenberg, or Weiskopf, are suitable for this purpose.

The location of pyrometers is shown at p, Fig. 229. These instruments cost about thirty-five dollars. They should register up to 1000° F. See Article 296.

Eighth. The degree of exhaustion in the smoke-box should be measured and recorded by means of a simple manometergauge. See Article 273. Ninch. The quality of the steam furnished by the boiler to the engines should be determined by the most approved methods: See Chapter XIII.

Tenth. Samples of gases passing from the flues to the smoke-box should be analyzed and results reported. The



means of taking such gases so as to insure perfect samples is to be further considered, and definite means prescribed. See Article 358, page 423.

#### COAL TESTS.

Directions to be observed in Supervising and Conducting Coaltrials.—The locomotive selected should be in good condition,

and either a new engine or one that has lately undergone repairs.

The boiler should be washed before commencing the trial, the steam-gauge tested, the flues cleaned, and the exhaust nozzles cleaned and measured, which operations should be performed also whenever the kind of coal is changed. Instructions should be given to round-house foremen that no repairs or alterations of any sort be made to the engine without the approbation of the conductor of the trial. The same engineman and fireman should operate the engine throughout the trial, and the same methods of firing and running should be strictly adhered to. The run selected should be one in which the same distance is covered on each trip. The trains should be through trains and unbroken from end to end of the run, and the same number of cars and same lading should be provided each trip. The same speed should, if possible, be preserved on all trips.

The conductor of the trial should be familiar with correct methods of firing and running locomotives, and should insist that the fireman adhere to approved methods of firing, and that the same methods be preserved throughout the duration of the trial, so that all coals shall receive the same treatment. (See Chapter XIV, on Heating Values of Fuels, and Chapter XV, on Steam-boiler Trials.)

He should also see that the coal supplied at coaling points is of the proper kind, and should weigh the coal personally, and keep an accurate record of the following items:

The coal consumed.

The amount of ash.

The amount of cinders in smoke-box.

The water evaporated.

The number of cars in train.

The weight of cars as marked thereon.

The weight of lading.

The state of the weather.

The direction and estimated velocity of wind.

The temperature of the atmosphere.

The temperature of the feed-water.

The time on road.

The steam-pressure,

The exhaust-nozzles.

The conductor should enter the above observations in a log-book, together with notes of repairs to engine, and any other items that might be of import.

#### REPORT OF COAL-TRIALS.

In order that coal-trials may be similar and consequently comparative, the following data should be observed (see Article 343, page 407):

## First.

Dates between which trials were conducted.

Class of locomotive.

Service in which trials were made, mentioning locality, etc.

Name of conductor of trial.

Second.

COAL A.

Kind of coal.

Name of mine and operator.

Location of mine.

Physical quality of coal (appearance).

Steaming quality of coal.

Kind of fire made.

Clinkers and ashes.

Cinders in smoke box.

Cleaning ash-pan and smoke-box.

Labor involved in firing.

COAL B.

Same as above.

#### GENERAL REMARKS.

Comparison of evaporation (pounds of water evaporated per pound of coal).

Comparison of coal consumed per 100 tons hauled one mile. Value coal A, 100%.

Value coal B.

Comparative value.

Coal A is 100% more or less valuable than coal B.

A table of engine-performance and a table of general results of engine-performance for each coal must accompany the report. (See Form D, page 584.)

#### WATER-MEASUREMENTS.

It has been found during the last year or two that meters are reliable and accurate within less than one per cent for measuring the water used by a locomotive. (The experience of the author does not accord with this statement—see Article 214, page 256.) The meters should be specially made for the purpose and, if possible, free from any material that is injured by contact with hot water. They should be placed so as to be read from the cab.

In mounting these meters, all pipes should be thoroughly cleaned before they are put into position, and a sufficiently large strainer should be placed between the meter and the tank. A most essential feature is to have a good flap check-valve between the injector and the meter; otherwise the hot water may flow backward and ruin the rubber recording-disks in the meter. As a check upon the meter, however, other means of measuring the water should be employed. The most convenient method is to use a float attached to a wooden bar which slides upon a graduated rod, the lower end of which rests upon the bottom of the tank. This rod is graduated to show 1000 lbs., and subdivided to 250 lbs.

The method of graduating the rod is as follows: Fill the tank, place the bar and float in the proper position for reading, and mark the stationary rod zero at a level with the top of the float bar. Draw from the tank 1000 lbs., place the measuring device in position again and mark the rod, calling this mark 1. Again draw off 1000 lbs., mark the rod 2, and so continue until the water is all drawn. If the tank has a uni-

FORM D.

TRAINS NOS. O AND O.

LOCOMOTIVE PERFORMANCE—COAL-TRIAL. R. R. LOCOMOTIVE CLASS

Between A and B. DATE.

Distance, 000 miles.

Fuel..... Coal.

BOILER-PRESSURE, OOO LBS.

Remarks.

Tone hauled One Mile.

Coal per Car per Mile, Lbs. Water evapo-rated perib. Coal.

Lbs. Water evaporasted per Trip.

Lbs. Coal consumed

Number of Cara in Train.

Average Running Speed in Miles per Hour.

Run-ring Time. H. M.

Time on Road. H. M.

Average, Steam-pressure, Average. Feed-Waler, Temperature of

mosphere.

Weather.

Temperature of At-

Date.

Number of Round Trip.

per Trip.

Total Weight Train in Tons.

Coal consumed per too Tons per Mile.

Totalsannon Averages.

LO

0

form horizontal section, several thousand pounds can be drawn off at once and the rod subdivided accordingly.

In general the float is placed in the man-hole of the tank; but as this is not in the centre of gravity of the water-space, its readings are not quite correct if the two ends of the tank change their relative heights. This can be overcome by having a special small opening made at the centre of gravity of the tank, or as near it as possible, and using a small float.

Another but less convenient way is to place a glass tube, on each side of the tank opposite the centre of gravity of the water-space, and to graduate scales behind them by the same method as above described. The objections to this method are the inconvenience in reading the scales (especially at way stations where there is but little time), their liability to freezing in cold weather, and the possibility of injuring them at any time.

The float is always convenient and serviceable.

When locomotive boilers are being fired hard, the water rises above the normal level, and a measurement of water just after the injectors have been throwing comparatively cold water into the boiler is not an accurate one: the water shrinks and swells according as the firing is hard or as the locomotive is being worked. Hence measurements taken under these variable conditions are necessarily approximations. There is also a continuous movement of the water in the water-glass, and a mean of the oscillations is not quite satisfactory. Although the amount of water fed into the boiler can be determined exactly by the use of meters, yet the inaccuracies of the location of the water-line render water-measurements on short runs almost impracticable. The six-hour test for a stationary engine is considered satisfactory when successive tests will give the same results; but in locomotive work, unless the engine be kept quiet, as it would be when tested in a shed, a short test is of little or no value. It may be accepted that a determination of the water-line by the sound of the gauge-cocks is too uncertain to be admissible in locomotive-tests unless the run is a long one. In such cases the total amount of water used is so large that any errors in estimating the water-level at the beginning or the end of the trip practically disappear.

A locomotive which is undergoing a test should have a water-glass on the boiler. Behind this should be a strip of wood graduated, and surrounding the glass and fastened to the wood should be a copper wire at the height at which the water should be left at the end of every trip. The tank-measurement should not be taken at the end of the trip until the water in the boiler is at the standard height. The temperature of the water should be taken as it enters the tank at every station where water is taken, and tank reading should be taken before and after each filling.

Leakage of Boiler.—To test for leakage, keep up the pressure to be carried, as nearly as possible, without blowing off, and note the fall of water in the water-glass in a given time, say four hours. Of course the injector must not be applied during this interval. The water-meter can then be used to determine the amount lost by leakage by reading the dial, applying the injector until the water reaches the original level, and then taking a second reading. The difference will be the amount of water lost. All boilers lose more or less from this cause, and if the test is to be a comparison between two different styles, the necessity for this information is obvious.

Before beginning a test, the pistons and the slide and throttle valves of the engine should be made tight. The point of cutoff for each notch of the quadrant should be ascertained, and the cut-off should be painted in white on the quadrant, or on

boiler-jacket, with pointer or lever. All leaks about the engine should be stopped.

A graduated scale and index should be attached to the throttle-rod to indicate its opening.

A special steam-gauge with a long siphon should be used for the boiler-pressure and attached to the front of the cab at the left side, so that it will not become incorrect from overheating. Readings of the gauge, reverse quadrant, throttle-scale, and boiler-height-scale should be taken frequently, the first as often as once in two and one-half, five, or ten minutes, depending on length and character of run, and all with each indicatordiagram, if the latter are being taken.

Just before beginning a trip the water in the boiler should be at the standard height and the tank reading taken in order to ascertain the amount of water used while running, or per indicated horse-power per hour.

Extraordinary efforts should be made to prevent blowing off before train time and while running. The number of times and the length of time safety-valve is blowing off should be recorded.

No water should be taken from the tank for any purpose except supplying the boiler, and the boiler should not be blown off during a test if it can be avoided. If it cannot be avoided, the water should be at the standard height before and after blowing.

### DYNAMOMETER RECORDS.

The dynamometer for measuring the resistance of the train, exclusive of the engine and tender resistance, should be able to record the following data:

- "A."—The pull upon the draw-bar.
- "B."—The speed at which the train is running.
- "C."—The location of any point along the line used for reference stations; and possibly
  - "D."—The wind-resistance.

## "A."—THE PULL UPON THE DRAW-BAR...

The force required to move the train or the pull upon the draw-bar should be registered upon a strip of paper travelling at a definite rate per mile of distance travelled over by the train. The scale upon which this diagram is drawn should be as large as is possible within reasonable limits; a scale of  $\frac{1}{4}$  inch per 1000 lbs. pull is probably as suitable as any that can be devised, and the maximum registered pull need hardly exceed 28,000 or 30,000 lbs. The height of the diagram should be

measured from a base-line drawn upon the paper by a stationary pen so located that when no force is exerted upon the draw-bar the base-line should coincide with zero pull.

"B."—THE SPEED AT WHICH THE TRAIN IS RUNNING.

This record should, if possible, be obtained in two ways:

First.—By an accurate time-piece, preferably a chronometer furnished with an electric circuit-breaking device. It is of considerable importance that the time-piece should have its circuit-breaking device very carefully made, to produce exact intervals-of-time marks, because, when the matters of acceleration or retardation of speeds enter into the data required, it is important that the time-record should be correct. The question of length of intervals of time required is open to discussion. In most cases of ordinary work, five-second intervals, or twelve to the minute, are probably as satisfactory as can be decided upon; for very careful work it would probably be advisable to have an auxiliary apparatus, something like the Boyer speed-recorder.

Boyer Speed-recorder.—This instrument is constructed in such a manner that its accuracy and reliability are without question when it is properly mounted and cared for. It is not a delicate machine, and only needs ordinary attention. Its principle of operation is as follows: It consists of an oilpump which works against a fixed resistance in the shape of an aperture through which the oil flows. The faster the pump runs, the greater is the pressure in the oil-cylinder. A piston in the oil-cylinder which moves against a spring rises in proportion to the increase of pressure. As the piston rises, a metallic pencil marks the movement on a roll of prepared paper, which moves in proportion to the longitudinal movement of the engine. In the cab is a dial which indicates at all times the speed of the engine with only a small error. The diagrams record all stops and make an accurate record of the rate of acceleration.

Second.—It would be well to have, in addition to the

apparatus just described, another one which produces a continuous curve upon the diagram paper, the ordinate of which, measured from a base-line, would give the speed in feet per second, or any other convenient measurement; this could be obtained by modification of the Boyer speed-indicator.

# "C."—THE LOCATION OF ANY POINT ALONG THE LINE USED FOR REFERENCE STATIONS.

These location-marks are most easily produced by having, at various convenient parts of the car, electric press-buttons, and having a pen upon the dynamometer which will be deflected sidewise when the circuit is made or broken; this pen to be operated by an observer whose special duty it is to attend to this part of the work.

## "D."-WIND-RESISTANCE.

Very little attention has so far been given to measurements of wind-resistance, or the relation it bears to the frictional resistance of journals and wheels, and few experiments on this subject are recorded. The subject is very complex, owing to the fact that it is generally supposed, and we think with good reason, that the train is so very largely surrounded by eddies of air, and that it will be very difficult to obtain any reliable data, especially when it is remembered that the clearances of a railroad are greatly circumscribed and reduced to a minimum, so that it will be impossible to put any apparatus which measures resistance of this kind far enough out from the car to get reliable data. The apparatus for measuring this resistance would probably be subdivided into three separate disks, one facing front and two facing toward the sides of the car, all three connected together to produce a single resultant curve drawn upon the diagram paper, and the scale upon which this is drawn could probably be best subdivided into ten points, as practised by the United States Government.

### GENERAL.

It is of very great advantage to have more than one relative speed on the paper upon which the diagrams are recorded, and the length of the paper consumed per mile run should bear some convenient relation to the distance travelled over.

We would suggest that the rates of travel of paper per mile be such that I inch measured upon the diagrams shall represent 100 feet as the maximum, and that this distance be further subdivided so that  $\frac{1}{2}$  inch shall represent 100 feet of track, and  $\frac{1}{2}$  inch shall represent 100 feet of track. It is of course also necessary to have all of the registering pens located upon one line transverse to the direction of the movement of the paper, as in that way only can simultaneous data be recorded.

The staff required to work the dynamometer is as follows: One chief, who has general supervision over the force, and whose duty it is to see that the records are properly obtained, and that all the location stations are properly marked upon the diagrams.

One outlook, whose duty it is solely to observe the location stations, and to locate them upon the diagrams by means of an electrically moved pen.

Besides this it is of considerable advantage to have a third person who is familiar with all the mechanism in the car, and who looks after the proper working of the mechanical parts of the apparatus, and assists the general observer.

### TABLE OF ENGINE-PERFORMANCE.

The following forms are recommended for tabulating the results of a locomotive-test, and in order to make the test complete each test item should be entered. It is particularly important that the "equivalent evaporation from and at 212° per pound of coal" be entered, as it is only by this that evaporative comparisons can be made.

RESULTS OF INDICATOR-TESTS OF LOCOMOTIVE, No..... FORM A.

......Bound.

Dimensions.....

CYLINDER-PERFORMANCE,

	35 36			
-	34 35			
20	33		Percentage of 32 to 3t.	
Fuel and Water Consumptions.	33 80	, inc	Release, per I. H. P. per ho	
bun	31	is rote:	Water per I. H. P. per hour.	
Cons	30		Fuel per I. H. P. per hour.	
	-	Top year w	Difference between H. P. and	
lors.	8 29	0.11	1	
powers.	88		Total	
Indicated Horse- powers.	27		Right or L. P. Cylinder.	
Ind	36		Left or H. P. Cylinder.	
	25	Euce-	Right or L. P. Cylinder Mean	
ures	7	Euce-	Right or L. P. Cylinder Mean	
Pressures,	50	1000	Left or H. P. Cylinder Mean	
d.	22		Left or H. P. Cylinder Mean	
	21.	1	Mid stroke.	
és.	90	1	Right or L. P. Cylinder Ba	
Pressures.	-	1	Right or L. P. Cylinder Initia	
Pre	61	le le	Right or L. P. Culinder Initia	
	35	team-	Right of L. P. Cylinder S	
	17		. Pressure in Receiver.	
8	91	ju	Lett or H. P. Cylinder Back	
Pressures	5		Lett or H. P. Cylinder Least	
85	. 2	1	Left or H. P. Cylinder Initia	
5	m		Left of H, P. Steam-chest.	
	12 13 14		1 Boiler-gauge	
4 . 1	H	1	L. P. per cent of Stroke,	
Soft	11 01		L. P. inches of Stroke.	
II.	0		H. P. per cent of Stroke.	
Points of Cut-off.	90		H. P. inches of Stroke.	
	7	10	Piston-speed, feet per minute	
	9		Revolutions per minute.	
		28	Time,	
	ή.	Mile-	'oN	
	Π	ds.	Time.	
	-	Cards	.oV	
- 11	m	1	Stroke of Pietone,	
	26	Jiam. eter.	L. P. Cylinder.	

## FORM B.

# LOCOMOTIVE-TESTS.—GENERAL RESULTS. Railroad Co.

• • •	· · · · · · · · · · · · · · · · · · ·	nd		• • • •	
	Bissess Bound.		•		
77.	Distance,miles. Train No		1		
Kı	nd of coal Coal analysis Calorimetric value				
	Date Left at Arrived Weather Weather Mean temperature of atmosphere Direction of wind Velocity of wind, miles per hour Condition of rail Size of exhaust-nozzle, single or double. Weight of train in tons of 2000 lbs., including locomotive, tender, passengers, and freight Weight of train in tons of 2000 lbs., exclud. the locomotive and tender. Equivalent number of standard cars at tons each Maximum boiler-pressure by gauge Minimum Average " " Prevailing position of throttle. " reverse-lever"  " points of cut-off. Schedule time in motion Actual ""	Π.	-		
	Date			٠ا	•••
	Leit	••••	· · · · · ·	••••	• • • •
. '	Weather	• • • • •		••••	
2	Mean temperature of atmosphere				
3	Direction of wind				
4	Velocity of wind, miles per hour				
5	Condition of rail		• • • •		• • •
0	Size of exhaust-nozzie, single or double		••••		•••
7	engers and freight		• • • • •		• • •
8	Weight of train in tons of 2000 lbs., exclud, the locomotive and tender.				
Q.	Equivalent number of standard cars attons each				
10	Maximum boiler-pressure by gauge			ıl	
11	Minimum " "				• • •
12	Average	••••	••••		•••
13	revailing position of thiottle		••••		•••
14	" points of cut-off				
16	Schedule time in motion				
17	Actual				
18	Time made up in minutes				• • •
19	Aggregate intermediate stops, minutes.	••••	••••	•••	• • •
31	Average speed, miles per hour	•••	••••	••••	•••
22	Maximum number of revolutions per minute				
23	" rate of speed, miles per hour				
24	Minimum number of seconds per mile				
25	Actual weight of coal used				
26	wood "				• • •
27 28	Number of miles run per ton (2000 lbs ) of coal				
20	Number of pounds of coal used per mile				
30	Weight of ashes and unconsumed coal in fire-box and ash-pan				
31	" unconsumed coal in fire-box and ash-pan				
32	" cinders (sparks) in smoke-box		••••		٠٠.
33	Percentage of other and unconsumed coal in fire-how and ash-nan			•••••	
34 35	" " unconsumed coal in fire-box and ash-pan				
36	" cinders in smoke-box				
37	" combustible consumed				
38	Average temperature of feed-water				
39	Weight of water drawn from tender	····			
40	Weight of water evaporated (20-40)				
42	Actual evaporation per pound of total coal				
43	Schedule time in motion Actual " " Time made up in minutes. Aggregate intermediate stops, minutes. Trime during which power was developed, or throttle open. Average speed, miles per hour Maximum number of revolutions per minute. " rate of speed, miles per hour. Minimum number of seconds per mile. Actual weight of coal used. " wood" Average weight of coal burned per square foot of grate per hour. Number of miles run per ton (2000 lbs.) of coal. Number of pounds of coal used per mile. Weight of ashes and unconsumed coal in fire-box and ash-pan. " unconsumed coal in fire-box and ash-pan. " "cinders (sparks) in smoke-box. " "combustible utilized Percentage of ashes and unconsumed coal in fire-box and ash-pan. " "cinders in smoke-box. " "combustible consumed. Average temperature of feed-water. Weight of water drawn from tender. Waste of injector. Weight of water evaporated (39-40) Actual evaporation per pound of total coal. Equivalent evaporation from and at 212° per pound of coal. " " car-mile. Water used per ton of train per 100 miles. " " car-mile. Water used per ton of train per 100 miles. " " car-mile. Waximum indicated horse-power developed Average (" " per square foot of heating surface. " " " " " " " " " " " " " " " " " " "	ļ			
44	" " combustible	• • • •			• • •
45	Coal used per ton of train per 100 miles				٠٠.
46	Water year per top of train per top miles			•••	
47 48	" " car mile				
49	" " hour while developing power				
50	" " per square foot of heating surface				٠.
51	" " grate "		<b> </b>	····	•••
52	Maximum indicated norse-power developed	····	····		
53	Total coal per indicated horse-power developed per hour	1	J		
<b>54</b> 55	Water evaporated per indicated horse-power per hour	1		l.::	I
56	Dry steam used per I. H. P. per hour, per indicator-diagram				
57	Percentage of moisture in steam		J		
58	Average number of sq. ft. of heating surface per indicated horse-power.		ا ا	•••	
5,	indicated norse-power per sq. it. of grate surface		•••		٠.
61	Prevailing vacuum " " " "		· · ·		!: :
~.		1	1		

### STEAM CALORIMETERS.

There is little doubt that the throttling calorimeter will fulfil all requirements for testing the dryness of steam in locomotives. It cannot measure quantitatively more than about 5 per cent of moisture, but it appears probable that locomotive boilers develop steam which either contains a fraction of 1 per cent of moisture, or the priming is a sudden temporary action, causing water to mix with the steam to such an extent that no quantitative measurement of its amount is practicable. Under these circumstances all that is desired of a calorimeter is to indicate the temporary occurrence of this sudden excessive priming, and a throttling calorimeter has been shown by Mr. D. L. Barnes to be capable of doing this, provided the thermometer has its bulb in direct contact with the steam flowing through the calorimeter. Such an arrangement is shown in the accompanying figure, of which the following is a description abstracted from the Railroad Gazette of November 27, 1801 (see Article 330):

Calorimeter.—This instrument (see Fig. 230) consisted of two pieces of brass pipe, one inside of the other, leaving an airspace between the outer and the inner. The outer pipe was screwed into the dome and extended within the dome to the throttle. At this interior end the two pipes were joined together by a cap which had a perforation  $\frac{3}{3}$  of an inch in diameter. On the outer end of the inner pipe was placed a globe-valve, and next to this and outside of it a tee in which was a stuffing-box and a thermometer, as shown in Fig. 230. Beyond this tee was another globe-valve and a short pipe of large diameter to carry the steam-jet away from the man in charge.

With this device the point of most rapid movement of the steam was located next to the throttle, and any water coming near it would immediately pass through the opening because of the high velocity. The thermometer-bulb was bared to the steam, and no cups were used. It was found possible to shut off the outer globe-valve and expose the thermometer to a full

boiler-pressure without blowing the thermometer from the stuffing-box. In this way it was determined that the thermometer recorded a steam-temperature which corresponded to the steam-gauge in the cab.

With this instrument priming was shown whenever the




FIG. 230.—THROTTLING CALORIMETER ATTACHED TO LOCOMOTIVE.

boiler was filled to a point where water could be seen coming from the stack. Immediately when the boiler foamed, the thermometer in the second calorimeter dropped to 212°. It is believed that this calorimeter is more accurate for locomotive work, because it often happens that the locomotive primes only at starting and not for a sufficient length of time to enable the throttling instrument to make a true record. And again, there are in a locomotive rapid changes in the rate of steam consumption which must cause rapid changes in the quality of the steam.

435. Experimental Engines.—During the last few years many of the engineering schools have been provided with en-

gines designed especially for experimental purposes. These engines do not resemble each other in any particular feature, but they do generally differ from the engines designed for commercial uses in the provision that is made for adjustment of the various working parts, and for varying the conditions under which the engine can be operated. Such engines are usually supplied with all the known devices for measuring the heat transmitted, the power received and that delivered from the whole or any part of the system.

Space cannot be spared for the detailed description of any of these engines, but the following are the principal dimensions of the Sibley College experimental engine, shown as the frontispiece of the present work.

## GENERAL DIMENSIONS OF SIBLEY COLLEGE EXPERIMENTAL ENGINE.

Diameter of high-pressure cylinder		9	inches
" intermediate-pressure cylinder		16	**
" "low-pressure cylinder		24	**
Length of stroke		36	**
Revolutions per minute, 90.		-	
Diameter of fly-wheels	10 feet		
Width of face of fly-wheels		17	"
Number of fly-wheels, 3.			
Diameter of brake-wheels	4 feet		
Width of face of brake-wheels		10	"
Number of brake-wheels, 3.			
Diameter of high-pressure crank-pin		31	• •
Drameter of intermediate-pressure crank-pin		7	16
Diameter of low-pressure crank-pin		31	**
Length of crank-pin		31	**
Length of connecting-rods	9 feet		
Diameter of main bearings		7	• •
Length of main bearings		13	"
Length of pillow-block bearings		IO]	"
Distance between centre lines of high-pressure and inter-			
mediate-pressure engines	14 feet		
Distance between centre lines of intermediate-pressure and			
low-pressure engines	12 feet	6	••
Rated horse-power, 175.			
Floor-space occupied, 23 feet 0 inches × 31 feet 7 inches.			

### HIGH-PRESSURE CYLINDER.

Steam-ports	ŧ	in.	×	12	inches
Exhaust-ports	11	••	×	12	"
Diameter of steam-valve seats				31	64
Diameter of exhaust-valve seats				31	••
Thickness of steam-space in jacket				ł	64
Diameter of piston-rod				2	r "
Diameter of steam-inlet				3	**
Diameter of exhaust-outlet				5	"
Intermediate-pressure Cylinder.					
Steam-ports	I	in.	X	20	inches
Exhaust-ports	ΙŞ	"	×	20	44
Diameter of steam-port				5	**
Diameter of exhaust-port				5	**
Thickness of steam-space in jacket				+	٠٠
Diameter of piston-rod				2 1	r "'
Diameter of steam-inlet				6	**
D' meter of exhaust-outlet				3	**
Low-pressure Cylinder.					
Steam-ports	Ιĝ	in.	x	28	inches
Exhaust-ports	2	"	X	28	"
Diameter of steam-ports				61	"

All the moving parts were weighed before they were put in place.

The weights are as follows:

Fly-wheels	0,807	pounds
Brake-wheels	5,264	"
Crank-shaft and eccentrics complete	,958	61
Total weight of crank-shaft, fly-wheels, brake-wheels, and ec-		
centrics3	6,029	"
Weight of high-pressure piston and cross-head	3781	"
Weight of intermediate-pressure piston and cross-head	503	**
Weight of low-pressure piston and cross-head	790	"
Weight of high-pressure connecting-rod	281	**
Weight of intermediate-pressure connecting-rod	341	**
Weight of low-pressure connecting-rod	262	44

The connecting-rods were suspended on knife-edges, and the time of their vibration was taken as follows:

	End on knife-edge.	
Low-pressure	Crank end	4 min. 45 sec.
Intermediate-pressure		
High-pressure	Crank end	4 min. 44 sec.

### RECEIVER DIMENSIONS.

HIGH-PRESSURE RECEIVER.	INTERMEDIATE-PRESSURE RECEIVER.
Length 7 in	Length 11 ft. 7 in.
Diameter 14 "	Diameter 20 "
Number of tubes 15	Number of tubes 19
Diameter of tubes 1½ "	Diameter of tubes 2¼ "
	Receiver volume 15.8 cu. ft.
Heating surface 62.34 sq. ft	Heating surface 119.8 sq. ft.

The methods of testing experimental engines do not differ in any essential feature from those for testing any engine of the same general class.

### CHAPTER XX.

# EXPERIMENTAL DETERMINATION OF EFFECTS OF INERTIA ON THE STEAM-ENGINE.

436. Inertia and its Effects.\*—The effect of inertia of the moving parts of the steam-engine is to modify to a considerable extent the resultant pressures which are transmitted by the connecting-rod to the crank-pin. The exact solution of this problem, including the effects of friction and gravity, has been accomplished by Prof. Jacobus and is published in the Trans. Am. Society of Mechanical Engineers, Vol. XI. Complete discussions of the effects of inertia will be found in various works devoted to the steam-engine; also approximate methods, usually graphical, are given in these treatises which are sufficiently accurate for practical purposes.

Prof. Jacobus gives the following formula for the approximate calculation of the inertia-effects when friction and gravity are neglected, and when the rod is symmetrical about its centre line, and the path of motion of the wrist-pin passes through the centre of the crank-shaft.

Let R equal radius of crank-circle; nR, length of connecting-rod;  $\theta$ , the crank-angle measured from its position when parallel to the centre line of the cylinder; M, mass of the piston, piston-rod, and cross-head; m, the mass of the connecting-rod;  $\tau$ , angular velocity of crank-shaft;  $\theta$ , connecting-rod angle;  $P_n$  and  $P_c$ , forces exerted by the connecting-rod upon wrist-pin and crank-pin, respectively;  $P_a$ , pressure of steam on the piston; T, tangential component of the force  $P_c$  acting on

<sup>\*</sup> See Thurston's Manual of the Steam-engine, Vol. II., page 425.

the crank-pin; N, radial component of the force  $P_c$  acting at the crank-pin; Z and  $P_b$ , auxiliary quantities. We have

$$Z = \frac{n^3 \cos^3 \theta - n^2 \sin^2 \theta + \sin^4 \theta}{(n^2 - \sin^2 \theta)^3};$$

$$P_{\rho} = (M + m)\tau^2 R(\cos \theta + Z);$$

$$T = (P_a - P_{\rho}) \sec \beta \sin (\theta + \beta);$$

$$N = (P_a - P_{\rho}) \sec \beta \cos (\theta + \beta);$$

$$P_{\sigma} = (P_a - P_{\rho}) \sec \beta.$$

When the accelerating forces are not included,

$$T = P_a \sec \beta \sin (\theta + \beta);$$
  
 $P_c = P_a \sec \beta.$ 

In this work is discussed only the experimental method of determining the inertia of an engine as developed by Mr. E. F. Williams of Buffalo, N. Y., and published in the *American Machinist* in 1884 and '5.

437. The Williams Inertia-indicator.—This instrument draws a curve (see Fig. 234) closely resembling the theoretical inertia-diagram, and similar in kind to an indicator-card. The horizontal length of the diagram corresponds to the stroke. The abscissa of any point of the curve identifies the position of the piston at a corresponding point in its travel, and its ordinate measures to a known scale the force required to give to a mass of known weight (one or two pounds) the acceleration, positive or negative, of the piston at that point of its stroke. The product of this force into the weight of the reciprocating parts, in pounds, gives for that point of stroke the positive or negative horizontal force at the crank-pin due to the inertia of the parts. The instrument is shown in Fig. 231 attached to the cross-head of an engine, and in Fig. 232 in plan.

The frame P is rigidly attached to the cross-head A by two studs j and r, the former serving also as a pivot for the arm B. The upper end of B is pivoted to one end of a horizontal bar y whose other end is attached by a pin to some fixed support. In this way B swings back and forth, its lower end, together




FIG. 231.—THE WILLIAMS INERTIA INDICATOR.

with the frame P and the parts carried by it, travelling with the cross-head. Within the case or cage d (shown in section in Fig. 233) the weight h is free to slide horizontally on steel friction rollers, except as controlled by the spring. This spring, whose tension is known by calibration, is the only means by which the motion of the cross-head is communicated to the weight h, and it must therefore be extended or compressed by an amount which measures the force needed to overcome the inertia of the weight.

For convenience h may be made to weigh, including the parts moving with it, exactly one pound. It is joined by a light rod e to the bent lever a which moves a pencil in a direction at right angles to that of the cross-head motion. By the vibration of the arm B the paper is carried under the pencil on the curved platform b shown in Figs. 231 and 232. This can at pleasure be drawn upward by the cord m, and kept in contact with the pencil for one or more revolutions while the engine is in motion. The paper is put in place while the engine is at rest, and the neutral line x, Fig. 232, is drawn by swinging the arm B back and forth by hand. As soon as the engine is running under the conditions desired, contact may be made and the diagram drawn.

In using the instrument so as to make a diagram from 2 to 3 inches long, the arm B may be varied in length to suit the stroke of the engine. To maintain a given average length of ordinates for widely differing speeds, the scale may be changed by changing the spring, or the weight, or both.

For obtaining the effect per pound weight of the reciprocating masses, determine the scale as follows: The force exerted by an 80-lb. indicator-spring when it is compressed or extended  $\frac{1}{4}$  inch, causing a pencil-movement of one inch, is 80 lbs. per square inch of indicator piston-area. The latter being one-half square inch, the actual force on the spring is 40 lbs. If, then, an 80-lb. spring with a 2-lb. weight be used, a 1-inch ordinate, will mean 40 lbs. exerted by the spring in total, or a force of 20 lbs. per pound of the mass it moves.

Thus a scale 20 means a force, for each inch of ordinate measured from the neutral line, equal to twenty times the weight of the moving body under investigation. In other words, each twentieth of an inch in length of ordinate represents a force equal to the weight of the reciprocating masses.

An 80-lb. spring with a 1-lb. weight, scale 40 " 80-lb. " " 2-lb. " " 20 " 40-lb. " " 1-lb. " " 10 " 10

- 438. The Inertia-diagram drawn by the Instrument.—In interpreting the diagram several points are to be noted:
- I. The evenness and general form of the diagram are largely influenced by the smoothness of running of the engine, which depends on the accuracy of bearing surfaces, and the degree in which the weight of reciprocating parts, their velocities, and the varying steam-pressures are suited to each other.
- 2. The curvature of the lines traced depends chiefly on the ratio of crank-length to that of connecting-rod; this ratio should be determined by measurement.
- 3. In combining the diagram with an indicator-card the ordinates should represent forces in pounds per square inch of piston-area, and in the same scale as that of the indicator-card. For this we determine by independent measurement (1) the force exerted by the spring for a given length of ordinate from the neutral line; (2) the ratio of the weight of the reciprocating parts of the engine to that of the parts of the instrument moved by the spring; and (3) the area of the engine-piston.
- 4. The difference in length of the corresponding ordinates in the inertia and indicator diagrams, the latter corrected for back pressure or compression, represents the net horizontal force transmitted to the crank-pin.

For combination with a steam indicator-card, the force per square inch of piston-area is required. This is best obtained by getting the weight-ratio or the weight of reciprocating parts per square inch of piston-area. This multiplied by the scale of the inertia-diagram gives the engine-scale or scale of pounds per

square inch at the speed at which the diagram was taken. An example will make this clear. The inertia-diagram in Fig. 234, taken from a very smooth-running engine, was obtained with an




FIG. 235.-INERTIA AND INDICATOR DIAGRAMS.

80 spring and a one-pound weight. Hence the diagram-scale is 40. But for this engine the weight-ratio was 3. Hence  $40 \times 3 = 120$  is the engine-scale.

Having, now, this inertia-diagram (Fig. 234) whose enginescale is 120, suppose we are to combine it with an indicatordiagram (Fig. 235) from the same engine at same speed, and taken with a 40 spring. The scale of the inertia-diagram can be changed from 120 to 40 by drawing it with the ordinate of each point increased three times, giving the curve ab in Fig. 235. The ordinates to the compression curve on the back stroke can be deducted from the corresponding ordinates of the inertia curve ab, and the included area shaded, thus exhibiting the modification of the steam-forces by the inertia of the reciprocating parts. By vertical measurement of the shaded portion, the true distribution of horizontal forces on the crank-pin during the backward stroke may be obtained.

Important Features of the Experimental Diagram.—Suppose that in Fig. 236 p and c are the positions respectively




FIG. 236.—RELATIVE MOTION OF CRANK-PIN AND PISTON.

of the cross-head and crank-pins with crank on its centre. Then, were it not for the angle of the connecting-rod, the cross-head pin would go to p' when the crank has moved to c'', pp' being equal to cc'.

But its true place is at p''; thus in the quarter-turn of the crank from c to c'' the cross-head has gone a distance p'p'' past its mid-stroke, and is then moving at the same speed as the crank-pin, while its maximum speed was attained before reaching mid-stroke. Again, on the return-stroke, when the crank is lowest, the piston has not gone half-way. This shows that the acceleration is greater when the piston is at the head

end of cylinder. The same thing is shown in Fig. 237, xy being much greater than x'y', while the fact that point of crossing of yy' and xx' is at the left of the centre shows that the




FIG. 237.—INBRTIA-DIAGRAM.

zero of acceleration, which of necessity corresponds with maximum velocity, falls where it should.




FIG. 238.—INERTIA-DIAGRAMS.

All this is revealed in the same way in the experimental inertia-diagram Fig. 234, page 603, and the accuracy of the dia-

gram may be further tested by comparing the area below the neutral line with that above it by means of a planimeter.

In Fig. 238 the inertia-diagrams for forward and backward strokes have been separated. The negative and positive signs show respectively where the inertia opposes and assists the steam-pressures. The curve y''y''' belongs to the forward stroke and y'y to the return.

In practical use the diagram should be divided into ten or more equal spaces, and the ordinate at the centre of each space being numbered, the crank-positions corresponding, may be found as shown in Fig. 239, and the relative velocity of





FIG. 239.—CRANK-POSITIONS CORRESPONDING TO GIVEN PISTON-POSITIONS.

piston and crank obtained. The method of dividing the diagram shown in Fig. 238 is convenient in transferring the curve to a steam indicator-card similarly divided. Care being taken to draw both to the same scale and in pounds per square inch of piston, the inertia curves may be drawn on an indicator-card arranged as shown in Fig. 240. Here the back-stroke steam-card has been drawn inverted and in contact with the forward card in its normal position, the two back-pressure lines being made coincident and used as the neutral inertia line.

The ordinate lines are then produced to cut the line X'X', which serves as a base-line from which to lay off ordinates of the net horizontal forces at the crank-pin. The actual forces



at the crank-pin are thus more clearly revealed for both strokes, and the areas above and below X'X' respectively, give the actual work on the crank-pin for forward and return strokes.

### CHAPTER XXI.

## THE STEAM-INJECTOR—THE PULSOMETER.

439. Description of the Injector.—The steam-injector is an instrument designed for feeding water to steam-boilers, although it can be and often is used as a pump to raise water from one level to another.\* It has been used as an air-compressor, and also for receiving the exhaust from a steam-engine,




Fig. 241.—THE MACK NON-LIFTING INJECTOR.

taking the place in that case of both condenser and air-pump. It was designed by Henri Jacques Giffard in 1858.

In its most simple form (see Fig. 241) it consists of a steamnozzle, the end of which extends somewhat into a chamber or converging tube called the combining or suction-tube; this

<sup>\*</sup>See Cassier's Magazine, January and February, 1892; Thermodynamics, by D. Wood, page 279; Thermodynamics, by C. H. Peabody, page 152.

connects with, or rather terminates in, a third nozzle or tube, A (Fig. 241), termed the "forcer." At the end of the combining-tube, and before entering the forcer, is an opening connecting the interior of the nozzle at this point with the surrounding area. This area is separated from the outside air by a checkvalve, E, opening outward in the automatic injectors, and by a globe valve termed the overflow-valve in the non-automatic injector. The injector-nozzles are tubes with ends rounded to conform to the form of the "vena contracta" as nearly as possible, and thus receive and deliver the fluids with the least possible loss by friction and eddies.

Some of the injectors are quite complicated, and adjust




FIG. 242.-THE SELLERS INJECTOR.

themselves automatically by varying the openings through the tubes to suit changes in steam-pressure.

Fig. 242 is a section of the Sellers injector of 1876; in this injector the steam-nozzle C can be inserted a greater or less distance, as required, into the combining-chamber NN. The overflow P is closed by a valve K operated by a rod L connected to the starting-lever T. The tube NNCO moves

automatically to vary the opening at C with change of steam-pressure.

In some of the injectors the tubes are so arranged that the discharge of one injector is made the feed for a second injector. This makes what is termed a double injector, of which familiar illustrations are to be seen in the Hancock, Park, and World injectors.




FIG. 243.—THE HANCOCK INSPIRATOR.

440. Thermodynamic Theory of the Steam-injector.—
As a thermodynamic machine the injector is nearly perfect, since all the heat received by it is returned to the boiler, ex-

## § 440.] THE STEAM-INJECTOR-THE PULSOMETER.

cepting a very small part that is lost by radiation; consequently the thermal efficiency should be in every case nearly 100 per cent. Its mechanical efficiency, or work done in lifting water, compared with the heat expended, is small, because its heat-energy is principally used in warming up the cold water as it enters the injector.

Let r equal the heat of evaporation in B. T. U. of a pound of dry steam; x, its quality; q, heat of the liquid of the entering steam in thermal units above  $32^{\circ}$ ;  $q_{\bullet}$ , heat of discharge-water in thermal units above  $32^{\circ}$ ; h, the total heat in a pound of wet steam; w, the weight of steam per hour uncorrected for calorimeter-determinations; W, the weight of water supplied; t, the temperature of the feed-water; t', the temperature of the delivery. Then we have, as the heat in one pound of the steam supplied, above  $32^{\circ}$ ,

$$h = xr + q. \quad . \quad . \quad . \quad . \quad . \quad (1)$$

If the mechanical work consist of W pounds of water lifted n feet by pressure and s feet by suction, the heat equivalent F of the mechanical work is

$$F = [(n+s)W + wn]A, \dots (2)$$

if delivered from the end of the discharge-pipe without sensible velocity. In case there is a velocity of  $v_1$  feet per second at delivery from discharge-pipe, the additional energy L, in heat-units, is

$$L = A(W+w)v_1^2 \div 2g.$$
 . . . (3)

The heat-units taken up by the feed-water are

The thermal efficiency E, if the injector is used for feeding boilers, is

$$E = \frac{F + L + \dot{K}}{w(h - q_s)}. \qquad (5)$$

If used as a pump, the heat K received by the discharge-water is to be neglected, and the efficiency  $E_{\bullet}$  is

$$E_{p} = \frac{F + L}{w(h - q_{2})}. \qquad (6)$$

441. Mechanical Action of the Injector.—In this case we consider only the impact of the jet of steam at high velocity against the mass of water. The case being similar to that of a small inelastic ball, moving at high velocity, impinging on a large ball.

Denote the velocity of the steam by v, that of the water before impact by V', and after impact by  $V_1$ ; then by the principles of impact of inelastic bodies,

$$\frac{wv}{g} + \frac{WV_1}{g} = \frac{(W+w)V}{g}. \quad . \quad . \quad . \quad (7)$$

When water is supplied the injector under pressure, the sign of  $V_1$  is positive, otherwise it is negative. The use of this equation requires the velocity of the steam, v; that of the supply,  $V_1$ ; and of the discharge, V, to be given.

The velocity of the steam, v, will not differ essentially from 1400 feet per second for the conditions in which it is used in the injector (see Article 230, page 273).

The velocity of the water discharged, V, from the injector may be found by dividing the volume that is delivered in cubic feet per second, c, by the area of the discharge in square feet, A; that is,

$$V = \frac{c}{A} = \frac{C}{3600} \times \frac{144}{a} = \frac{c}{25a}; \dots (8)$$

in which C represents the discharge in cubic feet per hour, and a the area of the discharge-nozzle in square inches.

The velocity of the water supplied,  $V_1$ , in the suction-pipe may be found by ascertaining the equivalent head,  $n_1$ , that will produce the same velocity. If p be the absolute pressure per square inch in the combining-chamber; b, the pressure per square inch, as shown by a barometer or pressure-gauge, on the water-supply; w'', the weight of a cubic foot of water at the temperature of the supply; s, the suction-head in feet,—then

$$n_1 = \frac{144(p-b)}{w''} - s;$$
 (9)  
 $V_1 = \sqrt{2gn_1}.$ 

The velocity of the suction is, however, expressed more conveniently by considering a body of water with a head, s, acting to accelerate or retard the whole mass of water in the injector. Let A be the smallest section of the water-jet, w'' the weight of a unit of water; then the pressure due to s feet of water will be saw''. As this acts on a mass of water  $Vaw'' \div g$ , the velocity imparted would be

$$\frac{saw''}{\underline{Vaw''}} = \frac{sg}{V}.$$

The total momentum produced by the suction would be

$$\frac{W+w(sg)}{gw}(\frac{sg}{V}) = \left(1 + \frac{W}{w}\right)\frac{s}{V} = (1+y)\frac{s}{V}, \quad . \quad (10)$$

in which

$$y = W \div w$$
.

The momentum produced by the suction would be negative, unless water was delivered to the injector under pressure.

As shown in equation (7) the momentum of the suction is  $\frac{WV_1}{g}$ , which for one pound of steam would be  $\frac{W}{w}\frac{V_1}{g} = y\frac{V_1}{g}$ .

Substitute this value for the momentum of the suction in equation (7), representing  $W \div w$  by y. We have

$$\frac{v}{g} + (1+y)\frac{s}{V} = \frac{(1+y)V}{g},$$

or

$$v = (1 + y)\left(V - \frac{sg}{V}\right)$$
. . . . (11)

From which

The plus sign to be employed before s when the suctionwater is supplied under pressure; otherwise the negative sign is to be used.

If the friction in the pipe be neglected,

$$V = \sqrt{2gn}$$

and we have

$$y = \frac{v\sqrt{2gn}}{2gn - sg} - 1. \dots (13)$$

442. Limits of the Injector.—Maximum Amount of Water Lifted.—This may be obtained from equation (12) or (13), but it can be obtained with sufficient accuracy by neglecting the momentum  $\frac{WV'}{g}$  due to the suction-water in equation (7); in this case

$$wv = (W + w)V,$$

from which

$$y = \frac{W}{w} = \frac{v}{V} - 1 = \frac{v}{\sqrt{2gn}} - 1 = \frac{1400}{\sqrt{2gn}} - 1$$
, nearly. (14)

The maximum ratio of water to steam is shown by the following table:

Delivery Pressure	Maximum Ratio	Delivery Pressure	Maximum Ratio
above that on	of Water to	above that on the	of Water to
Injector.	Steam by Weight.	Injector.	Steam by Weight.
10 15 20 25 30 35 40 45 50	36.5 29.8 25.6 23.8 20.9 19.5 17.87 17.0	55 60 65 70 75 80 85 90	15.5 14.7 14.3 13.7 13.3 12.9 12.6 12.1

The minimum amount of water required must be sufficient to condense the steam, in which case

$$y = \frac{W}{w} = \frac{h - q_1}{t' - t}, \quad . \quad . \quad . \quad (15)$$

in which k is the heat in one pound of entering steam;  $q_1$ , the heat of the liquid in the delivery, both reckoned from 32°; t', the temperature of the delivery; t, that of the feed-water, so that the ratio cannot be greater than shown in equation (14) nor less than that shown in equation (15).

Temperature of Feed-water.—As the temperature of the feed-water increases vapor is given off which increases the pressure, b, in equation (9) on the surface of the supply-water, and reduces the height through which the water can be lifted.

If the temperature of the feed-water is greater, the amount required to condense the steam must also be greater; but as the amount lifted by a given amount of steam cannot exceed the approximate value given in equation (14), we shall have at the extreme limit at which the injector works, the values of y as given in these two equations equal to each other, from which the maximum temperature of feed-water becomes

$$t = t' - \frac{(h - q_1)v}{v - V} = t' - \frac{(h - q_2)(1400)}{1400 - \sqrt{2gn}}$$
, nearly.

The following table gives approximately the limiting values of suction-head in feet and temperature of feed-water:

LIMIT OF SUCTION-HEAD IN FEET.

			Steam-pressure 100 lbs. Absolute.			
Temperature of Feed-water. Degs. Fahr.	Pressure of Vapor. Pounds per sq. inch.	Limit of Suction- head in case of Vacuum. Feet.	Delivery 212° Fahr. Number of Pounds of Water to con- dense one of Steam.	Delivery 180° Fahr. Number of Pounds of Water to con- dense one of Steam		
70	0.36	32.96	7.04	8.81		
80	0.50	32.6	7.57	9.61		
90	0.69	32.2	8.19	10.76		
100	0.94	31.4	8.92	12.11		
110	1.26	30.9	9.80	13.84		
120	1.68	29.7	10.87	16.15		
130	2.22	27.3	12.20	19.32		
140	2.87	25.9	13.89	24.22		
150	3.70	24.8	16.13	32.3		
160	4.72	22.5	19.23	48.45		
170	5.98	19.6	23.81	96.90		
180	7.50	16.9	31.25			
190	9.33	9.9	45.46			
200	11.52	9.3	83.33			
210	14.12	1.1	500.9			

### MAXIMUM TEMPERATURE FEED-WATER.

Gauge Press-	Maximum Temperature of Feed-water. Degrees Fahr.		Gauge Press-	Maximum Temperature of Feed-water. Degrees Fahr.		
ure. Pounds per sq. inch.	Discharge 180° Fahr.	Discharge 212° Fahr.	ure. Pounds per sq. inch.	Discharge 180° Fahr,	Discharge 212° Fahr.	
20	142	173	70	109	139	
25	137	168	75 80	107	137	
30	133	164	80	105	134	
35	129	160	90	99	129	
40	126	156	100	95	125	
45	123	153	110	j gt	121	
50	120	150	120	87	117	
55	117	147	130	83	113	
60	114	144	140	8o	110	
65	111	141	150	77	107	

A series of carefully conducted experiments\* made at Sibley College, Cornell University, to determine the efficiencies of different steam injectors, confirm the results expressed in the preceding computations.

443. Directions for Handling and Setting Injectors.—Injectors are of two general classes, lifting and non-lifting. In the first class water is drawn in by suction and then discharged against a pressure; in the second class water flows in under pressure and is discharged against a greater pressure.

As there is a limit to the temperature at which water will be handled by the injector, variations in steam-pressure will affect the discharge and may cause it to stop altogether. This may be regulated to a certain extent by manipulating the valves of the steam and water supply; some injectors are self-adjusting in this respect and are termed *automatic*.

The general directions for starting an injector are to open the overflow, turn on steam until the water appears at the overflow, and the temperature of the injector is sufficiently low to condense the steam. Then close the overflow and the injector should discharge against a pressure equal to or greater than the steam-pressure. In many of the injectors the overflow valve will open whenever the pressure in the injector becomes greater than that of the atmosphere. In several kinds the overflow is closed by a valve regulated independently or connected by a lever to the starting handle so as to be opened and closed at the proper time by the simple operation of admitting steam.

Injectors will not work with oily or dirty water, and are liable to be stopped by anything that will not pass the nozzles. In general they are to be connected by pipe-fittings made up without red lead and arranged so as to deliver water into a pipe leading to the boiler, in which is placed a check-valve to remove the boiler-pressure when starting the injector.

444. Directions for Testing.—For testing the injector use two tanks, both of which are to rest on weighing-scales.

<sup>\*</sup> See Cassier's Magazine, Feb. 1892.

Fill one of the tanks with water, and locate the injector any convenient distance above or below this tank, and arrange it so as to deliver water into the second tank.

If the water that escapes at the overflow is arranged to run into the tank from which the water is taken, no correction will be required; otherwise it must be caught and weighed.

Place a valve in the delivery-pipe, some distance from the injector or beyond an air-chamber, and regulate the delivery head by partly opening or closing this valve. The delivery-pressure, which can be reduced to head in feet of water, can be measured by a pressure-gauge in the delivery-pipe; the suction-pressure is observed in a similar manner by using a vacuum-gauge or a manometer.

The water received, W, is that taken from the first tank; the amount delivered, W + w, is that weighed in the second tank; the difference is w, the steam used.

Arrange thermometers to take the temperature of the water as it enters and leaves the injector.

Make runs with discharge-pressures equal respectively to one-fourth, one-half, three-fourths, once, and one and one-fourth times that on the boiler. During each run take observations, as required by the blank log furnished, once in two minutes.

Determine the limits at which the injector stops working, for temperature of feed-water, suction-head and delivery-head.

Careful trials show that the thermodynamic efficiency of any injector is 100 per cent; by assuming this as true the second tank may be dispensed with, and the amount of steam computed from its heating effect and known quality on the water passing through the injector.

In the report, describe the injector tested, explain method of action, and submit a graphical log, with time as abscissa, as well as an efficiency curve for varying pressures of discharge, also for varying temperatures of discharge.

Fill out the log and make complete report, after the standard form.

DATA AND RESULTS.

Quantities.	Symbol.	Formula,	Quantities.	Symbol.	Formula.
Discharge-head	R .		Momentum (1 + y') lbs. delivered	W	$\frac{V}{\mathcal{E}}(\iota + g')$
Water per hour supplied	· ¥		Momentum suction	, <b>H</b>	$\frac{\Delta}{s}(\sqrt{s}+1) \mp$
Water per hour delivered	1/4				,W + W
Wet steam per hour	ź.		Efficiency impact	•	*
Quality of steam	4		Work delivered, B. T. U. per hour	4	[(h + 4)W + wn] + 778
Dry steam per hour	È	n.r	Heating injection-water, B. T. U. per		•
Pounds of water to one of wet steam	'n	<b>≥</b> f	bour.	×	W(t-t')
	,		Energy of discharge, B. T. U., from		\$ (7.11.)
Pounds of water to one of dry steam	•	ž ž	pipe	7	A (" + ")"1-
Steam-pressure on injector, absolute	4		Energy from steam, B. T. U. per hr.	*	[w(k-q)]+(F+L)
Steam-pressure on orifice, absolute	ζ.	<b>3</b> 9.	breen Me Lemant	ķ	F+K+L.
Cubic feet steam per hour	u	w(vol. one 1b.)		9	₹ ;
Cubic feet water per hour delivered	U	(W + w')(vol. one lb.)	H. P per 34 lbs. of steam	Н	<b>a</b>   <b>3</b>
Velocity steam in nozzle, ft. per sec.	4	Adiabatic flow			<b>.</b> .
Velocity water in nozzle, ft. per sec	7	C 25 (area)	H. P. delivered per hour	Ē,	000E X 09
Velocity suction-lift	7.	<u> ک</u> افؤ	Ftlbs. per 1000 lbs. of steam	Ď	2
Velocity of discharge, ft. per sec	ž	C 25 (area dis. pipe)	Ptlbs. per 1,000,000 B. T. U	a	$a_{\delta}(\delta - \gamma)$
Momentum, one lb. steam	ŧ	6   <b>6</b>	Pounds of steam per H. P		<b>:</b>  &

REMARKS. - A = + +g.

446. The Pulsometer.—This is a pump consisting of two bottle-shaped cylinders joined together with tapering necks, into which a ball C is fitted so as to move in the direction of least pressure, with a slight rolling motion, between seats formed in the passages. These chambers connect by means of open-

ings fitted with clack-valves, EE, into

the induction-chamber D.

The water is delivered through the passage H, which is connected to the chamber by openings fitted with valves G. Between the chambers is a vacuum-chamber / which connects with the induction-passage D. Air is supplied the chambers by small airvalves moving inward, which open when the pressure is less than atmospheric.

The method of working is as follows: Conceive the left chamber full




FIG. 244.—THE PULSOMETER.

of water, and a vacuum in the right chamber; steam enters to the left of the valve C, presses directly on the surface of the water, and forces it past the check-valve G into the deliverypassage H and air-chamber J; at the same time the right chamber is filling with water, which rushes in and by its momentum moves the valve C to the left. The steam in the left chamber condenses, forming a vacuum, and the operation described is repeated, except that the conditions in the two chambers are reversed.

All the steam entering is condensed and forced out with the water, increasing its temperature.

The analysis is very similar to that of the injector, except that the steam acts by pressure instead of by impact. theory is fully stated in "Thermodynamics," by Prof. De Volson Wood, page 203. Thus: if w equal the weight of steam, W the weight of water raised, t the temperature of the supply, t, that of the delivery, r the latent heat of evaporation of the



steam, T the temperature of the steam, n the delivery-head, n, the suction-head, n + n, the total head,—no allowance being made for variation,—we have

$$w(T+r-t_1)=W(t_1-t).$$

The heat equivalent of the mechanical work done,

$$U = A[Wn_1 + (W+w)n].$$

The heat expended, in thermal units,

$$h = w(T - t + r).$$

The efficiency,

$$E = \frac{U}{h} = \frac{A[Wn, + (W+w)n]}{w(T-t+r)}.$$

Neglecting the work of lifting the condensed steam,

$$E = \frac{A(n_1 + n)}{t_1 - t}$$
, nearly.

The following form for data and results of test is used by the Massachusetts Institute of Technology:

### 447. Form for Data and Results of Test on Pulsometer.

		Flo	o w	f Ste	am.		,	Wate	r.			He	ads.		Cal	ori <b>m</b>	eter.	Cou	nter
Number.	Time.	Boiler pressure.	Orifice-pressure.	Pressure at Pulsom- eter.	Temp. at Pulsometer.	Depth on Weir in Ins.	(Depth on Weir)3.	Temp. at Weir, De- grees F.	Temp. of Suction, Degrees F.	Temp. of Discharge, Degrees F.	Suction-gauge, Ins. of	Discharge-gauge, Lbs.	Actual Suction, in Ft.	Actual Head, in Ft.	Boiler-pressure.	Calorimeter-pressure.	Temp., Degrees F.	Reading.	Difference.
Total Av Cor	•••	   				 					 						• • •		

§ 44 <b>7</b> .]	THE STEAM-INJECTOR—THE PULSOMETER. 62
Diameter s	uction and discharge pipesins
Transverse	area of pipesq. fi
Distance b	etween pressure-gaugesfi
Barometer	(cor.)lbs
Number of	pulses per minute
Width of w	reirsq. ft. Area steam-orificesq. ft
Steam used	inlbs
Water over	weir inlbs
Head due	o velocity in discharge-pipefe
Total lift =	pressure-heads + velocity-head + distance between gaugesfr
Total work	done by pulsometerftlbs.;B. T. U
Total heat	given up by steamB. T. U
Efficiency.	per cent
Duty (ft 11	s. per 1,000,000 B. T. U.)

### CHAPTER XXII.

### HOT-AIR AND GAS ENGINES.

448. Hot-air Engines.—Hot-air engines consist of engines in which the piston is driven backward and forward by the alternate expansion and contraction of a body of air caused by heating and cooling. Those now on the market are used prin-




Fig. 245 Fig. 246. Ericsson Hot-air Pumping-engine.

cipally for pumping-engines, and are arranged to use either coal or gas as fuel.

449. Ericsson Hot-air Engine.—This engine is shown in Fig. 245 in elevation, and in Fig. 246 in section.

The method of operation is as follows: There are two pistons, viz., A, the displacing piston or plunger, and B, the driving-piston. The driving-piston is connected to the mechanism as shown. The displacing-piston, A, is a vessel made of some non-conducting substance, and its office is to move a body of air alternately from the space above to that below it. As shown in the figure, the piston A is at the upper end of its stroke, and the piston B is moving rapidly upward, being driven by the expansion of the air in the lower part of the receiver A. The air in the upper part of the receiver is cooled by water which has been raised by the pump r, and which circulates in the annular space xx.

On the return stroke of the piston B the plunger A at first descends somewhat faster, and thus by transferring air maintains a nearly uniform pressure upon the piston. When the piston B reaches the position shown in Fig. 245 on its downward stroke, the plunger A will be at the bottom of its stroke, and all the working air will have been transferred above and its temperature maintained at its lower limit, while it is compressed by the completion of the downward stroke of the piston B, after which the plunger will rise to the position shown in the figure and the temperature and volume are both increased at nearly constant pressure. The mass of air in the engine remains constant.

450. The Rider Hot-air Engine.—In this engine the compression-piston A and the power-piston C work in separate cylinders, which are connected together by a rectangular passage D in which are placed a large number of thin metallic plates, forming the regenerator, whose office is to alternately abstract from and return to the air the heat in its passage backward and forward. The same air is used continuously; it may be admitted to the cylinders by a simple check-valve O, opening inward. The engine is used entirely as a pumping-engine, and the water so raised circulates around the compression-chamber B.

The operation of the engine is briefly as follows:

The compression-piston A first compresses the cold air in




Fig. 247.—The Rider Hot-air Pumping-engine.

the lower part of the compression-cylinder B, when, by the advancing or upward motion of the power-piston C and the completion of the down stroke of the compression-piston A. the air is transferred from the compression-cylinder B through the regenerator D and into the heater E without appreciable change of volume. The result is a great increase of pressure. corresponding to the increase of temperature, and this impels the power-piston up to the end of its stroke. The pressure still remaining in the power-cylinder and reacting on the compression-piston A forces the latter upward till it reaches nearly to the top of its stroke, when, by the cooling of the charge of air, the pressure falls to its minimum, the power-piston descends, and the compression again begins. In the mean time, the heated air, in passing through the regenerator, has left the greater portion of its heat in the regenerator-plates to be picked up and utilized on the return of the air towards the heater.

451. Thermodynamic Theory. — The thermodynamic theory of the hot-air engine will be found fully discussed in Rankine's Steam-engine and in Wood's Thermodynamics, from which it is seen that these engines may work under the conditions of change of temperature with either constant pressure or constant volume, or under the condition of receiving and rejecting heat at constant pressure.

The thermodynamic efficiency is found by dividing the range of temperatures of the fluid by the absolute temperature of the heated fluid.

452. Method of Testing.—The method of testing hot-air engines does not differ essentially from that for the steamengine. An indicator is to be attached so as to measure the pressures. Knowing the pressures and volumes, the corresponding temperatures can be computed from the formula

$$\frac{pv}{T} = R = 53.21,$$

in which p is the pressure in pounds per square foot, v the

corresponding volume in cubic feet, and T the absolute temperature. From this

$$T=\frac{pv}{R}$$
.

The quantities which should be taken in each test are shown on the following blank for data and results:

453. Forms for Data and Results of Test of Hot-air Engine.

# MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY.

		ne. Fuel
At Date	By {	

### LOG OF TRIAL.

Symbol.	<i>k'</i>	w	P	ø				ŧ	t'	£"		N		G		20
	Wa	ter.	F	ressu	ıres.	·	7	emper	atur	es.	Revo!	utions.	Ft	iel.	Lca	kage
Number.	Weir- reading.	Weight per Hour.	Pressure- gauge.	Suction- Gauge.	Gas.	M. E. P.	Room.	Water at Weir.	Rater- ing.	Leav.	Total per Counter.	Per Min- ute.	Total.	Per Hour.	Total.	Per Hour.

Average.

### RESULTS OF TEST OF HOT-AIR ENGINE.

### DATA AND GENERAL RESULTS.

Diameter of working-pistonin.;	Area of samesq. in.
Diameter of plungerin.;	Area of samesq. in.
Length of stroke, working-pistonft.;	Displacement
Length of stroke, plungerft.;	Displacement ft.
Distance between centres of gaugesft.;	Zero of weirft.

•		De	termina	ion.
	Symbol.	1	2	3
Head pumped against, feet  Average head over weir.  Water delivered, cu. ft. per sec.  " " lbs. per hr.  " gals. per 24 hrs  " " per hr. plunger-displacement  Percentage slip  Thermal units per lb. of fuel  Average fuel-consumption per hour.  Heat from combustion per hour.  Duty per weir.  Duty per plunger-displacement  Average M. E. P.  " indicated H. P.  " effective "  Efficiency, mechanical  Total efficiency  Expenditure of heat per hour.  Indicated work, B. T. U.  Heating jacket-water.  Radiation, etc  Total.	% Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q Q			

REMARKS.	R	EM	AB	LK.	S.
----------	---	----	----	-----	----

The indicator-diagram obtained from the hot-air engine will

depend largely on the principle of operation. The form of the



Fig. 248.—Diagram from Ericsson Hot-air Engine.

one obtained from the Ericsson engine in which there is change of temperature at constant pressure is well shown in Fig. 248.

SPECIAL DIRECTIONS FOR EFFICIENCY-TESTS OF THE RIDER AND THE ERICSSON ENGINE.

### Rider Engine.

Apparatus.—Steam-engine indicator with 16-pound spring; thermometers; low-pressure gauge.

Operation.—Build a fire in the heater; fill the jacket with water by priming the pump; attach indicator; place gauge behind the delivery-valve, and thermometers to obtain temperatures of water in supply and discharge pipes; open delivery-valve and start engine by hand.

Make five half-hour runs, increasing the head five pounds each time, and taking data every five minutes. To stop the engine, open fire-door and blow-off cock.

Submit graphical log and plot efficiency-curve, using heads as ordinates and efficiencies as abscissæ.

### Ericsson Engine.

Apparatus.—Indicator with 10-pound spring; low-pressure gauge.

Operation.—Light the gas under the heater; place pressuregauge behind delivery-valve, and attach indicator; proceed with test and report as in efficiency-test of Rider compressionengine, beginning with a head of five pounds and increasing by five pounds up to twenty-five pounds.

454. The Gas-engine.—The gas-engine is in many respects similar to a hot-air engine in which the furnace is included in the working-cylinder.

There are many types of these engines now constructed, differing from each other in form, in methods of igniting the gas, and in the number of strokes required to complete a cycle of operations. In all these engines a mixture of gas and air, in such proportions as to be readily exploded, is drawn into the cylinder; this is then exploded by firing either with an electric spark or with a lighted gas-taper, after which the piston is impelled rapidly forward, and the gas expanded; the burned gas

is then expelled from the cylinder before the introduction of a new charge.

Gas-engines are usually single-acting, but a few have been made that were double-acting like a steam-engine.

Dugald Clerk makes the following classification of gasengines:\*

- A. Engines igniting at constant volume but without previous compression, and of which the working cycle consists in—
  - 1. Charging the cylinder with explosive mixture.
  - 2. Exploding the charge.
  - 3. Expanding after explosion.
  - 4. Expelling the burned gases.

Many of the early engines were of this type, of which may be mentioned those of Lenoir, Hugon, and Bisschof.

A type of gas-engine in which the cycle is changed a little from that given was successfully introduced by Otto and Langen in 1866. In this engine the piston is shot forward by the force of the explosion in a long cylinder, while disconnected from the motor-shaft, but on the return stroke it engages with the motor-shaft and completely expels the burned gases.

The cycle is as follows:

- I. Charging the cylinder.
- 2. Exploding the charge.
- 3. Expanding after explosion while disconnected from the motor.
- 4. Compressing the burned gases after some cooling.
- 5. Expelling the burned gas. Work is done only on the return stroke.
- B. Engines igniting at constant pressure with previous compression, and of which the working cycle consists—
  - 1. Charging the pump-cylinder with the explosive mixture.
  - 2. Compressing the charge into an intermediate receiver.
  - 3. Admitting the charge to the motor-cylinder in the state of flame, at the pressure of compression.

<sup>\*</sup> The Gas-Engine, Dugald Clerk; N. Y., J. Wiley & Sons.

- 4. Expanding after admission.
- 5. Expelling the burned gases.

To carry out this process perfectly the following conditions are required:

- (a) No throttling or heating from the air during admission to the pump.
- (b) No loss of heat of compression to the pump and receiver-walls.
- (c) No throttling as the charge enters the motor-cylinder or the receiver.
- (d) No loss of heat to the iron of the motor-cylinder.
- (e) No back pressure during the exhaust-stroke.

The most successful engines of this type are Brayton's and Simon's.

- C. Engines igniting at constant volume with previous compression, of which the cycle of operations is—
  - 1. Charging the pump-cylinder with the explosive mixture.
  - 2. Compressing the charge into an intermediate receiver.
  - 3. Admitting the charge to the motor-cylinder under compression.
  - 4. Igniting the charge after admission to the motor.
  - 5. Expanding the hot gases after ignition.
  - 6. Expelling the burned gases.

The requirements for this cycle are essentially the same as for B, but they are somewhat more contradictory. In practice the receiver is dispensed with and the compression performed in the motor-cylinder.

The most common engines are of this type, of which may be mentioned Otto's and Clerk's.

For the complete theory and a description of most of the gas-engines the reader is referred to the work on Gas-engines by D. Clerk. The theory is also fully developed in Thurston's Manual of the Steam-engine, Vol. I., and De Volson Wood's Thermodynamics.

455. Method of Testing Gas-engines.—The method of testing gas-engines is in many respects the same as for a hotair engine, but if possible measurement should be made of the

volume of air drawn in as well as that of the gas. A complete log of a test is to be found in Engine and Boiler Trials, by Thurston, which the student is advised to consult.

In attaching the indicator it will be found necessary to use a heavy spring in order to resist the effect of the explosion. This spring, because of its stiffness, will show but little work on the intermediate strokes; for this reason it is advisable to use a second indicator with a light spring, in which is placed a stop





FIG. 249.—PLAN OF ARRANGEMENT FOR GAS-ENGINE TRIAL.

for the piston so that the spring cannot be compressed to such an extent as to injure it. A pyrometer should be inserted in the exhaust, and a gas-bag placed between the gas-meter and the engine. The proper arrangement of a gas-engine for trial is shown in Fig. 249, from Thurston's Engine and Boiler Trials.

The heat-units per cubic foot of gas used should be determined by a calorimetric experiment (see page 419). The actual

and ideal indicator-diagrams are shown in Fig. 250, the difference being in great part due to losses of heat in the cylinder.



Special Directions for Testing an Otto Gas-engine.

Apparatus.—Indicator with 100-pound spring, and one with 20-pound spring; revolution-counter; gas-meter; air-meter.

Operation.—Turn the gas on at the meter, light the ignition-flame and adjust it to a height of about two inches; depress the governor-blade and retain it in a horizontal position with the pawl which engages the pendulum; open air-cock at bottom of the cylinder, and turn the engine over several times, by hand or by power, at its proper speed; work the throttle-valve by hand backward and forward until an explosive mixture is

secured; set index to the throttle-valve at figure 3; after this explosions will be regulated by the governor. Turn on jacket-water; take diagrams on both indicators, number of revolutions, number of explosions, and amount of gas consumed; apply the brake and make a series of runs, each one hour in length, with observations at intervals of five minutes, increasing the load from minimum to maximum. To stop the engine at the end of the test, shut off the gas at the meter, turn off ignition-flame, and stop the supply of jacket-water.

Compute and tabulate data, plot efficiency-curve, and calculate the hourly consumption of gas per I. H. P. and D. H. P. Submit graphical log.

### 456. Forms for Data and Report of Test of Gas-engine.

# MECHANICAL LABORATORY, SIBLEY COLLEGE, CORNELL UNIVERSITY.

Log of test of	Gas-engine
by	, 189.

		ute.		ige.	Те	mpe	ratu	re.	Weight	D: mor	yna- neter,			Press	ures	Card.		
Number.	Time.	Revolutions per Minute.	Explosion, Total.	Explosions per Minute.	Room, Fe.	Exhaust, F °.	ī —		Water.	Reading, Foot-lbs.	Time for 100 Revo-	Cubic Feet Gas.	Gas Water-inches.		Tare.	 Maximum Pressure p	. Н. Р.	D. H. P.
						<u> </u>	I	α	н	<b>K</b>	L		0		_		1	-

by	, 189.,
Object of test	•••••
Dimensions of Engine.  Diameter of piston	Gas, weight of cu. ftlbs Air, """ Mixture, """ Specific heat, gas
Data.  Duration trial, hours	Indicated M. E. P
' per hour	Thermal units per I, H. P

## LIST OF TABLES.

	:	PAGE
I.	U. S. STANDARD AND METRIC MEASURES	
	Numerical Constants	
	LOGARITHMS OF NUMBERS	
	LOGARITHMIC FUNCTIONS OF ANGLES	
	NATURAL FUNCTIONS OF ANGLES	
VI.	COEFFICENTS OF STRENGTH OF MATERIALS	665
VII.	Test of Aluminium Bronzes	•
VIII.	WOODEN PILLARS AND BEAMS	667
	STRENGTH OF METALS AT DIFFERENT TEMPERATURES	668
X.	IMPORTANT PROPERTIES OF FAMILIAR SUBSTANCES	660
	COEFFICIENT OF FRICTION	
	MOISTURE ABSORBED BY AIR	
XIII.	RELATIVE HUMIDITY OF THE AIR	671
XIV.	TABLE FOR REDUCING BEAUME'S SCALE-READING TO SPECIFIC	•
	GRAVITY	672
XV.	PORTER'S STEAM-TABLES	673
XVI.	BUEL'S STEAM-TABLES	678
XVII.	ENTROPY OF THE LIQUID	684
KVIII.	HYPERBOLIC NAPERIAN LOGARITHMS	684
XIX.	DISCHARGE OF STEAM: NAPIER FORMULA	685
XX.	WATER IN STEAM BY THROTTLING CALORIMERER	
	DIAGRAM FOR DETERMINING PER CENT OF MOISTURE IN STEAM.	685
XXI.	FACTORS OF EVAPORATION	687
XXII.	Composition of Fuels of U. S	688
XIII.	THE COLLEGE CHARLES COLLEGE TO I HERDEN COLLEGE TO THE	
	Horse-power per Pound Mean Pressure	
	WATER COMPUTATION TABLE	
	ELECTRICAL HORSE-POWER TABLE	
	Horse-power of Shafting	
CVIII.	Horse-power of Belting	
	SAMPLE-SHEET OF PAPER	694
	637	

# UNITED STATES STANDARD WEIGHTS AND MEASURES. By T. C. MENDENHALL, SUPERINTENDENT, U. S. COAST SURVEY.

		LINEAR.	AR.		=			SQUARE	RE.				CUBIC	Ö,	
l	Inches to milli- metres.	Feet to Metres.	Yards to Metres.	o Miles to Kilometres	. 8	820 g	Sq. Ins. to Sq. Centi- metres.	Square Ft. to Square Deci- metres.	Square Yards to Square Metres.	Acres to Hectares.		Cu. Ins. to Cubic Centi- metres.	Cubic Feet to Cubic Metres.	Cubic Vards to Cubic Metres.	Bushels to Hecto- litres.
1 !! !		0.304801	0.914402	02 1.60935 1=	35 1		6.452	9.290	0.836		11 1	16.387	0.02832	0.765	0 35242
4 (2)	76.2001				3 6		9.355	27.871	2.508	1.2141	3 1	49.161		2.204	1.05727
1	_				7	= 25	25.807	37.161	3.344	1.6187	1	65.549		3.058	1.40969
5	127.0002				74 5	33	32.258	46.452	4.181	2.0234	1	81.936	0.14158	3.823	
=9				11 9.65608	9	38	8.710	55.742	5.017	2.4281	=9	98.323	0.16990	4.587	
7=	177.8003	2.133604	6.400813		13/1		191.51	65.032	5.853	2.8328	1=	114.710	0.19822	5.352	
8	203.2004	2.438405	7.315215	15 12.87478 8=	<u> 18</u>		51.613	74.323	6.689	3.2375	8	131.097	0.22654	6.116	2.81938
=6	9=  228.6004	2.743205	8.229516	16 14.48412  9=	12 0	— I	58.065	83.613	7.525	3.6422	=6	147.484	0.25485	6.881	3.17181
		CAPACITY	TY.			ľ		WEIGHT	tT.		=				
	Fluid Drams to Millilitres	Fluid Ounces to Milli-	Quarts	Gallons to		Grains to		Avoirdu- pois Ounces to	Avoirdu- pois Pounds to	Avoirdu- pois Pounds to Ounces to					
	timetres.	litres.				2		Grammes.	€			1			
=		29.57	0.94636	3.78544	#		64.7989	28.3495	0.45359		00				
<b>1</b>	7.39	59.15	1.89272	7.57088	11		5978	56.6991	•		=	chain	II .	20,1169	metres
3		88.72 2	83308	11.35632	11		3968	85.0486		93.3104	4	93.31044 I square mile	<u>ا</u>		hectares
4	14.79		3.78544	15.14176	#		259.1957	113.3981		1.81437 124.41392		fathom		1.829	
<b>ا</b>	_		4.73180	18.92720	اا	323.	323.9946	141.7470		2.20796 155.51740		nautical mile		= 1853.27	metres
# 0		177.44	5.67816	22.71264	<b>=</b> 9	388	7935	170.0972		2.72156 186.62089	-6	1 foot = 0.304801		ire, 9.4840	metre, 9.4840158 log
7	25.88	207.02		26.49808	1		453.5924	198.4467		3.17515 217.72437		l avoir, pound	= pun	453.5924	453.5924277 gram.
W S		236.59		30.28352	II SO		3914	226.7962		3.62874 248.82785		15432.35639 grains =	grains=	-	kilogramme
=6	33.28	266.16  8	8.51724	34.06895	=6	583	1903	255.1457	_	4.08233 279.93133	6		j		

The only authorized material standard of customary length is the Troughton scale belonging to the Coast Survey office, whose length at 59°,02 The roll standard. The yard in use in the United States is therefore gound to the British yard.

The only authorized material standard of customary weight is the Troy pound of the Mint. It is of brass of unknown density, and therefore not suitable for a standard of mass. It was derived from the British standard Troy pound of 1738 by direct comparison. The British Avoirdupois pound was also derived from the latter, and contains 7000 grains Troy is the reference the same as the grain Avoirdupois, and the pound Avoirdupois in use in the United States is equal to the British pound Avoirdupois. The British gallon = 4,5345 littes. The British bushel = 35,3477 littes.

					L	٠.	ა.		) <i>I</i>	A	ZV Z	IJΑ	κL	,	A	V Z	•	<i>1</i> V2	£	1 1	<b>T</b> I	C	21
!	Cubic	Yards.	1.308	2.616	3.924		_		9.156	10.464	11.771	!	Grammes	<b>ક</b>	Cunces Troy.	0.03215	0.06430	0.09645	0.12860	0.16075	0.19290	0.22505	0.25721
Ċ	Cubic Metres	Feet.	35.314	70.629	105.943	141.258	176.572	211.887	247.201	282.516	317.830		Milliers or	Lonnes	to Pounds	2204.6	4409.2	6613.8			13227.6	15432.2	17636.8
CUBIC	Cubic Decimetres	Inches.	61.023	122.047	183.070	244.093	305.117	366.140	427.163	458.187	549.210		Quintals	_	Pounds Av.	= 220.46			= 88I.84	1102.30	1 322.76	1543.22	17.63697   8 =   1763.68
	<del></del>	Inches.	0.0610	0.1220	0.1831	0.2441	0.3051	0.3661	0.4272	0.4882	0.5492	-	<u> </u> 		Spc	=1 29	324 2=	386 3=	849 4=	311 5=	773 6=	235 7=	597  8=
_		3.E.	0 = 1	1 2	3=	11 7	2=	0 = 9	7=	  00			Kilo	grannes	to Four	2.20462	4.40924	6.61386	8.81849	11.02311	13.22773	15.43235	17.63
	Square Hectares Metresto to	Acres.	2.471	4		1 9.884	12.355	14.826		892.61	22.239 9=	٦.	Hecto.	grammes (100	grammes) to Ounces Av.	3.5274	7.0548	10.5822	14.1096	17.6370	21.1644	24.6918	28.2192
ы́	Square	Yards.	1.196	2.302	3.588	4.784	5.980	7.176	8.372	9.568	10.764	WEIGHT				30	1.71	.07	.43	7161.78			
SQUARE		T.	10.764	21.528	32.292	43.055	53.819	64.583	75.347	86.111	96.874	3	Kilo-	E	Grains	15432.36	30864.71	46297.07	61729.43	_			123458.85
	L	Inches.	0.1550	0.3100	0.4650	0.6200	0.7750	0.9300	1.0850	1.2400	1.3950	1	Milli	grammes	Grains.	I = 0.01543	0.03086	0.04630	0.06173	0.07716	0.09259	0.10803	22.7000 8= 0.12346
	<u>ж</u> _	_	11	3 11 0	11	11	11	11		- 	1=6	_	<u> </u>			=	 	3=	1	5	<b>≡</b>	7=	8
_	Kilometres	mucs.	0.62137	=	3	2.18548 4	S	1.72822 6	.34959 7		.59233 19		Hekto-	litres to	Bushels.	2.8375		8.5125 3=	11.3500	14.1875	17.0250	19.8625	22.7000
				_	_	_	-	-	4	4	-	: 	Deka-	itres to	Gallons.	2.6417	5.2834	7.9251	0.5668	3.2085	15.8502	18.4919	21.1336
AR.	Metres to		1,09361		3.280833	4.37444	5.468056	6.561667	7.655278	8.748889	9.842500	CITY.	_	0	Quarts.	1.0567	2.1134	3.1700	_	.2834 1	_	_	8.4534 2
LINEAR.	Metres to	r cet.	3.28083	5.56167	.84250	3.12333	2.404.7	9.68500	22.96583	26.24667	29.52750	CAPACITY	١,	`	Pluid Ounces.	0.338	•	1.014 3	.4	1.69.1	v	2.368 7	2.706 8
		ri Pi	3700	_	18.1100 9	. 4800 r3	96.8500 16	_			[		1- *	_	_			3.	_	_		<u> </u>	
	Metres to	Tocuca	39.	78.	_	157	_	236.2200	275.5900	``	354.3300		Millilk	Cubic Centi-	Fluid Drams.	0.27		_	1.08		_		2.10
1	1		!!	8	3	4=	<b>S</b>	9	7=	<b>8</b>	6	ĺ	İ			=	8	3=	4=	<b>5</b> ≡	=9	7=	 

31.7466 | 19.84159||9=|1,703.00| 1,7030.0| 0.25/21 By the concurrent action of the principal governments of the world, an International Bureau of Weights and Measures has been established near Paris. Under the direction of the International Committee, two ingots were cast of pure platinum-indima in the proportion of a paris of the forter the direction of the International Committee, two ingots were cast of pure prepared, from the other a definite number of metre bare. These standards of weight and length were intercompared, without preference, and certain ones were selected as International prototype state. dards. The others were distributed by lot to the different governments, and are called national prototype standards. Those apportioned to the 25.5375 9= 0.13889 138891.21 23.7753 9.5101 3.043 2.43

United States are in the keeping of this office.

The metric system was legalized in the United States in 1866.

The metric system was legalized in the United States in 1866.

The international Standard Metre is derived from the Metre des Archives, and its length is defined by the distance between two lines at obCentigrade, on a platinum-iridium bar deposited at the International Bureau of Weights and Measures. The International Standard Kilogramme is a mass of platinum-iridium deposited at the same place, and its weight in vacuo is the same as that

of the Kilogramme des Archives.

The litre is equal to a cubic decimetre of water, and it is measured by the quantity of distilled water which, at its maximum density, will counterpoise the standard kilogramme in a vacuum, the volume of such a quantity of water being, as nearly as has been ascertained, equal to a

II.
NUMERICAL CONSTANTS.

I.O     3.142     0.7854     I.000     I.000     I.0       I.I     3.456     0.9503     I.210     I.331     I.0       I.2     3.770     I.1310     I.440     I.728     I.0	0488   1 0955   1 1402   1	1.0000 1.0323 1.0627
1.1     3.456     0.9503     1.210     1.331     1.4       1.2     3.770     1.1310     1.440     1.728     1.6	0488   1 0955   1 1402   1	1.0323 1.0627 1.0914
1.1 3.456 0.9503 1.210 1.331 1.0 1.2 3.770 1.1310 1.440 1.728 1.0	0955   1 1402   1	1.0627
1.2 3.770 1.1310 1.440 1.728 1.4	1402   1	1.0914
	1832	
1.4 4.398 1.5394 1.960 2.744 1.		1.1287
		1.1447
		1.1696
		1.1935
		1.2164
1.9 5.969 2.8353 3.610 6.859 1.5	3784 1	1.2386
		1.2599
		.2806
		. 3006
		3200
2.4 7.540 4.5239 5.760 13.824 1.5	5492   1	7.3389
2.5 7.854 4.9087 6.250 15.625 1.9	5811 1	.3572
		1.3751
		1.3925
2.8 8.797 6.1575 7.840 21.952 1.6	6733 1	1.4095
<b>2.</b> 9 9.111 6.6052 8.410 24.389 1.3	7029 1	1.4260
		. 4422
		.4581
		1.4736
	8166   1	<b>8884.</b> 1
3.4 10.681 9.0792 11.56 39.304 1.8	8439 1	.5037
	3708 1	.5183
		1.5326
		. 5467
		1.5605
3.9 12.252 11.946 15.21 59.319 1.0	9748   1	.5741
		. 5874
		.6005
		1.6134
		.6261
4.4 13.823 15.205 19.36 85.184 2.6	0976   1	1.6386
4.5 14.137 15.904 20.25 91.125 2.1	1213	.6510
	1448   1	1.6631
4.7 14.765 17.349 22.09 103.823 2.	1680 1	6751

## ## ## ## ## ## ## ## ## ## ## ## ##			Col	NSTANTS—CO	uinuea.		
15.394	*	ИT	g2 <sup>™</sup> 4	#3	250	√n	* <del>-</del>
5.0         15.708         19.635         25.00         125.000         2.2361         1.7100           5.1         16.022         20.428         26.01         132.651         2.2583         1.7213           5.2         16.336         21.237         27.04         140.608         2.2804         1.7325           5.3         16.650         22.002         29.16         157.464         2.3228         1.7435           5.4         16.965         22.902         29.16         157.464         2.3238         1.7524           5.5         17.279         23.758         30.25         166.375         2.3452         1.7558           5.6         17.593         24.630         31.36         175.616         2.3654         1.7758           5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         20.225         37.21         226.981         2.4698         1.8272 <td< td=""><td>4.8</td><td>15.080</td><td></td><td>23.04</td><td></td><td></td><td>1.6869</td></td<>	4.8	15.080		23.04			1.6869
5.1         16.022         26.428         26.01         132.651         2.2583         1.7213           5.2         16.336         21.237         27.04         140.608         2.2804         1.7323           5.3         16.650         22.062         28.09         148.877         2.3223         1.7544           5.4         16.965         22.902         29.16         157.464         2.3238         1.7544           5.5         17.279         23.758         30.25         166.375         2.3452         1.7652           5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4698         1.8272           6.2         19.478         30.191         38.44         238.328         2.490         1.8171	4-9	15.394	18.857	24.01	117.649	2.2136	1.6985
5.2         16.336         21.237         27.04         140.608         2.2804         1.7325           5.3         16.650         22.062         28.09         148.877         2.3022         1.7435           5.4         16.965         22.002         29.16         157.464         2.3238         1.7544           5.5         17.279         23.758         30.25         166.375         2.3452         1.7652           5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.7         17.907         25.518         32.49         185.103         2.3875         1.7863           5.9         18.535         27.340         34.81         205.379         2.4200         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4408         1.8272           6.2         19.478         30.191         38.41         238.328         2.4900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8768 <td< td=""><td>5.0</td><td></td><td></td><td></td><td></td><td></td><td></td></td<>	5.0						
5.3         16.650         22.002         28.00         148.877         2.3022         1.7435           5.4         16.965         22.902         29.16         157.464         2.3238         1.7544           5.5         17.270         23.758         30.25         166.375         2.3452         1.7652           5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.7         17.907         25.518         32.49         185.103         2.3875         1.7863           5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.961         2.4698         1.8570           6.2         19.478         30.191         38.41         238.328         2.4000         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>							
5.4         16.965         22.902         29.16         157.464         2.3238         1.7544           5.5         17.279         23.758         30.25         166.375         2.3452         1.7652           5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.7         17.907         25.518         32.49         185.193         2.3875         1.7863           5.8         18.212         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.081         2.4698         1.8272           6.2         19.478         30.191         38.441         238.328         2.1900         1.8371           6.3         19.478         30.191         39.509         250.047         2.5101         1.8469           6.3         19.793         34.1212         43.56         287.496         2.5691         1.8758							
5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.7         17.907         25.518         32.49         185.193         2.3875         1.7863           5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4698         1.8272           6.2         19.478         30.191         38.441         238.328         2.4900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.114         2.5298         1.8566           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5601         1.8758 <t< td=""><td></td><td></td><td>•</td><td></td><td></td><td></td><td></td></t<>			•				
5.6         17.593         24.630         31.36         175.616         2.3664         1.7758           5.7         17.907         25.518         32.49         185.193         2.3875         1.7863           5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4698         1.8272           6.2         19.478         30.191         38.441         238.328         2.4900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.114         2.5298         1.8566           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5601         1.8758 <t< td=""><td>5.5</td><td>17.270</td><td>23.758</td><td>30.25</td><td>166.375</td><td>2.3452</td><td>1.7652</td></t<>	5.5	17.270	23.758	30.25	166.375	2.3452	1.7652
5.8         18.221         26.421         33.64         195.112         2.4083         1.7967           5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4698         1.8272           6.2         19.478         30.191         38.44         238.328         2.1900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.144         2.5298         1.8566           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5691         1.8758           6.7         21.049         35.257         44.89         300.763         2.5841         1.8952           6.8         21.363         36.317         46.24         314.432         2.6077         1.8945 <td< td=""><td>5.6</td><td></td><td></td><td>31.36</td><td>175.616</td><td>2.3664</td><td></td></td<>	5.6			31.36	175.616	2.3664	
5.9         18.535         27.340         34.81         205.379         2.4290         1.8070           6.0         18.850         28.274         36.00         216.000         2.4495         1.8171           6.1         19.164         29.225         37.21         226.981         2.4698         1.8272           6.2         19.478         30.191         38.44         238.328         2.4900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.144         2.5298         1.8663           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5691         1.8758           6.7         21.049         35.257         44.89         300.763         2.5884         1.8852           6.8         21.363         36.317         46.24         314.432         2.6077         1.8945           6.9         21.677         37.393         47.61         328.509         2.6458         1.9129 <td< td=""><td>5.7</td><td></td><td></td><td></td><td></td><td></td><td></td></td<>	5.7						
6.0	5.8			33.64			
6.1 19.164 29.225 37.21 226.981 2.4698 1.8272 6.2 19.478 30.191 38.44 238.328 2.4900 1.8371 6.3 19.792 31.173 39.69 250.047 2.5100 1.8469 6.4 20.106 32.170 40.96 262.144 2.5298 1.8566 6.5 20.420 33.183 42.25 274.625 2.5495 1.8566 6.6 20.735 34.212 43.56 287.496 2.5691 1.8758 6.7 21.049 35.257 44.89 300.763 2.5884 1.8852 6.8 21.363 36.317 46.24 314.432 2.6077 1.8945 6.9 21.677 37.393 47.61 328.509 2.6268 1.9038 7.0 21.991 38.485 49.00 343.000 2.6458 1.9129 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 389.017 2.7019 1.9399 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487 7.5 23.562 44.179 56.25 421.875 2.7386 1.9574 7.6 23.876 45.365 57.76 438.976 2.7568 1.9661 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916 8.0 25.133 50.266 64.00 512.000 2.8284 2.0008 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.00247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.046 60.821 77.44 681.473 2.9665 2.0646 8.8 27.064 60.821 77.44 681.473 2.9665 2.0646	5.9	18.535	27.340	34.81	205.379	2.4290	1.8070
6.2         19.478         30.191         38.44         238.328         2.1900         1.8371           6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.144         2.5298         1.8566           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5691         1.8788           6.7         21.049         35.257         44.89         300.763         2.5884         1.8852           6.8         21.363         36.317         46.24         314.432         2.6077         1.8945           6.9         21.677         37.393         47.61         328.509         2.6268         1.9038           7.0         21.991         38.485         49.00         343.000         2.6458         1.9129           7.1         22.305         39.592         50.41         357.911         2.6646         1.9220           7.2         22.619         40.715         51.84         373.248         2.6833         1.9310 <td< td=""><td>6.0</td><td>18.850</td><td>28.274</td><td>36.00</td><td>216.000</td><td>2.4495</td><td>1.8171</td></td<>	6.0	18.850	28.274	36.00	216.000	2.4495	1.8171
6.3         19.792         31.173         39.69         250.047         2.5100         1.8469           6.4         20.106         32.170         40.96         262.144         2.5298         1.8566           6.5         20.420         33.183         42.25         274.625         2.5495         1.8663           6.6         20.735         34.212         43.56         287.496         2.5691         1.8758           6.7         21.049         35.257         44.89         300.763         2.5884         1.8958           6.8         21.363         36.317         46.24         314.432         2.6077         1.8945           6.9         21.677         37.393         47.61         328.509         2.6268         1.9038           7.0         21.991         38.485         49.00         343.000         2.6458         1.9129           7.1         22.305         39.592         50.41         357.911         2.6646         1.9220           7.2         22.619         40.715         51.84         373.248         2.6833         1.9310           7.3         22.34         41.854         53.29         389.017         2.7019         1.9329	6.1	19. 164		37.21		2.4698	1.8272
6.4 20.106 32.170 40.96 262.144 2.5288 1.8566 6.5 20.420 33.183 42.25 274.625 2.5495 1.8663 6.6 20.735 34.212 43.56 287.496 2.5691 1.8758 6.7 21.049 35.257 44.89 300.763 2.5884 1.8852 6.8 21.363 36.317 46.24 314.432 2.6077 1.8945 6.9 21.677 37.393 47.61 328.509 2.6268 1.9038 7.0 21.991 38.485 49.00 343.000 2.6458 1.9129 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 389.017 2.7019 1.9399 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487 7.5 23.562 44.179 56.25 421.875 2.7386 1.9647 7.6 23.876 45.365 57.76 438.976 2.7568 1.9667 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916 8.0 25.133 50.266 64.00 512.000 2.8284 2.0008 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.00247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.6 27.018 58.088 73.96 636.056 2.9326 2.0468 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.046 60.821 77.44 681.473 2.9665 2.0646			30.191				
6.5 20.420 33.183 42.25 274.625 2.5495 1.8663 6.6 20.735 34.212 43.56 287.496 2.5691 1.8758 6.7 21.049 35.257 44.89 300.763 2.5884 1.8852 6.8 21.363 36.317 46.24 314.432 2.6077 1.8945 6.9 21.677 37.393 47.61 328.509 2.6268 1.9038 7.0 21.991 38.485 49.00 343.000 2.6458 1.9129 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 389.017 2.7019 1.9399 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487 7.5 23.562 44.179 56.25 421.875 2.7386 1.9574 7.6 23.876 45.365 57.76 438.976 2.7568 1.9661 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916 8.0 25.133 50.266 64.00 512.000 2.8284 2.0000 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.00247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.6 27.018 58.088 73.96 636.056 2.9326 2.0488 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.046 60.821 77.44 681.473 2.9665 2.0646							
6.6 20.735 34.212 43.56 287.496 2.5691 1.8758 6.7 21.049 35.257 44.89 300.763 2.5884 1.8852 6.8 21.363 36.317 46.24 314.432 2.6077 1.8945 6.9 21.677 37.393 47.61 328.509 2.6268 1.9038 7.0 21.991 38.485 49.00 343.000 2.6458 1.9038 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 380.017 2.7019 1.9309 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487 7.5 23.562 44.179 56.25 421.875 2.7386 1.9667 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916 8.0 25.133 50.266 64.00 512.000 2.8284 2.0000 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.00247 8.4 26.389 55.418 70.56 592.704 2.8983 2.02247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 27.018 58.088 73.96 636.056 2.9326 2.0468 8.7 27.038 58.081 77.44 681.473 2.9665 2.0646 60.821 77.44 681.473 2.9665 2.0646	6.4	20.106	32.170	40.96	262.144	2.5298	1.8566
6.6 20.735 34.212 43.56 287.496 2.5691 1.8758 6.7 21.049 35.257 44.89 300.763 2.5884 1.8852 6.8 21.363 36.317 46.24 314.432 2.6077 1.8945 6.9 21.677 37.393 47.61 328.509 2.6268 1.9038 7.0 21.991 38.485 49.00 343.000 2.6458 1.9038 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 380.017 2.7019 1.9309 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487 7.5 23.562 44.179 56.25 421.875 2.7386 1.9667 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916 8.0 25.133 50.266 64.00 512.000 2.8284 2.0000 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.00247 8.4 26.389 55.418 70.56 592.704 2.8983 2.02247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 26.704 56.745 70.56 592.704 2.8983 2.0328 8.5 27.018 58.088 73.96 636.056 2.9326 2.0468 8.7 27.038 58.081 77.44 681.473 2.9665 2.0646 60.821 77.44 681.473 2.9665 2.0646	6.5	20.420	33.183	42.25	274.625	2.5495	1.8663
6.8         21.363         36.317         46.24         314.432         2.6077         1.8945           6.9         21.677         37.393         47.61         328.509         2.6268         1.9038           7.0         21.991         38.485         49.00         343.000         2.6458         1.9129           7.1         22.305         39.592         50.41         357.911         2.6646         1.9220           7.2         22.619         40.715         51.84         373.248         2.6833         1.9310           7.3         22.934         41.854         53.29         389.017         2.7019         1.9399           7.4         23.248         43.008         54.76         405.224         2.7203         1.9487           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832 <td< td=""><td>6.6</td><td></td><td></td><td></td><td></td><td></td><td></td></td<>	6.6						
6.9         21.677         37.393         47.61         328.509         2.6268         1.938           7.0         21.991         38.485         49.00         343.000         2.6458         1.9129           7.1         22.305         39.592         50.41         357.911         2.6646         1.9220           7.2         22.619         40.715         51.84         373.248         2.6833         1.9310           7.3         22.934         41.854         53.29         389.017         2.7019         1.9399           7.4         23.248         43.008         54.76         405.224         2.7203         1.9487           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9437           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000							
7.0 21.991 38.485 49.00 343.000 2.6458 1.9129 7.1 22.305 39.592 50.41 357.911 2.6646 1.9220 7.2 22.619 40.715 51.84 373.248 2.6833 1.9310 7.3 22.934 41.854 53.29 389.017 2.7019 1.9309 7.4 23.248 43.008 54.76 405.224 2.7203 1.9487  7.5 23.562 44.179 56.25 421.875 2.7386 1.9661 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916  8.0 25.133 50.266 64.00 512.000 2.8284 2.0000 8.1 25.447 51.530 65.61 531.411 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.0247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328  8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.6 27.018 58.088 73.96 636.056 2.9326 2.0468 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.646 60.821 77.44 681.473 2.9665 2.0646							
7.1         22.365         39.592         50.41         357.911         2.6646         1.9220           7.2         22.619         40.715         51.84         373.248         2.6833         1.9310           7.3         22.934         41.854         53.29         389.017         2.7019         1.9399           7.4         23.248         43.008         54.76         405.224         2.7203         1.9487           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9647           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165 <td< td=""><td>0.9</td><td>21.077</td><td>37-393</td><td>47.01</td><td>328.509</td><td>2.0208</td><td>1.9038</td></td<>	0.9	21.077	37-393	47.01	328.509	2.0208	1.9038
7.2         22.619         40.715         51.84         373.248         2.6833         1.9310           7.3         22.934         41.854         53.29         389.017         2.7019         1.9399           7.4         23.248         43.008         54.76         405.224         2.7203         1.9487           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165 <td< td=""><td>7.0</td><td>21.991</td><td>38.485</td><td>49.00</td><td>343.000</td><td></td><td>1.9129</td></td<>	7.0	21.991	38.485	49.00	343.000		1.9129
7.3         22.934         41.854         53.29         389.017         2.7019         1.9399           7.4         23.248         43.008         54.76         405.224         2.7019         1.9399           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9812           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>							
7.4         23.248         43.008         54.76         405.224         2.7203         1.9487           7.5         23.562         44.179         56.25         421.875         2.7386         1.9574           7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>							
7.5 23.562 44.179 56.25 421.875 2.7386 1.9574 7.6 23.876 45.365 57.76 438.976 2.7568 1.9574 7.7 24.190 46.566 59.29 456.533 2.7749 1.9747 7.8 24.504 47.784 60.84 474.552 2.7929 1.9832 7.9 24.819 49.017 62.41 493.039 2.8107 1.9916  8.0 25.133 50.266 64.00 512.000 2.8284 2.0000 8.1 25.447 51.530 65.61 531.441 2.8461 2.0083 8.2 25.761 52.810 67.24 551.468 2.8636 2.0165 8.3 26.075 54.106 68.89 571.787 2.8810 2.0247 8.4 26.389 55.418 70.56 592.704 2.8983 2.0328  8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.6 27.018 58.088 73.96 636.056 2.9326 2.0488 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.646 60.821 77.44 681.473 2.9665 2.0646							
7.6         23.876         45.365         57.76         438.976         2.7568         1.9661           7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0468 <td< td=""><td>7.4</td><td>23.248</td><td>43.008</td><td>54.70</td><td>405.224</td><td>2.7203</td><td>1.9487</td></td<>	7.4	23.248	43.008	54.70	405.224	2.7203	1.9487
7.7         24.190         46.566         59.29         456.533         2.7749         1.9747           7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0468           8.7         27.332         59.447         75.69         658.503         2.9496         2.0567 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>							
7.8         24.504         47.784         60.84         474.552         2.7929         1.9832           7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0468           8.7         27.332         59.447         75.69         658.503         2.9496         2.0567           8.8         27.646         60.821         77.44         681.473         2.965         2.0646							
7.9         24.819         49.017         62.41         493.039         2.8107         1.9916           8.0         25.133         50.266         64.00         512.000         2.8284         2.0000           8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0468           8.7         27.332         59.447         75.69         658.503         2.9496         2.0567           8.8         27.646         60.821         77.44         681.473         2.9665         2.0665							
8.0     25.133     50.266     64.00     512.000     2.8284     2.0000       8.1     25.447     51.530     65.61     531.441     2.8461     2.0083       8.2     25.761     52.810     67.24     551.468     2.8636     2.0165       8.3     26.075     54.106     68.89     571.787     2.8810     2.0247       8.4     26.389     55.418     70.56     592.704     2.8983     2.0328       8.5     26.704     56.745     72.25     614.125     2.9155     2.0408       8.6     27.018     58.088     73.96     636.056     2.9326     2.0488       8.7     27.332     59.447     75.69     658.503     2.9496     2.0567       8.8     27.646     60.821     77.44     681.473     2.9665     2.0665							
8.1         25.447         51.530         65.61         531.441         2.8461         2.0083           8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0468           8.7         27.332         59.447         75.69         658.503         2.9496         2.0567           8.8         27.646         60.821         77.44         681.473         2.9665         2.0646	7.9	24.819	49.017	02.41	493.039	2.0107	1.9910
8.2         25.761         52.810         67.24         551.468         2.8636         2.0165           8.3         26.075         54.106         68.89         571.787         2.8810         2.0247           8.4         26.389         55.418         70.56         592.704         2.8983         2.0328           8.5         26.704         56.745         72.25         614.125         2.9155         2.0408           8.6         27.018         58.088         73.96         636.056         2.9326         2.0488           8.7         27.332         59.447         75.69         658.503         2.9496         2.0567           8.8         27.646         60.821         77.44         681.473         2.9665         2.0665		25.133	50.266		512.000		2.0000
8.3     26.075     54.106     68.89     571.787     2.8810     2.0247       8.4     26.389     55.418     70.56     592.704     2.8983     2.0328       8.5     26.704     56.745     72.25     614.125     2.9155     2.0408       8.6     27.018     58.088     73.96     636.056     2.9326     2.0488       8.7     27.332     59.447     75.69     658.503     2.9496     2.0567       8.8     27.646     60.821     77.44     681.473     2.9665     2.0665							
8.4     26.389     55.418     70.56     592.704     2.8983     2.0328       8.5     26.704     56.745     72.25     614.125     2.9155     2.0408       8.6     27.018     58.088     73.96     636.056     2.9326     2.0468       8.7     27.332     59.447     75.69     658.503     2.9496     2.0567       8.8     27.646     60.821     77.44     681.473     2.9665     2.0646							
8.5 26.704 56.745 72.25 614.125 2.9155 2.0408 8.6 27.018 58.088 73.96 636.056 2.9326 2.0488 8.7 27.332 59.447 75.69 658.503 2.9496 2.0567 8.8 27.646 60.821 77.44 681.473 2.9665 2.0646							1
8.6     27.018     58.088     73.96     636.056     2.9326     2.0468       8.7     27.332     59.447     75.69     658.503     2.9496     2.0567       8.8     27.646     60.821     77.44     681.473     2.9665     2.0646	0.4	20.309	55.418	70.50	592.704	2.0953	2.0328
8.7 27.332 59.447 75.69 658.503 2.0496 2.0567 8.8 27.646 60.821 77.44 681.473 2.9665 2.0646							
8.8   27.646   60.821   77.44   681.473   2.9665   2.0646			1 -				
	0.7						
0.9 27.900 02.21 79.21 704.909 2.9033 2.0724			1 .				
	3.9	27.900		19.22	104.909	19033	~.~/=4

CONSTANTS-Continued.

9.1 28.588 65.039 82.81 753.571 3.0166 2.0878 9.2 28.903 66.476 84.64 778.685 3 0332 2.0954 9.3 29.217 67.929 86.49 804.357 3.0496 2.0954 9.4 29.531 69.398 88.36 830.584 3.0659 2.1105 9.5 29.845 70.882 90.25 857.375 3.0822 2.1105 9.6 30.159 72.382 92.16 884.736 3.0964 2.1253 9.7 30.473 73.898 94.09 912.673 3.1145 2.1253 9.8 30.788 75.430 96.04 941.192 3.1305 2.1406 9.9 31.102 76.977 98 01 970.299 3.1464 2.1473 10.0 31.476 78.540 100.00 1000.000 3.1623 2.1548 10.1 31.730 80.119 102.01 1030.301 3.1750 2.1616 10.1 31.730 80.119 102.01 1030.301 3.1750 2.1616 10.2 32.044 81.713 104.04 1061.208 3.1937 2.1687 10.4 32.673 84.949 108.16 1124.863 3.2249 2.1828 10.5 33.929 91.609 110.25 1157.625 3.2404 2.1827 10.6 33.301 88.247 112.36 1191.016 3.2558 2.1967 10.7 33.615 89.920 114.49 1225.043 3.2711 2.2036 10.9 34.243 93.313 118.81 1295.029 3.3015 2.2121 11.0 34.558 95.020 114.49 1225.043 3.2711 2.2036 11.9 34.243 93.313 118.81 1295.029 3.3015 2.2121 11.0 34.558 95.000 110.29 115.64 1259.712 3.28663 2.2104 11.2 35.186 98.520 125.44 194.928 3.3466 2.2374 11.2 35.186 98.520 125.44 194.928 3.3466 2.2374 11.3 35.500 10.29 127.69 144.2897 3.3615 2.2172 11.0 36.757 107.51 130.89 10.9 34.243 93.313 118.81 1295.029 3.3015 2.2172 11.7 36.757 107.51 130.89 10.1 130.89 10.1 130.80 3.3406 2.2231 11.1 33.5.500 10.9 127.69 144.597 3.3615 2.2173 11.1 33.5.500 10.9 127.69 144.597 3.3451 2.2561 11.7 36.757 107.51 130.89 100.1 131.00 3.4451 2.256 11.1 13.35.814 102.07 129.96 1481.544 3.3704 2.2566 11.1 1.2 135.186 98.520 125.44 11.95.88 3.3406 2.2374 11.1 2.2168 11.9 37.385 111.22 141.61 1685.159 3.4496 2.2831 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.22 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.1 11.1 11.1 11.1 11.1 11.1 11.1 1				1			
9.1 28.588 65.039 82.81 753.571 3.0166 2.0878 9.2 28.903 66.476 84.64 778.685 3 0332 2.0954 9.3 29.217 67.929 86.49 804.357 3.0496 2.0954 9.4 29.531 69.398 88.36 830.584 3.0659 2.1105 9.5 29.845 70.882 90.25 857.375 3.0822 2.1105 9.6 30.159 72.382 92.16 884.736 3.0964 2.1253 9.7 30.473 73.898 94.09 912.673 3.1145 2.1253 9.8 30.788 75.430 96.04 941.192 3.1305 2.1406 9.9 31.102 76.977 98 01 970.299 3.1464 2.1473 10.0 31.476 78.540 100.00 1000.000 3.1623 2.1548 10.1 31.730 80.119 102.01 1030.301 3.1750 2.1616 10.1 31.730 80.119 102.01 1030.301 3.1750 2.1616 10.2 32.044 81.713 104.04 1061.208 3.1937 2.1687 10.4 32.673 84.949 108.16 1124.863 3.2249 2.1828 10.5 33.929 91.609 110.25 1157.625 3.2404 2.1827 10.6 33.301 88.247 112.36 1191.016 3.2558 2.1967 10.7 33.615 89.920 114.49 1225.043 3.2711 2.2036 10.9 34.243 93.313 118.81 1295.029 3.3015 2.2121 11.0 34.558 95.020 114.49 1225.043 3.2711 2.2036 11.9 34.243 93.313 118.81 1295.029 3.3015 2.2121 11.0 34.558 95.000 110.29 115.64 1259.712 3.28663 2.2104 11.2 35.186 98.520 125.44 194.928 3.3466 2.2374 11.2 35.186 98.520 125.44 194.928 3.3466 2.2374 11.3 35.500 10.29 127.69 144.2897 3.3615 2.2172 11.0 36.757 107.51 130.89 10.9 34.243 93.313 118.81 1295.029 3.3015 2.2172 11.7 36.757 107.51 130.89 10.1 130.89 10.1 130.80 3.3406 2.2231 11.1 33.5.500 10.9 127.69 144.597 3.3615 2.2173 11.1 33.5.500 10.9 127.69 144.597 3.3451 2.2561 11.7 36.757 107.51 130.89 100.1 131.00 3.4451 2.256 11.1 13.35.814 102.07 129.96 1481.544 3.3704 2.2566 11.1 1.2 135.186 98.520 125.44 11.95.88 3.3406 2.2374 11.1 2.2168 11.9 37.385 111.22 141.61 1685.159 3.4496 2.2831 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.9 144.00 1728.000 3.4611 2.2804 11.9 37.385 111.22 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.2 141.61 1685.159 3.4496 2.2831 11.1 11.1 11.1 11.1 11.1 11.1 11.1 1	*	. 44	# <sup>2</sup> 7 4	#3	#B	<b>√</b> π	₹ <u>*</u>
9.2         28.903         66.476         84.64         778.688         3 0332         2.0934           9.4         29.531         69.398         88.36         804.357         3.0496         2.1032           9.5         29.845         70.882         90.25         857.375         3.0822         2.1179           9.6         30.159         72.352         92.16         884.736         3.0984         2.1253           9.7         30.473         73.898         94.09         912.673         3.1145         2.1323           9.8         30.788         75.430         96.04         941.192         3.1305         2.1402           10.0         31.476         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1661           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1667           10.3         32.358         83.323         106.09         106.273         3.2404         2.1897           10.4         32.045         86.590         110.25         1157.625         3.2404         2.1897 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td>2.0801</td></t<>							2.0801
9.3         29.217         67.929         86.49         80.584         3.0659         2.1026           9.4         29.531         69.398         88.36         830.584         3.0659         2.1102           9.5         29.845         70.882         90.25         857.375         3.0822         2.1175           9.6         30.159         72.382         92.16         884.736         3.0984         2.125           9.7         30.473         73.898         94.09         912.673         3.1145         2.123           9.8         30.788         75.430         96.04         941.192         3.1305         2.142           10.0         31.476         78.540         100.00         1000.00         3.1623         2.154           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1687           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.3         32.358         83.323         106.09         106.128         3.2249         2.1828           10.4         32.937         86.590         110.25         1157.625         3.2404         2.1897							
9.4         29.531         69.398         88.36         830.584         3.0659         2.1105           9.5         29.845         70.882         90.25         857.375         3.0822         2.1175           9.6         30.159         72.382         92.16         884.736         3.0984         2.1253           9.8         30.788         75.430         96.04         941.192         3.1305         2.1402           9.9         31.102         76.977         98.01         970.299         3.1464         2.1472           10.0         31.476         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1687           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.3         32.358         83.323         106.09         1092.727         3.2044         2.1876           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1897           10.7         33.615         89.920         114.49         1225.043         3.271         2.205							
9.6   30.159   72.382   92.16   884.736   3.0984   2.1252   9.7   30.473   73.898   94.09   912.673   3.1145   2.1327   9.8   30.788   75.430   96.04   941.192   3.1305   2.1406   9.9   31.102   76.977   98.01   970.299   3.1464   2.1472   10.0   31.476   78.540   100.00   1000.000   3.1623   2.1544   10.1   31.730   80.119   102.01   1030.301   3.1780   2.1687   10.2   32.044   81.713   104.04   1061.208   3.1937   2.1687   10.3   32.358   83.323   106.09   1092.727   3.2094   2.1757   10.4   32.673   84.949   108.16   1124.863   3.2249   2.1827   10.5   32.987   86.590   110.25   1157.625   3.2404   2.1897   10.6   33.301   88.247   112.36   1191.016   3.2558   2.1967   10.7   33.615   89.920   114.49   1225.043   3.2711   2.2036   10.9   34.243   93.313   118.81   1295.029   3.3015   2.2172   11.0   34.558   95.033   121.00   1331.000   3.3166   2.2237   11.2   35.186   98.520   125.44   1404.928   3.3466   2.2371   11.2   35.186   98.520   125.44   1404.928   3.3466   2.2371   11.3   35.500   100.29   127.69   1442.897   3.3615   2.2411   11.4   35.814   102.07   129.96   1481.544   3.3764   2.2566   11.7   30.757   107.51   130.89   1601.613   3.4205   2.2506   11.8   37.071   109.36   139.24   141.92   3.496   2.2831   11.9   37.385   111.22   141.61   1685.159   3.4496   2.2831   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.494   14.00   1728.000   3.4641   2.2894   12.2   38.327   110.9   36.594   120.06   120.76   133.76   120.00   3.5546   2.3577   2.3381   12.8   40.212   128.68   163.84   2097.152   3.5777   2.3381   12.9   40.527   130.70   106.41   2146.689   3.5977   2.3381   12.9   40.527   130.70   1							2.1029
9.7         30.473         73.898         94.09         912.673         3.1145         2.1327           9.8         30.788         75.430         96.04         941.192         3.1305         2.1402           9.9         31.102         76.977         98.01         970.299         3.1464         2.1472           10.0         31.476         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1667           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.3         32.358         83.323         106.09         1092.727         3.2094         2.1787           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1887           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1887           10.7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10.8         33.929         91.609         116.64         1259.712         3.2863         2.2104 </td <td></td> <td>29.845</td> <td></td> <td>90.25</td> <td></td> <td>3.0822</td> <td>2.1179</td>		29.845		90.25		3.0822	2.1179
9.8         30.788         75.430         96.04         941.192         3.1305         2.1406           9.9         31.102         76.977         98 of         970.299         3.1464         2.1472           10.0         31.476         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1687           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.3         32.358         83.323         106.09         1092.727         3.2094         2.1828           10.4         32.673         84.949         108.16         1124.863         3.2404         2.1897           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1897           10.7         33.615         89.920         114.49         1225.043         3.271         2.2036           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.00         3.3166         2.2237     <				•			2.1253
9.9         31.102         76.977         98.01         970.299         3.1464         2.1472           10.0         31.4r6         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1667           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.3         32.358         83.323         106.09         1092.727         3.2049         2.1827           10.4         32.673         84.949         108.16         1124.863         3.2404         2.1827           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1827           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10.8         33.929         91.609         116.64         1259.712         3.2863         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.22172							
10.0         31.4r6         78.540         100.00         1000.000         3.1623         2.1544           10.1         31.730         80.119         102.01         1030.301         3.1780         2.1616           10.2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10.4         32.358         83.323         106.09         1092.727         3.2094         2.1757           10.4         32.673         84.949         108.16         1124.863         3.2249         2.1828           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1897           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.2711         2.0361           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2237           11.1         34.872         96.769         123.21         1367.631         3.3317         2.237 <td>- 1</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	- 1						
10. 1   31.730   80.119   102.01   1030.301   3.1780   2.1616   10.2   32.044   81.713   104.04   1061.208   3.1037   2.1626   10.3   32.358   83.323   106.09   1092.727   3.2004   2.1627   10.4   32.673   84.949   108.16   1124.863   3.2249   2.1828   10.5   32.987   86.590   110.25   1157.625   3.2404   2.1827   10.6   33.301   88.247   112.36   1191.016   3.2558   2.1967   10.7   33.615   89.920   114.49   1225.043   3.2711   2.2036   10.9   34.243   93.313   118.81   1295.029   3.3015   2.2172   10.9   34.243   93.313   118.81   1295.029   3.3015   2.2172   11.0   34.558   95.033   121.00   1331.000   3.3166   2.2237   11.2   35.186   98.520   125.44   1404.928   3.3466   2.2374   11.2   35.186   98.520   125.44   1404.928   3.3466   2.2374   11.4   35.814   102.07   129.96   1481.544   3.3764   2.2506   11.5   36.128   103.87   132.25   1520.875   3.3912   2.2572   11.6   36.442   105.68   134.56   1560.896   3.4059   2.2637   11.8   37.071   109.36   139.24   1613.032   3.4351   2.2766   11.9   37.385   111.22   141.61   1685.159   3.4496   2.2831   11.9   37.385   111.22   141.61   1685.159   3.4496   2.2831   12.2   38.327   116.90   148.84   1815.848   3.4928   2.3021   12.3   38.642   118.82   151.29   1860.867   3.5214   2.3146   12.5   39.270   122.72   156.25   1953.125   3.5355   2.3268   122.7   39.898   126.68   161.29   169.875   3.5777   2.398   122.6   39.584   122.688   163.84   2007.152   3.5777   2.339   12.8   40.212   128.68   163.84   2007.152   3.5777   2.339   12.9   40.527   130.70   166.41   2146.689   3.5917   2.3351   2.3313   13.0   40.841   132.73   169.00   2197.000   3.6056   2.3513   13.1   41.155   134.78   171.61   2248.091   3.6194   2.3573   2.35731   2.35757   2.3393   13.1   41.155   134.78   171.61   2248.091   3.6194   2.3573   2.3575   2.3575   2.3351   2.3575   2.3351   2.35777   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577   2.3393   2.3311   2.3577	9.9	31.102	70.977	98.01	970.299	3.1404	2.1472
10. 2         32.044         81.713         104.04         1061.208         3.1937         2.1687           10. 4         32.358         83.323         106.09         1092.727         3.2094         2.1757           10. 4         32.673         84.949         108.16         1124.863         3.2249         2.1828           10. 5         32.987         86.590         110.25         1157.625         3.2404         2.1897           10. 6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10. 7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10. 9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11. 0         34.558         95.033         121.00         1331.000         3.3166         2.2237           11. 1         34.872         96.769         123.21         1367.631         3.3317         2.307           11. 2         35.186         98.520         127.69         1442.897         3.3615         2.2441           11. 3         35.500         100.29         127.69         1442.897         3.3015 <td< td=""><td>10.0</td><td></td><td></td><td></td><td></td><td></td><td>2.1544</td></td<>	10.0						2.1544
10.3         32.358         83.323         106.09         1092.727         3.2094         2.1757           10.4         32.673         84.949         108.16         1124.863         3.2249         2.1828           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1897           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10.8         33.929         91.609         116.64         1259.712         3.2863         2.2104           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2237           11.1         34.872         96.769         123.21         1367.631         3.3317         2.2374           11.2         35.186         98.520         127.69         1442.807         3.3615         2.2441           11.3         35.800         100.29         127.69         1442.807         3.3615         2.2441 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>							
10.4         32.673         84.949         108.16         1124.863         3.2249         2.1828           10.5         32.987         86.590         110.25         1157.625         3.2404         2.1807           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10.8         33.929         91.609         116.64         1259.712         3.2863         2.2104           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.237           11.2         35.186         98.520         125.44         1404.928         3.3466         2.237           11.3         35.814         102.07         129.96         1442.897         3.3615         2.244           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2572							
10.5         32.987         86.590         110.25         1157.625         3.2404         2.1897           10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.271         2.2036           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.2307           11.2         35.186         98.520         125.44         1404.928         3.3466         2.2374           11.3         35.500         100.29         127.69         1442.897         3.3615         2.2441           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2507           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.422         105.68         134.56         1560.896         3.4059         2.2673 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>							
10.6         33.301         88.247         112.36         1191.016         3.2558         2.1967           10.7         33.615         89.920         114.49         1225.043         3.2711         2.2036           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2104           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.2374           11.2         35.186         98.520         125.44         1404.928         3.3466         2.2374           11.3         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.422         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         130.89         1601.613         3.4205         2.2702 <td>10.4</td> <td>32.0/3</td> <td>04.949</td> <td>100.10</td> <td>1124.003</td> <td>3.2249</td> <td>2.1020</td>	10.4	32.0/3	04.949	100.10	1124.003	3.2249	2.1020
10.7         33.615         89.920         114.49         1225.043         3.2711         2.206           10.8         33.929         91.609         116.64         1259.712         3.2863         2.2104           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.237           11.2         35.186         98.520         125.44         1404.928         3.3466         2.237           11.3         35.814         102.07         129.96         1442.897         3.3615         2.241           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.422         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         130.89         1601.613         3.4205         2.270	10.5	32.987			1157.625	3.2404	2.1897
10.8         33.929         91.609         116.64         1259.712         3.2863         2.2104           10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.2307           11.2         35.186         98.520         125.44         1404.928         3.3466         2.2371           11.3         35.500         100.29         127.69         1442.897         3.3615         2.241           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.422         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         136.89         1601.613         3.4205         2.2702           11.8         37.071         109.36         139.24         1643.032         3.4351         2.276	10.6						2.1967
10.9         34.243         93.313         118.81         1295.029         3.3015         2.2172           11.0         34.558         95.033         121.00         1331.000         3.3166         2.2236           11.1         34.872         96.769         123.21         1367.631         3.3317         2.2374           11.2         35.186         98.520         125.44         1404.928         3.3466         2.2374           11.3         35.500         100.29         127.69         1442.897         3.3615         2.2441           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.442         105.68         134.56         1560.896         3.4059         2.2637           11.8         37.071         109.36         139.24         1643.032         3.4351         2.276           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>2.2036</td>							2.2036
11.0       34.558       95.033       121.00       1331.000       3.3166       2.2239         11.1       34.872       96.769       123.21       1367.631       3.3317       2.307         11.2       35.186       98.520       125.44       1404.928       3.3466       2.2374         11.3       35.500       100.29       127.69       1442.897       3.3615       2.2441         11.4       35.814       102.07       129.96       1481.544       3.3764       2.2506         11.5       36.128       103.87       132.25       1520.875       3.3912       2.2572         11.6       36.442       105.68       134.56       1560.896       3.4059       2.2637         11.7       36.757       107.51       136.89       1601.613       3.4205       2.2702         11.8       37.071       109.36       139.24       1643.032       3.4351       2.2761         11.9       37.385       111.22       141.61       1685.159       3.4496       2.2831         12.0       37.699       113.10       144.00       1728.000       3.4641       2.2894         12.1       38.013       114.99       146.41       1771.561       3.4	-						
11.1         34.872         96.769         123.21         1367.631         3.3317         2.2307           11.2         35.186         98.520         125.44         1404.928         3.3466         2.2374           11.3         35.500         100.29         127.69         1442.897         3.3615         2.244           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.422         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         136.89         1601.613         3.4205         2.2702           11.8         37.071         109.36         139.24         1643.032         3.4351         2.2766           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2894           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957 <td>10.9</td> <td>34.243</td> <td>93.313</td> <td>118.81</td> <td>1295.029</td> <td>3.3015</td> <td>2.2172</td>	10.9	34.243	93.313	118.81	1295.029	3.3015	2.2172
11.2         35.186         98.520         125.44         1404.928         3.3466         2.2374           11.3         35.500         100.29         127.69         1442.897         3.3615         2.2441           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.442         105.68         134.56         1560.896         3.4059         2.2637           11.8         37.071         109.36         139.24         1643.032         3.4351         2.2762           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3.5214         2.3084 <td>11.0</td> <td>34.558</td> <td>95.033</td> <td>121.00</td> <td>1331.000</td> <td>3.3166</td> <td>2.2239</td>	11.0	34.558	95.033	121.00	1331.000	3.3166	2.2239
11.3         35.500         100.29         127.69         1442.897         3.3615         2.2441           11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.442         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         136.89         1601.613         3.4205         2.2766           11.9         37.385         111.22         141.61         1685.159         3.4351         2.2766           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         18.82         151.29         1860.867         3.571         2.308           12.4         38.956         120.76         153.76         1906.624         3.5214         2.3146	11.1	34.872	96.769	123.21		3.3317	2 2307
11.4         35.814         102.07         129.96         1481.544         3.3764         2.2506           11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.442         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         130.89         1601.613         3.4205         2.2702           11.8         37.071         109.36         139.24         1643.032         3.4351         2.276           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4988         2.3021           12.3         38.642         118.82         151.29         1860.867         3.5214         2.308           12.4         38.956         120.76         153.76         1906.624         3.5214         2.364	11.2						2.2374
11.5         36.128         103.87         132.25         1520.875         3.3912         2.2572           11.6         36.442         105.68         134.56         1560.896         3.4059         2.2637           11.7         36.757         107.51         136.89         1601.613         3.4205         2.2702           11.8         37.071         109.36         139.24         1643.032         3.4351         2.2762           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2894           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3.571         2.3084           12.4         38.956         120.76         153.76         1906.624         3.5355         2.326           12.5         39.584         124.69         158.76         2000.376         3.5355         2.320							
11.6         36.442         105.68         134.56         1560.896         3.4059         2.2657           11.7         36.757         107.51         136.89         1601.613         3.4205         2.2762           11.8         37.071         109.36         139.24         1643.032         3.4351         2.2766           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3.571         2.3084           12.4         38.956         120.76         153.76         1906.624         3.5214         2.3146           12.5         39.270         122.72         156.25         1953.125         3.5355         2.320           12.6         39.584         124.69         158.76         2000.376         3.5496         2.327	11.4	35.814	102.07	129.90	1481.544	3.3754	2.2500
11.7         36.757         107.51         130.89         1601.613         3.4205         2.2702           11.8         37.071         109.36         139.24         1643.032         3.4351         2.2761           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3.5071         2.308           12.4         38.956         120.76         153.76         1906.624         3.5214         2.314           12.5         39.270         122.72         156.25         1953.125         3.5355         2.320           12.7         39.898         126.68         161.29         200.376         3.5496         2.327           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3393	11.5	36.128	103.87	132.25		3.3912	2.2572
11.8         37.071         109.36         139.24         1643.032         3.4351         2.2766           11.9         37.385         111.22         141.61         1685.159         3.4496         2.2894           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.2957           12.3         38.642         118.82         151.29         1860.867         3.5071         2.308           12.4         38.956         120.76         153.76         1906.624         3.5214         2.3146           12.5         39.584         122.72         156.25         1953.125         3.5355         2.3206           12.7         39.898         126.68         161.29         2048.383         3.5537         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3393           12.9         40.527         130.70         166.41         2146.689         3.5917         2.345							2.2637
11.9         37.385         111.22         141.61         1685.159         3.4496         2.2831           12.0         37.699         113.10         144.00         1728.000         3.4641         2.2894           12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3.5071         2.3084           12.4         38.956         120.76         153.76         1906.624         3.5214         2.3146           12.5         39.270         122.72         156.25         1953.125         3.5355         2.3208           12.6         39.584         124.69         158.76         2000.376         3.5496         2.327           12.7         39.898         126.68         161.29         2048.383         3.5637         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3392           12.9         40.527         130.70         106.41         2146.689         3.5917         2.345	11.7						2.2702
12.0     37.699     113.10     144.00     1728.000     3.4641     2.2894       12.1     38.013     114.99     146.41     1771.561     3.4785     2.2957       12.2     38.327     116.90     148.84     1815.848     3.4928     2.3021       12.3     38.642     118.82     151.29     1860.867     3.5071     2.3084       12.4     38.956     120.76     153.76     1906.624     3.5214     2.3146       12.5     39.270     122.72     156.25     1953.125     3.5355     2.3208       12.6     39.584     124.69     158.76     2000.376     3.5496     2.327       12.7     39.898     126.68     161.29     2048.383     3.5537     2.3331       12.8     40.212     128.68     163.84     2097.152     3.5777     2.3392       12.9     40.527     130.70     106.41     2146.689     3.5917     2.3453       13.0     40.841     132.73     169.00     2197.000     3.6056     2.3513       13.1     41.155     134.78     171.61     2248.091     3.6194     2.3573	- 1						
12.1         38.013         114.99         146.41         1771.561         3.4785         2.2957           12.2         38.327         116.90         148.84         1815.848         3.4928         2.3021           12.3         38.642         118.82         151.29         1860.867         3 5071         2.3084           12.4         38.956         120.76         153.76         1906.624         3.5314         2.3146           12.5         39.584         122.72         156.25         1953.125         3.5355         2.320           12.7         39.898         126.68         161.29         2048.383         3.5637         2.3391           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3391           12.9         40.527         130.70         166.41         2146.689         3.5917         2.3451           13.0         40.841         132.73         169.00         2197.000         3.6056         2.3513           13.1         41.155         134.78         171.61         2248.091         3.6194         2.3573	11.9	37 385	111.22	141.01	1055.159	3.4490	2.2831
12.2     38.327     116.90     148.84     1815.848     3.4928     2.3021       12.3     38.642     118.82     151.29     1860.867     3.5071     2.3084       12.4     38.956     120.76     153.76     1906.624     3.5214     2.3146       12.5     39.270     122.72     156.25     1953.125     3.5355     2.3206       12.6     39.584     124.69     158.76     2000.376     3.5496     2.3276       12.7     39.898     126.68     161.29     2048.383     3.5637     2.3331       12.8     40.212     128.68     163.84     2097.152     3.5777     2.3392       12.9     40.527     130.70     166.41     2146.689     3.5917     2.3452       13.0     40.841     132.73     169.00     2197.000     3.6056     2.3513       13.1     41.155     134.78     171.61     2248.091     3.6194     2.3573	12.0						2.2894
12.3         38.642         118 82         151.29         1860.867         3 5071         2.3084           12.4         38.956         120.76         153.76         1906.624         3.5214         2.3146           12.5         39.270         122.72         156.25         1953.125         3.5355         2.3208           12.6         39.584         124.69         158.76         2000.376         3.5496         2.3276           12.7         39.898         126.68         161.29         2048.383         3.5637         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3392           12.9         40.527         130.70         106.41         2146.689         3.5917         2.3452           13.0         40.841         132.73         169.00         2197.000         3.6056         2.3513           13.1         41.155         134.78         171.61         2248.091         3.6194         2.3573							2.2957
12.4     38.956     120.76     153.76     1906.624     3.5214     2.3146       12.5     39.270     122.72     156.25     1953.125     3.5355     2.3206       12.6     39.584     124.69     158.76     2000.376     3.5496     2.3276       12.7     39.898     126.68     161.29     2048.383     3.5537     2.3331       12.8     40.212     128.68     163.84     2097.152     3.5777     2.3392       12.9     40.527     130.70     166.41     2146.689     3.5917     2.3452       13.0     40.841     132.73     169.00     2197.000     3.6056     2.3512       13.1     41.155     134.78     171.61     2248.091     3.6194     2.3573							
12.5         39.270         122.72         156.25         1953.125         3.5355         2.3206           12.6         39.584         124.69         158.76         2000.376         3.5496         2.3276           12.7         39.898         126.68         161.29         2048.383         3.5537         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3392           12.9         40.527         130.70         166.41         2146.689         3.5917         2.3452           13.0         40.841         132.73         169.00         2197.000         3.6056         2.3512           13.1         41.155         134.78         171.61         2248.091         3.6194         2.3573			1				
12.6         39.584         124.69         158.76         2000.376         3.5496         2.3276           12.7         39.898         126.68         161.29         2048.383         3.5637         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3392           12.9         40.527         130.70         166.41         2146.689         3.5917         2.3452           13.0         40.841         132.73         169.00         2197.000         3.6056         2.3513           13.1         41.155         134.78         171.61         2248.091         3.6194         2.3573	12.4	38.950	120.70	153.70	1900.024	3.5214	2.3140
12.7         39.898         126.68         161.29         2048.383         3.5637         2.3331           12.8         40.212         128.68         163.84         2097.152         3.5777         2.3392           12.9         40.527         130.70         166.41         2146.689         3.5917         2.3452           13.0         40.841         132.73         169.00         2197.000         3.6056         2.3512           13.1         41.155         134.78         171.61         2248.091         3.6194         2.3573							2.3208
12.8     40.212     128.68     163.84     2007.152     3.5777     2.3393       12.9     40.527     130.70     166.41     2146.689     3.5917     2.3453       13.0     40.841     132.73     169.00     2197.000     3.6056     2.3513       13.1     41.155     134.78     171.61     2248.091     3.6194     2.3573							
12.9     40.527     130.70     166.41     2146.689     3.5917     2.3453       13.0     40.841     132.73     169.00     2197.000     3.6056     2.3513       13.1     41.155     134.78     171.61     2248.091     3.6194     2.3573							
13.0 40.841 132.73 169.00 2197.000 3.6056 2.3513.1 41.155 134.78 171.61 2248.091 3.6194 2.3573	1						
13.1 41.155 134.78 171.61 2248.091 3.6194 2.3573	12.9	40.52/	130.70	100.41	2140.009	3.5917	2.3453
							2.3513
	13.1	41.155	134.78	171.01	2218.091 2299.968	3.6332	2.3573

### CONSTANTS—Co. stinued,

*	##	# <sup>2</sup> # 4	# <sup>3</sup>	n <sup>Q</sup>	4%	v <sub>n</sub>
13.3 13.4	41.783 42.097	138.93 141.03	176.89 179.56	2352.637 2406.104	3.6469 3.6606	2.3693 2.3752
13.5	42.412	143.14	182.25	2460.375	3.6742	2.381t
13.6 13.7	42.726 43.040	145.27 147.41	184.96 187.69	2515.456 2571.353	3.6878	2.3870
13.8	43.354	149.57	190.44	2628.072	3.7013	2.3928
13.9	43.668	151.75	193.21	2685.619	3.7283	2.3986
14.0	43.982	153.94	196.00	2744.000	3.7417	2.410 <b>1</b>
14.1	44.296	156.15 158.37	198.81 201.64	2803.221 2863.288	3.7550	2.4159
14.3	44.611 44.925	160.61	201.49	2924.207	3.7683 3.7015	2.4216
14.4	45.239	162.86	207.36	2985.984	3.7947	2.4272 2.4329
14.5	45 - 553	165.13	210.25	3048.625	3.8079	2.4385
14.6	45.867	167.42	213.16	3112.136	3.8210	2.4441
14.7	46.181	169.72	216.09	3176.523	3.8341	2.4497
14.0	46.496 46.810	172.03 174.37	219.04 222.01	3241.79 <b>2</b> 3307.949	3.8471 3.8600	2.4552 2.4607
15.0	47. 124	176.72	225.00	3375.000	3.8730	2.4662
15.1	47.438	179.08	228.01	3442.951	3.8859	2.4717
15.2	47.752	181.46	231.04	3511.808	3.8987	2.4772
15.3 15.4	48.066 48.381	183.85 186.27	234.09 237.16	3581.577 3652.264	3.9115	2.4825
-3.4	40.301	100.0,	23,1.10	3032.204	3.9-43	2.40/9
15.5	48.695	188.69	240 25	3723.875	3.9370	2.4933
15.6	49.003	191.13	243.36	3796.416	3 9 4 9 7	2.4986
15.7	49.323	193.59	246.49	3869.893	3.9623	2.5039
15.8 15.9	49.637 49.951	196.07 198.56	249.64 252.81	3944.312 4019.679	3.9749 3.9875	2.5092 2.5146
16.0	50.265	201.06	256.00	4096.000	4.0000	2.5198
16.1	50.585	203.58	259.21	4173.281	4.0125	2.5251
16.2	50.894	206.12	262.44	4251.528	4.0249	2.5303
16.3 16.4	51.203	208.67 211.24	265.69	4330.747	4.0373	2.5355
	51.522	, i	268.96	4410.944	4.0497	2.5406
16.5	51.836	213.83	272.25	4492.125	4.0620	2.5458
16.6	52.150	216.42	275.56	4574.296	4.0743	2.5509
16.7 16.8	52.465 52.779	219.04 221.67	278.89 282.24	4657.463 4741.632	4.0866	2.5561
16.9	53.093	224.32	285.61	4826.809	4.1110	2.5663
17.0	53.407	226 98	289.00	4913.000	4.1231	2.5713
17.1	53.721	229.66	292.41	5000.211	4.1352	2.5763
17.2 17.3	54.035 54.350	132.35 235.06	295.84 299.29	5088.448 5177.717	4.1473	2.5813 2.5863
17.4	54.664	237.79	302.76	5268.024	4.1713	2.5913
-,-4	J4:5-4	-37.19	1	,	1 7,-3	2.39-3

*	NR	#3 T 4	#3	**	V.	¥,
17.5	54.978	240.53	306.25	5359 - 375	4.1833	2.5963
17.6	55.292	243.29	309.76	5451.776	4.1952	2.6012
17.7	55.606	246.00	313.29	5545.233	4.2071	2.6061
17.8	55.920	248.85	316.84	5639.752	4.2190	2.6100
17.9	56.235	251.65	320.41	5735 - 339	4.2308	2.6158
18.0	56.549	254 - 47	324.00	5832.000	4.2426	2.6207
18.1	56.863	257.30	327.61	5929.741	4.2544	2.6256
18.2	57.177	260.16	331.24	6028.568	4.2661	2.6304
18.3 18.4	57.491 57.805	263.02 265.90	334.89 338.56	6128.487 6229.504	4.2778	2.6352 2.640I
18.5	58.110	<b>2</b> 68.80	342.25	6331.625	4.3012	2.6448
18.6	58.434	271.72	345.96	6434.856	4.3128	2.6495
18.7	58.748	274.65	349.69	6539.203	4.3243	2.6543
18.8	59.062	277.59	353-44	6644.672	4.3359	2.6590
18.9	59.376	280.55	357.21	6751.269	4 · 3474	2.6637
19.0	59.690	283.53	361.00	6859.000	4.3589	2.6684
19. I	60.001	286.52	364.81	6967.871	4.3703	2.6731
19.2	60.319	289.53	368.64	7077.888	4.3818	2.6777
19.3	60.633	292.55	372.49	7189.057	4.3932	2.6824 2.6860
19.4	60.947	295.59	376.36	7301.384	4.4045	2.0809
19.5	61.261	298.65	380.25	7414.875	4-4159	2.6916
19.6	61.575	301.72	384.16	7529.536	4.4272	2.6962
19.7	61.889	304.81	388.00	7645 - 373	4 - 4385	2.7008
19.8	62.204	307.91	392.04	7762.392	4-4497	2.7053
19.9	62.518	311.03	396.01	7880.599	4.4609	2.7098
20.0	62.832	314.16	400.00	8000.0 <b>0</b> 0	4.4721	2.71.14
20. I	63.146	317.31	404.01	8120.601	4.4833	2.7189
20.2	63.460	320.47	408.04	8242.408	4 - 4944	2.7234
20.3	63.774	323.66	412.09	8365 427	4.5055	2.7279
20.4	64.088	326 85	416.16	8489.664	4.5166	2.7324
20.5	64.403	330.06	420.25	8615.125	4.5277	2.7368
20.6	64.717	333.29	424.36	8741.816	4.5387	2.7413
20.7	65.03ī	336.54	428.49	8869.743	4 - 5497	2.7457
20.8 20.9	65.345	339.80	432.64 436.81	8989.912	4.5607 4.5716	2.7502
<b>2</b> 0.9	05.659	343.07	450.01	3129.329		'''
21.0	65.973	346.36	441.00	9261.000	4.5826	2.7589
21.1	66.288	349.67	445.21	9393.931	4-5935	2.7633
21.2	66.602	352.99	449.44	9528.128	4.6043	2.7676
21.3	66.916	356.33	453.69	9663.597	4.6152	2.7720
21.4	67.230	359.68	457.96	9800.344	4.6260	2.7763
21.5	67.544	363.05	463.25	9938.375	4.6368	2.7806
21.6	67.858	366.44	466.56	10077.696	4.6476	2.7849
21.7	68.173	369.84	470.89	10218.313	<u>4</u> .6589_	2.7893

*	яя	я <sup>3 Т</sup> 4	N <sub>S</sub>	m <sup>2</sup>	√ <sub>n</sub>	· ·
21.8	68.487	373 - 25	475.24	10360.232	4.6690	2.7935
21.9	108.80	376.69	479.61	10503.459	4.6797	2.7978
22.0	69.115	380.13	484.00	10648.000	4.6904	2.8021
22. I	69.429	383.60	488.41	10793.861	4.7011	2.8063
22.2	69.743	387.08	492.84	10941.048	4.7117	2.8105
22.3	70.058	390.57	497.29	11089.567	4.7223	2.8147
22.4	70.372	394.08	501.76	11239.424	4.7329	2.8189
22.5	70.686	397.61	506.25	11390.625	4 · 7434	2.8231
22.6	71.000	401.15	510.76	11543.176	4.7539	2.8273
22.7	71.314	404.71	515.29	11697.083 11852.352	4.7644	2.8314
22.8 22.9	71.268	408.28 411.87	519.84 5 <b>2</b> 4.41	12008.989	4.7749	2.8356
22.9	71.942	411.07	2-4-41	12000.909	4.7034	2.8397
23.0	72.257	415.48	529.00	12167.000	4.7958	2.8438
23. I	72.571	419.10	533.61	12326.391	4.8062	2.8479
23.2	72 885	422.73	538.24	12487.168	4.8166	2.8521
23.3	73.199	426.39	542.89	12649.337	4.8270	2.8562
23.4	73.513	430.05	547 - 56	12812.904	4.0373	2.8603
23.5	73.827	433 · 74	552.25	12977.875	4.8477	2.8643
23.6	74.142	437 • 44	556.96	13144.256	4.8580	2.8684
23.7	74.456	441.15	561.69	13312.053	4.8683	2.8724
23 8	74.770	444.88 448.63	566.44 571.21	13481.272	4.8785	2.8765
23.9	75.084	440.03	3/1.21	13651.919	4.0000	2.8805
24.0	75.398	452.39	576.00	13824.000	4.8990	2.8845
24.1	75.712	456.17	580.81	13997.521	4.9092	2.8885
24.2	76.027	459.96	585.64	14172.488	4.9193	2.8925
24.3	76.341	463.77	590.49	14348.907	4.9295	2.8965
24.4	76.655	467.60	595.36	14526.784	4.9396	2.9004
24.5	76.969	471.44	600.25	14706.125	4.9497	2.9044
24.6	77.283	475.29	605.16	14886.936	4.9598	2.9083
24.7	77 - 597	479.16	610.09	15069.223	4.9099	2.9123
24.8	77.911	483.05	615.04	15252.992	4.9799	2.9162
24.9	78.226	486.96	620.01	15438.249	4.9899	2.9201
25.0	78.540	490.87	625.00	15625.000	5.0000	2.9241
25. I	78.854	494.81	630.01	15813.251	5.0099	2.9279
25.2	79.168	498.76	635.04	16003.008	5.0199	2.9318
<b>2</b> 5 · 3	79.482	502.73	610.00	16194.277	5.0299	2.9356
25.4	79.796	506.71	645.16	16387.064	5.0398	2.9395
25.5	80.111	510.71	650.25	16581.375	5.0497	2.9434
25.6	80.425	514.72	655.36	16777.216	5.0596	2.9472
25.7	80.739	518.75	660.49	16974.593	5.0695	2.9510
25.8 25.9	81.053 81.367	522.79 526.85	665.64 670.81	17173.512	5.0793	2.9549 2.9586
-3.9	01.307	320.03	0,0.01	-/3/3.9/9	3.0092	2.9500

				<del></del>		
#	NW	я <sup>в</sup> <del>Г</del> 4	#3	<b>*</b>	478	<i>*</i>
26.0	81.681	530.93	675.00	17576.000	5.0990	2.9624
26.1	81.996	535.02	12.186	17779.581	5.1088	2.0662
26.2	82.310	539.13	686.44	17984.728	5.1185	2.9701
26.3	82.624	543.25	691.69	18191.447	5.1283	2.9738
26.4	82.938	547 · 39	696.96	18399.744	5.12%	2.9776
26.5	83.252	551.55	702.25	18609.625	5.1478	2.9814
26.6	83.566	555 - 72	. 707 . 56	18821.096	5.1575	2.9851
26.7	83.88r	559.90	712.89	19034.163	5.1672	2.9888
26.8	84.195	564.10	718.24	19248.832	7.1768	2.9926
26.9	84.509	568.32	723.61	19465.109	5.1865	2.9963
27.0	84.823	572.56	729.00	19683.000	5.1962	3.0000
27.1	85.137	576.80	734.41	19902.511	5.2057	3.0037
27.2	85.451	581.07	739.84	20123.648	5.2153	3.0074
27.3	85.765 86.080	585.35 589.65	745.29 750.76	20346.417 20570.824	5.2249 5.2345	3.0111
27.4	60.060	509.05	750.70	20570.024	3.4343	3.0147
27.5	86.394	593.96	756.25	20796.875	5.2440	3.0184
27.6	86.708	598.29	761.76	21024.576	5.2535	3.0221
27.7	87.022	602.63	767.29	21253.933	5.2630	3.0257
27.8	87.336	606.99	772.84	21484.952	5.2725	3.0293
27.9	87.650	611.36	778.41	21717.639	5.2820	3.0330
28.0	87.365	615.75	784.00	21952.000	5.2915	3.0366
28.1	88.279	620.16	789.61	22188.041	5.3009	3.0402
28.2	88.593	624.58	795 - 24	2242768 22 65.187	5.3103	3.0438
28.3	88.907	629.02	800.89 806.56	22 05.187	5.3197 5.3291	3.0474
28.4	89.221	633.47	300.50	22900.304	3.3291	
28.5	89.535	637.94	812.25	23149.125	5.3385	3.0546
28.6	89.85 <b>0</b>	642.42	817.96	23393.656	5.3478	3.0581
28.7	90.164	646.93	823.69	23639.903	5.3572	3.0617
28.8	90.478	651.44	. 829.44	23887.872	5.3665	3.0652
28.9	90.792	655.97	835.21	24137.569	5.3758	3.0000
29.0	91.106	660.52	841.00	24389.000	5.3852	3.0723
29.I	91.420	665.08	846.81	24642.171	5 - 3944	3.0758
29.2	91.735	669.66	852.64	21897.088	5.4037	3.0794
29.3	92.049	674.26	858.49	25153.757	5.4129	3.0829
29.4	92.363	678.87	864.36	25412.184	5.4221	3.0864
29.5	92.677	683.49	870.25	25672.375	5.4313	3.0899
29.6	92.991	688.13	876.16	25934.336	5.4405	3.0934
29.7	93.305	692.79	882.09 888.04	26198.073	5 4497	3.0968
29.8	93.619	697.47	894.01	26463.592 26730.899	5.4589 5.4680	3.1038
<b>29</b> .9	93.934	702.15	094.01	20/30.099	3.4000	3.1030
30.0	94.248	706.86	y30.00	27000.000	5 - 4772	3.1072
<b>3</b> 0.1	94.562	711.58	906.01	27270.901	5.4863	3.1107
30.2	94.876	716.32	912.04	27543.608	5 • 4954	3.1141

	•			1		
I .	##	# <sup>3</sup> <sup>T</sup> / <sub>4</sub>	<i>n</i> 3	#3	√ <u>-</u>	*.
30.3	95.190	721.07	918.09	27818.127	5.5045	3.1176
30.4	95.505	725.83	924.16	28094.464	5.5136	3.1210
30.5	95.819	730.62	930.25	28372.625	5.5226	3.1244
30.6	96.133	735 - 42	936.36	28652.616	5.5317	3.1278
30.7 30.8	96.447 96.761	740.23 745.06	942.49 948.64	28934.443 29218.112	5.5407	3.1312
30.9	97.075	749.9I	954.81	29503.629	5·5497 5·5587	3.1346 3.1380
31.0	97.389	754 - 77	961.00	29791.000	5.5678	3.1414
31.1	97.704	759.65	967.21	30080.231	5.5767	3.1448
31.2	810.80	764.54	973 - 44	30371.328	5 5857	3.1481
31.3	98.332	769.45	979.69	30664.297	5.5946	3.1515
31.4	98.646	774 - 37	985.96	30959.144	5.6035	3.1548
31.5	98.960	779.31	992.25	31255.875	5.6124	3.1582
31.6	99.274	784.27	998.56	31554.496	5.6213	3.1615
31.7	99.588	789.24	1001.89	31855.013	5.6302	3.1648
31.8	99.903	794.23	1011.24	32157.432	5.6391	3.1681
31.9	100.22	799 - 23	1017.61	32461.759	5.6480	3.1715
32.0	100.53	804.25	1024.00	32768.000	5.6569	3.1748
32.1 32.2	100.85	809.28 814.33	1030.41	33076.161 33386.248	5.6656 5.6745	3.1781
32.3	101.47	819.40	1043.29	33698.267	5.6833	3.1847
32.4	101.79	824.48	1049.76	34012.224	5.6921	3.1880
32.5	102.10	829.58	1056.25	34328.125	5.7008	3.1913
32.6	102.42	834.69	1062.75	34645.976	5.7096	3.1945
32.7	102.73	839.82	1069.29	34965.783	5.7183	3.1978
32.8	103.04	844.96	1075.84	35287.552	5.7271	3.2010
32.9	103.36	850.12	1082.41	35611.289	5.7358	3.2043
33.0	103.67	855.30	1089.00	35937.000	5.7446	3.2075
33.1	103.99	860.49	1095.61	36264.691	5.7532	3.2108
33.2	104.30	865.70	1102.24	36594 368	5.7619	3.2140
33·3 33·4	104.62	870.92 876.16	1115.56	36926.037 37259.704	5.7706	3.2172
1		·			(	
33.5	105.24	881.41	1122.25	37595 - 375	5.7879	3.2237
33.6	105.56	886.68	1128.96	37933.056	5.7965	3.2269
33·7 33.8	105.87 106.10	891.97 897.2 <b>7</b>	1135.69	38272.753 38614.472	5.8051	3.230I 3.2332
33.9	106.50	902.59	1149.21	38958.219	5.8223	3.2364
34.0	106.81	907.92	1156.00	39304.000	5.8310	3.2396
34.1	107.13	913.27	1162.81	39651.821	5.8395	3.2428
34.2	107.44	918.63	1169.64	40001.688	5.8480	3.2460
34.3	107.76	924.01	1176.49	40353.607	5.8566	3.2491
34.4	108.07	929.41	1183.36	40707.584	5.8651	3.2522

	ЯĦ	n <sup>2</sup> # 4	m?	m <sup>2</sup>	4-	i.
34 - 5	108.38	934.82	1190.25	41063.625	5.873ú	3.2554
34.6	108.70	940.25	1197.16	41421.736	5.8821	3.2586
34.7	109.01	945.69	1204.09	.;1781.923	5.8906	3.2617
34.8	109.33	951.15	1211.04	42144.192	5.8991	3.2648
34.9	109.64	956.62	1218.01	42508.549	5.9076	3.2679
35.0	109.96	962.11	1225.00	42875.000	5.9161	3.2710
35.1	110.27	967.62	1232.01	43243.551	5.9245	3.2742
35.2	110.58	973.14	1239.04	43614.208	5.9329	3-2773
35.3	110.90	978.68	1246.09	43986.977	5 9413	3.2804
35.4	111.21	984.23	1253,16	44361.864	5.9497	3.2835
35.5	111.53	989.80	1260.25	44738.875	5.9581	3.2866
35.6	111.84	995.38	1267.36	45118.016	5.9665	3.2897
35.7	112.15	1000.98	1274.49	45499 • 293	5.9749	3.2927
35.8	112.47	1006.60	1281.64	45882.712	5.9833	3.2958
35.9	112.78	1012.23	1288.81	46268.279	5.9916	3.2989
36.0	113.10	1017.88	1296.00	46656 000	6.0000	3.3019
36.I	113.41	1023.54	1303.21	47045.881	6.0083	3.3050
36.2	113.73	1029.22	1310.44	47437.928	6.0166	3.3080
36.3	114.04	1034.91	1317.69	47832.147	6.0249	3.3111
36.4	114.35	1040.62	1324.96	48228.544	6.0332	3.3141
39.5	114.67	1046.35	1332.25	48627.125	6.0415	3.3171
36.6	114.98	1052.00	1339.56	49027.896	6.0497	3.3202
36 7	115.30	1057.84	1346.89	49430.863	6.0580	3.3232
36.8	115.61	1063.62	1354.24	49836.032	6.0663	3.3262
36.9	115.92	1069.41	1361.61	50243.409	6.0745	3.3292
37.0	116.24	1075.21	1369.00	50653.000	6.0827	3.3322
37.1	116.55	1081.03	1376.41	51064.811	6.0909	3.3352
37.2	116.87	1086.87	1383.84	51478.848	6.0991	3.3382
37 · 3	7.7.18	1092.72	1391.29	51895.117	6.1073	3.3412
37.4	117.50	1093.58	1398.76	52313.624	6.1155	3.3442
37.5	117.81	1104.47	1406.25	52734 - 375	6.1237	3.3472
37.6	118.12	1110.36	1413.76	53157.376	6.1318	3.3501
37.7	118.44	1116.28	1421.29	53582.633	6.1400	3.3531
37.8	118.75	1122.21	1428.84	54010.152	6.1481	3.3501
37.9	119.07	1128.15	1436.41	54439.939	6.1563	3.3590
38.0	119.38	1134.11	1444.00	54872.000	6.1644	3.3620
38.1	119.69	1140.00	1451.61	55306.341	6.1725	3.3619
38.2	120.01	1146.08	1459.24	55742.068	6.1806	3.3679
38.3	120.32	1152.00	1466.89	56181.887	6.1887	3.3708
38.4	120.64	1158.12	1474.56	56623.104	6.1967	3 - 3737
38.5	120.95	1164.16	1482.25	57066.625	6.2048	3.3767
38.6	121.27	1170.21	1489.96	57512.456	6.2120	3.3796
38.7	121.58	1 1176.28	1497.69	57960.603	6.2209	3.382 <b>5</b>

		COR	ISTANTS—CON	in meu.		
=	ЯТ	π <sup>2</sup> π 4	я³	n <sup>2</sup>	√ <u>*</u>	v̄π
38.8	121.89	1182.37	1505.44	58411.072	6.2289	3.3854
38.9	122.21	1188.47	1513.21	58863.869	6.2370	3.3883
39.0	122.52	1194.59	1521.00	59319.000	6.2450	3.3912
39. I	122.84	1200.72	1528.81	59776.471	6.2530	3.3941
39.2	123.15	1206.87	1536.64	60236.288	6.2610	3.3970
39.3	123.46	1213.04	1544.49	60698.457	6.2689	3.3999
3 <del>9</del> · 4	123.78	1219.22	1552.36	61162.984	6.2769	3.4028
<b>3</b> 9 · 5	124.09	1225.42	1560.25	61629.875	6.2849	3.4056
39.6	124.41	1231.63	1568.16	62099.136	6.2928	3.4085
39.7	124.72	1237.86	1576.09	62570.773	6.3008	3.4114
39.8	125.04	1244.10	1584.04	63044.792	6.3087	3.4142
39.9	125.35	1250.36	1592.01	63521.199	6.3165	3.4171
40.0	125.66	1256.04	1600.00	64000.000	6.3245	3.4200
40.1	125.98	1262.93	1608.01	64481.201	6.3325	3.4228
40.2	126.29	1269.23	1616.04	64964.808	6.3404	3.4256
40.3	126.61	1275.56	1624.09	65450.827	6.3482	3.4285
40.4	126.92	1281.90	1632.16	65939.264	6.3561	3.4313
40.5	127.23	1288.25	1640.25	66430.125	6.3639	3.4341
40.6	127.55	1294.62	1648.36	66923.416	6.3718	3.4370
40.7	127.86	1301.00	1656.49	67419.143	6.3796	3.4398
40.8	128.18	1307.41	1664.64	67911.312	6.3875	3.4426
40.9	128.49	1313.82	1672.81	68417.929	6.3953	3 - 4454
41.0	128.81	1320.25	1681.00	68921.000	6.4031	3.4482
41.1	129.12	1326.70	1689.21	69426.531	6.4109	3.4510
41.2	129.43	1333.17	1697.44	69934.528	6.4187	3.4538
41.3	129.75	1339.65	1705.69	70444.997	6.4265	3.4566
41.4	130.06	1346.14	1713.96	<b>7</b> 0957.944	6.4343	3 - 4594
41.5	130.38	1352.65	1722.25	71473-375	6.4421	3.4622
41.6	130.69	1359.18	1730.56	71991.296	6.4498	3.4650
41.7	131.00	1365.72	1738.89	72511.713	6.4575	3.4677
41.8	131.32	1372 28	1747.24	73034.632	6.4653	3.4705
41.9	131.63	1378.85	1755.61	73560.059	6.4730	3 · 473 <b>3</b>
42.0	131.95	1385.44	1764.00	74088.000	6.4807	3.4760
42. I	132.26	1392.05	1772.41	74618.461	6.4884	3.4788
42.2	132.58	1398.67	1780.84	75151.448	6.4961	3.4815
42.3	132.89	1405.31	1789.29	75686.967	6.5038	3.4843
42.4	133.20	1411.96	1797.76	76225.024	6.5115	3.4870
42.5	133.52	1418.63	1806.25	76765.625	6.5192	3.4898
42.6	133.83	1425.31	1814.76	77308.776	6.5268	3.4925
42.7	134.15	1432.01	1823.29	77854.483	6.5345	3 4952
42.8	134.46	1438.72	1831.84	78402.752	6.5422	3.4980
42.9	134.77	I445·45	1840.41	78953.589	6.5498	3.5007
		1	<b>'</b>			1

CONSTANTS-Continued.

<del></del> 1					I		
*	##	# <sup>3</sup> <del>1</del> 4	Mg.	g-9	<b>√</b> **	i,	
43.0	135.09	1452.20	1849.00	79507.000	6.5574	3.5034	
43.1	135 .40	1458.96	1857.61	80062.991	6.5651	3.506E	
43.2	135.72	1465.74	1866.24	80621.568	6.5727	3.5088	
43.3	136.03	1472.54	1874.89	81182.737	6.5803	3.5115	
43.4	136.35	1479.34	1883.56	81746.504	6.5879	3.5142	
43.5	136.66	1486.17	1892.25	82312.875	6.5954	3.5169	
43.6	136.97	1493.01	1900.96	82881.856	6.6030	3.5196	
43.7	137.29	1499.87	1909.69	83453.453	6.6166	3.5223	
43.8	137.60	1506.74	1918.44	84027.672	6.6182	3.5250	
43.9	137.92	1513.63	1927.21	84604.519	6.6257	3.5277	
44.0	138.23	1520.53	1936.00	85184.000	6.6333	3.5303	
44.I	138.54	1527.45	1944.81	85766.121	6.6408	3.5330	
44.2	138.86	1534.39	1953.64	86350.888	6.6483	3 - 5357	
44.3	139.17	1541.34	1962.49	86938.307	6.6558	3.5384	
44.4	139.49	1548.30	1971.36	87528.384	6.6633	3.5410	
44.5	139.80	1555.28	1980.25	88121.125	6.6708	3 - 5437	
44.6	140.12	1562.28	1989.16	88716.536	6.6783	3.5463	
44.7	140.43	1569.30	1998.09	89314.623	6.6858	3.5490	
44.8	140.74	1576.33	2007.04	89915.392	6.6933	3.5516	
44.9	141.06	1583.37	2016.01	90518.849	6.7007	3 - 5543	
45.0	141.37	1590.43	2025.00	91125.000	6.7082	3.5569	
45.I	141.69	1597.51	2034.01	91733.851	6.7156	3 - 5595	
45.2	142.00	1604.60	2043.04	92345.408	6.7231	3.5621	
45.3	142.31	1611.71	2052.00	92959.677	6.7305	3.5648	
45.4	142.63	1618.83	2061.16	93576.664	6.7379	3-5674	
45.5	142.94	1625.97	2070.25	94196.375	6.7454	3.5700	
45.6	143.26	1633.13	2079.36	94818.816	6.7528	3.5726	
45.7	143.57	1640.30	2088.49	95443.993	6.7602	3-5752	
45.8	143.88	1647.48	2097.64	96071.912	6.7676	3 5778	
45.9	144.20	1654.68	2106.81	96702.579	6.7749	3.5805	
46.0	144.51	1661.90	2116.00	97336.000	6.7823	3 5830	
46.1	144.83	1669.14	2125.21	97972.181	6.7897	3.5856	
46.2	145.14	1676.39	2134.44	98611.128	6.7971	3.5882	
46.3	145.46	1683.65	2143.69	99252.847	6.8044	3.5908	
46.4	145.77	1690.93	2152.96	99897.344	6.8117	3 · 5934	
46.5	146.08	1698.23	2162.25	100544.625	6.8191	3.5960	
46.6	146.40	1705.54	2171.56	101194.696	6.8264	3.5986	
46.7	146.71	1712.87	2180.89	101847.563	6.8337	3.6011	
46.8	147.03	1720.21	2190.24	102503.232	6.8410	3.6037	
46.9	147.34	1727.57	2199.61	103161.709	6.8484	3.606 <b>3</b>	
47.0	147.65	1734.94	2209.00	103823.000	6.8556	3.6088	
47.I	147.97	1742.34	2218.41	104487.111	6.8629	3.6114	
47.2	148.28	1749.74	2227.84	105154.048	6.8702	3.6139	

47.4   14 47.5   14 47.6   14 47.7   14 47.8   15 48.0   15 48.1   15 48.2   15 48.3   15 48.4   15 48.6   15 48.7   15 48.8   15 49.0   15 49.1   15 49.2   15 49.3   15 49.4   15 49.7   15 49.6   15 49.7   15 49.7   15 50.0   16 51.0   16 52.0   16 55.0   17 55.0   17 55.0   17 57.0   18	48.60 48.91 49.23 49.54 49.85 50.17 50.48 50.80 51.11 51.42 51.74	1757.16 1764 60 1772.05 1779.52 1787.01 1794.51 1802.03	2237.29 2246.76 2256.25 2265.76 2275.29 2284.84 2294.41	105823.817 106496.424 107171.875 107850.176 108531.333 109215.352	6.8775 6.8847 6.8920 6.8993 6.9065	3.6165 3.6190 3.5216 3.6241
47.4   14 47.5   14 47.6   14 47.7   14 47.8   15 47.9   15 48.0   15 48.1   15 48.2   15 48.3   15 48.6   15 48.7   15 48.8   15 49.0   15 49.1   15 49.2   15 49.3   15 49.4   15 49.7   15 49.6   15 49.7   15 49.7   15 50.0   16 51.0   16 52.0   16 55.0   17 55.0   17 55.0   17 55.0   17 57.0   18	48.91 49.23 49.54 49.85 50.17 50.48 50.80 51.11 51.42 51.74	1764 60 1772.05 1779.52 1787.01 1794.51 1802.03	2246.76 2256.25 2265.76 2275.29 2284.84	106496.424 107171.875 107850.176 108531.333 109215.352	6.8920 6.8920 6.8993 6.9065	3.6190 3.6216
47.5   14 47.6   14 47.7   14 47.8   15 47.9   15 48.0   15 48.1   15 48.2   15 48.3   15 48.4   15 48.5   15 48.6   15 48.7   15 48.8   15 48.9   15 49.0   15 49.1   15 49.2   49.3   15 49.3   15 49.4   15 49.5   15 49.7   49.8   15 49.7   49.8   15 49.9   15 50.0   15 51.0   16 52.0   16 53.0   16 55.0   17 57.0   17 57.0   18 57.0   18 57.0   16 57.0   17 57.0   18 57.0   18	49.23 49.54 49.85 50.17 50.48 50.80 51.11 51.42 51.74	1772.05 1779.52 1787.01 1794.51 1802.03	2256.25 2265.76 2275.29 2284.84	107171.875 107850.176 108531.333 109215.352	6.8920 6.8993 6.9065	3.5216
47.6   14 47.7   14 47.8   15 47.7   14 47.8   15 48.0   15 48.1   15 48.2   15 48.3   15 48.6   15 48.7   15 48.8   15 48.9   15 49.0   15 49.1   15 49.2   15 49.6   15 49.7   15 49.8   15 50.0   16 51.0   16 52.0   16 53.0   16 55.0   17 57.0	19.54 19.85 50.17 50.48 50.80 51.11 51.42 51.74	1779.52 1787.01 1794.51 1802.03	2265.76 2275.29 2284.84	107850.176 108531.333 109215.352	6.8993 6.9065	
47.7 47.8 47.9 48.0 48.1 48.2 48.3 48.4 48.5 48.6 48.7 48.8 48.9 49.0 49.1 49.2 49.3 49.4 49.5 49.4 49.5 49.6 49.7 49.8 49.9 50.0 51.0 53.0 53.0 53.0 55.0 57.0 57.0 58.0	49.85 50.17 50.48 50.80 51.11 51.42 51.74	1787.01 1794.51 1802.03	2275.29 2284.84	108531.333	6.9065	3.6241
47.8   15 47.9   15 48.0   15 48.1   15 48.2   15 48.3   15 48.5   15 48.6   15 48.7   15 48.8   15 48.9   15 49.0   15 49.1   15 49.2   15 49.3   15 49.4   15 49.5   15 49.7   49.8   15 49.7   49.8   15 49.9   15 50.0   15 51.0   16 52.0   16 53.0   16 55.0   17 57.0   17 57.0   17 57.0   17 57.0   17 57.0   17 57.0   18	50.17 50.48 50.80 51.11 51.42 51.74	1794.51 1802.03 1809.56	2284.84	109215.352		
48.0   15 48.1   15 48.2   15 48.3   15 48.6   15 48.6   15 48.7   15 48.9   15 49.0   15 49.1   15 49.1   15 49.2   15 49.3   15 49.4   15 50.0   15 51.0   16 52.0   16 55.0   17 55.0   17 57.0   18	50.48 50.80 51.11 51.42 51.74	1802.03				3.6267
48.0 48.1 48.2 48.3 48.4 15 48.5 48.6 48.7 48.8 48.9 15 49.0 15 49.1 15 49.2 15 49.3 15 49.4 15 49.6 15 49.7 49.8 49.9 15 50.0 15 51.0 15 52.0 15 53.0 16 55.0 17 57.0 17 57.0 18 18 18 18 18 18 18 18 18 18	50.80 51.11 51.42 51.74	1809.56	2294.41		6.9137	3.6292
48.1 15 48.2 15 48.3 15 48.4 15 48.6 15 48.7 15 48.8 15 48.9 15 49.0 15 49.1 15 49.2 15 49.3 15 49.4 15 50.0 15 51.0 16 52.0 16 53.0 16 553.0 16 553.0 17 550.0 17 550.0 17 550.0 17 550.0 17 57.0 17	51.11 51.42 51.74			109902.239	6.9209	3.6317
48.2 15 48.3 15 48.4 15 48.6 15 48.6 15 48.7 15 48.9 15 49.0 15 49.1 15 49.2 15 49.3 15 49.4 15 50.0 15 51.0 16 52.0 16 552.0 16 553.0 16 553.0 17 556.0 17 57.0 18	51.42 51.74		2304.00	110592.000	6.9282	3 6342
48.3 15 48.4 15 48.5 15 48.6 15 48.7 15 48.8 15 49.0 15 49.1 15 49.3 15 49.4 15 49.5 15 49.6 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 56.0 17 57.0 17 57.0 17	51.74	1817.11	2313.61	111284.641	6.9354	3.6368
48.4 15 48.5 15 48.6 15 48.7 15 48.8 15 49.0 15 49.1 15 49.2 49.4 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 55.0 17 57.0 17 58.0 18		1824.67	2323.24	111980.168	6.9426	3.6393
48.5 48.6 48.7 48.8 48.9 49.0 49.1 49.2 49.3 49.4 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 51.0 52.0 53.0 54.0 55.0 57.0 57.0 17 57.0 18		1832.25	2332.89	112678.587	6.9498	3.6418
48.6 15 48.7 15 48.8 15 48.9 15 49.0 15 49.1 15 49.3 15 49.4 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 55.0 17 57.0 17 57.0 17	52.05	1839.84	2342.56	113379.904	6.9570	3.6443
48.7 48.8 48.9 49.0 49.1 49.2 49.3 49.4 15 49.5 49.6 49.7 49.8 49.9 50.0 51.0 52.0 53.0 54.0 55.0 17 57.0 18	52.37	1847.45	2352.25	114084.125	6.9642	3.6468
48.8 15 48.9 15 49.0 15 49.1 15 49.2 15 49.3 15 49.6 15 49.6 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 56.0 17 57.0 17 58.0 18	52.68	1855.08	2361.96	114791.256	6.9714	3.6493
48.9 15 49.0 15 49.1 15 49.2 15 49.3 15 49.4 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 56.0 17 57.0 17 58.0 18	53.00	1862.72	2371.69	115501.303	6.9785	3.6518
49.0 49.1 49.2 49.3 15 49.4 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 53.0 16 55.0 17 56.0 17 56.0 17 57.0 18 18 18 18 18 18 18 18 18 18	53.31	1870.38	2381.44	116214.272	6.9857	3.6543
49.1 15 49.2 15 49.3 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 53.0 16 55.0 17 57.0 17 57.0 17 58.0 18	53.62	1878.05	2391.21	116930.169	6.9928	3.6568
49.2 49.3 49.4 15 49.5 15 49.6 15 49.7 15 49.9 15 50.0 15 52.0 16 53.0 16 53.0 16 55.0 17 56.0 17 57.0 18	53-94	1885.74	2401.00	117649.000	7.0000	3.6593
49.3 49.4 15 49.5 15 49.7 15 49.8 15 49.9 15 50.0 15 52.0 16 53.0 16 55.0 17 55.0 17 55.0 17 57.0	54.25	1893.45	2410.81	118370.771	7.0071	3.6618
49.4 15 49.5 15 49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 55.0 17 57.0 17 58.0 18	54 - 57	1901.17	2420.64	119095.488	7.0143	3.6643
49.5 49.6 15 49.7 49.8 15 50.0 51.0 52.0 53.0 54.0 55.0 17 56.0 17 57.0 17 58.0	54.88	1908.90	2430.49	119823.157	7.0214	3.6668
49.6 15 49.7 15 49.8 15 50.0 15 51.0 16 52.0 16 53.0 16 53.0 16 55.0 17 56.0 17 57.0 17 58.0 18	55.19	1916.65	2440.36	120553.784	7.0285	3.6692
49.7 49.8 49.9 50.0 51.0 16 52.0 53.0 54.0 16 55.0 17 55.0 17 57.0	55.51	1924.42	2450.25	121287 375	7.0356	3.6717
49.8 15 49.9 15 50.0 15 51.0 16 52.0 16 53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	55.82	1932.21	2460.16	122023.936	7 0427	3.6742
49.9 15 50.0 15 51.0 16 52.0 16 53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	56.14	1940.00	2470.09	122763.473	7.0498	3.6767
50.0 15 51.0 16 52.0 16 53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	56.45	1947.82	2480.04	123505.992	7.0569	3.6791
51.0 16 52.0 16 53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	56.77	1955.65	2490.01	124251.499	7.0640	3.6816
52.0 16 53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	57.08	1963.50	2500.00	125000.000	7.0711	3.6840
53.0 16 54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	50.22	2042.82	2601.00	132651.000	7.1414	3.7084
54.0 16 55.0 17 56.0 17 57.0 17 58.0 18	63.36	2123.72	2704.00	140608.000	7.2111	3.7325
55.0 17 56.0 17 57.0 17 58.0 18	66.50	2206.19	2809.00	148877.000	7.2801	3.7563
56.0 17 57.0 17 58.0 18	69.64	2290.22	2916.00	157464.000	7.3485	3.7798
57.0 17 58.0 18	72.78	2375.83	3025.00	166375.000	7.4162	3.8030
58.0 18	75 93	2463.01	3136.00	175616.000	7.4833	3.8259
	79.07 82.21	2551.76 2642.08	3249.00	185193.000	7.5498	3.8485
	85.35	2733. 7	3364.00 3481.00	195112.000 205379.000	7.6158 7.6811	3.8709
	38.49	2827.44	3600.00	216000.000	7.7460	3.9:49
	91.63	2922.47	3721.00	226981.000	7.8102	3.936
_   -	91.03 94.77	3019.07	3844.00	238328.000	7.8740	
		3117.25	3969.00	250047.000	7.9373	3.9579
		3216.99	4096.00	262144.000	8.0000	4.0000
	7.92	3318.31	4225.00	274625.000	8.0623	4.0207
66.0 20		3421.20	4356.00	287496 000	8.124)	1.0412

-	##	# <sup>8</sup> - 4	n2	<b>#</b> *	√R	<b>*</b>
67.0	210.48	3525.66	4489.00	300763.000	8.1854	4.0615
68.0	213.63	3031.69	4624.00	314432.000	8.2462	4.0817
<b>6</b> 9.0	216.77	3739.29	4761.00	328509.000	8.3066	4.1016
70.0	219.91	3848.46	4900.00	343000.000	8.3666	4.1213
71.0	223.05	3959.20	5041.00	357911.000	8.4261	4.1408
72.0	226.19	4071.51	5184.00	373248.000	8.4853	4.1602
73.0	229.33	4185.39	5329.00	389017.000	8.5440	4.1793
74.0	232.47	4300.85	5476.00	405224.000	8.6023	4.1983
75.0	235.62	4417.87	5625.00	421875.000	8.6603	4.2172
76.0	238.76	4536.47	5776.00	438976.000	8.7178	4.2358
77.0	241.90	4656.63	5929 00	456533.000	8.7750	4 - 2543
78.0	245.04	4778.37	6084.00	474552.000	8. 318	4.2727
79.0	248.18	4901.68	6241.00	493039.000	8.8882	4.2908
80.0	251.32	5026.56	6100.00	512000.000	8.9443	4.3089
81.0	251.47	5153.01	6561.00	531441.000	9.0000	4.3267
82.0	257.61	5281.03	6724.00	551368.000	9.0554	4 - 3445
83.0	260.75	5410.62	6889.00	571787.000	9.1104	4.3621
84.0	<b>26</b> 3.89	5541.78	7056.00	592704.000	9.1652	4 . 3795
85.0	267.03	5674.50	7225.00	614125.000	9.^195	4.3968
86.o	270.17	5808.81	7396.00	636056.000	9.2736	4.4140
87.0	273.32	5944.69	7569.00	658503.000	9.3274	4.4310
8S.o	276.46	6082.13	7744.00	681472.000	9.3808	4.4480
89.0	279.60	6221.13	7921.00	704969.000	9.4340	4.4647
90.0	282.74	6361.74	8100.00	729000.000	9.4868	4.4814
91.0	285.88	6503.89	8281.00	753571.000	9.5394	4 - 4979
92.0	289.02	6647.62	8464.00	778688.000	9.5917	4.5144
93.0	292.17	6792.92	8649.00	804357.000	9.6437	4.5307
94.0	295.31	6939.78	8836.00	830584.000	9.6954	4.5468
95.0	298.45	7088.23	9025.00	857375.000	9.7468	4.5629
96.0	301.59	7238.24	9216.00	884736.000	9.7980	4.5789
97.0	304.73	7389.83	9409.00	912673.000	9.8489	4 - 5947
98.0	307.87	7542.98	9604.00	941192.000	9.8995	4.6104
99.0	311.02	7697.68	9801.00	970299.000	9.9499	4.6251
00.0	314.16	7854.00	10000.00	1000000.000	10.0000	4.6416

III. LOGARITHMS OF NUMBERS.

No.	0	1	2	3	4	5	6	7	8	9
10	0000	0043	0086	0128	0170	0212	0253	0294	0334	0374
11	0414	0453	0492	0531	0569	0607	0645	0682	0719	0755
12	0792	0828	0864	0899	0934	0969	1004	1038	1072	1106
13	1139	1173	1206	1239	1271	1303	1335	1367	1399	1430
14	1461	1492	1523	1553	1584	1614	1644	1673	1703	1732
15	,1761	1790	1818	1847	1875	1903	1931	1959	1987	2014
16	2041	2068	2095	2122	2148	2175	2201	2227	2253	2279
17	2304	2330	2355	2380	2405	2430	2455	2480	2504	2529
18	2553	2577	2601	2625	2648	2672	2695	2718	2742	2765
19	2788	2810	2833	2856	2878	2900	2923	2945	2967	2989
20	3010	3032	3054	3075	3096	3118	3139	3160	3181	3201
21	3222	3243	3263	3284	3304	3324	3345	3365	3385	3404
22	3424	3444	3464	3483	3502	3522	3541	3560	3579	3598
23	3617	3636	3655	3674	3692	3711	3729	3747	3766	3784
24	3802	3820	3838	3856	3874	3892	3909	3927	3945	3962
25	3979	3997	4014	4031	4048	4065	4082	4099	4116	4133
26	4150	4166	4183	4200	4216	4232	4249	4265	4281	4298
27	4314	4330	4346	4362	4378	4393	4409	4425	4440	4456
28	4472	4487	4502	4518	4533	4548	4564	4579	4594	4609
29	4624	4639	4654	4669	4683	4698	4713	4728	4742	4757
30	4771	4786	4800	4814	4829	4843	4857	4871	4886	4900
31	4914	4928	4942	4955	4969	4983	4997	5011	5024	5038
32	5051	5065	5079	5092	5105	5119	5132	5145	5159	5172
33	5185	5198	5211	5224	5237	5250	5263	5276	5289	5302
34	5315	5328	5340	5353	5366	5378	5391	5403	5416	5428
35	5441	5453	5465	5478	5490	5502	5514	5527	5539	5551
36	5563	5575	5587	5599	5611	5623	5635	5647	5658	5670
37	5682	5694	5705	5717	5729	5740	5752	5763	5775	5786
38	5798	5809	5821	5832	5843	5855	5866	5877	5888	5899
39	5911	5922	5933	5944	5955	5966	5977	5988	5999	6010
40	6021	6031	6042	6053	6064	6075	6085	6096	6107	6117
41	6128	6138	6149	6160	6170	6180	6191	6201	6212	6222
42	6232	6243	6253	6263	6274	6284	6294	6304	6314	6325
43	6335	6345	6355	6365	6375	6385	6395	6405	6415	6425
44	6435	6444	6454	6464	6474	6484	6493	6503	6513	6522
45	6532	6542	6551	6561	6571	6580	6590	6599	6609	6618
46	6628	6637	6646	6656	6665	6675	6684	6693	6702	6712
47	6721	6730	6739	6749	6758	6767	6776	6785	6794	6803
48	6812	6821	6830	6839	6848	6857	6866	6875	6884	6893
49	6902	6911	6920	6928	6937	6946	6955	6964	6972	6981
50	6990	6998	7007	7016	7024	7033	7012	7050	7059	7067
51	7076	7084	7093	7101	7110	7118	7126	7135	7143	7152
52	7160	7168	7177	7185	7193	7202	7210	7218	7226	7235
53	7243	7251	7259	7267	7275	7284	7292	7300	7308	7316
54	7324	7332	7340	7348	7356	7364	7372	7380	7388	7396
No.	0	1	2	3	4	5	8	7	8	9

### LOGARITHMS OF NUMBERS-Continued.

No.	0	1	2	3	4	5	6	7	8	9
							<u> </u>	<b> </b>		
55 56	7404 7482	7412 7490	7419 7497	7.427 7505	7435 7513	7443 7520	7451 7528	7459 7536	7466 7543	7474 7551
57	7559	7566	7574	7582	7589	7597	7604	7612	7619	7627
58	7634	7642	7649	7657	7664	7672	7679	7686	7694	7701
59	7709	7716	7723	7731	7738	7745	7752	7760	7767	7774
60	7782	7789	7796	7803	7810	7818	7825	7832	7839	7846
61	7853	7860	7868	7 <sup>8</sup> 75	7882	7889	7896	7903	7910	7917
62 63	7924	7931 8000	7938 8007	7945 8014	7952	7959 8028	7966	7973 8041	7980	7987
64	7993 8062	8069	8075	8082	8021. 8089	8096	8035 8102	8109	8048 8116	8055 8122
65	8129	8136	8142	8149	8156	8162	8169	8176	8182	8180
66	8195	8202	8209	8215	8222	8228	8235	8241	8248	8254
67	8261	8267	8274	8280	8287	8293_	8299	8306	8312	8319
68	8325	8331	8338	8344	8351	8357	8363	8370	8376	8382
69	8388	8395	8401	8407	8414	8420	8426	8432	8439	8445
70	8451	8457	8463	8470.	8476	8482	8488	8494	8500	8506
71	8513	8519	8525	8531	8537	8543	8549	8555	8561	8567
72	8573	8579	8585	8591	8597	8603	8609	8615	8621	8627
73 74	8633 8692	8639° 8698	8645 8704	8651 8710	8657 8716	8663 8722	8669 8727	8675 8733	8681	8686
	8751		8762	8768	•				8739	8745 8802
75 76	8808	8756 8814	8820	8825	8774 8831	8779 8837	8785 8842	8791 8848	8797 8854	8859
77	8865	8871	8876	8882	8887	8893	8899	8904	8910	8915
78	8921	8927	8932	8938	8943	8949	8954	8960	8965	8971
79	8976	8982	8987	8993	8998	9004	9009	9015	9020	9025
80	9031	9036	9042	9047	9053	9058	9063	9069	9074	9079
81	9085	9090	9096	9101	9106	9112	9117	9122	9128	9133
82	9138	9143	9149	9154	9159	9165	9170	9175	9180	9186
83 84	9191 9243	9196 <b>924</b> 8	9201 9253	9206	9212	9217	9222	9227	9232	9238
- 1				9258		-	9274	9279	9284	9289
85 86	9294 9345	9299 9350	9304 9355	9309 9360	9315	9320 9370	9325 9375	9330 9380	9335	9340
87	9395	9400	9405	9410	9303	9420	93/5	9430	9385 9435	9390 9440
88	9445	9450	9455	9460	9465	9469	9474	9479	9484	9489
89	9494	9499	9504	9509	9513	9518	9523	9528	9533	9538
90	9542	9547	9552	9557	9562	9566	9571	9576	9581	9586
91	9590	9595	9600	9605	9609	9614	9619	9624	9628	9633
92	9638	9643	9647	9652	9657	9661	9666	9671	9675	9680
93 94	9685	9689	9694 9741	9699 9745	9703 9750	9708	9713.	9717 9763	9722 9768	9727
		9782	9786			9754 9800	9759 9805	9809	9814	9773 9818
95 96	9777 9823	9827	9832	9791 9836	9795 9841	9845	9850 9850	9854	9859	9863
97	9868	9872	9877	9881	9886	9890	9894	9899	9903 9903	9908
98 96	9912	9917	9921	9926	9930	9934	9939	9943	9948	9952
99	9956	996i	9965	9969	9974	9978	9983	9987	9991	9996
No.	0	1	2	3	4	5	6	7	8	9

· IV. LOGARITHMIC FUNCTIONS OF ANGLES.

Angle.	Sin.	D. 1'.	Cos.	D. 1'.	Tan.	D. 1'.	Cot.	
0° 0′	-8		10.0000		. – ∞		<b>∞</b>	90° 0'
00 10	7:4637 .7648	301.1	,0000	.0	7.4637	301:1	2.5363	89° 50'
00 20/	.7648	176.0	.0000	.0	.7648	176.1	.2352	180° 40'
0° 30'	.9408		.0000		.9409		.0591	89° 30′
00 40	8.0658	125.0 96.9	,0000	0.	8.0658	124.9	1.9342	180° 20′
0° 50'	.1627		.0000	1.	.1627	96.9 79.2	.8373	89° 10′
1º 0'	8.2419	79.2 66.9	9.9999	.0	8.2419	67.0	1.7581	89° 0'
10 10'	.3088	58.0	.9999	.0	.3089	58.0	.6911	88° 50'
1° 20′	.3668	51.1	-9999	.0	3669	51.2	.6331	88° 40′
1° 30′	-4179	45.8	9999	1.	.4181	45.7	.5819	88° 30'
10 40	.4637	41.3	:9998	۵	.4638	41.5	.5362	880 20/
1° 50'	.5050	37.8	.9998	1.	.5053	37.8	-4947	88° 10'
2º 0'	8.5428	34.8	9.9997	.0	8.5431	34.8	1.4569	88° 0′
20 10	.5776	32.1	-9997	1	·5779		.4221	87° 50'.
2º 20'	.6097	30.0	.9996	I. O.	.6101	.32.2 30.0	.3899	1 87° 40'
2° 30′	.6397	28.0	.9996	1.	·.6401	28.1	-3599	187 <sup>0</sup> 30/
20 40	.6677	26.3	-9995	.0	.6682	26.3	.3318	87º 20
2° 50'	.6940	24.8	-9995	1.	.6945	24.9	.3055	87° 10'
8° 0′	8.7188	23.5	9.9994	.1	8.7194	23.5	1.2806	87° 0′
30.10	.7423	22.2	9993	.0	7429	22.3	.2571	86° 50'
1 10 20 1	.7645	21.2	.9993	1.1	7652	21.3	2348	86° 40′
30 30'	7857	20.2	.9992	ı.	.7865	20.2	.2135	86° 30'
	.8059	19.2	-9991	1.	.8067	19.4	.1933	86° 20′
30.50	.8251	18.5	.9990	1.	.826i	18.5	.1739	86° 10'
40 0'	8.8436	17.7	9.9989	.0	8.8446	17.8	1.1554	86° 0′
40 10/	.8613	17.0	.9989	.1	.8624	17.1	.1376	85° 50′
1 AU 20	.8783	16.3	.9988	1.	.8795	16.5	.1205	85° 40'
4° 30′ 4° 40′	.8946	15.8	.9987		.8960	15.8	.1040	85° 30'
4° 40'	.9104	15.2	.9986	·.i	.9118	15.4	.0882	85° 20'
40 50	.9256	14.7	.9985	.2	.9272	14.8	.0728	850 10'
8° 0'	8.9403	14.2	9.9983	.I	8.9420	14.3	1.0580	85° 0′
50 10	-9545	13.7	.9982	ı.	.9563	13.8	0.0437	840 50
50 20	.9682	13.4	.9981	1.	.9701	13.5	.0299	84° 40′ 84° 30′
5° 30′ 5° 40′	.9816	12.9	.9980	.ı	.9836	13.0	,0164	84° 30′ 84° 20′
5° 50′	•9945	12.5	9979	.2	.9966	12.7	.0034	840 10
6° 0'	9.0070	12.2	9977	1.	9.0093	12.3	0.9907	84° 0′
60 101	9.0192	11.9	9.9976	.1	9.0216	12.0	0.9784	
6° 20′	.0311	11.5	·9975	.2	.0336	- 11.7	.9664	83° 50′ 83° 40′
60 30	.0426	11.3	.9973	ı.	.0453	11.4	9547	83° 30′
60 40'	.0539	10.9	.9972	.ī	.0567 .0678	11.1	.9433	830 20
6° 50′	.0755	10.7	.9971 .9969	.2	.0786	10.8	.9322	83° 10′
7° 0'	9.0859	10.4	9.9968	ı.ı	9.0891	10.5	0.9109	83° 0′
70 101	.0961	10.2	.9966	.2	.0995	10.4	.9005	82° 50′
1 -0/ 1	.1060	9.9	.9964	.2	.1096	10.1	.8904	82° 40'
70 30	.1157	9.7	.9963	ı.I	.1194	9.8	.8806	82° 30'
	Cos.	D. 1'.	Sin	D. 1'.	Cot.	D. 1'.	Tan.	Angle.

Angle.	Sin.	D. 1'.	Cos.	D. 1'.	Tan.	D. 1'.	Cot.	
70 30	9.1157		9.9963		9.1194		0.8806	82° 30'
7º 40'	.1252	9.5	.9961	.2	.1291	9.7	.8709	820 201
7° 40′ 7° 50′	.1345	9.3	.9959	.2	.1385	9.4	.8615	820 10/
8° 0′	9.1436	9. <b>1</b> 8.9	9.9958	.I	9.1478	9.3	0.8522	820 0
80 101	.1525	0.9	.9956	1	.1569	9.1	.8431	810 50
8° 20'	.1612	8.7	9954	,2	.1658	8.9	.8342	181°,40′ 1
8° 30'	.1697	8.5	.9952	.2	.1745	8.7 8.6	.8255	81° 30′
8° 40'	.1781	8.4 8.2	.9950	.2	.1831	8.4	.8169	81° 20'
8° 50′	.1863	8.0	.9948	.2	.1915	8.2	.8085	81° 10'
9° 0'	9.1943	7.9	9.9946	.2	9.1997	8.1	0.8003	81° 0′
9° 10'	.2022	7.8	-9944	.2	.2078	8.0	.7922	80° 50′
1 00 20/	.2100	7.6	.9942	.2	.2158	7.8	.7842	80° 40′
100 201	.2176	7.5	.9940	.2	.2236	7.7	.7764	80° 3c/
1 00 40'	.2251	7·3	.9938	.2	.2313	7.6	.7687	80°.20′
90 50'	.2324	7.3	.9936	.2	.2389	7.4	.7611	800 101
100 0	9.2397	7.1	9.9934	-3	9.2463	7.3	0.7537	80° 0′
100 101	.2468	7.0	.9931	.2	.2536	7.3	-7464	79° 50′
10° 20′ 10° 30′	.2538	6.8	.9929	.2	.2609	7.1	.7391	79° 40′
10° 40′	.2674	6.8	.9927	.3	.2680	7.0	.7320	79° 30′ 79° 20′
10° 50'	.2740	6.6	.9924	.2	.2750	6.9	.7250 .7181	79° 10′
11° 0'	9.2806	6.6	9.9919	•3	9.2887	. 6.8	0.7113	79° 0'
110 10'	.2870	6.4	.9917	.2	.2953	6.6	.7047	78° 50'
110 20'	.2934	6.4	.9917	-3	.3020	6.7	.6980	78° 40'
1110 30'	.2997	6.3	.9912	.2	.3085	6.5	.6915	280 201
110 40'	.3058	6.1	.9909	-3	.3149	6.4	.6851	7S' 20'
11° 50'	.3119	6.1	9907	.2	.3212	6.3	.6788	75° 10'
12° 0′	9.3179	6.0 5.9	9.9904	-3	9.3275	6.3 6.1	0.6725	78° 0'
120 10	.3238		.9901	-3	.3336		.6661	77° 50′
120 20'	.3296	5.8	.9899	.2	-3397	6.1 6.1	.6603	770 10/1
120 30'	.3353	5.7	.9896	.3	.3458	5.9	.6542	77 201
120 401	.3410	5.7 5.6	.9893	.3 .3	.3517	5.9 5.9	.6483	ויחי יידר
12° 50′	.3466	5.5 5.5	.9890	.3	3576	5.8	.6424	77° 10'
13° 0′	9.3521	5.4	9.9887	.3	9.3634	5.7	0.6366	77° 0′
130 101	-3575	5.4	-9884		.3691	27	.6300	767 501
130 20	.3629	5.3	.9881	.3	.3748	5.7 5.6	.6252	760 40'
11 20 30'	.3682	5.2	.9873	3	.3804	5.5	.6196	769 30
130 401	-3734	5.2	.9875	<u>ئ</u> ئۇين	.3859	5.5	.6141	76° 20'
130 50'	.3786	5.1	.9872	.3	-3914	5.4	.6086	76° 10′
14° 0′	9.3837	5.0	9.9869	.3	9.3968	5.3	0.6032	76° 0′
140, 10	.3887	5.0	.9866	.3	.4021	5.3	•5979	75° 50′
14° 20′	-3937	4.9	.9863	.4	-4074	5.3	.5926	75° 40′
14° 30′ 14° 40′	.3986	4.9	.9859	.3	.4127	5.1	·5873	75° 30′
14° 40′ 14° 50′	.4035 .4083	4.8	.9856	.3	.4178	5.2	.5S22	75° 20′ 75° 10′
15° 0'	9.4130	4.7	9.9849	-4	9.4281	5.1	.5770	75° 10′ 75° 0′
(		D. 1'.	9.9549 Sin.	D 1		- T	0.5719	
L	Cos.	10.10	Sin.	D. 1%	Cot.	D. 1%	Tan.	Angle.

Angle.	Sin.	D. 1'.	Cos.	D. 1'.	Tan.	D. 14	Cot.	
15° 0′	9.4130	4.7	9.9849	-3	9.4281	5.0	0.5719	75° 0′
15° 10′	-4177	4.6	.9840		.4331	5.0	.5669	74° 50'
112 Y 20 1	.4223	4.6	.9843	·3	4381	4:9	,5619	74° 40′
11 C 20' 1	.4269	4.5	.9839	.3	.4430	4.9	.5570	74° 30′
115" 40' 1	.4314	4-5	.9836	.3	·4479	4.8	.5521	74° 26'
1150 500	<b>-4359</b> .	4.4	.9832	-4	4527	4.8	·5473	74° 10′
16° 0′	9.4403	4.4	9.9828	-3	9.4575	4.7	0.5425	74° 0′
16° 10'	-4447	4.4	.9825	.4	.4622	4.7	-5378	73° 50'
160 20/	.4491	4.2	.9821	4	.4669	4.7	.5331	73° 40′
160 30'	·4533	4.3	.9817	-3	4716	4.6	.5284	73° 30′
160 40	.4576	4.2	.9814	4	.4762	4.6	.5238	73° 20′
16° 50′	.4618	4.1	.9810	4.	.4808	4.5	.5192	73° 10'
17° 0′	9.4659	4.I	9.9806	4	9.4853	4.5	0.5147	78° 0′
170 101	.4700	4.1	.9802	-4	.4898	4.5	-5102	72° 501
170 20'	4741	4.0	.9798	-4	·4943	4.4	:5057	720 401
170 30'	.4781	4.0	·9794	4	.4987	4.4	.5013	72° 30′
170 40'	. 4821 .4861	4.0	.9790	4	.5031	4.4	.4969	72° 20' 72° 10'
17° 50′ 18° 0′		3.9	.9786	-4	.5075 9.5118	4.3	-4925 0.4882	72° 0′
180 10'	9.4900	3.9	9.9782	-4		4.3		71° 50′
180 20	-4939	3.8	.9778	.4	.5161	4.2	.4839	710 40
180 30'	4977 .5015	3.8	.9774	.4 .	.5203 .5245	4.2	4797	710 30
1S° 40'	.5052	3.7	.9770	-5	.5287	4.2	-4755 -4713	71° 20'
180 50	.5090	3.8	.9761	-4	.5329	4.2	.4671	71° 10'
19° 0′	9.5126	3.6	9.9757	.4	9.5370	4.1	0.4630	71° 0′
190 10	.5163	3.7	·9752	-5	.5411	4.1	.4589	70° 50'
1100 201	.5199	3.6	.9748	-4	.5451	4.0	4549	700 40
1100 201	·5235	3.6	.9743	-5	.5491	4.0	4509	700 301
110, 40,	5270	3.5 3.6	-9739	-4	.5531	4.0	.4469	700 20
19" 50"	.5306	3.5	•9734	.5 .4	.5571	4.0 4.0	-4429	70° 10'
20° 0′	9.5341	3.4	9.9730	.5	9.5611	3.9	0.4389	70° 0′
20 <sup>0</sup> 10'	. •5375	3.4	-9725	.4	5650	3.9	-4350	69° 50′
20° 20' l	:5409	3.4	.9721	.5	.5689	3.8	-4311°	600 401
200 301	-5443	3.4	.9716	.5	.5727	3.9	-4273	69° 30′
200 401	-5477	3.3	.9711	.5	.5766	3.8	·4234	69° 20'
20° 50′	.5510	3.3	.9706	.4	5804	3.8	.4196	69° 10'
21° 0′	9.5543	3.3	9.9702	.5	9.5842	3.7	0.4158	69° 0′
210 10'	.5576	3.3	.9697	.5	.5879	3.8	.4121	68° 50'
210 201	.5609	3.2	.9692	.5	.5917	3.7	.4083	68° 40'
21° 30'	.5641	3.2	.9687	.5	-5954	3.7	.4046	68° 30′
21° 40' 21° 50'	.5673 .5704	3.1	.96S2 .9677	-5	.5991 .6028	3.7	.4009 .3972	68° 10'
220 0'	9.5736	3.2	9.9672	-5	9.6064	3.6	0.3936	68° 0'
22'0 10'	.5767	3.1	.9667	-5	.6100	3.6	.3900	67° 50'
220 201	.5798	3.1	.9661	.6	.6136	3.6	.3864	67° 40'
220 301	.5828	3.0	.9656	-5	.6172	3.6	.3828	67° 30'
	Cos.	D. 1'.	. Sin.	D. 1'.	Cot.	D. 1'.	Tan.	Angle.

Angle,	Sin.	D.1'.	Cos.	D. 1′.	Tan.	D. 1'.	Cot.	
22° .30′	9.5828	3.1	9.9656	.5	9.6172	3.6	0.3828	67° 30'
22° 40′	.5859	3.0	.9651	.5	.6208	3.5	-3792	67° 20'
22° 50′	.5889	3.0	.9646	.5 .6	.6243	3.6	<u>-3757</u>	67° 10′
23° 0′	9.5919	2.9	9.9640	.5	9.6279	3.5	0.3721	67° 0′
23° 10′	.5948	-	.9635	.6	.6314		.3686	66° 50′
122 201	.5978	3.0	.9629		.6348	3.4	.3652	66° 40'
12 30 30'	.6007	2.9 2.9	.9624	.5 .6	.6383	3·5 3·4	.3617	66° 30′
123° 40' 1	.6036	2.9	.9618		.6417	3.5	.3583	66° 20′
23° 50'	. <b>6</b> 065	2.8	.9613	.5 .6	.6452	3.4	-3548	66° 10′
24° 0′	9.6093	2.8	9.9607	-5	9.6486	3.4	0.3514	66° 0′
24° 10′	.6121	2.8	.9602	.6	.6520	3.3	.3480	65° 50′
240 201	.6149	2.8	.9596	.6	.6553	3.4	-3447	1650 AO' 1
240 201	.6177	2.8	.9590	.6	.6587	3.3	.3413	65° 30′
24° 40′	.6205	2.7	.9584		.6620	3.4	.3380	65° 20'
24° 50′	.6232	2.7	<u>.9579</u>	.5 .6	.6654	3.3	.3346	65° 10'
25° 0′	9.6259	2.7	9.9573	.6	9.6687	3.3	0.3313	65° 0′
25° 10′	.6286	2.7	.9567	.6	.6720	.3.2	.3280	64° 50′
1250 20/ 1	.6313	2.7	.9561	6.	.6752	3.3	.3248	64° 40′
125 70' 1	.6340	2.6	-9555	.6	.6785	3.2	.3215	64° 30′
250 40'	.6366	2.6	-9549	.6	.6817	3.3	.3183	64° 20' 64° 10'
25° 50′	.6392	2.6	·9 <u>543</u>	.6.	.6850	3.2	.3150	
26° 0′	9.6418	2.6	9.9537	.7	9.6882	3.2	0.3118	64° 0′
26° 10′	.6444	2.6	.9530	.6	.6914	3.2	.3086	63° 50'
26° 20′	.6470	2.5	.9524	.6	.6946	3.1	.3054	63° 40′
26° 30′	.6495	2.6	.9518	.6	.6977	3.2	.3023	63° 30′ 63° 26′
26° 40′ 26° 50′	.6521	2.5	.9512	.7 .6	.7009	3.1	.2991 .2960	630 10'
	.6546	. 2.4	.9505	ا 6.	.7040	3.2		63° 0′
27° 0′	9.6570	. 2.5	9.9499	.7	9.7072	3.1	0.2928	
27° 10'	.6595	2.5	.9492	.6	.7103	3.1	.2897	62° 50'
27° 20'	.6620	2.4	.9486		.7134	3.1	.2866	62° 40′ 62° 30′
27° 30′ 27° 40′	.6644 .6668	2.4	-9479	.7 .6	.7165	3.1	.2835 2804	62° 30'
27° 40′ 27° 50′	.6692	2.4	9473	.7	.7196 .7226	3.0	.2774	62° 16′
2/ 50 28° 0'		2.4	.9466	.7		3.1	0.2743	62° 0′
	9.6716	2.4	9.9459	.6	9.7257	3.0		
28° 10'	.6740	2.3	-9453	.7	.7287	3.0	.2713	61° 50' 61° 40'
28° 20' 28° 30'	.6763	2.4	.9440	.7	7317	3.1	.2652	61° 30'
28° 30′ 28° 40′	.6787 .6810	2.3	.9439 .9432	.7	.7348 .7378	3.0	.2622	61° 20'
28° 50'	.6833	2.3	.9425	-7	.7408	3.0	.2592	610 10'
29° 0′	9.6856	2.3	9.9418	.7	9.7438	3.0	0.2562	61 °0'
29° 10′		2.2		-7		2.9		60° 50′
29° 10'	.6878. .6901	2.3	.9411	.7	.74 <sup>6</sup> 7 -7497	3.0	.2533 .2503	60° 40′
29° 30′	.6923	2.2	.94 <b>0</b> 4 .9397	.7	.7526	2.9	.2474	60° 30'
29° 40'	.6923	2.3	.9397	.7	.7556	3.0	:2444	60° 20'
29° 50'	.6968	2.2	.9383	·7 .8	.7585	2.9	.2415	60° 10'
30° 0′	9.6990	2.2	9.9375	٥.	9.7614	2.9	0.2386	<b>60</b> ° 0′
<b></b>	Cos.	D. 1'.	,Sin.	D. 1'.	Cot.	D. 1 .	Tan.	Angle.

Angle.	Sin.	D. 1/.	Cos.	D. 1'.	Tan.	D. 1'.	Cot.	
80° 0'	9.6990							60° 0′
		2.2	9.9375	.7	9.7614	3.0	0.2386	
30° 10′ 30° 20′	.7012	2.1	.9368	.7	.7644	2.9	.2356	59° 50′
30° 20′ 30° 30′	.7033	2.2	.9361	.7 .8	.7673	2.8	.2327	59° 40′
30° 40′	.7055 7076	2.1	•9353	.g	.7701	2.9	.2299	59° 30′
30° 50′		2. I	.9346 .9338		-7730	2.9	.2270	59° 20' 59° 10!
31° 0′	.7097	2.1		.7	·7759	2.9	.2241	
	9.7118	2.1	9.9331	.8	9.7788	2.8	0.2212	59° 0′
31° 10′ 31° 20′	7139	2.1	.9323	.8	.7816	2.9	.2184	58° 50'
31° 30′	.7160	2.1	.9315	-7	.7845	2.8	.2155	58° 40' 58° 30'
31° 30′ 31° 40′	.7181	2.0	.9308	·7	.7873	2.9	.2127	58° 30' 58° 20'
31° 50′	.7201 .7222	2. I	.9300	.8	.7902	2.8	.2098	580 10
		2.0	.9292	ا 8,	.7930	2.8	.2070	20.10
	9.7242	2.0	9.9284	.8	9.7958	2.8	0.2042	58° 0′
32° 10′	.7262	2.0	.9276	.8	.7986	2.8	.2014	57° 50'
32° 20′ 32° 30′	.7282	2.0	.9268 .9260	.8	.8014	2.8	.1986	57° 40'
32° 40′	.7302	2.0		.8	.8042 .8070	2.8	1958	57° 30′ 57° 20′
32° 50′	.7322	2.0	.9252 .9244	.8	.8070	2.7 2.8	.1930	57° 10'
33° 0′	·7342	1.9		.8		2.8	0.1875	57° 0'
	9.7361	1.9	9.9236	.8	9.8125	2.8		
33° 10′	.7380	2.0	.9228	.9	.8153	2.7	.1847	56° 50'
33° 20′ 33° 30′	.7400	1.9	.9219	.9 .8	.8180 .8208	2.7 2.8	.1820	56° 40′ 56° 30′
33° 30′ 33° 40′	.7419	1:9	.9211	.8	.8235	2.7 2,8	.1792	56° 30′ 56° 20′
33° 50′	.7438	1.9	.9 <b>2</b> 03	.9 .8	.8263		.1765	560 101
34° 0′	·7457	1.9	9.9186		9.8290	2.7	0.1737	56° 0'
34° 10'	9.7476	1.8		.9		2.7	.1683	
34° 20′	•7494	1.9	.9177 .9169	.8	.8317 .8344	2.7	.1656	55° 50′ 55° 40′
34° 30′	.7513 .7531	1.8	.9160	.9	.8371	2.7	.1620	55° 30′
34° 40′	.7550	1.9	.9151	.9	.8398	2.7	.1602	55° 20'
34° 50'	.7568	1.8	.9142	.9 .8	.8425	2.7	.1575	55° 10′
35° 0′	9.7586	1,8.	9.9134		9.8452	2.7	0.1548	55° 0′
35° 10′	.7604	1.8	.9125	.9	.8479	2.7	.1521	240 50
35° 20′	.7622	1.8	.9116	.9	.8506	2.7	.1494	EAO AO
35° 30'	.7640	1.8	.9107	.9	.8533	2.7	.1467	ICA 201
175 40	.7657	I.7 I.8	.9098	.9	.8559	2.6	.1441	1 54 20'
35° 50′	.7675		.9089	.9	.8586	2.7	.1414	540 101
36° 0′	9.7692	1.7	9.9080	.9	9.8613	2.7	0.1387	54° 0'
360 10'	.7710	1.8	.9070	1.0	.8639	2.6	.1361	E 20 EO!
136° 20'	.7727	1.7	.9061	.9	.8666	2.7	.1334	1 5 2 0 AO
260 20/	·7744	1.7	.9052	.9	.8692	2.6	.1308	1 E 2 \( \text{20} \)
36° 40'	.7761	1.7	.9042	1.0	.8718	2.6	.1282	1 5 2 20
36° 50'	.7778	1.7	.9033	1.0	.8745	2.7 · 2.6	.1255	530,10
37° 0'	9.7795	1.7	9.9023	1	9.8771	2.6	0.1229	28° 0
37° 10'	.7811	l .	.9014	.9	.8797	1	.1203	52° 50'
137° ·20'	.7828	1.7	.9004	1.0	.8824	2.7	.1176	52° 40'
37° 30'	.7844	1.6	.8995	.9	.8850	2.0	.1150	52° 30′
	Cos.	D. 1'.	Sin.	D. 1'.	Cot.	D. 1'.	Tan.	Angle.

Angle.	Sin.	D.1'.	Cos.	Ď. 1′.	Tân.	D. 1%	Cot.	
37° 30′	9.7844		9.8995		9.8850		0.1150	52° 30'
127 40	.7861	1.7	.8985	1.0	.8876	2.6	.1124	52° 20'
37° 50'	.7877	1.6	8975	1.0	.8902	2.6	.1098	52° 10'
38° 0′	9.7893	1.6	9.8965	1.0	9.8928	2.6 2.6	0.1072	52° 0′
38° 10′	.7910	1.7	.8955	1.0	.8954		.1046	510 50
128° 20' 1	.7926	1.6	.8945	-1.0	.8980	2.6	.1020	510 40
1280 20/	.7941	1.5 1.6	.8935	1.0	.9006	2.6	.0994	51° 30'
180 40'	·7957		.8925	1.0	.9032	2.6	.0968	510 201
38° 50'	.7973	1.6	.8915	1.0	.9058	2.6	.0942	510 10
39° 0′	9.7989		9.8905	1.0	9.9084	2.6 2.6	0.0916	51° 0′
39° 10′	.8004	1.5	.8895		.9110	1	.0890	50° 50′
100 20	.8020	1.6	.8884	1.1	.9135	2.5	.0865	500 401
20' 20'	.8035	1.5	.8874	1.0	.9161	2.6	.0839	1 KO 20/
1300 40'	.8050	1.5	.8864	1.0	.9187	2.6	.0813	500 20
39° 50'	.8066	1.6	.8853	1.1	.9212	2.5	.0788	500 101
40° 0′	9.8081	1.5	9.8843	1.0	9.9238	2.6	0.0762	50° 0'.
400 101	.8096	1.5	.8832	1.1	.9264	2.6	.0736	490 50
100 20/	.8111	1.5	.8821	1.1	.9289	2.5 2.6	.0711	49° 40′
1400 301	.8125	1.4	.8810	1.1	.9315		.0685	49° 30′
40° 40'	.8140	1.5	.8800	1.0	.9341	2.6	.0659	49° 20'
40° 50'	.8155	1.5	.8789	1.1	.9366	2.5 2.6	.0634	490 10
410 0'	9.8169	1.4	9.8778	1.1	9.9392	•	0.0608	49° 0'
410 10/	.8184	1.5	.8767	1.1	.9417	2.5	.0583	480 50
41° 20'	.8198	1.4	.8756	1.1	9443	2.6	.0557	48° 40′
1410 30'	.8213	1.5	.8745	1.1	.9468	2.5 2.6	.0532	480 30'
1410 401	.8227	1.4	.S733	1.2	.9494		.0506	480 201
41° 50'	.8241	1.4	.8722	1.1	9519	2.5	.0481	480 101
42° 0′	9.8255	.I.4 I.4	9.8711	I.I I.2	9.9544	2.5 2.6	0.0456	48° 0'
420 10	.8269	I.4	.8699	4	.9570		.0430	420 col
1120 20	.8283		.8688	1.1	.9595	2.5 2.6	.0405	47° 40′
12° 30′	.8297	I.4 I.4	.8676	1.1	.9621	2.0	.0379	17 <sup>0</sup> 20!
42° 40′	.8311	1.3	.8665	1.1	.9646	2.5	.0354	470 20
42° 50′	.8324	1.4	.8653	1.2	.9671	2.5 2.6	.0329	47° 10'
43° 0′	9.8338	1.3	9.8641	1.2	9.9697	i	0.0303	47° 0'
43° 10′	.8351	, -	.8629	1	.9722	2.5	.0278	46° 50′
112 70	.8365	1.4	.8618	1.1	.9747	2.5	.0253	460 40
117 70	.8378.	1.3	.8606	1.2	.9772	2.5 2.6	.0228	46° 30'
113° 40'	.8391	I.4	.8594	r.2	.9798		.0202	46° 20'
143° 50'	.8405	1.3	.8582	1.3	.9823-	2.5 2.5	.0177	460 10
440 0'	9.8418	,1.3	9.8569	1.2	9.9848	2,6	0.0152	46° 0′
44° 10′	.8431	1.3	.8557	1.2	.9874		.0126	45° 50'
144 20'	.8444	1.3	.8545	1.2	.9899	2.5	1010.	450 AO
113 20	.8457	:1.2	.8532	1.3	.9924	2.5	.0076	145° 30'
440 401	.8469	1.3	.8520	1.3	-9949	2.5 2.6	.0051	45 20
44° 50′ 45° 0′	.8482	1.3	.8507.	1.2	·9975	2.5	.0025	145° 10'
450 0'	9.8495		9.8495		0.0000		0.0000	45° 0′
	Cos.	D. 1'.	Sin.	D. 1'.	Cot.	D. 1'.	Tan.	Angle.

V.
NATURAL FUNCTIONS OF ANGLES.

A.	Sin.	Cos.		A.	Sin	Cos.		A.	Sin.	Cos.	
0°	.000000	1.0000	<b>90°</b>	30'	.1305	.9914	30'	15°	.2588	.9659	75°
10'	.002909.	1.0000	501	40	.1334	.9911	20′	10'	.2616	.9652	.501
20/	.005818	1.0000	40	501	.1363	.9907	10/	20/	.2644	.9644	40'
30'	.008727	1.0000	30'	8º.	.1392	.9903	<b>82</b> °	301	.2672	.9636	30'
40'	.011635	.9999	20/	10'	.1421	.9899	50'	40'	.2700	.9628	201
50	.014544	.9999	10'	20'	.1449	.9894	40'	50'	.2728	.9621	10'
10	.017452	.9998	89°	30'	.1478	.9890	30'	16°	.2756	.9613	74°
10'	.02036	.9998	50'	40	.1507	.9886	20′.	.10	.2784	9605	50'
20'	.02327	-9997	40'	501	.1536	.9881	10,	201	.2812	.9596	40'
30'	.02618	-9997	30'	80.	.1564	.9877	81°	30'	.2840	.9588	30'
40	.02908	.9996	20'	10	.1593	.9872	501	401	.2868	.9580	20'
50'	.03199	.9995	10'	20'	.1622	.9868	40'	50'	.2896	.9572	10'
20	.03490	-9994	880	_30'	.1650	.9863	30'	17°	.2924	.9563	73°
10	.03781	.9993	50'	40'	.1679	9858	20'	10'	.2952	-9555	50'
20'	.04071	.9993	40'	50'	.1708	.9853	10'	20'	.2979	.9546	40'
30'	.04362	.9990	30'	10°	.1736	.9848	80°	30'	.3007	.9537	30'
40'	.04653	.9989	20'	10'	.1765	.9843	50'	40'	.3035	.9528	201
50'	.04943	.9988	10'	20'	.1794	.9838	40'	50'	.3062	.9520	10'
3°.	.05234	.9986	870	30'	.1822	.9833	301	.180	.3090	.9511	720
10'	.05524	.9985	50'	40'	.1851	.9827	20'	10	.3118	.9502	50'
20'	.05814	.9983	40'	50'	.1880	.9822	10'	20'	.3145	.9492	40%
30'	.06105	.9981	30'	110	.1908	.9816	79°	301	.3173	.9483	30'
40'	.06395	.9980	20'	10'	.1937	.9811	50'	40'	.3201	.9474	201
50'	.06685	.9978	10'	201	.1965	.9805	40'		.3228	.9465	10'
40	.06976	.9976	86°	30'	.1994	. 9799	30/	19°	.3256	-9455	71°
10'	.07266	-9974	5c/	40'	.2022	.9793	20′	10'	.3283	.9446	50'
20'	.07556	.9971	40'	50'	.2051	.9787	10'	201	.3311	.9436	40'
1.30/	.07846	.9969	30'	12°	.2079	.9781	78°	301	.3338	.9426	30'
40'	.08136	:9967	20'	10'	.2108	·9775	50'	40'	.3365	.9417	20'
50'	.08426	.9964	101	201	.2136	.9769	40'	50'	.3393	.9407	10'
50	.08716	.9962	85°	30'	.2164	.9763	30'	<b>20</b> °	. 3420	-9397	70°
10	.09005	-9959	50'	40'	.2193	-9757	201	10'	.3448	.9387	50'
20'	.09295	.9957	40'	50'	.2221	.9750	10'	201	-3475	.9377	40
30'	.09585	-9954	30'	13°	.2250	-9744	77°	30'	.3502	.9367	30'
40'	.09874	.9951	20'	10'	.2278	.9737	50'	401	.3529	.9356	20'
50'	.10164	.9948	10'	20'	.2306	.9730	40'	50'	.3557	.9346	10'
60	.10453	-9945	84°	30'	.2334	.9724	30'	21°	3584	.9336	69°
10'	.10742	.9942	50'	40'	.2363	.9717	20/	10'	.3611	.9325	50'
20'	.11031	.9939	40'	50'	.2391	.9710	10'	20'	.3638	.9315	40'
30'	.11320	.9936	30'	14°	.2419	`.9703	76°	30'	.3665	.9304	30'
40'	.11609	.9932	20	10'	.2447	9696	50'	40'	.3692	.9293	20′
50'	.11898	.9929	10'	20'	.2476	.9689	10'	50'	.3719	.9283	10,
70	.12187	.9925	83°	30'	.2504	.9681	30	22°	.3746	.9272	68°
10'	.12476	.9922	50'	40'	.2532	.9674	20'	10	.3773	.9261	50'
20'	.12764	.9918	40'	50'	.2560	.9667	10	20'	.3800	.9250	40'
30'	.13053	.9914	30'	15°	.2588	.9659	75°	3º'	.3827	.9239	30'
	Cos.	Sín.	Λ.		Cos.	Sin.	A.		Cos.	Sin.	A.

NATURAL FUNCTIONS OF ANGLES-Continued.

A.	Sin.	Cos.		A.	Sin.	Cos.		A.	Sin.	Cos.	
301	.3827	.9239	30′	<b>80</b> °	.5000	.8660	<b>60</b> °	30′	.6088	·7934	301
401	.3854	.9228	20/	10/	.5025	.8646	50'	40'	.6111	.7916	20/
50'	.388i	.9216	10'	20	.5050	.8631	40'	50'	6134	.7898	10
<b>28</b> °	.3907	.9205	67°	301	.5075	.8616	30'	<b>38</b> °	.6157	.7880	<b>52</b> °
10'	·3934	.9194	50'	40	.5100	.8601	20/	10'	.6180	.7862	50'
20/	.3961	.9182	40	50'	.5125	.8587	10	20/	.6202	.7844	40'
30'	.3987	.9171	30'	31°	.5150	.8572	<b>59°</b>	30/	.6225	.7826	30,
40'	.4014	.9159	20/	10	.5175	.8557	50'	401	.6248	.7808	20 <sup>1</sup>
50'	.4041	.9147	10'	20'	.5200	.8542	40'	50'	.6271	<u>7790</u>	
24°	.4067	.9135	<b>66</b> °	30'	.5225	.8526	30'	<b>39</b> °	.6293	·7771	51°
10'	-4094	.9124	50'	40	.5250	.8511	20'	10'	.6316	·7753	50'
20′	.4120	.9112	40	50'	.5275	.8496		20′	6338	·7735	40
30'	4147	.9100	30'	<b>32</b> °	.5299	.8480	<b>58</b> °	30'	.6361	.7716	30' 20'
40	.4173	.9088	20 <sup>1</sup>	10	.5324	.8465	50'	40' 50'	.6383	.7698 .7679	10
50'	.4200	.9075		20	.5348	.8450	40'		.6406	.7660	500
25°	.4226	.9063	<b>65</b> °	30'	-5373	.8434	301	40°	.6428		
10'	.4253	.9051	50'	40' 50'	-5398	.8418	20'	10'	.6450	.7642	50
20/	4279	.9038	40		.5422	.8403		20'	.6472	.7623	40
30' 40'	.4305	.9026	30' 20'	<b>33</b> °	.5446	.8387	57°	30 <sup>1</sup>	.6494	.7604 .7585	30 <sup>1</sup>
50'	.4331 .4358	.9013 1009.	10'	10'	·5471	.8371	501	50'	.6517 .6539	7566	10'
260		.8988	64°	20/	.5495	.8355	40'	410	.6561		490
1 - 1	.4384			30' 40'	.5519	.8339 .8323	30'			·7547	
10'	.4410	.8975	50'	50	·5544 ·5568	.8307	10'	10'	.6583	.7528	50
30'	.4436 .4462	.8962 .8949	40 <sup>1</sup>	340		.8290	<b>56</b> °	30	.6604 .6626	.7509	40 <sup>1</sup>
40'	.4488	.8936	201	4	.5592			401	.6648	.7490 .7470	20'
50'	.4514	.8923	10'	10/	.5616 .5640	.8274 .8258	50'	50'	.6670	.7451	10'
270	.4540	.8910	63°	30'	.5664	.8241	40 <sup>1</sup>	420	.6691	.7431	480
10'	.4566	.8897	50'	40'	.5688	.8225	20/	10'	.6713		50
20	.4592	.8884	40'	50'	.5712	.8208	10'	20'	6734	.7412	40
30'	.4617	.8870	30'	350	.5736	.8192	550	30'	.6756	·7373	30'
40'	.4643	.8857	20'	10'	.5760	.8175	50'	40'	.6777	7353	20
50'	.4669	.8843	10'	20'	.5783	.8158	40'	50'	.6799	.7333	10'
28°	.4695	,8829	620	30'	.5807	.8141	30'	430	.6820	.7314	470
10'	.4720	.8816	50'	40'	.5831	.8124	20'	10'	.6841	.7294	50'
20'	.4746	.8802	40'	50'	.5854	.8107	10'	20'	.6862	.7274	40
30'	.4772	.8788	30'	36°	.5878	.8090	<b>54</b> °	30'	.6884	.7254	30,
40'	4797	.8774	20'	10'	.5901	.8073	501	40'	.6905	.7234	20'
50'	.4823	.8760	10'	20'	.5925	.8056	40'	50'	.6926	.7214	10/
29°	.4848	.8746	61°	30'	.5948	.8039	30'	440	.6947	.7193	460
10'	.4874	.8732	50'	40'	.5972	.8021	20/	10'	.6967	.7173	50'
20′	.4899	.8718	40'	50'	.5995	.8004	10'	20/	.6988	.7153	40'
30′	.4924	.8704	30'	37°	8100.	79S6	<b>53</b> °	30	.7009	.7133	30'
40	.4950	.8689	20	10'	.6041	.7969	50'	40'	.7030	.7112	20/
50'	-4975	.8675_	10	201	.6065	.7951	40'	50'	.7050	.7092	10,
<b>30</b> °	.5000	.8660	<b>30</b> °	30	.6038	.7934	30'	45°	.7071	.7071	45°
	Cos.	Sin.	A.		Cos.	Sin.	A.		Cos.	Sin.	A.

NATURAL FUNCTIONS OF ANGLES-Continued.

A.	Tan.	Cot.		A.	Tan.	Cot.		A.	Tan.	Cot.	
<b>0</b> °	.000000	× ×	<b>90</b> °	30'	.1317	7.5958	30′	15°	.2679	3.7321	75°
10	.002909	343-7737	50'	40	.1346	7.4287	20/	10'	.2711	3.6891	50'
20′-	.005818	171.8854	40	501	.1376	7.2687	10'	20	.2742	3.6470	40/
30'	.008727	114.5887	30'	80	.1405	7.1154	<b>82</b> °	30'	.2773	3.6059	30′
40'	.011636	85.9398	20/	10	.1435	6.9682	50'	40'	.2805	3.5656	20'
50'	.014545	68.7501	10'	20	.1465	6.8269	40'	50'	.2836	3.5261	10
10	.017455	57.2900	89°	30	.1495	6.6912	30'	16°	.2867	3.4874	74°
10'	.02036	49.1039	50'	40/	.1524	6.5606	20′	10'	.2899	3.4495	501
20'	.02328	42.9641	40'	501	.1554	6.4348	10	20	.2931	3.4124	40'
30/	.02619	38.1885	30'	80	.1584	6.3138	<b>81</b> °	30	.2962	3.3759	30'
40	.02910	34.3678	20'	10	.1614	6.1970	50'	40'	.2994	3.3402	20/
50'	.03201	31.2416	10'	20'	.1644	6.0844	40'	50'	.3026	3.3052	10'
2°	.03492	28.6363	88°	30'	.1673	5.9758	30'	170	.3057	3.2709	<b>73</b> º
10'	.03783	26.4316	50'	40'		5.8708	20′	10'	.3089	3.2371	50/
20'	.0.1075	24.5418	40'	50'	.1733	5.7694	10'	20	.3121	3.2041	40
30'	.04366	22.903S	30'	10°	.1763	5.6713	<b>80</b> °	30'	.3153	3.1716	30'
40'	.04658	21.4704	20′	10'	.1793	5.5764	50'	40	.3185	3.1397	20/
50'	.04949	20.2056	10/	201	.1823	5.4845	40'	50'	.3217	3.1084	10
3°	.05241	19.0811	87°	30'	.1853	5.3955	30/	18°	.3249	3.0777	<b>72</b> °
10,	.05533	18.0750	50'	40	.1883	5.3093	20′	10'	.3281	3.0475	50
20'	.05824	17.1693	40'	50'	.1914	5.2257	10'	20'	.3314	3.0178	40'
301	.011100.	16.3499	30'	110	.1944	5.1446	79°	301	.3346	2.9887	301
40'	.06408	15.6048	20/	10'	.1974	5.0658	50'	40'	.3378	2.9600	20/
50'	.06700	14.9244	10'	20′	.2004	4.9894	40'	50'	.3411	2.9319	10
40	.06993	14.3007	<b>86</b> °	30	.2035	4.9152	30'	19°	.3443	2.9042	71 <sup>c</sup>
10'	.07285	13.7267	50'	40'	.2065	4.8430	20'	10	.3476	2.8770	50'
20'	.07578	13.1969	40'	501	.2095	4.7729	10/	20/	.3508	2.8502	40'
30′	.07870	12.7062	30'	12°	.2126	4.7046	<b>78</b> °	30 <b>′</b>	.3541	2.8239	30'
40'	.08163	12.2505	20'	10'	.2156	4.6382	50'	40'	.3574	2.7980	20′
50'	.08456	11.8262	10,	20'	.2186	4.5736	40'	50'	.3607	2.7725	10'
5°	.08749	11.4301	85°	30'	.2217	4.5107	30'	20°	.3640	2.7475	70°
10	.09042	11.0594	50'	40'	.2247	4-4494	20'	10'	.3673	2.7228	50'
20′	.09335	10.7119	40'	50	.2278	4.3897	10'	20′	.3700	2.6985	40
30'	.09629	10.3854	30'	13°	.2309	4.3315	77°	30'	.3739	2.6746	30'
40'	.09923	10.0780	20'	10'	.2339	4.2747	50'	40'	.3772	2.6511	20'
50'	.10216	9.7882	10,	20'	.2370	4.2193	40'	50	.3805	2.6279	10,
	.10510	9.5144	81°	30' 40'	.2401 .2432	4.1653	30' 20'	21°	.3839	2.6051	<b>69</b> °
10'	.10805	9.2553	50'	50'	.2462	4.0611	10'	10'	.3872	2.5826	50'
20'	.11099	9.0098	40'	140			76°	20/	.3906	2.5605	40' 30'
30' 40'	.11394	8.7769	30' 20'		.2493	4.0108		30/	.3239	2.5386	20'
50'	.11983	8.5555	10'	10'	.2524	3.9617	50'	40' 50'	3973	2.5172	10'
70	.12278	8.3450	83°	30	.2555	3.9136 3.8667	40' 30'	22°	.4006	2.4960	68°
10'	.12574	7.9530	50'	40'	.2530	3.8208	201	10'	.4040	2.4545	50'
20'	.12869	7.7704	40'	501	.2648	3.7760	10'	20'	.4108	2.4342	40'
30'	.13165	7.5958	30'	150	.2679	3.7321	75°	30'	.4142	2.4142	30'
<u> </u>	Cot.	Tan.	Λ.	<u> </u>	Cot.		A.		Cot.	Tan.	A.

### NATURAL FUNCTIONS OF ANGLES-Continued.

A.	Tan.	Cot.		A.	Tan.	Cot.		A.	Tan.	Cot.	
30'	.4142	2.4142	30'	<b>30</b> °	-5774	1.7321	<b>60°</b>	30'	.7673	1.3032	30'
40'	.4176	2.3945	201	10'	.5812	1.7205	50	40	.7720		20
501	.4210	2.3750	10'	201	.5851	1.7090	40	501	.7766	1.2876	10
230	.4245	2.3559	67°	30'	.5890	1.6977	301	<b>38</b> °	.7813	1.2799	<b>52</b> °
10'	.4279	2.3369	50'	40'	.5930	1.6864	20'	10'	.7860	1.2723	501
20'	.4314	2.3183	40'	50'	.5969	1.6753	10	20/	.7907	1.2647	40'
30'	.4348	2.2998	30'	31°	.6009	1.6643	<b>59</b> °	30′	7954	1.2572	30'
40'	.4383	2.2817	20′	10	.6048	1.6534	50'	40'	.8002	1.2497	201
50'	-4417	2.2637	10'	20′	.6088	1.6426	40	50	.8050	1.2423	10
240	-4452	2.2460	<b>66</b> °	30'	.6128	1.6319	30'	<b>39</b> °	.8098	1.2349	51°
10'	.4487	2.2286	50'	40' 50'	.6168 .6208	1.6212	20 <sup>f</sup>	10	.8146	1.2276	50
20′	.4522	2.2113	40				58°	20/	.8195	1.2203	40
30/	·4557	2.1943	30'	32°	.6249	1.6003		30' 40'	.8243	1.2131	30' 20'
40	.4592   .4628	2.1775	10'	10'	.6289	1.5900	50'	50'	.8292 .8342	1.1988	10
50' 250			65°	20'	.6330	1.5798	40' 30'	40°			<b>50</b> °
1	.4663	2.1445		30' 40'	.6371 .6412	1.5697	20'	i e	.8391	1.1918	
10'	.4699	2.1283	501	50'	.6453	1.5497	10'	10'	.8441	1.1847	50
20'	4734	2.1123	40' 30'	330	.6494	1.5399	570	30'	.8491 .8541	1.1778	40 <sup>1</sup>
30' 40'	.4770 .4806	2.0809	20'	10'				40	.8591	1.1640	20'
50'	.4841	2.0655	10'	207	.6536	1.5301	50' 40'	501	.8642	1.1571	10'
26°	.4877	2.0503	64°	30'	.6577 .6619	1.5108	30	41°	.8693	1.1504	490
10'	.4913		501	40'	.6661	1.5013	20'	10'	.8744	1.1436	50'
20'	.4950	2.0353	40'	501	.6703	1.4919	10'	20'	.8796	1.1369	40'
30'	.4986	2.0057	30/	34°	.6745	1.4826	<b>56</b> °	30'	.8847	1.1303	30'
40'	.5022	1.9912	20/	10	.6787	1.4733	50'	40'	.8899	1.1237	20'
50'	.5059	1.9768	10	20'	.6830	1.4641	401	50'	.8952	1.1171	10
270	.5095	1.9626	<b>63</b> °	30'	.6873	1.4550	30'	<b>42</b> °	.9004	1.1106	<b>48</b> °
10'	.5132	1.9486	50	40'	.6916	1.4460		10'	.9057	1.1041	50
201	.5169	1.9347	40'	50	.6959	1.4370	10'	20/	.9110	1.0977	40
30'	.5206	1.9210	301	<b>35</b> °	.7002	1.4281	55°	30'	.9163	1.0913	30′
40'	.5243	1.9074	20'	10'	.7046	1.4193	50'	40′	.9217	1.0850	20
50′	.5280	1.8940	10'	20/	.7089	1.4106	40'	501	.9271	1.0786	10'
28°	-5317	1.8807	<b>62</b> °	301	.7133	1.4019	30'	43°	.9325	1.0724	47°
10	-5354	1.8676	50'	40	.7177	1.3934	20 <sup>1</sup>	10'	.9380	1.0661	50'
20′	.5392	1.8546	40'	50'	.7221	1.3848		20′	.9435	1.0599	40
30'	.5430	1.8418	30'	<b>36</b> °	1	1.3764	<b>54</b> °	30/	.9490	1.0538	30'
40'	.5467	1.8291	10'	10	.7310	1.3680	50'	40' 50'	.9545	1.0477	20'
50'	-5505	1.8165		20	.7355		401	440	.9601	1.0416	46°
29°	·5543	1.8040	61°	30' 40'	.7400 ·7445	1.3514	30 <sup>1</sup>		.9657	1.0355	
10'	.5581	1.7917	50'	50'	.7490	1.3351	10'	10' 20'	.9713	1.0295	50'
20' 30'	.5619 .5658	1.7796	40' 30'	370		1.3270	530	30'	.9770	1.0235	40' 30'
40'	.5696	1.7675	20'		.7536			40'	.9827 .9884	1.0176	201
50'	.5735	1.7437	10'	20'	.7581	1.3190	50' 40'	50'	.9942	1.0058	10,
30°	·5774	1.7321	<b>60</b> °	30'	.7673	1.3111	30'	45°	1.0000	1.0000	45°
	Cot.	Tan.	A.		Cot.	Tan.	A.		Cot	Tan.	A.
	<del>.</del>	1	<u></u>	·	<u> </u>						

VI.
TABLE OF COEFFICIENTS, STRENGTH OF MATERIALS.

	Ulti Tons	mate Stren per Square	gth. Inch.	Moduli. Tons per Sq. Inch.	
	Tension.	Com- pression.	Shearing.	Elasticity.	Rig.
	T	С	S	E	Es
Cast-iron	51-101	25-65	9-13	)	
Average	7	42	11	5000	1300
American ordnance	14	36-58	İ	} to	to
Repeatedly melted	15-20	60-75		6000	2500
Wrought-iron-		''	ŀ		
Finest Low-(with grain	27-29		ר (	ו ו	
moor plates: { across "	24	ł	!	<b>   </b>	
(with "	22		1	11	
Bridge-iron: { across "	10		11 .	12,000	
Bars, finest	27-29		18-22	} to	5000
Bars, ordinary	25	20		13,000	
Bars, soft Swedish	19-24		1		
Wire	25-50			1	
Steel-	_5 50		,	,	
Mild-steel plates	26-32		ا ا	) ·	
Axle and rail steel	30-45		•	1	
Crucible tool- "	40-65	ĺ	🛎	12,000	5000
Chrome "	80		ll 🗦	} to ∣	to
Tungsten "	72		l i	13,000	5200
Steel wire	70		of Tension		
Piano-wire	150			7 70 000	
Copper—	150		را	13,000	
Cast.	10-14		i	7000	
Rolled	15-16			7000	
Wire, hard drawn	28	35	10~14	8000	.0
Brass	_	_		8000	2800
	8–13 22	5		5500	1500
Wire Gun-metal				6400	2200
	11-23			4500-6000	1700
Phosphor bronze	15-26			6000	2400
Zinc, cast	2-3				
Zinc, rolled	7-10			5500	
	2	_			
Lead Timber—	0.9	3		1000	
			_	0	
Oak	3-7	4,	I	800	
White pine	14-34	2 1/2		600	
Pitch-pine	4		,	950	
Ash	4-7	2-4	1	750	
Beech	4-6	4,			
Mahogany	4-7	31		650	
Stone—					
Granite		23-5			
Sandstone		I 1-2-1			
Limestone		14-3			
Brick		1-6	I		

From Vol. XXII., Encyc. Britannica.

VII.

### TEST OF CAST ALUMINIUM BRONZES.

[Made by J. E. KRESS in 1891 at Sibley College Laboratories.]

		Comp	osition.	Stree per Sq.	ngth Inch.	oches.	Area.		Ioduli.
No.	Material.	Al. Per Cent.	Cu. Per Cent.	Elastic Limit. Pounds.	Ultimatum, Pounds.	Elongation in 8 Inches. Per Cent.	Reduction of Per Cent	Resilience. Foot-pounds.	Elasticity, Pounds per Sq. Inch.
	Al. brass	-}	7	45,186	62,722	7.5	5.0	20.8	11,859,900
2	Al. bronze	10	90	20,281		5.7	7.83	12.5	5,696,800
3	i	5	95	8,473	33.730	39. I	46.3	.66	
4		8 <b>o</b>	20	12,018	18,400	<b>2</b> 6	9.4	1.13	17,180,000
5		90	10	6,856	17,066	54	7.7	1.56	9,203,600
Ğ		92	8		14,154	50	1.36	1.36	8,593,000
7 8	1	94	6	3,094	11,913	58	2.02	1.12	9,253,000
8		96	4 2	2,977	16,567	25	3.48	1.13	
9		96 98		3,048	13,323	25	3 - 54	1.17	5,990.900
10	Aluminum	99	0	2,234	9.776	2.5	3.54	1.14	5,990,900
11	"	99.3	0	1,612		6.4	4.17	1.06	3.3-3.3
12	Al. bronze	10.5	89.5		72,064	7.1	8.9	10.6	6,900,700
13		5	95	6,795	29, 132	21.5	34.1	1.45	10,214,000
14	[	2	98		24,986	14.6	31.9	1.07	
15		I	99		16,123	10.5	22.2	1.08	, , , , , ,
10	_	7	93		40,794	18.1	28.6	1.9	9.537,900
17	Pure copper.	0	100	2,297	16,508	17.0	18.5	1.10	5,945,000

Nos. 10 and 11 were commercially pure Al, with composition about as follows: Al, 97 to 99; silicon, graphitic, 0.1 to 1.0; silicon combined, 0.9 to 2.8; iron, 0.04 to 0.2 per cent.

### VIII.

### WOODEN PILLARS.

Experiment of Prof. Lanza on pillars 2 to 14 feet long, 6½ to 10½ inches in diameter, in some cases slightly tapered at the top. In all cases they failed by crushing.

ULTIMATE RESISTANCE TO COMPRESSION.
Pounds per Square Inch.

Kind of Timber.	Maximum.	Minimum.	Mean.
White Oak		3006	3470
Yellow pine		3604	4544

The following series of tests were made at the Watertown Arsenal on rectangular posts with a length of from 5 to 28 feet and a sectional area ranging from 27 to 140 square inches. In the table l is the length of post, s the least side of cross-section in inches, and f the ultimate compression in pounds per square inch.

	White Pine.	•		Yellow Pine	•
l+s	ſ	Ratio of Decrease.	l+s	ſ	Ratio of Decrease.
o to 10 10 to 35 35 to 45 45 to 60	2500 2000 1500 1000	1.00 0.80 0.60 0.40	0 to 15 15 to 30 30 to 40 40 to 45 45 to 50 50 to 60	4000 3500 3000 2500 2000 1500	1.00 0.88 0.75 0.63 0.50 0.38

### LARGE WOODEN BEAMS.

The following is a general summary of the tests by Prof. Lanza on wooden beams of an average section of 12 × 4 inches, and were tested on span lengths of about 18 feet.

Kind of Timber.	Maximum Fibre Strain $p = Me + I$ . Pounds per Sq. Inch.					
	Maximum.	Minimum.	Mean.	Safe.		
Spruce	5,878 6,415 7,659 11,360	2995 3438 4984 5092	488.4 4808 6075 7292	3000 3000 4000 5000		

### IX.

### STRENGTH OF METALS AT DIFFERENT TEMPERATURES.

[EXPERIMENTS OF A. LE CHATELIER, PARIS, 1891.]

### CAST-BRASS.

### Strength remains about constant until 500° C.

Breaking-load per Square Inch. Lbs.	Elongation. Per Cent.	
19,457	0.24	
17,864	0.71	
17,508	0.35	
17,693	0.89	
11,677	0.54	
5,660	0.71	
	19.457 17.864 17,508 17,693	

### TIN-BRONZE.

Temperature Centigrade. Deg.	Breaking-load per Square Inch. Lbs.	Elongation. Per Cent.	Duration of Test.
			M. S.
15	22,614	5.7	8 30
140	23,582	7.08	5 30
230	20.524	3.9	6 30
250	18,717	4.28	21 0
300	17,124	2.0	17 0
350	15,574	1.4	16 O
415	9,031		2 30

### ALUMINIUM-BRASS.

Temperature Centigrade. Deg.	Breaking-load per Square Inch. Lbs.	Elongation in 5.502 Inches. Per Cent.
15	49,183	30.7
140	46, 168	37.0
230	42,100 .	33.2
320	30,380	15.6

X. IMPORTANT PROPERTIES OF FAMILIAR SUBSTANCES.

	Specific Gravity. Water, 1.	Specific Heat. Water, 1.	Absorbing and Radiat- ing Power of Bodies in Units of Heat per Square Foot for Dif- ference of 1°.	Conducting Power in Units of Heat per Square Foot of Sur- face with Difference of 1°.	l in	Decrees.
Metals from 32° to 212°—					Per cu. in.	
Aluminium	2.61 to 2.65			l	0.0956	
Antimony	6.712	.0508			0.2428	
Bismuth	9.823	.0308			0.3533	
Brass	8.1	.0939	.049		0.2930	
Copper	8. <sub>7</sub> 88	.092	.0327	515.0	0.3179	
Iron, cast	7.5	.1208	.648	233.0	0.2707	
Gold	7.744 19.258	.1138	. 566	233.0	0.6965	
Lead	11.352	.0324	.1320	113.0	0.4106	
Mercury at 32°	13.598	.0333		1	0.4918	
Nickel	8.800	.1086			0.3183	
Platinum	16,000	.0324			0.5787	
Silver	10.474	.056	.0265		0.3788	
<u>St</u> eel	7.834	. 1165			0.2016	
Tin	7.291	.0562	.0439	•••••	0.2637	446
Zinc	7.191	.0953	.049	225.0	0.26	680
Stones-	ł	i			Per cu. ft.	1
Chalk		.2140	.6786		174.0	1
Limestone	2.784 3.156	.2174	.735		197.0	ŀ
Masonry	2.240	.2./4	·735	·	140.0	
Marble, gray	1.686	.2604	.735	28.0	168.0	l
Marble, white,	2.650	.2158	.735	22.4	165.0	1
Woods-		-	1	•	•	
Oak	.86		.73	1.7	54.0	
Pine, white	-55	·57 ·65	.73	748	34.6	1
Mineral substances—		]	1			
Charcoal, pine	.44	.2415			27.5	
Coal, anthracite	1.43	.2411			88.7	1
Coke	1.00	,203	1		62.5	i
Glass, white	2.80	.1977	.5948	6.6	180.7	i
Sulphur	2.03	.2026			127.0	ı
Liquids—	ì	Ì	ŀ	ļ	1	ļ
Alcohol, mean	.0	.6588			57.5	1
Oil, petroleum	,88	.31	1.480		55.0	1
Steam at 212°	.0006	-847			.050	1
Turpentine	.87	.416			54.37	1
Water at 62°	1.000	1.000	1.0853		62.35	
Solid-		1	1			
Ice at 32°	.922	.504			57.5	1
Gases—	İ		1	I		1
Air at 32°		.238			.0807	1
Oxygen		.2412	*****	•••••	.0892	.
Hydrogen	.000089	3.2936			.00559	1
Carbonic acid	80100.	.2210			1	1

See also pages 310 and 355.

XI. (Page 170.)
COEFFICIENTS OF FRICTION. (MORIN.)

No.	Surfaces.	Angle of Repose,	Coefficient of Friction.	
		ф	∫= tan φ	1+f
		Deg		
I	Wood on wood, dry		0.25 to .5	4 to 2
2	SUARCU	II to 2	.2 to .04	5 to 25
3	Metals on oak, dry	261 to 31	.5 to .6	2 to 1.67
4	WCL	131 to 141	.24 to .26	4.17 to 3.85
5 6	soapy	114	.2	1 5
	" " elm, dry	111 to 14	.2 to .25	5 to 4
7 8	Hemp on oak, "	28	- 53	1.89
8	" " " wet	18∦	-33	3
9	Leather on oak	15 to 19 <del>1</del>	.27 to .38	3.7 to 2.86
10	Leather on metals, dry	291	.56	1.79
11	" " wet	20	. 36	2.78
12	" " " greasy	13	.23	4.35
13	" " " oily	84	.15	6.67
14	Metals on metals, dry	81 to 111	.15 to .2	6.67 to 5
15	" " wet	161	.3	3.33
	Smooth surfaces, occasionally	-	1	1 55
	greased	4 to 41	.07 to .08	14.3 to 12.5
17	Smooth surfaces, continually	4 43	10, 11	14.5
-,	greased	3	.05	20
18	Smooth surfaces, best results	14 to 2		33.3 to 27.0
10	Bronze on lignum vitæ, wet	37	.05?	20?

Note.—The above table is defective since the pressure per square inch is not given. The coefficient of friction diminishes with increase of pressure, so that in some cases the total friction remains constant.

XII. MOISTURE ABSORBED BY AIR.

THE QUANTITY OF WATER WHICH AIR IS CAPABLE OF ABSORBING TO THE POINT OF MAXIMUM SATURATION, IN GRAINS PER CUBIC FOOT FOR VARIOUS TEMPERATURES.

Degrees Fahr.	Grains in a Cubic Foot.	Degrees Fahr.	Grains in a Cubic Foot.
10	1.1	85 .	12.43
15	1.31	90	14.38
20	1.56	95	16.60
<b>2</b> 5	1.85	100	19.12
30	2.19	105	22.0
32	2.35	110	25.5
35	2.59	115	30.0
40	3.06	130	42.5
45	3.61	141	58.0
50	4.24	157	85.0
55	4.97	170	112.5
60	5.82	179	138.0
65	6.81	188	166.0
70	7.94	195	101.0
75	9.24	212	265.0
8o	10.73		

XIII. RELATIVE HUMIDITY OF THE AIR.

Difference of Temperature of the Air and Dew-point.	Temperature of Air. 32° Fahr.	Temperature of Air. 70° Fahr.	Temperature of Air. 95° Fahr.
0	100	100	100
I	96	97	97
2		93	94
3	9 <b>2</b> 88	90	91
3 4 5 6	85	90 87	88
5	8 t	84	86
	78	81	83
7 8	74	78	8o
8	71 68	76	78
9	68	73	75
10	65	71 66	73 68
12	60		68
14	54	61	64
16	50	57	60
18	45	53	56
20	41	49	53
22	38	46	49
24	34	42	46
1	34		40

XIV.

(Page 176.)

### TABLE OF BEAUME'S HYDROMETER SCALE WITH CORRESPONDING SPECIFIC GRAVITIES.

FOR LIQUIDS LIGHTER THAN WATER. TEMP. 60° FAHR.

Beaumé.	Specific Gravity.	Beaumé	Specific Gravity.	Beaumé.	Specific Gravity.	Beaumé.	Specific Gravity.
10	1.0000	31	0.8695	52	0.7692	73	0.6896
1:	0.9929	32	0.8641	53	0.7650	1 74	0.6863
12	0.9859	33	0.8588	54	0.7608	75	0.6829
13	0.9790	34	0.8536	55	0.7567	76	0.6796
14	0.9722	35	0.8484	56	0.7526	. 77	0.6763
15	0.9655	36	0.8433	57	0.7486	78	0.6730
16	0.9589	37	0.8383	58	0.7446	79	0.6698
17	0.9523	38	0.8333	59	0.7407	8o	0,6666
1 Š	0.9459	39	0.8284	60	0.7368	. 8r i	0.6635
19	0.9395	40	0.8235	61		82	0.6604
20	0.9333	41	0.8187	62	0.7200	83	0.6573
21	0.9271	42	0.8139	63.	0.7253	84	0.6542
22	0.9210	43	0.8092	64	0.7216	85	0.6511
23	0.9150	44	0.8045	65	0.7179	86	0.6481
24	0.9090	1 45 1	0.8000	66	0.7142	87	0.6451
25	0.9032	46	0.7954	67	0 7106	88	0.6422
. 26	0.8974	47	0.7909	68	0.7070	89	0.6392
27	0.8917	48 (	0.7865	69	0.7035	gó	0.6363
28	o.886o	49	0.7821	' 70	0.7000	1 .	
29	0.8805	50	0.7777	71	0 6965		
30	0.8750	51	0.7734	72	0.6930	l i	

### FOR LIQUIDS HEAVIER THAN WATER. TEMP. 60° FAHR.

Beaumé.	Specific Gravity.	Beaumé.	Specific Gravity.	Beaumé.	Specific Gravity.	Beaumé.	Specific Gravity.
ī	1.0069	19	1.1507	37	1.3425	55	1.6111
2	1.0139	20	1.1600	' 38	1.3551	1 56	1.6292
3	1.0211	21	1.1693	39	1.3679	57 i	1.6477
4	1.0283	22	1.1788	40	1.3809	58	1.1666
5	1.0357	23	1.1885	41	1.3942	. 59	1.6860
6	1.0431	2.4	1.1983	42	1.4077	60	1.7056
7	1.0507	25	1.2083	43	1.4215	61 '	1.7201
8 !	1.0583	20	1.2184	44	1.4356	62	1.7469
9	10001	27	1.2288	45	1 4500	63	1.7682
10	1.0740	28	1.2393	46	1.4646	64	1.7901
1:	1.0820	29	1.2500	47	1.4795	65	1.8125
12	1.0902	30	1.2608	18	1.4949	66	1.8354
13	1.0984	31	1.2719	49	1.5104	67 .	1.8559
14	1.1668	32	1.2Š 7 Í	50	1.5263	6S .	1.8831
15	1.1153	33	1.2946	51	1.5425	6g	1.9079
10	1.1240	34	1.3063	52	1.5591	70	1.9333
17	1.1328	35	1 3181	53	1.5760	•	,5.0
18	1.1417	36	1.3302	54	1.5934		

XV.

(Page 312.)

PROPERTIES OF SATURATED STEAM.
[From Charles T. Porter's treatise on The Richards Steam-engine Indicator.]

Press- ure above sero.	Temperature.	Sensible Heat above zero Fahr.	Latent Heat.	Total Heat above zero Fahr.	Weight of One Cubic Foot.
bs. per	Fahr. Deg.	B.T.U.	B.T.U.	B.T.U.	Lbs.
1	102.00	102.08	1042.96	1145.05	.0080
8	126,26	126.44	1026.01	1152.45	.0058
8	141.63	141.87	1015.25	1157.18	.0085
4	153.07	153.39	1007.23	1160.63	.0112
5	162.83	162.72	1000.72	1163.44	.0137
6 7 8	170.12	170.57	995.24	1165.83	:0163
7	176.91	177.43	990 47	1167.89	.0189
9	182.91 188.81	183.48 188.94	986.24 982.43	1169.72 1171.37	.0214
10	198.24	193.91	978.95	1172.87	.0264
11	197.76	198.49	975.76	1174.25	.0289
13	201.96	202.73	972.80	1175.53	.0313
18	205.88	206.70	970.02	1176.73	.0387
14 15	209.56 218.02	210.42 213.93	967.42 964.97	1177.85 1178.91	0362
16	216 29	217.25	962.65	1179.90	.0118
17	219.41	220.40	960.45	1180.85	.0437
18	222.87	228.41	958.84	1181.76	.0462
19	225.20	226.28	956.54	1182.62	.0487
20	227.91	229.03	954.41	1183.45	0511
21	280.51·	281.67	952.57	1184.24	.0586
22 23	233.01 235.48	234.21 236.67	950.79 949.07	1185.00 1185.74	.0561 .0585
24	237.75	239.02	947.42	1186.45	.0810
25	240.00	241.81	945.82	1187.18	.0684
26	242.17	243.52	944.27	1187.80	.0658
27	244.28	245.67	942.77	1188.44	.0683/
28	246.82	247.74	941.82	1189.06	.0707
29	248.31	249.76	939.90	1189.67	.0781
80	250.24	251.78	938.92	1190.26	.0755
81 82	252.12 253.95	253.64 255.51	937.18 935.88	1190.83 1191.89	.0779
83	255.73	257.32	934.60	1191.93	.0827
84	257.47	259.10	933.36	1192.46	.0851
85	259.17	260.83	932.15	1192.98	.0875
86	260.83	262.52	930.96	1193.49	.0899
87	262.45	264.18	929.80	1193.98	:0922
88	264.04	265.80	928.67	1194.47	.0946
89	265.59	267.38	927.56	1194.94	.0970
40	267.12	268.93	926.47	1195.41	.0994
41	268.61	270.46	925.40	1195.86 1196.31	1017 1041
42 43	270.07 271.50	271.95 273.41	924.35 923.88	1196.31	1064
44	271.50 272.91	274.85	922.33	1197.17	1088
45	274.29	276.26	921.83	1197.60	.1111
46	275.65	277.65	920.86	1198.01	.1134

PROPERTIES OF SATURATED STEAM-Continued.

Press- ure above zero.	Temperature.	Sensible Heat above zero Fahr.	Latent Host.	Total Heat above zero Fahr.	Weight of One Cubic Foot.
Lbs.per sq. in.	Fahr. Deg.	B.T.U.	B.T.U.	B.T.U.	Lbs.
457	050 00	070 01	010.40	1100 10	1150
47 48	276.98 278.29	279.01 280. <b>3</b> 5	919.40 918.46	1198.42 1198.83	.1158
49	279.58	281.67	917.54	1199.21	.1204
50	280.85	282.96	916. <b>6</b> 8	1199.60	.1227
51	282.09	284.24	915.78	1199.98	.1251
52	283.82°	285.49	914.85	1200.35	.1274
58	284.53	286.78	913.98	1200.73	.1297
54 55	285.72 286 89	287.95 289.15	918.18 912.29	1201.08 1201.44	.1848
56	288.05	290.88	911.46	1201.79	.1366
57	289.11	291.50	910.64	1202.14	.1388
58	290.81	292.65	909.88	1202.48	.1411
<b>5</b> 9	291.43	293.79	909.08	1202.82	.1484
60	292.52	294.91	908.24	1208.15	.1457
61	298.59	296.01	907.47	1203.48	.1479
62	294.68	297.10	906.70	1208.81	.1502
63	295.71	298.18	905.94	1204.13	.1524
64	296.75	299.24 800.80	905 20 904.46	1204.44 1204.76	.1547
65 66	297.77 298.78	801.88	908.78	1205.07	.1592
67	299.78	802.36	903.01	1205.87	.1614
68	800.77	803.87	902.29	1205.67	.1637
69	801.75	304.38	901.59	1205.97	.1659
70	802.71	805.87	900.89	1206,26	.1681
$\eta$	808.67	306.85	900.21	1206.56	.1708
72	804.61	807.82	899.53	1206.84	.1725
78	805.55	808.27 809.23	898.85	1207.18 1207.41	.1748
74 75	806.47 807.38	810.16	898.18 897.52	1207.69	.1792
76	808.29	811.09	896.87	1207.96	.1814
77	809.18	812.01	890.28	1208.24	.1886
78	810.06	812.92	895.59	1208.51	.1857
79	810.94	313.82	894.95	1208.77	.1879
80	811.81	814.71	894.88	1209.04	.1901
81	812.67	815.59	898.70	1209.80	.1928
82	813.52	816.46	893.09	1209.56	.1945-
83	814.86	817.33	892.48	1209.83 1210.07	.1988
84 85	315.19 316.03	818.19 819.04	891.88 891.28	1210.82	2010
86	816.83	319.88	890.69	1210.57	.2033
87	817.65	820.71	890.10	1210.82	.2053
88	818.45	821.54	889.53	1211.06	.2075 .2097
89 90	319.24 320.03	822.36 823.17	888.94 888.87	1211.81 1211.55	.2007
<b>27</b> U					0100
91	820.82	823.98	887.80	1211.79 1212.02	.2180 .2160
92	321.59	324.78 325.57	887.24 886.68	1212.02	.2183
98 94	822.86 823.13	326.85	886.13	1212.49	.2204
95	823.88	327.13	885.58	1212.72	.2224
•	1	1	1	i	1

PROPERTIES OF SATURATED STEAM-Continued.

Pressure above zero.	Temperature.	Sensible Heat above zera Fahr.	Latent Heat.	Total Heat above zero Fahr.	Weight of One Cubic Foot.
Lbs.pcr sq. in.	Fahr. Deg.	B.T.U.	B.T.U.	B.T.U.	Lbs
96	824.63	827.90	885.04	1212.95	.2245
97	825.87	828.67	884.50	1213.18	.2266
98	826.11	829.43	883.97	1218.40	.2288
99	826.84	330.18	883.44	1218.62	. 2309
100	827.57	880.98	882.91	1218.84	.2380
101	828.29	331.67	882.89	1214.06	.2851
102	829.00	882.41	881.87	1214.28	.2371
108	829.71	838.14	881.85	1214.50	.2392
104	880.41	883.86	880.84	1214.71	.2418
105	881.11	834.58	880.84	1214.92	.2484
106	831.80	885.80	879.84	1215.14	.2454
107	882.49	886.00	879.84	1215.85	.2475
108	883.17	886.71	878.84	1215.55	.2496
109	888.85	837.41	878.85 877.86	1215.76	.2516 .2587
110	884.52	838.10	811.80	1215.97	1
111	835.19	888.79	877.87	1916.17	.2558
112	885.85	889.47	876.89	1216.87	.2578
118	836.51	840.15	876.41	1216.57	.2599
114	887.16	840.83	875.94	1216.77	.2619
115	837.81	841.50	875.47	1216.97	.2640
116	838.45	842.16	875.00	1217.17	.2661
117	889.10	842.83	874.58	1217.86	,2681
118	889.78	843.48	874.07	1217.56	.2702
119 120	840.86 840.99	844.14 844.78	873.61 873.15	1217.75 1217.94	.2722
404	841.61	845.48	872.70	1218.18	.2762
191 122	842.23	846.07	872.25	1218.82	2782
123	342.85	846.70	871.80	1218.51	.2802
124	848.46	847.84	871.85	1218.69	.2822
125	844.07	847.97	870.91	1218.88	.2842
126	844.67	348.50	870.47	1219.06	.2862
127	345.27	849.21	870.08	1219.25	.2882
128	845.87	849.83	869.59	1219.48	.2902
129	846.45	850.44	869.16	1219.61	.2922
180	847.05	851.05	868.73	1219.79	.2942
181	847.64	851.66	868.80	1219.97	.2961
132	848.22	852.26	867.88	1220.15	.2981
188	848.80	852.86	867.46	1220.83	.3001
184	849.88	858.46	867.03	1220.50	.8020
185	849.95	854.05	866.62	1220.67	.8040
186	850.53	854.64	866.20	1220.85	.8060
137	851.08	855.28	866.79	1221.02	.8079
138	851.75	855.81	865.88	1221.19	.8099
189 140	852.21 852.76	356.89 856.96	864.97 864.56	1221.36 1221.53	.8118 .8188
		857.54	864.16		1
141 142	858.81 858.86	857.54 858.11	863.76	1221.70 1221.87	.8158 .8178
148	854.41	358.67	863.86	1222.08	.3178
144	854.96	859.24	863.96	1222.00	.3219
444	002.00			1,00,00	.0015

### PROPERTIES OF SATURATED STEAM-Continued.

Prese- ure above sero.	Temperature.	Sensible Heat above zero Fahr.	Latent Heat.	Total Heat above zero Fahr.	Weight of One Cubic Foot.
Lbs, per	Fahr, Deg.	B.T.U.	B.T.U.	B.T.Ü.	Lbs.
145	855.50	859.80	862.56	1222.36	.8289
146 147	356.08	860.85	862.17	1222.53	.8259
147	856.57	860.91	861.78	1222.69	.3279
148	857.10	861.46	861.39	1222.85	.8299
149	<b>357.63</b>	862.01	861.00	1228.01	.8319
150	858.1 <b>6</b>	862.55	860.62	1228.18	.8340
151	<b>858.68</b>	868.10	860.28	1228.38	.3858
152	859.20	868 64	859.85	1228.49	.8376
158	<b>359.72</b>	864.17	859.47	1223.65	.8894
154	860.28	864.71	859.10	1223.81	.8418
155	860.74	865.24	858.73	1228.97	.8430
156	861.26	865.77	858.35	1224.18	.3448
157	861.76	866.80	857.98	1224.28	.3466
158	862.27	866.83	857.61	1224.48	.3484
159 160	862.77 868.27	867.34 867.86	857.24 856.87	1224.58 1224.74	.3502 .3520
	000 00		070 70		1
161 162	868.77	868.88	856.50	1224.89	.8589 .3558
163	864.27 864.76	868.89	856.14	1225.04 1225.19	.3577
164	865.25	369.41	855.78	1225.19	.8596
165	865.74	869.92 870 42	855.42 855.06	1225.49	.3614
166	866.28	870.98	854.70	1225.64	.3633
167	866.71	871.48	854.35	1225.78	.3652
168	867.19	871.93	853.99	1225.98	.8671
169	367.68	872.43	853.64	1226.08	.8690
170	868.15	872.93	858.29	1226.22	.3709
171	868.63	878.42	852.94	1226.37	.8727
172	869.10	373.91	852.59	1226.51	.8745
173	369.57	874.40	852.25	1226.66	.3763
174	870.04	874.89	851.90	1226.80	.3781
175	<b>370.51</b>	875.88	851.56	1226.94	.3799
176	<b>370.97</b>	875.86	851.22	1227.08	.8817
177	871.44	876.84	850.88	1227.23	.3835
178	871.90	876.82	850.54	1227.87	.3853
179 180	872.86 872.82	877.30 877.78	850.20 849.86	1227.51 1227.65	.3871
					1
181	878.27	878.25	849.58	1227.78	.3907
182	878.78	878.72	849.20	1227.92	. 3925
188	874.18	879.19	848.86	1228.06	.8944
184	874 . 68	379.66	848.53	1228.20	.3962
185	875.08	880.13	848.20	1228.88	.3980
186	875.52	880.59	847.88	1228.47	.3999
187	875.97	881.05	847.55	1228.61	.4017
188 189	376.41	881.51	847.22	1228.74	.4083
190	876 85 877.29	881.97 882.42	846.90 846.58	1228.87 1229.01	.4053 .4072
191			1		1 "
192	877.72	882.88	846.26	1229.14	.4089
193	378.16 878.59	383.83	845,94	1229.27 1229.41	.4107
-00	010.00	883.78	845.68	1239.41	.4125

### PROPERTIES OF SATURATED STEAM-Continued.

Press- ure above zero.	Temperature.	Sensible Heat above zero Fahr.	Latent Heat.	Total Heat above zero Fahr.	Weight of One Cubic Foot.
Lbs.per	Fahr, Deg.	B.T.U.	B.T.U.	B.T.U.	-Lbs.
194	879.02	894.23	845.80	1229.54	74143
195	379.45	384.67	844.99	1229.67	.4160
196	379.97	385.12	844.68	1229.80	.4178
197	380.30	385.56	844.86	1229 93	.4196
198	380.72	386.00	844.05	1230.06	.4214
199	381.15	386.44	843.74	1230.19	. 4231
200	381.57	886.88	843.43	1280.31	.4249
201	381.99	387.82	843.12	1230.44	7.4266
202	382.41	387.76	843.81	1230.57	.4288
203	382.82	888.19	842.50	1280.70	.4300
204	383.24	388.62	842.20	<b>128</b> 0 82	.4318
205	383. <b>65</b>	889.05	841.89	1230.95	.4335
206	384.06	869.48	841.59	1231.07	4352
207	384.47	389.91	841.29	1231.20	4.4369
208	384.88	390.33	840 99	12833	4886
209	385.28	390.75	840.69	1231 . 45)	4408
, 210	385.67	<b>Ե91.17</b>	840.39	1231 .57	14421

TABLE No. 2.

QUANTITIES OF HEAT CONTAINED IN ONE POUND OF WATER AT\_VARIOUS TEMPERATURES, RECRONED FROM ZERO, FAHRENHEIT.

[From Charles T. Porter's treatise on The Richards' Steam-Engine Indicator.]

Temperature.	Heat contained above zero.	Temperature.	Heat contained above zero.	Temperature.	Heat contained
Fahr. Deg.	, B.T.U.	Fahr. Deg.	B.T.U.	Fahr. Deg.	B.T.U.
1 35 ·	35.00	155	155.33	275	276.98
140	40.00	160	160.37	280	282.09
45	45.00	165	165.41	285	287.21
50	50.00	170	170 45	290	292.32
55	55.00	175	175 49	295	297.45
160	60.00	180	180.54	300	302.58
65	65.01	185	185.59	805	307.71
70	70.02	190	190.64	810	312.84
75	75.02	195	195.69	815	317.98
80	80.03	200	200.75	320	823.13
85	85.04	205	205.81	325	828.28
.90	90.05	210	210.87	330	383.48
/ 95	95.06	215	215.93	835	338.59
100	100.08	220	221.00	340	343.75
105	105.09	225	226.07	345	348.92
110	110.11	230	231.15	850	854.10
115	115.12	235	236.28	855	859.28
120	120.14	240	241 81	830	864.46
/125	125.16	245	246.39	865	-869.65
130	180.19	250	251.48	870	874.84
185	135.21	255	256.57	875	880.04
.1 <b>4</b> 0	140.84	260	261.67	880	885.24
145	145.27	265	266.77	885	890.45
ı <b>150</b>	150.30	270	271.87	890	895.67

### XVI.

(Page 312.)

# PROPERTIES OF SATURATED STEAM.

Norm.—The following table gives the data required by the engineer in this connection as based upon the experiments of Regnault. The temperatures, and heat-measures are all from Regnault's experiments. The other quantities were calculated by Mr. R. H. Buel.\* adopting the formulas of Rankine already given to obtain quantities not ascritained by direct experiment. The two parts of the latent heat of vaporization are separately determined, and the internal thus distinguished from the experiment. British measures are adopted. The nomenclature is sufficiently well explaned by the table-headings.

ber square inco. 00 : 2 500 E • Pressure above a vacuum, in pounds atio of volume of steam to volume of equal weight of distilled water at temperature of maximum density. 25.5 9,040 1,614 0,730 5,588 5,588 1,830 3,30 2.912 2.507 2.361 1 VOLUME. OiseA 330.4 171.9 117.3 89.51 61.14 52.89 54.66 37.83 8,8,88 S 200 33 Of a pound of steam in cubic feet. 104 õ 2 4 8 4.62 .031376 .033328 .036265 037928 038688 .005818 .008522 .011172 .016357 .018908 .021436 .023944 .026437 043519 £ .spanod 50 Weight of a cubic foot of steam, in 1.1872 1.1522 1.1599 1.1647 1.1683 1.1712 1.1737 1.1758 1.1777 1.1794 1.1824 1.1837 1.1840 1.1861 1869 Total heat of evaporation above 32°, in units of evaporation. 5 Total heat of evaporation above  $32^{\circ}$  = 5 + L. 113.055 1130.402 1125.144 1131.402 1133.942 1135.908 1137.740 1139.389 1142.275 1143.555 1144.748 1145.869 1146.926 146.600 87. Ħ 5 144 evaporation at pressure P = I + E. Latent heat of HEAT. 1043.015 1026.044 1007.370 1000.899 995.441 990.695 986.485 986.485 976.050 973.095 970.346 967.757 963.338 963.038 818.038 7 ફુ 5 British Thermal Units ģ 9 QUANTITIES A Pa or E External latent best. 61.619 64.114 65.653 66.773 66.663 70.106 70.106 70.96 71.33 71.663 71.973 72.175 2 5 5 2 E 222 Internal latent beat. ૡ૾૾ૢૹ૽ૼૡ૿૽ૹૼ 893.894 3 4 8 ع o o ~ 0 8 8 8 5253555 \$ 5 8 8 8 8 8 temperature of the water from 32° to P. Required to raise the S 225 457 402 112 181.608 184.919 188.056 531 è 2 3 8 2 8 5 5 8 6 6 6 7 5 8 6 6 48 ģ 141.654 153.122 162.370 170.173 176.945 188.357 193.284 197.814 202.012 8.3 8 434 6 Temperature, Fahrenheit degrees. 200 202 58 212 **17**.8 per square inch. 20 Ascaum in boangs R STOOK STURESTY

Weisbach's Mechanics, vol 11., part 11., Dubous' translation. N. Y.; J. Wiley & Sons. 188,

4	<b>8</b> 2	8	:	2	23	*	25	ଜୁ	3	200	ç	ይ	12	, 8	, 5	3	2	8	32	300	3	ţ	17	4	43	‡	Đ,	<b>Q</b> !	<b>}</b> 0	19	9		2	Z,	5.	\$	S,	, <b>1</b>
4	1,359	1,231	1,176	1,126	080,1	1,038	908	968.3	928.8	897.6	808.5	841.3	816.8	8.102	90.0	748.0	727.9	8.80	8.00	673.7	657.5	042.0	627.3	613.3	280.0	587.0	574.7	203.0	251.7		200	!	510.9	501.7	492.8	484.2	6229	
2 ot C	81.78 0.70	19.73	18.84	18.0	17.30	10.03	8.91	15.42	25.4	14.38	13.91	13.48	13 63	12.68	12.33	11.98	99:11	11.36	11.07	10.79	10.53	10.28	10.05	9.836	0.600	9.403	9.207	9.00	0.030	000	8.238	3	8.185	8.037	7.894	7.750	7.024	7.373
8 or W	.045924	050606	.053074	.055446	.057812	1/1000	.002524	004870	.007210	S#5600.	.074875	.074301	.076522	078810	.081152	.083461	.085766	.088067	+9£06a.	.092657	946460.	.097231	.000514	46Z101.	10001	. 106345	.108616	110884	642677		.110027	1	181221.	.124433	.126682	. 128928	131173	139651
ď	1.1901	1.1919	1.1927	1.1935	1.1943	1.1950	1.1957	1.1904	1.1971	1.1978	1.1984	1.1990	1.1006	1.2002	1.2008	1.2013	1.2018	1.3023	1.2028	1.9033	1.2038	1.2043	1.2048	1.2053	1.2058	1.2062	1.2066	1.2070	9000	1.3083	1.2086		1.2090	1.2094	1.2008	1.3102	1.2100	1.2114
γ or H	1149 779	1131.469	1152.269	1153.026	1153.764	1154.471	1155.157	1155.819	1150.401	1157.084	1157.091	1158.280	1148.852	1150.410	1150.054	1160.485	1161.003	1161.509	1162.004	1162.488	1162.962	1103.420	1164.882	1164.320	1164.766	761.5911	1165.615	1100.020	95	1167	1167.615		1167.905	1168.369	1168.738	1169.103	1100.400	1170.161
7 10.4	958.721	954.814	952.978										037.687	036.380	015.127	033.BQI	932.687	931.508	930-354	929.227	928.122	927.040	925.080	924.940	923.920	222.919	921.935	90.00	90.010	191	017.260		916.371	915-494	914.632	913.781	912.942	911.304
A Pu or B	73.060	73.525	73.739	73.942	74.130	74.323	7.503	74.078	74.847	79.011	75.108	75.319	75.466	900.52	75.745	75.878	76.007	76.133	76.955	76.375	26,493	70.00 90.00	76.719	76.827	76 932	77.035	77.130	77.235	77.331	77.513	77.601		27.696	77.784	77.870	77.954	70.030	78.196
p or 1	885.661 883.427	881.289	879.239	877.367	875.308	873.536	871.707	870.052	808.301	800.780	805.215	803.700	862.221	860.781	850.382	858.013	856.680	855.375	854.099	852.852	851.629	850.433	849.261	848.113	846.988	845.884	244.700	043.733	84.65	840.647	830.653		838.675	837.760	830.703	635.527	34.400	833. ro8
g of S	191.058	196.655	199.285	801.817	204.258	900.010	208.887	211.080	213.223	215.293	217.308	819.201	221.165	233.021	224.827	226.594	228.316	230.001	231.650	233.201	234.840	\$30.380	237.002	239.389	2.0.846	242.275	<b>3</b> 43.080	245.001	974 358	240.064	850.355		251.624	252.875	254.100	255.321	200.540	\$58.857
••	822.424	\$27.964	830.565	833.ogô	236.479	\$37.803	240.053	242.825	244-333	240.370	846.303	250.293	252.171	254.002	255.782	257.523	259.221	aco.883	262.505	204:003 204:003	905.047	807.108	268.660	270.123	271.557	272,965	274.347	2/3:/2	278.23	270.617	280.004		282.151	283.381	204.500	205.701	286.111	289.251
•	<b>6</b> 5	8	ă	2	83	đ	25	8	28	200	6	ಜ	12	. 5	. 5	*	8	ě	37	ž	8	•	7	4	43	‡	<b></b>		~ **	9	9,	1	21	C. (	25	*	- 25	2

PROPERTIES OF SATURATED STEAM-(Continued).

span	oq ni	Pressure above a vacuum, per square mch.	•	& & &	1	ĕ 8	5.5°	28	63	<b>3</b> 2	;	. 2	73	2;	72
Volume.	to 1 o 1 o 1 o 1	Ratio of voluric of steam volume of equal weigh distilled water at tempera of maximum density.	7	452.7 445.5 438.5	1	431.7	412.6	0 00 0 00 0 00	395.2	384.5	394.3	8	364.6	360	351.1
Лог	npic	Of a pound of steam in c	د ور ري 4	7.252		6.916	6.6 6.6 50	6.515	6.333	6.0.0	100	5.017	5.841	6.5	100
ni ,t	Sican	Weight of a cubic foot of pounds.	N so 8	.137892		.14594	.151277	.153500	157940	162372	100932	10001	012171.	173417	.177825
	oove bowe	Total hear of evaporation a 32°, in units of evaporati	u	1.2117		1.2127	1.2133	1.2140	1.2146	1.2158	1 2158	1 2161	1.2164	1.9167	1.0173
		Total heat of evaporation above $= S + L$ .	A or H	1170.503		1171.505	1172.149	1172.779	1173.393	1173.991	1174 C7R	1174.866	1175.150	1175.431	1175.985
QUANTITIES OF HEAT.	d Units.	Latent heat of evaporation a present $E = I + E$ .	1 10 t	910.501 900.709 908.928		908.157	905.900	905.107	903.727	900.192	970	000.300	800,600	808.038	897.635
Опанти	In British Thermal Units.	External latent beat.	A Pu or E	78.273		78.50	78.739	78.779	78.913	79.042	20.169	70. 228	79.288	79.349	79.469
	In Briti	Internal latent beat.	p of I	832.228 831.361 830.507		820.663 828.830	827.191	825-388 825. 506	824.814	823.280 822.524	801 27B	821.041	820.312	810.589	818.165
		Required to raise the temperature of the water from 32° to T.	g or S	260.002 261.132 262.248		263.348	265.500 266.566	267.612	200.666	272.657	623	274.507	275.550	276.493	878 350
,	legree:	Temperature, Fahrenheit d	•	290-374 291-483 202-575	215	293.653 294.717	295.708 296.805	297.830 208.842	299.843	301.807	Act con	304.660	305.603	306.526	308.344
epur	od vi	Pressure above a vacuum, per square inch.	•	8,8,8		55.	23	2.8	2.8	388		. 2	3.	2;	e

1		l	l	l	
•	<b>5</b> 458	*******	288388888	22222222222	######################################
7	346.8 342.6 338.5 334.5	330.6 326.8 325.6 315.9 315.9 309.1 305.8 302.5	296.3 293.2 293.2 287.3 284.5 281.7 276.3 276.3	866 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	243.6 243.6 243.6 239.6 235.7 233.8
2 of C	5.588 5.488 5.388	25.23 25.23	+ + + + + + + + + + + + + + + + + + +	4.302 4.263 4.283 4.185 4.147 4.034 4.033 3.969	3 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9
8 or W	. 180027 . 184239 . 186627	.18883 .191017 .193210 .193501 .197501 .204155 .204155 .204155	.210709 .215874 .215774 .21775 .21604 .223776 .223776 .228522	. 23464 . 234634 . 23683 . 23897 . 241139 . 24156 . 24166 . 240789	.254105 .256403 .258420 .267732 .267837 .267841
n	1.9176 1.9179 1.9181 1.9184	1. 2190 1. 2193 1. 2193 1. 2193 1. 2203 1. 2203 1. 2203 1. 2203 1. 2206 1. 2206	1.2212 1.2215 1.2220 1.2220 1.2224 1.2224 1.2231 1.2232 1.2233	1. 23.6 1. 23.8 1. 22.4 1. 22.4 1. 22.4 1. 23.4 1. 23.4 1. 23.4	1.2258 1.2260 1.2264 1.2264 1.2266 1.2268 1.2268
A or H	1176.859 1176.589 1176.795 1177.000	1177 321 1177 580 1177 580 1178 337 1178 343 1178 592 1179 328 1179 328	1179, 809 1180.045 1180.279 1180.311 1180.970 1181.197 1181.645	1182 .085 1182 303 1182 303 1182 733 1183 156 1183 366 1183 561 1183 561	1184.190 1184.393 1184.594 1184.994 1185.188
1 or 2	896.994 896.339 895.729 895.108	894-491 893-879 893-879 893-875 893-677 890-496 889-703 889-703	888 6)3 888 6)3 886 973 886 973 886 497 885 887 884 995 884 995	883.853 882.737 882.236 881.234 881.234 880.718 880.714 870.720 870.720	878.263 877.784 877.309 876.838 876.371 875.907
A Pu or A	79.526 79.582 79.639 79.695	79.749 79.862 79.856 79.961 79.961 80.063 80.163 80.163	80.25 80.35 80.35 80.35 80.44 80.53 80.53 80.650	80.709 80.752 80.754 80.835 80.875 80.956 81.034 81.034	81.110 81.147 81.221 81.257 81.257 81.330
bor !	817.468 816.777 816.090 815.413	814, 742 813, 419 813, 419 812, 768 811, 484 810, 850 809, 601	808.375 807.770 807.770 805.175 805.405 804.4821 804.445 804.445 803.675	802 544 801 985 801 432 802 84 800 339 790 796 798 775 798 775	797-153 796-637 796-125 795-614 794-614 794-114
g or S	279. a65 280. 170 281. o66 281. 952	282.830 283.701 285.701 285.414 287.040 287.040 288.750 288.750 289.750	891.176 291.976 292.758 293.359 295.083 295.843 295.843 295.843 296.601	298.832 299.566 300.293 301.734 301.734 303.152 303.854 304.551	305.927 306.609 307.285 307.056 306.621 309.233
,	309.239 310.123 311.000 311.866	312.725 313.576 314.417 316.936 316.936 316.893 317.705 319.306 320.094	320.877 321.653 321.422 323.939 323.643 326.609 326.609	328,345 329,060 339,769 331,169 331,862 333,550 333,550 334,582	335.250 335.914 336.573 337.226 33.874 33.5.518
•	<b>E&amp; 2%</b>	9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	2888888888	1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	111111111111111111111111111111111111111

PROPERTIES OF SATURATED STEAM-(Continued).

span	od ui	Pressure above a vacuum,	•	E 8	611	8	ï	121	123	<b>+</b> 25 1	120	762	136	5 5		131	<b>B</b> ,	2		78	E E
Volume.	to i	Ratio of volume of steam volume of equal weight distilled water at tempera of maximum density.	7	231.0	230.1	228.3	226.5	224.7	223.0	210.0	218.0	216.4	214.8	211.6		100	0		2 2	8	201.4 200.0
Vot	əjqn	Of a pound of steam in c	2 10 a	3.715	3.685	3.656	3.628	3.60	3.572		3.408	3.466	3.40	3.412		38	3.348		0.00	i è	3.937
ai ,a	GESTS	Weight of a cubic foot of pounds.	8 or W	\$61698.	.271348	.273500	.275651	108/12.	-279949	.88227	286389	.288533	140062	.294961		50170E.	. 299242	301308	303531	707705.	309934
	TX	Total heat of evaporation algae, in units of evaporation	U	1.2272	1.2274	1.2276	1.2278	1.2280	1.2363	1.2284	1.2288	1.2390	1.2292	1.2293		1.2200	1.2206	1.2300	1.2302	200.2	1.8308
		Total heat of evaporation above as S+L.	A or H	1185.577	1185.770	1185.961	1186.150	1186.339	1180.527	1186.714	1187.083	1187.266	1187.448	1187.809		1187.988	2	1156.344	200.00	1188.860	1189.041
QUANTITIES OF HEAT.	al Units.	Latent heat of exporation at pressure P = I+B.	ror L	874.985	874.529	874.076	873.626	873.178	872.732	871.848	871.411	870.977	870.545	869.688	1	600.203	179.841	605.428	864.603	867.177	866.767 866.360
QUANTIT	British Thermal Units.	External latent beat.	A Pu or E	81.366	81.403	81.439	81.474	81.500	81.543	81 612	81.646	81.679	81.711	81.774		80.805	21.017	902.19	3.0	200	81.992
	In Brit	Internal latent beat.	b or I	793.619	793.126	792.637	792.152	791.669	701.180	790.711	780.765	789.398	788.834	787.914		787.450	787.00	780.554	780.105	784.814	784.775
		Required to raise the temperature of the water from 32° to T.	S so s	310.508	311.241	311.885	312.524	313.161	313.795	314.425	315.672	316.289	310.003	317.513		318.725	319.325	319.922	320.513	231.603	322.274
*8:	egree	Temperature, Fahrenheit o	,	339.796	340.430	341.058	347.681	342.300	342.910	343.520	344.741	345.340	245.930	347.121		347.700	348.287	340.807	347-443	350.584	351.149
spun	od u	Pressure above a vacuum, per square inch.	*	811	611	130	121	22	123	7 5	130	Zez	2 2	5 5	Ī	131	13 S	133	5	72	137

•		-							
-	p or I	A Pu or B	r or L	γ or H	A	8 or W	2 10 a	7	•
<u> </u>	783.505	82.050 82.080	865.955 865.55	1189.384 1159.555	1.2311	.316338	3.182	198.7 197.3	8.3
<u></u>	783.042	82.100 82.138	865.151	1189.724	1.2315	.318471	3.140	1960	72
	782.188	82.166	864-354 862-065	1190.059	1.2318	.322735	80.0	193.4	143
_	781.346	82.221	863.567	1190.390	1.2321	326998	3.05	6.6	3
_	780.927	82.249	863.176	1190.554	1.2323	.329128	3.038	189 7	9
	780.000	82.304	862.400	1190.879	1.2320	333386	6 8	2.2.2	147
	779.684	82.332 82.359	862.016 861.634	1191.040	1.2328	.335515	80°6	186.1	5 6
⊢		82.616	857.012		1.2346	.358886	2.786	171 0	8
	771.505	82.854	854.359		1,2361	.380071	2.631	164.3	5.
		83.072	850.903		1.2370	102104.	2.493	155.0	8 8
		83.462	8 <del>4</del> 573	1198.339	1.2404	.443310	3.25	140.8	<u>8</u> .8
<u> </u>	757.916	83.640	841.556	1199-597	1.2417	.464295	27.5	134.5	015
_	754-834	83.808	838.642	1200.810	1 2430	.485237	2.001	128.7	230
_	751.002	84.114	813.103	1201.900	1.245	500139	6.6	123.3	230
_	746.203	84.256	830.459	1204-300	1.2465	.547831	1.825	0.41	250
_	743.508	84.388	827.896	1205.273	1 2476	. 568626	1.759	100.8	8
	740.891	84.510	825.401	1200.300	1 2407	.589390	1.007	105.0	2,8
	735.878	84.731	820 600	1208.286	1.2507	630820	1.585	8	8 8
	733.470	84.835	818.305	1209.238	1.2517	.651506	1.535	95.8	8
_	722.80			1213.74	1.256	-754534	1.325	82.7	350
	712.34			1317.70	1.260	.857185	1.167	72.8	8
	703.88 695.01	86.01 86.01	789.12	1224 . 54	1.204	.959530	2 2 2 3 3 3 3	28.8 58.8	<del>&amp;</del> 8
-	89°	20.23	773.46	1227.60	1.270	1.16389	.859	53.6	SS.
	860.08	80.18	8.5	1230.48	1.273	1.20580	8.5	ģ;	8 8
	667.11	90.00	759.00	1235.10	2.70	1.46005		42.4	3 8
	661.04	86,114	747.18	1238.04	1.282	1.57198	9:9.	30.6	8
	665.34	86.08	741.42	1240.30	1.285	1.67401	.597	37.1	8
	40.04	8 8	735.84	1242.50	1.287	1.77603	.503	¥.	8
	630.60		725.40	1846 70	1 201	1.08004	Š	33.0	3 9
_	634 68	85.68	720.30	1248.65	1.203	2.08203	. 2	90.0	8

XVII. (Page 315.) ENTROPY OF THE LIQUID.

Absolute Steam Pressure.	Entropy of the Liquid. 8	Absolute Steam Pressure.	Entropy of the Liquid.
1 10	0.1329 0.2842	65 70	0.4337 0.4402
15	0.3143	75	0.1161
20 25	0.3363 0.3539	80 85	0.4522 0.4579
30	0.3685	90	0.4633
35 40	0.3811 0.3921	95	0.4686 0.4733
45	0.4020	105	0.4780
50 55	0.4109	110	0.4826 0.4869
<b>6</b> 0	0.4267	120	0.4911

XVIII.

HYPERBOLIC NAPERIAN LOGARITHMS.

N.	Log.	N.	Log.	N.	Log.	N.	Log.	N.	Log.
1.00	0.0000	2.30	0.8329	3.60	1.2809	4.90	1.5892	6.40	1.8563
1.05	0.0488	2.35	0.8544	3.65	1.2947	4.95	1.5994	6.50	1.8718
1.10	0.0953	2.40	0.8755	3.70	1.3083	5.00	1.0094	6.60	1.8871
1.15	0.1398	2.45	0.8961	3.75	1.3218	5.05	1.6194	6.70	1.9021
1.20	0.1823	2.50	0.9163	3.80	1.3350	5.10	1.6292	6.80	1.9169
1.25	0.2231	2.55	0 9361	3.85	1.3481	5.15	1.6390	6.90	1.9315
1.30	0.2624	2.60	0.9555	3.90	1.3610	5.20	1.6487	7.00	1.9459
1.35	0.3001	2.65	0.9746	3.95	1.3737	5.25	1.6582	7.20	1.9741
1.40	0.3365	2.70	0.9933	4.00	1.3863	5.30	1.6677	7.40	2.0015
E-45	0.3716	2.75	1.0116	4.05	1.3987	5.35	1.6771	7.60	2.0281
1.50	0.4055	2.80	1.0296	4.10	1.4110	5.40	z.6864	7.80	2.0541
z.55	0.4383	2.85	1.0473	4.15	1.4231	5.45	1.6956	8 00	2.0794
1.60	0.4700	2.90	1.0647	4.20	1.4351	5.50	1.7047	8.25	8.1102
1.65	0.5008	2.95	1.0818	4.25	1.4469	5.55	1.7138	8.50	2.1401
1.70	0.5306	3.00	1.0986	4.30	x.4586	5.60	1.7228	8.75	2.1601
1.75	0.5596	3.05	1.1154	4.35	1.4701	5.65	1.7317	9.00	2.1972
1.80	0.5878	3.10	1.1314	4.40	1.4816	5.70	1.7405	9.25	2.2246
z.85	0.6152	3.15	1.1474	4-45	1.4929	5.75	1.7492	9.50	2.2513
1.90	0.6419	3.20	1.1632	4.50	1.5041	5.80	1.7570	9.75	2.2773
1.95	0.6678	3.25	1.1787	4.55	1.5151	5.85	1.7664	10.00	2.3026
2.00	0.6931	3.30	1.1039	4.60	1.5261	5.90	2.7750	11.00	2.3979
2.05	0.7178	3.35	1.2000	4.65	1.5369	5.95	1.7834	12.00	2.4840
2.10	0.7410	3.40	1.2238	4.70	1.5476	6.00	1.7018	13.00	8 5649
2.15	0.7655	3.45	1.2384	4.75	1.5581	6.10	z.8083	14.00	2.6391
2.20	0.7885	3.50	1.2528	4.80	1.5686	6.20	1.8245	15.00	2.7081
2.25	0.8100	3.55	1.2669	4.85	1.5790	6.30	1.8405	16.00	2.7720

XIX. (Page 274.)
DISCHARGE OF STEAM IN POUNDS PER HOUR CALCULATED
BY NAPIER'S FORMULA.

Absolute	1	Pounds of Steam.	
Pressure. Pounds.	Diameter of Orifice 1/2 inch.	Diameter of Orifice 18 inch.	Diameter of Orifice ‡ inch.
1	0.039	0.158	0.631
2	0.079	0.316	1.262
3	0.118	0.473	1.893
4	0.158	0.631	2.524
3 4 5 6	0.197	0.789	3.155
	0.237	0.947	3.786
7 8	0.276	1.101	4.417
8	0.315	1.262	5.048
9	0.354	1.420	5 6So
10	0.395	1.578	6.311
20	0.789	3.155	12.622
30	1.183	4.733	18.937
40	1.578	6.311	25.244
50	1.972	7.8§a	31.556
60	2.367	9.467	37.867
70	2.761	11.045	44.178
8 <b>o</b>	3.156	12.623	50.488
90	3.550	14.200	56.800
100	3.947	15.778	63.115

XX.

Page 392)

### PER CENT OF WATER AND STEAM EXHAUSTING INTO ATMOSPHERE.—BY THROTTLING CALORIMETER.

(Per cent of moisture.)

Tempt. in Calorimeter.			Gauge	e-pressur	e on Ma	in Steam	-pipe.		
Degrees Fahr.	40	45	50	55	60	65	70	75	80
115	.0233	.0253	.0271	.0290	.0307	.0322	.0338	.0354	.0368
20	.0207	.0227	.0245	.0263	.0280	.0206	1150.	.0327	.0340
25	.0181	.0201	.0218	.0237	.0253	.0260	.0234	.0330	.0313
30	.0154	.0173	.0192	.0210	.0227	.0242	.0257	.0273	.0287
35	.0128	.0147	.0165	.0184	.0200	.0215	.0230	.0245	.0200
40	.0102	.0122	.0139	.0157	.0173	.0183	.0204	.0210	.0233
45	.0076	.0005	.0112	.0130	.0147	.0162	.0177	.0102	.0206
50	.0049	.0060	.0086 '	.0104	.0120	.0135	0150	.0165	.0170
55	.0023	0042	.0050	.0077	.00033	.0108 1	.0123	8:10.	.0152
60	.0005-1	.0016	.0033	.0051	.oo66	.0081	.თენ	.0111	.0125
65	.0030-	.0010-	.oos6 '	.0024	.0040	.0055	.cots	.00.4	.0008
70	.0057 -	.0037-	.0020-	.0002-	.0013	0028	.0042	.0057	, nona
75	.0083-	.0063-	.0047-	.0020-	.0013	.0.01	.0015	.0030	.0042
80	.0100 -	.008o-	.0073-	.0056-	.0040-	0026 <del>-</del> '	.0011-	.0003	.00:5
δ5	.0136-	.0116-	.0100-	∞82-	.0067-	.∞53−	.დკ8−	.0024	.0012
oiff. 1° Fahr	.00052	.00052	.00053	.00053	.00053	.00054	.00054	.00054	.0005

The minus sign indicates superheat.

This amount divided by 0.48 and multiplied by the value of the latent heat will give the degree of superheat.




DIAGRAM FOR DETERMINING PER CENT OF MOISTURE FROM READING OF THERMOMETER IN THROTTLING CALORIMETER. (See text, page 395.)

(Page, 443.)

	900	13.3	1.241	.238	.233	.227	.223	.217	.212	207	202	161	186	181	176	171	. 165	<u>8</u>	.155	5.	. 45	6	¥£1.	. 139	124		<b>8</b> 01.	.103	3	86	3.	83	.077	.o73	9.6	630
	81	13	1.239	.236	162.	.225	02	512.	012	S S	9 2	81	184	170	174	. i	. 163	.158	. 153	148	5	.137	.132	.127	133	1	901	101	8	8.	S.	8	.075	ė,	8.8	2,00
rrs.	92	10.7	1.237	.234	533	.223	.218	.213	808	Š.	2 5	187	.182	.177	.172	.167	191	.156	.151	941	7	• 135	o£1.	.125	8		01.	8	60.	8	9	8/0.	93	60.	6 6	250
MOSPHE	9	9.3	1.234	152	.226	.230	2.0	2	é	8	3.5	oğ.	.170	174	ě.	ě.	85.	.153	.143	7	25.	. 132	.127	. 133		9	101.	960.	60	8,	8	.075	.070	ė,	8 6	3
rA Mi di	120	c.80	1.231	.228	. 223	.217	. 32	6	8	761	2	181	921.	171.	99.	īģi.	.155	8	.145	9	.135	621.	124	611.	7	6	86	8	88		.077	.072	9,	ģ	.057	740
HERE AP	8	6.7	1.237	. 224	616	.213	8	6	8		5 4	111	173	.167	162	.157	151	941.	141	39	.131	. 125	.130	511.	9	8	8	8	80.	6/0	.073	80.	.00	.058	0.03	6
GAUGE PRESSURE IN POUNDS PER SQUARE INCH ABOVE THE ATMOSPHERE AND IN ATMOSPHERES.		6.9	1.22	122	912.	210	Š.	8	.195	8.	9	174	160	10.	159	3.	.148	.143	.138	133	126	.133	.117	.112	6	8	8	86.		9/0	o. 0/0	290.	8	.055	ê, ş	90
OVE THE	&	5 3	1.222	617	.214	808	Š	<u>.</u>	5	2	2	172	.167	162	.157	.152	146	7	961.	131	120	2	.115	011.	<u>.</u>	8	8	80.	6/6	.07	8	8	850.	٠. در	900	82
INCH A	2	4.7	1.219	912.	.211	208	8		8.	50.	2 2	9	791	150	154	140	.143	861.	.133	128	. 123	.117	.113	107	8	3 8	980	180	96	16	ş	8	.055	050	5	20
Square	8	<b>•</b> ••	1.217	712.	200	.203	2	56.	2	ë i	2.2	167	201	.157	.152	.147	141.	961.	131	130	121	511.	011.	Sor.	8 8	3.8	80	620.	•/6	Š,	8	850.	.053	<u>م</u>	9.0	6
NDS PER	ይ	3.3	1.214	.211	908	8	261	3.	. 185 20	8 ;	2.5	10	150	15.	140	¥.	.133	.133	120	.123	911		.107	102	8	38	180.	9/0.	.0	, 8	8	.055	.050	ş	6 0	0.0
и Роп	*	3.0	1.212	8	<u>ğ</u>	86 <u>r</u> .	669	8 4	e e	2.5	79	162	.157	.152	.147	.142	.136	.131	320	121	011	9	.105	8	8.8	8	9,6	.07	8	ġ,	ş.	.053	20.	9	95.0	
RESSURE	ę	2.7	1.211	808	.203	.197	60.	, To 7	20			191	951.	151	146	141	.135	o£1.	.125	8	511.	6 6 7	ð.	86	8.6	8	8/0.	6/0.	8	ģ	25	.05	.047	9	.037	.037
GAUGE 1	35	2.3	1.209	908.	.201	. 195	8.	501.	2	273	2,4	651	7	140	‡	.139	.133	821.	.123	81.	113	· voz	102	.00	8 6	9.8	960.	.6	80.	8	S.	S	Sp.	ģ	.035	200
	8	0.0	1.206	.303	861.	192	.187	707.	.177	27.	7.5	156	151	146	141	136	.13o	.125	200	.115	oi i	đ.	8	ġ.	8	8,6	.673	890.	8	.038	.052	.647	200.	.037	9 9	2
		1.7	1.204	201	961.	8.		9	.175	0,1	٠ د	154	.140	171	.139	134	821.	.123	811.	E.	8	201	660	<u>6</u>	60	9,6	160	990.	90.	.056	Ş.	545	960.	.035	6.8	8
ture of		ن	•	1.6	;	7.2	9	13.7	15.5	20.3	21.1	9	30.5	33.3	35.0	37.7	40.5	43.3	46.r	œ, ·	51.0	<u>*</u>	57.3	8.	2.7		1.14	73.8	9.9/	* 56 66	22.2	85.0	87.7	8	6,69	. ee
Temperature of Feed-water in	-	æ.	33	32	Ç	54	S,	S .	8.	S	2 8		ŏ	8	56	201	Š	110	115	20	125	2	135	140	145	155	92	165	170	175	2	E	8	262	8 8	6

XXII. (Page 414.)
COMPOSITION OF VARIOUS FUELS OF THE UNITED STATES.

	c.	н. о.	N.	s.	Mois- , ture.	Ash.	Spec. Grav.
Pennsylvania Anthracite	78.6	2.5 T.7	0.8	0.4	1.2	14.8	1.45
Rhode Island "Massachusetts "North Carolina"	85.8 92 0 83.1	10.5 6.0 7.8	::::	3.7 2.0 9.1			1.85 1.78
Welsh "Maryland Semi-bituminous	84.2 80.5	3.7 2.3 4.5 2.7	0.9	0.9	1.3	6.7 8.3	1.40
Pennsylvania "	75.8 59.4 70.0	20.2 38.8 28.0				4.0 1.8	1.32 1.30 1.24
Illinois Bituminous	52.0 62.6 58.2	39.0 35.5 37.1		••••	-:::	9.0	1.27 1.30
Illinois and Indiana (Cannel) Bituminous Kentucky (Cannel) Bituminous. Tennessee Bituminous.	59.5 48.4 71.0	36.6 48.8		::::		3 9	1.27
Alabama "Virginia "	41.5 54.0 55.0	56.5 42.6		1.0	1.2	12.0 2.5 1.2 4.0	I.45
California and Oregon Lignite	74.0	18.6	0.0	1.5	16.7	7-4	1.32

		1	THEORET	ICAL VALUE.
STATE.	COAL, KIND OF COAL.	Per Cent. of Ash.	In Heat Units.	In Pounds of Water Evaporated
Pennsylvania	Anthracite	3-49	14,100	14.70
	4.	6.13	13.535	14.08
		2.00	14,221	14.72
"	Cannel	15.02	13,143	13.60
	Connelsville	6.50	13,368	13.84
	Semi-bitummous	10.77	13,155	13.62
	Stone's Gas	5.00	14,021	14.51
	Youghiogheny.	5.60	14.265	
	Brown	9.50	12,324	14.76
	Caking	2.75	14,391	12.75
	Cannel	2.00	15,198	10.70
44		14.80	13,360	13.84
44	Lignite	7.00	9,326	9.65
Minoie	Bureau County	5.20	13,025	13.48
4	Mercer County	5.60	13,123	13.58
44	Montauk	5.50	12,650	13.10
	Block	2.50	13,588	14.38
	Caking	5.66	14.146	14.64
	Cannel	6.00	13,097	13.50
	Cumberland	13.08	13,226	12.65
	Lignite	5.00	0,215	
Colorado		9.25	13,562	9.54
		4.50	13,866	
Texas		4.50	13,000	14.35 13.41
Washington.		3.40	11,551	11.06
	Petroleum	3.40	20,746	21.47

### ANALYSES OF ASH.

	Specific Grav.	Color of Ash.	Silica.	Alum- ina.	Ozide Iron.	Lime.	Mag- nesia.	Loss.	Acids S.&P.
Pennsylvania Anthracite	1.559 1.372 1.38 1.26 1.27	Reddish Buff. Gray.	45.6 76.0 40.0 37.6 19.3	42.75 21.00 44.8 52.0 11.6		1.41  19.0 3.7 93.7	0.33 trace 1.1 s.6	0.48	2.97 5.02 33.8

XXIII.

FOR REDUCING BAROMETRIC OBSERVATIONS TO THE FREEZING-POINT.

Reading of Ba- rometer. Inches.	Correction at 10° Fahr. Inches.	Correction at 40° Fahr. Inches.	Correction at 70° Fahr, Inches.	Correction at 90° Fahr. Inches.
•	+	_	_	_
27	0.045	0.028	0.100	0.148
27.5	0.046	0.028	0.102	0.151
28.0	0.047	0.029	0.104	0.153
28.5	0.048	0.029	0.106	0.156
29	0.049	0.030	0.108	0.150
29.5	0.050	0.030	0.100	0.162
30.0	0.051	0.031	0.111	0.164
30.5	0.052	0.032	0.113	0.167
31.0	0.053	0.032	0.115	0.170

XXIV.
HORSE-POWER PER POUND MEAN PRESSURE.

Diameter of Cylinder. Inches.				SPEED	or Pist	on in Fi	ET PER	MINUTE.			
Dien Cylind Incl	100	240	800	850	400	450	500	550	600	650	.750
4	.038	.091	.114	.133	. 152	.171	.19	.209	.228	-247	. 285
44	.048	.115	.144		.192	.216	.24	.264	.288	.312	. 360
5,	.06 .072	.144	.10	.21	.288	.27	.30	·33 ·396	.36 .432	.39 .468	.450 .540
şi	.086	.205	.256	.299	. 342	. 385	.428	.471 .563	.513 .614	· 555 .698	.64z
61	.102	-245	. 307 . 348	.391	.409 .466	.464 .5 <b>2</b> 4	.512	.563 .643	.614	.698	.800
7	. 116 . 134	. 279	.401	.468	-534 -608	.002	.583 .669	.735	.699	.756 .869	1.003
₹ <b>†</b>	. 158	. 365	.456	.532 .602	806.	.685	.761	.735 .837	.918	.080	I.ISE
81	.172	.413	.516	.602 .674	.688	.774 .866	.86 .963	1.059	1.032	1.118	1.290
9	.192	.515	· 577 · 644	.751	.770 .859	.966	1.074	1.181	1.154	1.395	1.444
30	.238	.571 .63	.714	.751 .833	.952	1.071	1.190	1.309	1.428	I.547	1.785
10	. 262 . 288	,691	. 787 . 864	.919 1.008	1.050	1.181	1.313	1.444 1.584	1.575 1.728	1.706	1.969
21	.314		.943	1.1	1.257	1.414	1.572	1.720	1.886	2.043	2.357
12	. 342	·754	1.025	1.195	1.366	1.540	1.708	1.88o	2.050	2.222	2.564
23	.402	1,119	1.206	1.407	1.864	2.097	2.01	2.211	2.412	3.020	3.015
14 25	.466 -535	1.285	1.398 1.606	1.873	2.131	2.409	2.677	2.945	3.797	3.479	3.495 4.004
16	.609	1,461	1.827	2.131	2.436	2.741 3.08t	3.045	3.349 3.766	3.654	3.958	4.567
17	.685	1.043	2.054	2.396	2.739 3.083	3.081	3.424 3.854	4.239	4.108	4.450	5.135 5.780
18	. 771 . 859	1.849	2.312	2.697 3 006	3.436	3.468 3.865	4.295	4.724	5.154	5.583	6.442
20	.952	2.292	2.577 2.855	3.331	3.436 3.807	4.285	4.759	5.234	5.731	0.150	7.138
21	1.049	2.518	3.148	3.672	4.197	5.183	5.247	5.771	6.296	6.820	7.869
22	1.152	2.764 3.021	3·455 3.776	4.405		5.664	5.759 6.294	6.334	6.911 7.552	7.486 8.181	8.63 <b>8</b> 9-44
24	1.370	3.280	4.111	4.797	5.035 5.482	0.167	6.853	7.538	7·552 8·223	8.908	10.270
25	1.487	3.569	4.461	5.105	5.948	6.692	7.436 8.044 8.666	7.538 8.179 8.848	8 923	9.566	11.053 12.005
26 27	1.609	3.86t	4.826 5.199	5.630 6.066	6.435	7.239	8.666	9.532	9.652	10.456	12.998
28	1.865	1.477	5.596 6.006	6.529	7.462 8.008	7.799 8.395	9.328	10.261	11.193	12.125	13.992
29	2.002	4.805		7.007		9.009	10.01	11.011	12.012	13.013	15.015
30 31	2.142	5.486	6.426	7.497 8.001	8.568 9.144	9.639	10.71	11.781	12.852	13.923 14.866	16.065
32	2.436	5.846	7.308	8.526	9.744	10.962	12.18	13.398	14.616	25.834	8.270
33	2.590	6,215	7.770	9.065	10.360	11.655	12.959	14.245	15.54	z6.835	19.425
34	2.746	6.59	8.238	9.611	10.984 11.656	12.357	13.73	15.103	16.476 17.484	17.849	20.59 <b>5</b> 21.85 <b>5</b>
35 36	3.084	7.401	9.252	10.794	12.336	13.878	15.42	16.962	18.504		23.130
37 38	3.253	7,819	9.774	11.403	13.032	14.861	16.29	17.010	10.548	21.177	24 435
38	3.436	8,246	10.308 10.86	12.026 12.67	13.744 14.48	15.462 16.29	17.18	19.91	20.616 21.62	22.334 23.53	25.770 27.150
40	3.808	9.139	II.424	13.328	15.232	17.136	19.04	20.944	22.848		28.560
4º	4.002	9.604	12.006	14.007	16.008	18.009	20.00	22.011	24.012	26.013	30.015
42		10.065	12.594	14.693 15.4	16.792 17.6	18.901 19.8	20.99	23.089 24.2	25.188 26.4	27.287	31.485 33.00
43 44		11.046	13.818	16.121	18.424	20.727	23.03	25 - 333	27.636	29.939	34 - 545
45	4.818	11.563	24-454	16.863	19.272	21.681	24.00	26.399 27.698	28.908	31.317	36.135
40	5.043	12.086	15.768	17.626 18.396	20.144	22.662 23.652	25.18 26.28	28.908	30.216	32.754 34.164	37.770 39.420
47 48		12.846	16.446	19.187	21.028	24.669	27.41	30.151	39 152		41.115
49	5.714	12.913	17.142	19.999	22.856	25.713	28.57	31.427	34.284	37.141	42.855
50 51	5.950	14.28	17.85 18.54	20.825	23.8 24.76	26.775 27.855	29.75 30.95	32.725 34.045	35.7	38.675	44.625
52		15.437	19.296	22.512	25.728	28.944	32.16	35.376	37.08 38.592	41.808	48 240
<b>5</b> 3	6.684	16.041	20.058	23.394	26.736	30.078	33.42	36.762	40.104	43.446	50.130
54	7.108	16.65 <b>6</b> 17.275	20.82	24.29 25.193	27.76 28.792	31.23	34·7 35·99	38.17	41.64 43.188	45.11 46.787	59.05
55 56		17.909	21.524	26.117	29 848	33.579	37.31	41.041	44.772	48.503	55.965
57 58	7.732	18.557	23.196	27.062	30.928	34 - 794	37.31 38.66	42.526	40.392	50.258	57.99
58		19 214	24.018 24.852	28.021 28.964	32.024 33.136	36.027 37.278	40.03	44.033 45.562	48.036 48.704	58.039 53.846	60.045 62.13
59 60	8.566	20.558	25.698	29.981	34.264	38.547	41.42 42.83	47.113	51.396	55.679	64.245

(Page sor.)

## XXV. WATER-COMPUTATION TABLE.

T.	•	=	01	•	•	<b>16</b>	•		∞	•
3		121.015		128.406	132.083	135.748	139.399	143.075	146.665	150.279
4	153.880	157.514	161.137	164.750	168.353	171.945	175.527	179.098	182.659	186.210
'n		193.336		200.483	204.044	207.598	211.142	214.679	218.208	221.728
•		228.799		235.897	239.437	242.970	246.497	250.017	253.531	257.039
7		264.056		271.071	274.570	278.063	281.550	285.031	288.506	291.976
<b>∞</b>		298.922		305.872	309.338	312.800	316.256	319.708	323.154	326.534
6		333.488		340.389	343.833	347.273	350.707	354.137	357.563	360.984
<b>2</b>		367.843		374.714	378.144	381.570	384.992	388.410	391.824	395.234
11		402.064		408.902	412.315	415.725	419.131	422.534	425.933	429.328
12		436 120		442.911	446.301	449.688	453.071	456.451	459.828	463.200
13		469.950		476.699	480.068	483.435	486.798	490 I59	493.516	496.869
14		503.596		510.338	513.706	517.070	520 432	523.790	527.146	530.500
15		537.213		543.930	547.285	550.638	553.987	557.334	\$60.679	564.01F
9		570.713		577.411	580.757	584.100	\$87.44I	590.780	594.115	597.449
17		604 . 109		610.759	614.081	617.400	620.717	624.031	627.343	630.653
81		637.265		643.867	647.165	650.460	653.753	657.043	660.331	663.617
61		670.200		676.793	680.086	683.378	986.666	689.953	693.238	696.520
8		703.098		709.688	712.980	716.270	719.558	722.844	726.128	729.410
ä		735.968		742.518	745.790	749.060	752.328	755.594	758.858	762.120
22		768.660		775.215	778.490	781.763	785.034	786.303	791.570	794.836
83		801.362		807.881	811.138	814.393	817.646	820.897	824.146	827.334
त्रं		833.908		840.440	843.703	846.965	850.225	853.484	856.741	859.996
23		866.502		873.002	876.249	879.495	882.739	885.982	889.223	892.462
9		898.936		905.404	908.635	911.865	915.093	918.320	921.545	924.768
27		931.210		937.646	940.831	944.075	947.287	950.498	953.707	956.914
8		963.352		969.813	973.041	976.268	979.493	982.717	985.939	989.160
50.		995.598		1002.031	1005.245	1008.458	1011.669	1014.879	1018.087	1021.294
ဇ္တ	•	1027.704		1034.109	1037.309	1040.508	1043.705	106.9401	1050.095	1053.288
31	•	1059.670		1066.047	1069.233	1072.418	109.5701	1078.783	1081.963	1085.142

## XXV.—(Continued.) Water Comeutation Table—Continued.

•	1117.152 1180.876 1180.876 1180.876 1124.453 1124.453 1124.453 1134.613 1137.113 1137.113 1145.558 1145.558 1146.020 1146.020 1146.020 1146.020 1146.020 1146.020 1146.030 11902.189 11902.189
<b>.</b>	1113.954 1145.888 1177.702 1241.264 1241.264 1304.844 1306.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1430.804 1610.574 161
	1110.754 1174.700 1174.526 1206.233 1206.233 1209.075 1301.675 1301.675 1304.875 1304.875 1304.875 1305.300 1490.834 1490.834 1490.834 1490.834 1490.834 1490.834 1490.834 1490.834 1553.802 1616.450 161
•	1107 . 552 1139 . 510 1171 . 348 1234 . 884 1226 . 504 1238 . 504 1330 . 164 1371 . 724 1371 . 724 1371 . 724 1424 . 54 1424 . 54 1425 . 605 1457 . 604 1613 . 326 1613 . 604 1737 . 604 1737 . 604 1738 . 604 1738 . 604 1738 . 604 1739 . 604 17
9	1104.350 1136.420 1168.170 1199.900 1231.693 1243.553 1327.003 1358.573 1358.573 1358.573 1421.413 1421.413 1421.413 1421.413 1421.413 1431.600 1578.900 1610.200 1610.200 1611.200 1734.600 1734.600 1734.600 1734.600 1734.600 1734.600 1734.600 1734.600 1735.200 1736.200 1736.200 1736.200 1737.600 1738.258 1889.738 1980.738
₩.	1101 . 146 1133 . 128 1164 . 990 1128 . 500 1292 . 160 1393 . 840 1395 . 420 1385 . 420 1449 . 734 1449 . 734 1449 . 734 1449 . 734 1449 . 734 1544 . 376 1575 . 766 1609 . 600 1700 . 518 1731 . 506 1731 . 506 1732 . 414 1733 . 506 1734 . 211 1885 . 417 1885 . 623 1914 8 . 739
••	1097 .942 1129.936 1161.810 1193.564 1225.307 1288.937 1320.677 1346.566 1446.566 1478.202 1572.630 1572.630 1603.946 1603.946 1607.946 16
<b>6</b> 4	1126.745 1158.628 1190.394 1222.112 1224.012 1235.812 1317.512 1349.112 1412.012 1413.096 1443.398 1443.398 1443.398 1443.398 1443.398 1659.494 1660.818 1659.494 1659.226 1654.310 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1725.314 1737.082
1	1091 . 528 1123 . 546 1187 . 222 1218 . 917 1220 . 827 1282 . 637 1314 . 347 1315 . 957 1315 . 957 1316 . 330 140 . 230 1471 . 882 1593 . 694 1596 . 35 1597 . 694 1691 . 206 1722 . 218 1722 . 218 1732 . 218 1734 . 605 1734 . 605 1735 . 150 1736 . 605 1737 . 277 1967 . 277 1967 . 277
•	1120.350 1152.260 1152.260 1215.720 1217.540 1317.320 1311.180 1314.320 1374.320 1374.320 150.300 1531.800 1531.800 1553.220 1553.220 1553.220 1553.220 1553.220 1553.200 1544.560 1688.100 1719.120 1719
F. P.	######################################

VOLTS OR AMPERES.

### XXVI.

# ELECTRICAL HORSE-POWER TABLE. By H. W. FISHER, M.E.

## VOLTS OR AMPERES.

	-	64	e	4	47	co	7	00	0	10	:	12	13	14	15	16	17	8	IO	20	
20	02920	05300	08040	10720	13400	16080	18760	21440	24120	26800	29480	32160	34840	37520	40200	42880	45560	48240	50020	53600	20
61	02546	05002	86920	10184	12730	15276	17822	30368	22014	25460	28006	30552	3300g	35644	38190	40736	43282	45828	48374	50020	61
18	02412	04824	07236	84960	12060	14472	16884	.195561.	21708	24120	26532	28944	31356	33768	36180	38592	41004	43416	45828	48240	18
17	02278	04556	.00834	.00112	11390	13668	15946	18224	.20502	22780	25058	98842	290r4	31892		36448	38726	41004	43282	45560	17
91	.02144	.04288			10720	12864	15008	.17152	90201.	21440	.23584	.25728	.27879	30006	32160	.343o4	36448	.38592	40736	42880	91
15	02020	04020	06000	08040	10050	12060	14070		.18000	20100	.22110	.24120	26130	28140	30150	321	.34170	361	38190	40200	15
14	01876	03752	.05628		.09380	.11256	.13132		.16884		20636	.22512	24388		28140		31892		.35644	7520	14
13	.01742	.03484	.05220	.06068	01/80	10452	12104	3936	15678	17420	.19162	, 20004	22646	24388	o£ 195	.27872	4196z.	31356	33008	.34840	13
13	gogio.	-	.04824	.o6432	.08040	8 9000	11256	12804	. 14472	-	17688	96261	20004	.22512	24120	.25728	.27336	.28944	30552	. 32160	12
11	.or474	.02948	.04422	20850	.07370	.08844	81501.		.13266	.14740	16214	17688	.19162	20636	22110	.23584	.25058	.26532	38006	.29480	11
IO	.01340	.02680	04020	.05360	00290	08040	. 09380	.10720	12060	00781	.14740	,10080	17420	.18760	20100	.21440	.22780	.24120	25460	.26800	OI
6	,01206	.02412	Sideo.	.04824	ogogo.	.07236	08442	00048	, ro834	ogo.J.	.13266	.14470	. 1567B		18000	10296	. 20502	.21708	.22014	24120	0
00	.oro72	.02144	03216	.04288	09850	.06432	,07564	.08576	84960		11792	12864	9.6€1.	.15008	16080	.17132	.18224	19206	20368	21440	00
7		.01876	.02814	.03752		82950.	99590	.07504	.08442	.09380			12104	.13132	14070	15008	15946	16884	.17822	18760	7
0	,00804	eogio.	.02412	.o3zre	.04020	.04824	,05628	.06432			3844	84960.		11256	12060	.12864	13668	14472	15276	16080	9
S	02900	.01340	.02010	.02680	.03350		ofice.	.05360	060000	00290	.07370	08040	01/80.	09380	.10050		.11300	.12060	.12730	.13400	ın
4	.00536	.01072	90010	.02144	.02680	.o3216	.03752	.04288	.04824	o. 05350. o	96850	.06432	.06968	.07504	-	.08576	E1160.	.00648	.10184	.10720	4
60	.00402	,00004	01206	.01608	02010	.02417	02814	03216	Sigto.	04020	CA	.04824	- 11		06030	.0432	.06634	.07236	.07638	08040	3
eq	.00268	.00536	togoo.	.oro72	01340	900110.	92810.	.02144	.02412	.02630	.02048		.03484		04020	.04288	.04556	04824	.05092	.05360	cı
	.00134	.00268	.00402	00530	.00670	,00804	81,000.	,01072	,01206	.01340	.01474	80910	01742	92810.	02010	.02144	.02278	.02412	.02546	.02680	+
		_		_			-	m	6											- 1	

## VOLTS OR AMPERES.

## HORSE-POWER TABLE.

At the juncture of columns 12 and 19 we find 30552, which is the required horse-power for Example No. 1.

BENNET is 3.53 H. There are two aignificant figures after the 19 and 12, hence we move the decimal point two places to the right and the answer is 30.53 H. There are three aignificant figures in Example No. 3, hence the horse-power is 305.52.

Now suppose we have 2500 volts and 45 amperes. In this case we must take The product of volts and amperes measures electrical energy or power. Dividing by 46 reduces electrical energy to horse-power. Brankries:-ist. What electrical horse-power corresponds to 19 amperes and 12 volts?

120 de 20. 3 1000

2000 Volts and 40 amperes = 107.9 The horse-power for

= 150.75 Total horse-power 888

VOLTS OR AMPERES.

XXVII.

### HORSE-POWER LINE-SHAFTING WILL TRANSMIT WITH SAFETY. BEARINGS, 8 TO 10 FT, CENTRES.

Diameter of	Horse-power	Diameter of	Horse-power	Diameter of	Horse power
Shaft	in one	Shaft	in one	Shaft	in one
in Inches.	Revolution.	in Inches.	Revolution.	in Inches.	Revolution.
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	.008 .0156 .027 .043 .064 .091 .125	218 370 370 318 318 478 418 576	.216 .272 .343 .424 .512 .728 1.00	515 615 615 715 877 815 815	. 728 2.195 2.744 3.368 4.096 4.912 5.824 6.848

For jack-shafts, or main section of line-shafts, allow only three-fourths of the horse-power given above, and also provide extra bearings wherever heavy strains occur, as in main belts or gears.

XXVIII.
HORSE-POWER BELTING WILL TRANSMIT WITH SAFETY.

Width of Belt	Horse-power Velocity	per 100 Feet. y of Belt.	Width of Belt	Horse power per 100 Feet. Velocity of Belt.			
in Inches.	Single Belt.	Double Belt.	in Inches.	Single Belt.	Double Belt.		
ı	.09	.18	12	1.09	2.18		
2	. 18	.36	14	1.27	2.55		
3	.27	.55	16	1.45	2.91		
4	.36	.73	18	1.64	3.27		
5	.45	.91	20	1.82	3.64		
5 6	∙55	1.09	22	2.00	4.00		
7 8	.64	1.27	24	2.18	4.36		
8	-73	1.46	28	2.55	5.09		
9	.82	1.64	32	2.91	5.82		
10	.91	1.82	36	3.27	6.55		
11	1.00	2.00	40	3.64	7.27		

In the calculations for horse-power in the above table, the belt is assumed to run about horizontally; the semi-circumference of smaller pulley has been considered as the ordinary arc-contact of belt. Any reduction of this contact will make approximate proportional reduction of horse-power.



		,	,				<del></del>	· · · · · · · · · · · · · · · · · · ·	
			1	· :: ·			!		
	<u> </u>	:		: :.::			‡1 1.		<u>:</u> .
		1 ::		! .				:::::::::::::::::::::::::::::::::::::::	
		<del></del>			<del></del>	<del>                                     </del>		1	
	: :		: :		: :	İ			
:	• !	; !	i : .	: . :					
	·			<del></del>	ļ.— <u>.</u> —-	<del> </del>	<del>!</del>	· · · · · · · · · · · · · · · · · · ·	<del></del> -
	: :	1 : . :	1	! . ;: .		1::		: • · ·	· :
	1 : : : : :		<u> </u>	: :.		-:			
1		1 1111		1.				1 :	1
	i.: ·i	1	: : .	: :			1 : .:		.: .;.
	ļ i <sub>7</sub> . i .	1 : :		1 1		<u>.</u>		1	ļ
		1 :	1			1 :.			: -
1		† <del></del>			<del> </del>	<del>                                     </del>		<del>                                     </del>	
1. 1			<u> </u>	1					
li	1.		1				1		:
	ļ		·	<u> </u>	<u> </u>		ļ	<del></del>	
			1::						::::::
1	: ::::i	1							· · · · · ·
	1	1				1 .	<u> </u>		<u> </u>
	İ	1						1 .	
1	ļ	1	1				1	1 :	:
1						<u> </u>			1
<u> </u>	1		1				<del>                                     </del>	<del></del>	1
		i					]   .:	1	<u> </u>
		1:							
ļ	1		•	· · · · · · · · · · · · · · · · · · ·	· -	·	1	<del> </del>	<del> </del> -
	::	1 1 1 1			1	į			· :
	i : .: : :	1	i · · ·						1
		1	İ				1	<u> </u>	!
			1		:			. ::::	1 :
	1		1 1 -		! .	! -		÷ -i: -	
		1			1	. :		. ! :	
		1:	11. 11.11	:	1	:		T:	
1		1:	1 :		1		1	1 :	
1 :			100		:		1.	1	1
	ļ	ļ	<b></b>	:		·	<del> </del>	<del></del>	<del> </del>
;	- :			1			ł .	: ::	
	-	: : :			<del> </del>	-	1:		1
	·			1.3	ļ	1	· · · · · · · · · · · · · · · · · · ·		<u> </u>
			: : : .	1	1		1		
			<u> </u>	1 -11-1	<b>:</b>				<b>!</b>
1 :	1: -: -	: :	i ;				1.	1:::	1 :
			<u> </u>		: - :		<del></del>	+	1::
	ļ - ·				· - i	::		1	المائيات
,	:	. 1 ***	1.	1 : .				1	
	<del>-</del> -	:	<del></del>		<del>!</del>			<del> </del>	<del></del> .
	1:	1 ***							1
-::		- :	1 '	: :	: : .			1 -: -	:- :
i	1,	بالنالية	<u> </u>	<u>:</u>	<u> </u>	<u> </u>		1	
F ( CAN) E	Y'LH, I HALA N.	٧.							

### A

	-	AGE
Abrasion Test of Materials of Construction		146
Adiabatic Curve, The		497
Admiralty Test of Materials		152
Air, Absorption of Moisture (Table)		671
. Flow of		268
Humidity of (Table)		671
Orifices, Flow through		•
Pipes, Flow in		•
Thermometer		
Alden Brake		
Aluminum Bronzes, Test of (Table)		
Anemometers, Calibration of		
Description of		,
·		
В		
Barometer Observations reduced to Freezing Point (Table)		
Beaumé's Scale reduced to Specific Gravity (Table)		672
Belts, Friction of		
, Horse-power of (Table)		694
Belt-testing, Directions		
, Machines for		236
, Method of		235
, Report, Form of	•••••	2.10
Bending Test of Materials of Construction		146
Boilers, Efficiency of		443
, Efficiency of Furnace		
, Horse-power of		
	605	

	PAGE
Boiler Tests, Combustible	443
, Evaporation, Actual, Definition of	
Equivalent, Definition of	
Factor, Definition of	
, Graphical Log	445
, Method of Standard Testing	445
, Abbreviated Directions	
, Objects for	442
, Report, Form of A. S. M. E	412
, Sibley College Form	457
Brake, see Dynamometer.	
Brick, Method of Testing	158
Bridge Materials, Method of Testing	148
С	
<b>v</b>	
	15
Calorimeter, Fuel, Combustion, when Perfect	
, Berthelot Calorimeter	420
, Berthier "	420
, Favre and Silbermann Calorimeter	416
, Heat Equivalent of Calorimeter	416
, Principles	415
, Samples of Fuel, How obtained	416
, Thompson Calorimeter	
Calorimeters, Steam, Barrel	372
, Barrus Continuous	380
, Barrus Superheating	386
, Chemical	404
, Comparative Value of	405
, Condensing	
	375
, Equivalent of Calorimeter	37 I
, Errors in Calorimetric Processes	
, Heisler Calorimeter	39 <b>T</b>
, Hoadley Calorimeter	377
, Kent Calorimeter	
, Peabody Calorimeter	388
, Quality, Definition of	
, Quality determined graphically	
, Sample of Steam	
, Steam Tables, Use of	
, Separating Calorimeter	
, Superheating Calorimeter	
Throttling Calorimeter	

INDEX.	. 697
Car-wheels, Test of	PAGE
Cast-iron, Testing Bridge Materials	
, Test Pieces, Form of	•
Cathetometer, The	
Cements, Description	• .
, Method of Testing	
, Report, Form of	
Cement Testers, Fairbanks'	
, Fuertes'	
, Olsen's	
Chains, Test Specimens, Form of	•
Chronograph, The	•
, The Tuning-fork	
Clearance of Engines from the Indicator-diagram	
Compression, Formulæ of	
Compression Tests, Method.	
, Specimens	
Condensation and Re-evaporation from the Indicator-card	
Condenser Test	
Constants, Numerical (Table)	_
Constants, Numerical (1801e)	040
D	
Deflectometer for Transverse Testing	
Draught-gauges	
Drop Tests of Materials of Construction	
Ductility, Definition of	
, Method of Measuring	
Dynamometer, Absorption	
, Alden Brake	
, Constants of	
, Designing	
, Fan Brake	
, Horse-power	
, Hydraulic Friction	•
, Operation	
, Prony Brake	
, Pump	=
, Self-regulating	
, Strap-brake	
Dynamometer, Traction, The Giddings Recording	218
Dynamometers, Transmission	
, Belt, The	
, Differential, The	227

PAGE
Dynamometers, Transmission, Emerson's Power-scale
, Lewis, The 224
, Morin's Rotation 219
, Pillow-block, The 224
, Steelyard, The 222
, Van Winkle Power-meter, The 233
,
_
E
Efficiency Tests xx
Elastic Curve 139
Elastic Limit
Elasticity, Modulus of
, Modulus of, from Sound
34 1 4 1 M 11 1 101 1 0 1
, Modulus of, in Tensile and Shearing Strains
Engines, Pumping, Method of Testing
Engine Testing, Calibration of Apparatus
, Clearance, Determination of
, Efficiency-tests
, Friction-tests 531
, Hirn's Analysis
, Indicator Practice 526
, Objects of
, Piston Displacement 525
, Preparation for 523
, Speed Measurements 513
, Quantities to be observed 525
, Valve-setting 528
, Water Consumption, Measurements of 518
Entropy of the Liquid (Table)
Errors, When to neglect
Evaporation, Factors of (Table)
Experiments, Classification of xix
, Graphical Method of representing 16
, Objects of xvii
, Relation to Theoryxviii
Extensometers, Attachment of
, Boston Micrometer, The 112
, Buzby Hair line, The 107
, General Requirements 106
, Henning, The 110
, Marshall, The 111
, Paine, The 107

INDEX.	699
	FAGR
Extensometers, Sibley, The	113
, Thurston, The	
, Wedge Scale	•
F	
Factor of Safety	50
Fatigue of Metals	
Favre and Silbermann's Calorimeter	
Flexure, Table of External Moments of	
Fluids, Compressible, Flow of	
Flue-gas Analysis, see Gas Analysis.	20/
Forging-test of Materials	- 46
Formulæ, Empirical, Deduction of	
for Approximate Calculation	
Fracture, Character of, in Materials	
Friction, Angle of Repose. Definition of	
, Belts, Friction of	· <del>-</del>
, Coefficient of, Definition of	
, (240.0)	
, Collars, Friction on	
, Cords, " of	
, Formulæ	•
, Journals, Friction on	
, Laws of	• •
, Lubricants, Friction of	
, Motion, " "	-
, Normal Force, Definition of	•
, Pivots, Friction of	
, Rest, " "	
, Rolling Friction	
, Teeth of Gears, Friction of	
, Total Pressure, Definition of	•
Fuels, Calorimeters for	•
, Combustion of	
, Composition of	
, " " (Table)	
, Heating Value Determinations	410
, Heat of Combustion	
, Temperature produced by Combustion	
, Total Heat of Combustion with Oxygen (Table)	
Furnace, Efficiency of	444
G	
Gas Analysis, Computations	
, Form of Report	
,	

\_\_\_\_\_\_

٦

	PAGE
Gas Analysis, Method	424
, Object of,	423
, Reagents, how prepared	425
, Samples of Gas, how obtained	427
, Elliot's Apparatus	
, Fisher Orsat Apparatus	131
, Hempel's Apparatus	
, Wilson's Apparatus	121
Gas-engines	431
, Testing	
, Form for Report of Test	035
Gas, Measurement of Flow	274
Gas-meters	275
Gauges, Pressure, Calibration and Correction	338
, Forms for Calibration	340
, Crosby Apparatus for Testing	335
, Bourdon	329
, Diaphragm	331
, Draught	323
, Manometer	317
, Manometers with Piston	327
, Mercury Columns	321
, Recording	222
, Square Inch	223
, Vacuum	331
3 * **********************************	332
н	
Hammer-test of Materials	146
Hardening Test of Materials	146
Heat of Combustion, see Fuels.	
Heat, Absorption of (Table)	669
, Conduction of (Table)	669
, Mechanical Equivalent of	311
, Melting Points (Table)	354
, Radiation of (Table)	660
, Specific	310
, Determinations of	35.1
, Specific (Table)	660
Hirn's Analysis of the Steam-engine:	oog
Compound Engine, Application to	
Example	242
Non-condensing Engine, Application to	547
Report, Forms for	545
Theory of	540
Triple-expansion Engine. Application to	
I HORE-EXUADSION CUPIDE, ADDITION TO	E 15

INDEX.	701
Harry comes of Debler (Table)	PAGE
Horse-power of Belting (Table)	
, Electrical (Table)	093
, Indicated, Dynamometric	400
of Shafting (Table)per Pound M. E. P. (Table).	. 094
Hot-air Engines	
, Ericsson	
, Rider	
, Thermodynamic Theory	025
, Testing	
, Form for Data and Results	
, Indicator-diagram	
Hydraulic Machinery, Classification	
Hydraulic Motors, Classification	
, Forms for Report of Tests	
, Formulæ	
, Hydraulic Power System	
, Hydraulic Ram	
, Directions for Testing	
, Discussion to a community to the state of	297
<b>I</b>	
P M	
Impact Machine, Heisler's Directions for Testing by	. 143
Test, Method of A. S. M. E	
Inertia Diagram	
Indicator, The Williams	. 599
, Moment of, Experimental Determination	. 70
" "(Table)	
Indicator, Dimensions of Parts of (Table)	• • •
, Operation and Attachments of	
Pencil-movement, Test for Parallelism	
Reducing-motion	
Spring, Calibration of	
, Standardization of	
Drum-motion, Accuracy of	•
Drum-spring Tension (Table)	-
Drum-spring, Adjustment and Calibration	
, Steam-engine, Arc	
, Bachelder	. 400
C-11-1	
, Calkins	. 467
, Crosby	. 467 . 465
	. 467 . 465 . 461

Indicator, Steam-engine, Richards	
, Straight Line	
, Straight Lyne	
, Tabor	
, Thompson	
, Watt	
Indicator-diagrams, Adiabatic and Saturation Curves	
, Compound and Triple-expansion Engine 50	
, Clearance from the	
, Condensation and Re-evaporation 50	
, Discussion of the 50	
, Form of the 49!	
, Measurements of the	
, Parts of the	
, Steam Consumption from the Diagram 499	
Injector, Description	
, Forms for Results of Test	
, Handling	
, Limits	
, Mechanical Action	
, Tables of the Limits of the	
, Testing	
, Thermodynamical Theory 6rd	
Investigation, Methods ofxvii	
Iron, Admiralty Tests of	
Iron in Bridge Materials, Tests of	8
L	
Least Squares, Method of	
Locomotive Testing, Boiler Leakage 580	
, Boiler Tests 377	7
, Calorimeter, Application of	
, Coal Tests 580	0
, Form of Report	4
, Dynamometer Records 587	7
, Fuel Measurements 573	3
, Indicator, Application of the 574	4
, Performance, Form of Report of 591	I
, Speed Measurements 588	3
, Standard Method 572	2
, Water Measurements 583	
. Wind Resistance, Measurements of	^

•		
	INDEX.	703
Logarithms (Table)		PAGE
Logarithms (Hyperbolic Table).		
Logarithmic Functions of Angle		
Lubricant Testing	• • • • • • • • • • • • • • • • • • • •	····· 175
	36	
	M	
Materials of Construction, Tests	of, Admiralty Tests	I52
		158
	=	ests 148
	Cement	" 161
	, Coefficients (Table)	and the second s
	, Compression	" 134
	, Drop	
	, Impact	" 144 " 143
	•	•••
	, Mortar	
	, Paving Material	159
	, Pipe	154
	, Stone	" 155
	, Special	" 145
	, Tension	" I25
Tests :	for Different Materials	(Table) 148
•	Transverse	135
Measures, U.S. Standard and M	letric (Table)	638
Meters, Gas	*****************	275
, Water		
Measuring Machine, The Sweet.		
Melting Points (Table)		
Micrometer Calipers		
Micrometer Screws, Accuracy		-
· · · · · · · · · · · · · · · · · · ·	iversity, Errors of	
Moisture absorbed by Air (Table		
Moisture absorbed by Air (Table	:/	••••••••••••
	Ο	
Observations, Rejection of Dou	btful	13
Oils, Acid Test	***************************************	186
, Adulteration of		
. Burning Point		-
. Chill Point		
, Coefficiency of Friction		
, Cold Test		· · · · · · · · · · · · · · · · · · ·

•	PAGE
Oils, Density	
, Durability	108
, Electrical Conductivity	
, Evaporation	
, Feed, Limited Test with	
, Flash-point	
, Form for Report of Test	
, Gumming Test	
, Heat, Effect of	
, Viscosity	
, Viscosity, Method of Measuring	
, Table of Determinations	
Oil-testing.	
Oil-testing Machines, Ashcroft's	
, Boult's	
, Rankine's	
, Riehle's	
, Thurston's	
Oil, Viscosimeters for Testing, Gibbs'	
, Perkins'	
, Pipette, The	
, Standard Orifice, The	
, Stillman's	
, Tagliabue's	179
P	
D 1 26 1 26 1 26 1 26 1 26 1 26 1 26 1 2	
Paving Materials, Method of Testing	150
Pipes and Pipe-fittings, Method of Testing.	
, Cast-iron, Specifications for	15.
Pitot's Tube	26.
Planimeters, Adjustment	42
, Calibration	4-
, Coffin, The	33
, Mean Ordinate by the Polar	31
, New, The	36
, Polar, The	2.
, Roller, The	37
, Special	49
, Suspended, The	33
Pressure-gauges	323
Prony Brake	
Pulsometer, The	
Tage Form for Date and Decults	

INDEX.	705
	PAGE
Pumping-engines, Testing	552
Pumps, Classification	300
, Duty and Capacity	300
, Efficiency Test	302
, Form of Report of Tests	304
, Piston Displacement, Measurement of Delivery	
, Slip	
, Testing, Directions for	
, Work, Measurements of Useful	
Punching Test of Materials.	
Pyrometers, Air	
, Calorimetric	
, Clay Wedgewood's	
, Electric,	
, Hoadley's Calorimetric	354
, Metallic	352
, Siemens'	357
0	
Ω	
Quality of Steam, see Calorimeters.	
Quanty of Steam, 322 Caloffficiers.	
R	
Radiation of Heat (Table)	669
Resilience of Metals	58
"Rest" of Metals	147
Rigidity of Materials	5.5
, Modulus of	
, by Swinging under Torsion	
Rivet-iron, Tests for	
Rope, Form of Test-pieces	120
	120
S	
•	
Saturation Curves	407
Shafting, Horse-power of (Table)	
Slide-rule, The	
Specific Gravity (Table)	
Specific Heat (Table)	000

ń

ij

٠,


	PAG&
Speed-recorder, Autographic	-
Steam, Consumption of, from the Indicator-diagram	
, Discharge of (Napier's Formula, with Table)	
, Entropy of the Liquid (Table)	
, Flow through an Orifice	
Pressure, Relation of, to Temperature	
, Units of	
Properties and Thermodynamic Conditions, Definitions	312
Tables, Buel's	
Porter's	673
Relative Accuracy of	
Steam-engines, Effects of Inertia on	
, Efficiencies of	
, Experimental	
at Sibley College, Dimensions of	
Testing of, see Engine-testing.	393
Steel, Admiralty Tests of	152
Bridge Materials, Tests of	
Lloyd's Tests	
Stone, Testing of	
Strain, Definition of	59
Strain-diagram, The	59 59
, Autographic	
, in Tension	124
Strength of Materials, Coefficients of	58
" "(Table)	66r
, Definitions	
, Temperature, Variations of (Table)	57 668
Stress, Definition of	58
in Materials, Thermodydamic Relations of	50 76
Stresses, Combined	-
Sitesses, Combined	74
•	
•	
T	
•	
<del>_</del>	
Tachometer, The	-
Temperature, Effect on Strength of Materials	147
Tensile Strength, Notation and Formulæ	62
Tension Tests, Method	125
, Object	125
, Report, Form of	129
, Specimens, Form of	116


INDEX.	707
·	PAGE
Testing Machines, Calibration	. 79
, Description	. 78
, Emery, The	. 84
, Government Specifications	. 82
, Olsen, The	. 92
, Riehle, The	. 89
Test-pieces, Form of	
Thermometers, Calibration	. 352
, Method of inserting, in Steam-pipe	370
, Table of Boiling-points	303
Thermometers, Air	242
, Construction	248
, Correction of Determinations	240
, Form of Report	249
, Formulæ	951
, Practical Uses	340
Thermometers, Alcohol	
Thermometers, Mercurial	
Torsional Stress, Formuke	71
Torsion Test, Method with Thurston's Machine	
, Object	
, Record, Form of	
, Specimens, Form of	122
, Strain-diagram, The	98
Torsion Testing-machines, Olsen	
, Riehle	99
, Thurston	99
Traction-dynamometer	218
Transverse Stress, Formulæ	66
Transverse Tests, Deflectometer for	115
, Object	135
, Report, Form of	
, Specimens, Form of	
Turbines, Classification	
, Fourneyron's	
, Reaction Wheel	201
, Testing, Directions for	
, Theory	
,	_00
v	
·	
Valve-setting	528
Venturi Tubes	

	PAGE
Vernier, The	23
Vernier Caliper, The	49
Viscosity of Metals	60
Viscosimeter, see Oil Viscosimeter.	
1 10000100001 and Ott 1 100001000111	
w	
W	
Water Computation Table	601
Water, Diaphragm, Flow through Perforated	252
Discharge Formulæ	
, Measurement of Flow, General Methods	
, Nozzles, Calibration of	
, Efflux through,	
, Orifices, Flow through	
, Pendulum, The Hydrometric	
, Pipes, Flow in	
, Measurement of Flow in	
, Pitot's Tube	
, Pressure, Flow under	248
, Streams, Measurement of Flow in	262
, Tachameter, The	262
, Venturi Tubes, Calibration of	
, Efflux through	247
Water-meters, Calibration	
, Classes	
, Errors	
Water-motors, Method of Testing	
, Backus, Special Directions for Testing	
, Pelton, The	
Water-pressure Engines, Description	
, Direction for Testing	
Water-weirs	
Water-wheels, Breast	-
, Impulse	
, Overshot	
, Poncelet's	
, Undershot	285
, Vertical	
Weights of Materials (Table)	669
Weirs, Accuracy	
, Calibration	
, Errors, Effect of	255


INDEX.	709
	PAGI
Weirs, Formulæ	. 244
, Head, Measurement of	. 253
, Hook-gauge, The	. 25
Welding Test of Materials	. 14
Wooden Pillars, Strength of (Table)	. 66
Wood Test-pieces. Form of	. II







• • • 



. .

.

